

GO:KEYS 3 / GO:KEYS 5 Tone List

piano

Category	No.	ToneName	MSB	LSB	PC
Ac.Piano	PR001	Concert Piano	71	96	1
Ac.Piano	PR002	Mellow Grand	71	96	2
Ac.Piano	PR003	Grand XV	71	96	3
Ac.Piano	PR004	Nice Piano	71	96	4
Ac.Piano	PR005	Rocker Piano	71	96	5
Ac.Piano	PR006	Piano Thang	71	96	6
Ac.Piano	PR007	Magical Piano	71	96	7
Ac.Piano	PR008	Piano+Str Layer	71	96	8
Ac.Piano	PR009	WarmVoxPiano	71	96	9
Ac.Piano	PR010	Bright Honkey	71	96	10
Ac.Piano	PR011	Power Octs	71	96	11
Ac.Piano	PR012	Tape MellowGrand	71	96	12
Ac.Piano	PR013	Tiny Piano	71	96	13
Ac.Piano	PR014	LoFi Ac.Piano	71	96	14
Ac.Piano	PR015	Nostalgic Piano	71	96	15
Ac.Piano	PR016	Dynamic JD-Piano	71	96	16
Ac.Piano	PR017	Reverse Piano 1	71	96	17
Ac.Piano	CM001	Piano 1	87	85	1
Ac.Piano	CM002	Piano 1 w	87	85	2
Ac.Piano	CM003	Piano 1 d	87	85	3
Ac.Piano	CM004	Piano 1 Bright	87	85	4
Ac.Piano	CM005	Piano 1 Amp	87	85	5
Ac.Piano	CM006	Piano 1 w 2	87	85	6
Ac.Piano	CM007	Piano + Str 1	87	85	7
Ac.Piano	CM008	Piano + Str 2	87	85	8
Ac.Piano	CM009	Piano + Choir 1	87	85	9
Ac.Piano	CM010	Piano + Choir 2	87	85	10
Ac.Piano	CM011	Piano + Pad 1	87	85	11
Ac.Piano	CM012	Piano + Pad 2	87	85	12
Ac.Piano	CM013	Healing Piano	87	85	13
Ac.Piano	CM014	Piano Vib	87	85	14
Ac.Piano	CM015	Piano Dly	87	85	15
Ac.Piano	CM016	Piano 2	87	85	16
Ac.Piano	CM017	Piano 2 w	87	85	17
Ac.Piano	CM018	JD Piano	87	85	18
Ac.Piano	CM019	JD Piano w	87	85	19
Pop Piano	PR018	SA Piano	71	96	23
Pop Piano	PR019	Mixture Piano	71	96	24
Pop Piano	PR020	Pop Toy	71	96	25
Pop Piano	CM023	Honky-tonk	87	85	23
Pop Piano	CM024	Honky-tonk w	87	85	24
Pop Piano	CM025	Honky-tonk w 2	87	85	25
E.Grand Piano	PR021	70s E.Grand	71	96	21
E.Grand Piano	CM020	Piano 3	87	85	20
E.Grand Piano	CM021	Piano 3 w	87	85	21
E.Grand Piano	CM022	Piano 3 w 2	87	85	22

e.piano

Category	No.	ToneName	MSB	LSB	PC
E.Piano1	PR022	70s Suitcase	71	96	22
E.Piano1	PR023	Lite Tine EP	71	96	23

Category	No.	ToneName	MSB	LSB	PC
E.Piano1	PR024	Lite Pop EP	71	96	24
E.Piano1	PR025	Soft Stage EP	71	96	25
E.Piano1	PR026	Wurly Vibrato	71	96	26
E.Piano1	PR027	Vintage Phase EP	71	96	27
E.Piano1	PR028	Phase EP Mix	71	96	28
E.Piano1	PR029	EP 90 Phaser	71	96	29
E.Piano1	PR030	Vortex EP	71	96	30
E.Piano1	PR031	Flicker Piano	71	96	31
E.Piano1	PR032	Suitcase EP OD	71	96	32
E.Piano1	PR033	EP Wah	71	96	33
E.Piano1	PR034	LoFi E.Piano	71	96	34
E.Piano1	CM026	E.Piano 1	87	85	26
E.Piano1	CM027	E.Piano 1 w	87	85	27
E.Piano1	CM028	E.Piano 1 Trem	87	85	28
E.Piano1	CM029	Detuned EP 1	87	85	29
E.Piano1	CM030	Vintage EP	87	85	30
E.Piano1	CM031	60s E.Piano	87	85	31
E.Piano1	CM032	60s E.Piano w	87	85	32
E.Piano1	CM033	60s E.Piano Trem	87	85	33
E.Piano1	CM034	Tremolo EP	87	85	34
E.Piano1	CM035	Tremolo EP w	87	85	35
E.Piano1	CM036	Curly Wurly	87	85	36
E.Piano1	CM037	Sinus EP	87	85	37
E.Piano2	PR035	More Tine EP	71	96	35
E.Piano2	PR036	80s FM EP	71	96	36
E.Piano2	PR037	MK-80 Bright EP	71	96	37
E.Piano2	PR038	Mood Azure	71	96	38
E.Piano2	PR039	Mixture EP	71	96	39
E.Piano2	CM038	E.Piano 2	87	85	38
E.Piano2	CM039	E.Piano 2 w	87	85	39
E.Piano2	CM040	Detuned EP 2	87	85	40
E.Piano2	CM041	St.FM EP	87	85	41
E.Piano2	CM042	St.FM EP w	87	85	42
E.Piano2	CM043	EP Legend	87	85	43
E.Piano2	CM044	EP Legend w	87	85	44
E.Piano2	CM045	EP Phaser 1	87	85	45
E.Piano2	CM046	EP Phaser 2	87	85	46
E.Piano2	CM047	EP Phaser 3	87	85	47
E.Piano2	CM048	EP Belle	87	85	48

strings

Category	No.	ToneName	MSB	LSB	PC
Ensemble Strings	PR040	Rich Strings	71	96	40
Ensemble Strings	PR041	Full Strings	71	96	41
Ensemble Strings	PR042	Decay Strings	71	96	42
Ensemble Strings	PR043	Strings/Pizz	71	96	43
Ensemble Strings	PR044	CharacterStrings	71	96	44
Ensemble Strings	PR045	Chamber Strings	71	96	45
Ensemble Strings	PR046	LoFi Strings	71	96	46
Ensemble Strings	PR047	Phono Strings	71	96	47
Ensemble Strings	PR048	Ending Scene	71	96	48
Ensemble Strings	CM317	Tremolo Str	87	87	61
Ensemble Strings	CM318	Pizzicato Str	87	87	62
Ensemble Strings	CM319	Pizzicato Str w	87	87	63

GO:KEYS 3 / GO:KEYS 5 Tone List

Category	No.	ToneName	MSB	LSB	PC
Ensemble Strings	CM320	Pizz	87	87	64
Ensemble Strings	CM321	Pops Seq 4	87	87	65
Ensemble Strings	CM322	Pops Seq 4 w	87	87	66
Ensemble Strings	CM331	Strings	87	87	75
Ensemble Strings	CM332	Orchestra	87	87	76
Ensemble Strings	CM333	60s Strings	87	87	77
Ensemble Strings	CM334	Small Strings	87	87	78
Ensemble Strings	CM335	Hybrid Strings	87	87	79
Ensemble Strings	CM336	Small Str Stacc	87	87	80
Ensemble Strings	CM337	Strings Stacc	87	87	81
Ensemble Strings	CM338	Strings Stacc w	87	87	82
Ensemble Strings	CM339	Strings Amp	87	87	83
Ensemble Strings	CM340	Slow Strings	87	87	84
Ensemble Strings	CM341	Mood Strings	87	87	85
Solo Strings	PR049	Pop Violin	71	96	49
Solo Strings	PR050	Pop Viola	71	96	50
Solo Strings	PR051	Pop Cello	71	96	51
Solo Strings	PR052	Pop Contrabass	71	96	52
Solo Strings	PR053	String Solo	71	96	53
Solo Strings	CM307	Violin	87	87	51
Solo Strings	CM308	Slow Violin	87	87	52
Solo Strings	CM309	Violin w	87	87	53
Solo Strings	CM310	Violin Amp	87	87	54
Solo Strings	CM311	Viola	87	87	55
Solo Strings	CM312	Viola Amp	87	87	56
Solo Strings	CM313	Cello	87	87	57
Solo Strings	CM314	Cello Amp	87	87	58
Solo Strings	CM315	Contrabass	87	87	59
Solo Strings	CM316	Contrabass Amp	87	87	60
Solo Strings	CM750	Fiddle	87	90	110
Solo Strings	CM751	Fiddle w	87	90	111

synth

Category	No.	ToneName	MSB	LSB	PC
Synth Lead	PR054	Clear Dual Saws	71	96	54
Synth Lead	PR055	FXM Saw Lead	71	96	55
Synth Lead	PR056	Tight Saw Lead	71	96	56
Synth Lead	PR057	Mild Saw Lead	71	96	57
Synth Lead	PR058	Wind Syn Lead	71	96	58
Synth Lead	PR059	Dual SuperSaw Ld	71	96	59
Synth Lead	PR060	NSoul Synth Lead	71	96	60
Synth Lead	PR061	Windy Synth	71	96	61
Synth Lead	PR062	Textured Touch	71	96	62
Synth Lead	PR063	Driven OB	71	96	63
Synth Lead	PR064	Dual Sqr Lead	71	96	64
Synth Lead	PR065	Next Sqr Lead	71	96	65
Synth Lead	PR066	Blow Lead	71	96	66
Synth Lead	PR067	LqFunk Syn Lead	71	96	67
Synth Lead	PR068	Pale Sine	71	96	68
Synth Lead	PR069	Modern Vintage	71	96	69
Synth Lead	PR070	Organic Lead	71	96	70
Synth Lead	PR071	Linear Lead	71	96	71
Synth Lead	PR072	Synth Hero	71	96	72
Synth Lead	PR073	Be Happy OctLead	71	96	73

Category	No.	ToneName	MSB	LSB	PC
Synth Lead	PR074	SpkPop Syn Lead	71	96	74
Synth Lead	PR075	Irish Finite Ld	71	96	75
Synth Lead	PR076	Billa-Lead	71	96	76
Synth Lead	PR077	Rind Mod Lead	71	96	77
Synth Lead	PR078	ZenoPoly	71	96	78
Synth Lead	PR079	ZenoLead 8000	71	96	79
Synth Lead	PR080	Big Room Lead	71	96	80
Synth Lead	PR081	3 Analog OSC	71	96	81
Synth Lead	PR082	X-MOD Lead	71	96	82
Synth Lead	PR083	HiPitch Buzz Ld	71	96	83
Synth Lead	PR084	Buzz Sucker	71	96	84
Synth Lead	PR085	Sync Ld Mono	71	96	85
Synth Lead	PR086	SyncModulate	71	96	86
Synth Lead	CM475	Square Lead 1	87	88	91
Synth Lead	CM476	Square Lead 2	87	88	92
Synth Lead	CM477	Sine Lead	87	88	93
Synth Lead	CM478	Porta Sine Lead	87	88	94
Synth Lead	CM479	Pure Lead Dly	87	88	95
Synth Lead	CM480	Dist Flt TB 2	87	88	96
Synth Lead	CM481	Dist Flt TB 1	87	88	97
Synth Lead	CM482	DistFlt TB 1 Dly	87	88	98
Synth Lead	CM483	80's Tech Lead	87	88	99
Synth Lead	CM484	Sqr Buzz Lead	87	88	100
Synth Lead	CM485	Ana Vox Lead	87	88	101
Synth Lead	CM486	CS Lead	87	88	102
Synth Lead	CM487	Classic GR	87	88	103
Synth Lead	CM488	Therasaw	87	88	104
Synth Lead	CM489	Bell Lead	87	88	105
Synth Lead	CM490	Bell Lead w	87	88	106
Synth Lead	CM491	Simple Tri	87	88	107
Synth Lead	CM492	Spooky Lead	87	88	108
Synth Lead	CM493	Soft Lead	87	88	109
Synth Lead	CM494	Sqr Lead 1	87	88	110
Synth Lead	CM495	Sqr Lead 2	87	88	111
Synth Lead	CM496	Sqr Lead 3	87	88	112
Synth Lead	CM497	Saw Lead 1	87	88	113
Synth Lead	CM498	Saw Lead 1 w	87	88	114
Synth Lead	CM499	Saw Lead 2	87	88	115
Synth Lead	CM500	Doctor Solo	87	88	116
Synth Lead	CM501	Natural Lead	87	88	117
Synth Lead	CM502	Sequenced Saw	87	88	118
Synth Lead	CM503	Sequenced Saw w	87	88	119
Synth Lead	CM504	Ah Super Saw	87	88	120
Synth Lead	CM505	Ah SuperSaw Dst1	87	88	121
Synth Lead	CM506	Ah SuperSaw Dst2	87	88	122
Synth Lead	CM507	Porta Super Saw	87	88	123
Synth Lead	CM508	S-Saw Stac Ld	87	88	124
Synth Lead	CM509	S-Saw Stac Ld w	87	88	125
Synth Lead	CM510	Tekno Lead 1 Atk	87	88	126
Synth Lead	CM511	Tekno Lead 1 Bit	87	88	127
Synth Lead	CM512	OSC-Sync Ld 1	87	88	128
Synth Lead	CM513	Wave Shape Ld	87	89	1
Synth Lead	CM514	Wave Shape Ld w	87	89	2
Synth Lead	CM515	Legato Tkno	87	89	3
Synth Lead	CM516	Legato Tkno w	87	89	4
Synth Lead	CM517	Tekno Lead 2	87	89	5
Synth Lead	CM518	Buzz Lead	87	89	6
Synth Lead	CM519	Buzz Lead Dist	87	89	7

GO:KEYS 3 / GO:KEYS 5 Tone List

Category	No.	ToneName	MSB	LSB	PC
Synth Lead	CM520	Saw Buzz Ld	87	89	8
Synth Lead	CM521	Saw Buzz Ld w	87	89	9
Synth Lead	CM522	Saw Lead 3	87	89	10
Synth Lead	CM523	Saw Lead 4	87	89	11
Synth Lead	CM524	Classic Lead	87	89	12
Synth Lead	CM525	Ramp Lead	87	89	13
Synth Lead	CM526	Saw Lead 5	87	89	14
Synth Lead	CM527	Jupiter Lead 1	87	89	15
Synth Lead	CM528	JupiterLead1 Atk	87	89	16
Synth Lead	CM529	Jupiter Lead 2	87	89	17
Synth Lead	CM530	Saw Lead 6	87	89	18
Synth Lead	CM531	On Air	87	89	19
Synth Lead	CM532	Saw Lead 7	87	89	20
Synth Lead	CM533	Saw Lead 8	87	89	21
Synth Lead	CM534	Warm Lead	87	89	22
Synth Lead	CM535	Saw Lead 9	87	89	23
Synth Lead	CM536	Saw Lead 10	87	89	24
Synth Lead	CM537	EQ Lead	87	89	25
Synth Lead	CM538	Saw Lead 11	87	89	26
Synth Lead	CM539	Saw Lead 12	87	89	27
Synth Lead	CM540	Waspy Lead	87	89	28
Synth Lead	CM541	Octa Square	87	89	29
Synth Lead	CM542	Octa Juice	87	89	30
Synth Lead	CM543	Fat GR Lead	87	89	31
Synth Lead	CM544	Octa Saw	87	89	32
Synth Lead	CM545	Juicy Lead	87	89	33
Synth Lead	CM546	OSC-Sync Ld 2	87	89	34
Synth Lead	CM547	OSC-Sync Ld 3	87	89	35
Synth Lead	CM548	Syn.Calliope	87	89	36
Synth Lead	CM549	Syn.Calliope w	87	89	37
Synth Lead	CM550	Syn.Calliope Dly	87	89	38
Synth Lead	CM551	Chiffer Lead	87	89	39
Synth Lead	CM552	Chiffer Lead w	87	89	40
Synth Lead	CM553	Charang	87	89	41
Synth Lead	CM554	Wire Lead	87	89	42
Synth Lead	CM555	Wire Lead Cho	87	89	43
Synth Lead	CM556	Solo Vox	87	89	44
Synth Lead	CM557	Solo Vox w	87	89	45
Synth Lead	CM558	Solo Vox Cho	87	89	46
Synth Lead	CM559	OB Lead	87	89	47
Synth Lead	CM560	5th Saw Lead	87	89	48
Synth Lead	CM561	5th Saw Lead Dly	87	89	49
Synth Lead	CM562	Housechord	87	89	50
Synth Lead	CM563	Ju-D Fifths	87	89	51
Synth Lead	CM564	Major 7	87	89	52
Synth Lead	CM565	Dance Saws 1	87	89	53
Synth Lead	CM566	Bass+Lead	87	89	54
Synth Lead	CM567	Bass+Lead w	87	89	55
Synth Lead	CM568	Delayed Lead	87	89	56
Synth Lead	CM569	Delayed Lead w	87	89	57
Synth Lead	CM570	Delayed Lead Cho	87	89	58
Synth Brass	PR087	SawsSynBrass	71	96	87
Synth Brass	PR088	DetuneSawBrS	71	96	88
Synth Brass	PR089	Mild SynBrass	71	96	89
Synth Brass	PR090	Silky JP	71	96	90
Synth Brass	PR091	FatSynBrass	71	96	91
Synth Brass	PR092	Soft Center	71	96	92
Synth Brass	PR093	Trad Syn Brass	71	96	93

Category	No.	ToneName	MSB	LSB	PC
Synth Brass	PR094	J-Pop Brass	71	96	94
Synth Brass	PR095	Brash!	71	96	95
Synth Brass	PR096	J-Brass For KY	71	96	96
Synth Brass	PR097	Neo SuperBrS	71	96	97
Synth Brass	PR098	Large Rave	71	96	98
Synth Brass	PR099	Invite Big Brass	71	96	99
Synth Brass	PR100	Horn Blast	71	96	100
Synth Brass	CM408	Synth Brass 1	87	88	24
Synth Brass	CM409	Synth Brass 3	87	88	25
Synth Brass	CM410	Synth Brass 3 w	87	88	26
Synth Brass	CM411	Analog Brass 1	87	88	27
Synth Brass	CM412	Analog Brass 1 w	87	88	28
Synth Brass	CM413	Analog Brs 1 w 2	87	88	29
Synth Brass	CM414	Jump Brass	87	88	30
Synth Brass	CM415	Jump Brass Amp	87	88	31
Synth Brass	CM416	JP8 Brass 1	87	88	32
Synth Brass	CM417	JP8 Brass 1 w	87	88	33
Synth Brass	CM418	Syn Brass	87	88	34
Synth Brass	CM419	Syn Brass w	87	88	35
Synth Brass	CM420	JP8 Brass 2	87	88	36
Synth Brass	CM421	80's Brass 1	87	88	37
Synth Brass	CM422	80's Brass 2	87	88	38
Synth Brass	CM423	Synth Brass 2	87	88	39
Synth Brass	CM424	Synth Brass 4	87	88	40
Synth Brass	CM425	Analog Brass 2	87	88	41
Synth Brass	CM426	Analog Brass 3	87	88	42
Synth Brass	CM427	Analog Brass 3 w	87	88	43
Synth Brass	CM428	Reso Brass	87	88	44
Synth Brass	CM429	Poly Brass	87	88	45
Synth Brass	CM430	Soft Brass	87	88	46
Synth Brass	CM431	FM Brass	87	88	47
Synth Brass	CM432	Warm Syn Brass	87	88	48
Synth Brass	CM433	Dual Saw Brass	87	88	49
Synth Brass	CM434	Soft Syn Brass	87	88	50
Synth Brass	CM435	Vintage Brass	87	88	51
Synth Brass	CM436	Vintage Brass w	87	88	52
Synth Brass	CM437	Euro Express	87	88	53
Synth Brass	CM438	Mix Brass	87	88	54
Synth Brass	CM439	Brite Syn Brass	87	88	55
Synth Brass	CM440	JP8 Brass 3	87	88	56
Synth Brass	CM441	Synth Brass 5	87	88	57
Synth Brass	CM442	80's Brass 3	87	88	58
Synth Brass	CM443	80's Brass 4	87	88	59
Synth Pad/Str	PR101	Legend Pad	71	96	101
Synth Pad/Str	PR102	New Jupiter	71	96	102
Synth Pad/Str	PR103	Chord Of Canada	71	96	103
Synth Pad/Str	PR104	Underscore BPF	71	96	104
Synth Pad/Str	PR105	Super SynPad	71	96	105
Synth Pad/Str	PR106	JP8 Slow Strings	71	96	106
Synth Pad/Str	PR107	Soft Warm Pad	71	96	107
Synth Pad/Str	PR108	Boreal Pad	71	96	108
Synth Pad/Str	PR109	Air Pad	71	96	109
Synth Pad/Str	PR110	Voice Heaven	71	96	110
Synth Pad/Str	PR111	Retro ChoirPad	71	96	111
Synth Pad/Str	PR112	Long Breath	71	96	112
Synth Pad/Str	PR113	SynthChord01 MC	71	96	113
Synth Pad/Str	PR114	Bright Counter	71	96	114
Synth Pad/Str	PR115	ReverseSweep	71	96	115

GO:KEYS 3 / GO:KEYS 5 Tone List

Category	No.	ToneName	MSB	LSB	PC
Synth Pad/Str	CM342	Syn Strings 1	87	87	86
Synth Pad/Str	CM343	Syn Strings 1 w	87	87	87
Synth Pad/Str	CM344	Syn Strings 3	87	87	88
Synth Pad/Str	CM345	Syn Strings 3 w	87	87	89
Synth Pad/Str	CM346	Syn Strings 2	87	87	90
Synth Pad/Str	CM347	Syn Strings 2 w	87	87	91
Synth Pad/Str	CM586	Warm Pad	87	89	74
Synth Pad/Str	CM587	Warm Pad Dly	87	89	75
Synth Pad/Str	CM588	Sine Pad	87	89	76
Synth Pad/Str	CM589	JP8 Strings 1	87	89	77
Synth Pad/Str	CM590	Soft Pad	87	89	78
Synth Pad/Str	CM591	JP8 Strings 2	87	89	79
Synth Pad/Str	CM592	JUNO Str	87	89	80
Synth Pad/Str	CM593	JUNO Str w	87	89	81
Synth Pad/Str	CM594	Oct Strings	87	89	82
Synth Pad/Str	CM595	Brite Str	87	89	83
Synth Pad/Str	CM596	Voyager	87	89	84
Synth Pad/Str	CM597	Voyager w	87	89	85
Synth Pad/Str	CM598	JP8 Strings 3	87	89	86
Synth Pad/Str	CM599	PWM Str 1	87	89	87
Synth Pad/Str	CM600	PWM Str 2	87	89	88
Synth Pad/Str	CM601	Fading Str	87	89	89
Synth Pad/Str	CM602	Vintage Str	87	89	90
Synth Pad/Str	CM603	Vintage Str Amp	87	89	91
Synth Pad/Str	CM604	Analog Str	87	89	92
Synth Pad/Str	CM618	Space Voice	87	89	106
Synth Pad/Str	CM619	Space Voice Dly	87	89	107
Synth Pad/Str	CM620	Itopia	87	89	108
Synth Pad/Str	CM621	Itopia Dly	87	89	109
Synth Pad/Str	CM622	JP8 Hollow 1	87	89	110
Synth Pad/Str	CM623	JP8 Hollow 2	87	89	111
Synth Pad/Str	CM624	Hollow Pad	87	89	112
Synth Pad/Str	CM625	Strobe Pad	87	89	113
Synth Pad/Str	CM626	Heaven Pad	87	89	114
Synth Pad/Str	CM627	Itopia w	87	89	115
Synth Pad/Str	CM628	Bowed Glass	87	89	116
Synth Pad/Str	CM629	Bowed Glass Dly	87	89	117
Synth Pad/Str	CM630	Brite Wine	87	89	118
Synth Pad/Str	CM631	Bell Pad	87	89	119
Synth Pad/Str	CM632	Wine Pad	87	89	120
Synth Pad/Str	CM633	Fine Wine Pad	87	89	121
Synth Pad/Str	CM634	Organ Pad	87	89	122
Synth Pad/Str	CM635	Brite Wine w	87	89	123
Synth Pad/Str	CM636	Metallic Pad	87	89	124
Synth Pad/Str	CM637	Metallic Pad Dly	87	89	125
Synth Pad/Str	CM638	Chime Pad	87	89	126
Synth Pad/Str	CM639	Halo Pad	87	89	127
Synth Pad/Str	CM640	Halo Pad w	87	89	128
Synth Pad/Str	CM641	Halo Pad Dly	87	90	1
Synth Pad/Str	CM642	Sweep Pad 1	87	90	2
Synth Pad/Str	CM643	Sweep Pad 1 Dly	87	90	3
Synth Pad/Str	CM644	Trns Sweep Pad w	87	90	4
Synth Pad/Str	CM645	Trns Sweep Pad	87	90	5
Synth Pad/Str	CM646	Giant Sweep	87	90	6
Synth Pad/Str	CM647	Sweep Pad 2 w	87	90	7
Synth Pad/Str	CM648	Sweep Pad 2	87	90	8
Synth Pad/Str	CM649	Reso Pad	87	90	9
Synth Pad/Str	CM650	Ice Rain	87	90	10

Category	No.	ToneName	MSB	LSB	PC
Synth Pad/Str	CM651	Ice Rain Dly	87	90	11
Synth Pad/Str	CM652	Healing Pad	87	90	12
Synth Pad/Str	CM653	Healing Pad w	87	90	13
Synth Pad/Str	CM654	Soundtrack	87	90	14
Synth Pad/Str	CM655	Soundtrack Dly	87	90	15
Synth Pad/Str	CM656	Random Str	87	90	16
Synth Pad/Str	CM657	Fairy's Song	87	90	17
Synth Pad/Str	CM732	Star Theme	87	90	92
Synth Pad/Str	CM733	Star Theme Dly	87	90	93
Synth Bellpad	PR116	D50 Fantasia	71	96	116
Synth Bellpad	PR117	D50 Stac Heaven	71	96	117
Synth Bellpad	PR118	D50 Stack Pad	71	96	118
Synth Bellpad	PR119	Amethyst Dream	71	96	119
Synth Bellpad	PR120	Dreaming Harp	71	96	120
Synth Bellpad	CM571	Fantasia	87	89	59
Synth Bellpad	CM572	D50 Bell	87	89	60
Synth Bellpad	CM573	D50 Bell w	87	89	61
Synth Bellpad	CM574	Fantasy 1	87	89	62
Synth Bellpad	CM575	D50 Fantasy	87	89	63
Synth Bellpad	CM576	D50 Fantasy w	87	89	64
Synth Bellpad	CM577	Soft Bell	87	89	65
Synth Bellpad	CM578	Dreambell	87	89	66
Synth Bellpad	CM579	Dreambell w	87	89	67
Synth Bellpad	CM580	Dreaming Box	87	89	68
Synth Bellpad	CM581	Dreaming Box w	87	89	69
Synth Bellpad	CM582	Fantasy 2	87	89	70
Synth Bellpad	CM583	Fantasy 2 w	87	89	71
Synth Bellpad	CM584	Stacc Heaven	87	89	72
Synth Bellpad	CM585	Stacc Heaven w	87	89	73
Synth PolyKey	PR121	Remember EP	71	96	121
Synth PolyKey	PR122	Lo-Fi Synth Keys	71	96	122
Synth PolyKey	PR123	Dreamer Keys	71	96	123
Synth PolyKey	PR124	Power Short	71	96	124
Synth PolyKey	PR125	Cue Tip	71	96	125
Synth PolyKey	PR126	Hybrid Synth Key	71	96	126
Synth PolyKey	PR127	Trance-Touch	71	96	127
Synth PolyKey	PR128	Glitterwheelie	71	96	128
Synth PolyKey	PR129	Aah Formant	71	97	1
Synth PolyKey	PR130	Cinema Transform	71	97	2
Synth PolyKey	PR131	Chomping	71	97	3
Synth PolyKey	PR132	Chiptune Square	71	97	4
Synth PolyKey	PR133	Chiptune Octave	71	97	5
Synth PolyKey	PR134	Chiptune FX	71	97	6
Synth PolyKey	PR135	Wet Keys	71	97	7
Synth PolyKey	PR136	Spaghetti Square	71	97	8
Synth PolyKey	CM605	Polysynth	87	89	93
Synth PolyKey	CM606	Polysynth Dly	87	89	94
Synth PolyKey	CM607	Digitaleess	87	89	95
Synth PolyKey	CM608	Analog Saws	87	89	96
Synth PolyKey	CM609	Super Saws	87	89	97
Synth PolyKey	CM610	Super Saws Atk	87	89	98
Synth PolyKey	CM611	Dance Saws 2	87	89	99
Synth PolyKey	CM612	S-Saw Pad	87	89	100
Synth PolyKey	CM613	S-Saw Pad w	87	89	101
Synth PolyKey	CM614	DOC Stack	87	89	102
Synth PolyKey	CM615	Trance Saws	87	89	103
Synth PolyKey	CM616	Trance Saws w	87	89	104
Synth PolyKey	CM617	PWM Pad	87	89	105

GO:KEYS 3 / GO:KEYS 5 Tone List

Category	No.	ToneName	MSB	LSB	PC
Synth PolyKey	CM701	Atmosphere	87	90	61
Synth PolyKey	CM702	Atmosphere Cho	87	90	62
Synth PolyKey	CM703	Analog Dream	87	90	63
Synth PolyKey	CM704	Analog Dream Atk	87	90	64
Synth PolyKey	CM705	Choir Key	87	90	65
Synth PolyKey	CM706	Choir Key Echo	87	90	66
Synth PolyKey	CM707	Brass Key	87	90	67
Synth PolyKey	CM708	Harpsi Key	87	90	68
Synth PolyKey	CM709	Harpsi Key w	87	90	69
Synth PolyKey	CM710	Brightness	87	90	70
Synth PolyKey	CM711	Brightness Cho	87	90	71
Synth PolyKey	CM712	Vox Key	87	90	72
Synth PolyKey	CM713	Air Key 1	87	90	73
Synth PolyKey	CM714	Air Key 2	87	90	74
Synth PolyKey	CM715	Digital Key	87	90	75
Synth PolyKey	CM716	Dreamheaven 1	87	90	76
Synth PolyKey	CM717	Dreamheaven 2	87	90	77
Synth FX	PR137	Flanging Atmos.	71	97	9
Synth FX	PR138	FS Crystal	71	97	10
Synth FX	PR139	Mixture Fx Pad	71	97	11
Synth FX	PR140	Unknown Planet	71	97	12
Synth FX	PR141	Atmospheric Oohs	71	97	13
Synth FX	PR142	Breathy Bubbles	71	97	14
Synth FX	PR143	New Planetz	71	97	15
Synth FX	PR144	1Note Synth Maj7	71	97	16
Synth FX	PR145	SynthFX+Pluck	71	97	17
Synth FX	PR146	Future Chord	71	97	18
Synth FX	PR147	Vibes BendChord	71	97	19
Synth FX	PR148	ResoSweep Vib	71	97	20
Synth FX	PR149	SoundStrange	71	97	21
Synth FX	PR150	Tubulence	71	97	22
Synth FX	PR151	Zap B3 & C4	71	97	23
Synth FX	PR152	Gridder	71	97	24
Synth FX	PR153	Flying Key	71	97	25
Synth FX	CM718	Goblins	87	90	78
Synth FX	CM719	Cosmic Drops	87	90	79
Synth FX	CM720	Echo Drops	87	90	80
Synth FX	CM721	Echo Drops Cho	87	90	81
Synth FX	CM722	Echo Bell	87	90	82
Synth FX	CM723	Echo Bell Cho	87	90	83
Synth FX	CM724	Echo Bell Dly	87	90	84
Synth FX	CM725	Echo Pan	87	90	85
Synth FX	CM726	Echo Pan Cho	87	90	86
Synth FX	CM727	LFO Saw	87	90	87
Synth FX	CM728	Keep Going	87	90	88
Synth FX	CM729	Electrostar	87	90	89
Synth FX	CM730	Scream at me	87	90	90
Synth FX	CM731	Scream at me w	87	90	91
Synth Pluck	PR154	Electric Pluck	71	97	26
Synth Pluck	PR155	Heartbeat Pluck	71	97	27
Synth Pluck	PR156	Margherita Pizz	71	97	28
Synth Pluck	PR157	Kernels	71	97	29
Synth Pluck	PR158	Doctopus /Mod	71	97	30
Synth Pluck	PR159	PWM Acid Syn	71	97	31
Synth Pluck	PR160	Seq X-Mod Wave	71	97	32
Synth Pluck	PR161	Flip Pluck	71	97	33
Synth Pluck	PR162	Thin PW Pluck	71	97	34
Synth Pluck	CM658	Crystal	87	90	18

Category	No.	ToneName	MSB	LSB	PC
Synth Pluck	CM659	Crystal w	87	90	19
Synth Pluck	CM660	Synth Mallet	87	90	20
Synth Pluck	CM661	Synth Mallet w	87	90	21
Synth Pluck	CM662	Synth Mallet Dly	87	90	22
Synth Pluck	CM663	Sine Mallet	87	90	23
Synth Pluck	CM664	Seq Saw	87	90	24
Synth Pluck	CM665	Seq 1	87	90	25
Synth Pluck	CM666	Seq 1 w	87	90	26
Synth Pluck	CM667	Seq 2	87	90	27
Synth Pluck	CM668	Seq 3	87	90	28
Synth Pluck	CM669	Seq Sqr 1	87	90	29
Synth Pluck	CM670	Seq Sqr 1 Atk	87	90	30
Synth Pluck	CM671	Seq Sqr 2	87	90	31
Synth Pluck	CM672	Seq Tri	87	90	32
Synth Pluck	CM673	Seq Tri w	87	90	33
Synth Pluck	CM674	Synth Seq 1	87	90	34
Synth Pluck	CM675	Synth Seq 2	87	90	35
Synth Pluck	CM676	Synth Seq 3	87	90	36
Synth Pluck	CM677	Analog Seq	87	90	37
Synth Pluck	CM678	Detune Seq	87	90	38
Synth Pluck	CM679	Uni-G	87	90	39
Synth Pluck	CM680	Seq 4	87	90	40
Synth Pluck	CM681	Analog Poly	87	90	41
Synth Pluck	CM682	Analog Poly Dly	87	90	42
Synth Pluck	CM683	Saws Key	87	90	43
Synth Pluck	CM684	Vintage Key	87	90	44
Synth Pluck	CM685	Analog Key w	87	90	45
Synth Pluck	CM686	Analog Key	87	90	46
Synth Pluck	CM687	Bell 1	87	90	47
Synth Pluck	CM688	Bell 1 Atk	87	90	48
Synth Pluck	CM689	Bell 2	87	90	49
Synth Pluck	CM690	Bell 3	87	90	50
Synth Pluck	CM691	Bell 3 Amp	87	90	51
Synth Pluck	CM692	MusicBox Key w	87	90	52
Synth Pluck	CM693	MusicBox Key	87	90	53
Synth Pluck	CM694	Music Bells	87	90	54
Synth Pluck	CM695	Music Bells w	87	90	55
Synth Pluck	CM696	Dreaming Bell	87	90	56
Synth Pluck	CM697	FingBell Key	87	90	57
Synth Pluck	CM698	FingBell Key w	87	90	58
Synth Pluck	CM699	Org Bell	87	90	59
Synth Pluck	CM700	Pluck Synth	87	90	60
Synth Bass	PR163	AX MG Bass 1	71	97	35
Synth Bass	PR164	Syn Bass Hook	71	97	36
Synth Bass	PR165	Round Bass	71	97	37
Synth Bass	PR166	Pop SynthBass 1	71	97	38
Synth Bass	PR167	Pop SynthBass 2	71	97	39
Synth Bass	PR168	Pop SynthBass 3	71	97	40
Synth Bass	PR169	XMod2 Donk Bs	71	97	41
Synth Bass	PR170	Super-Basso	71	97	42
Synth Bass	PR171	Buzz Biter	71	97	43
Synth Bass	PR172	Res Cooker	71	97	44
Synth Bass	PR173	Persist Bass	71	97	45
Synth Bass	PR174	Shave Bass	71	97	46
Synth Bass	PR175	Monster Bass	71	97	47
Synth Bass	PR176	Synthwave Bass	71	97	48
Synth Bass	PR177	Wub Bass	71	97	49
Synth Bass	PR178	TB Dist Bass	71	97	50

GO:KEYS 3 / GO:KEYS 5 Tone List

Category	No.	ToneName	MSB	LSB	PC
Synth Bass	PR179	Dark Sub	71	97	51
Synth Bass	PR180	Dist.808StyleBs1	71	97	52
Synth Bass	PR181	Bit Subby	71	97	53
Synth Bass	PR182	Mod Growl Bass1	71	97	54
Synth Bass	PR183	Show Me Low	71	97	55
Synth Bass	PR184	Organ Bs	71	97	56
Synth Bass	PR185	Razor Bass Lead	71	97	57
Synth Bass	CM228	Synth Bass 1	87	86	100
Synth Bass	CM229	Synth Bass 1 w	87	86	101
Synth Bass	CM230	Warm Syn Bass	87	86	102
Synth Bass	CM231	Synth Bass 3	87	86	103
Synth Bass	CM232	Clav.Bass	87	86	104
Synth Bass	CM233	Clav.Bass w	87	86	105
Synth Bass	CM234	Hammer Bass	87	86	106
Synth Bass	CM235	Hammer Bass Atk	87	86	107
Synth Bass	CM236	Juno Sqr Bass	87	86	108
Synth Bass	CM237	MKS-50 Bass	87	86	109
Synth Bass	CM238	R&B Bass 1	87	86	110
Synth Bass	CM239	R&B Bass 1 w	87	86	111
Synth Bass	CM240	R&B Bass 1 Atk	87	86	112
Synth Bass	CM241	MC202 Bass	87	86	113
Synth Bass	CM242	Compu Bass 1	87	86	114
Synth Bass	CM243	Compu Bass 1 Atk	87	86	115
Synth Bass	CM244	Muffled Bass	87	86	116
Synth Bass	CM245	R&B Bass 2	87	86	117
Synth Bass	CM246	R&B Bass 2 w	87	86	118
Synth Bass	CM247	R&B Bass 2 Atk	87	86	119
Synth Bass	CM248	R&B Bass 3	87	86	120
Synth Bass	CM249	R&B Bass 3 w	87	86	121
Synth Bass	CM250	R&B Bass 4	87	86	122
Synth Bass	CM251	MG Bass 1	87	86	123
Synth Bass	CM252	MG Bass 1 w	87	86	124
Synth Bass	CM253	MG Bass 1 Atk	87	86	125
Synth Bass	CM254	MG Bass 2	87	86	126
Synth Bass	CM255	MG Bass 2 w	87	86	127
Synth Bass	CM256	MG Bass 3	87	86	128
Synth Bass	CM257	MG Bass 4	87	87	1
Synth Bass	CM258	MG Bass 5	87	87	2
Synth Bass	CM259	New Reso Bs 1	87	87	3
Synth Bass	CM260	New Reso Bs 1 w	87	87	4
Synth Bass	CM261	New Reso Bs 2	87	87	5
Synth Bass	CM262	Reso Bass 1	87	87	6
Synth Bass	CM263	Rubber Bass	87	87	7
Synth Bass	CM264	Reso Bass 2	87	87	8
Synth Bass	CM265	Reso Bass 3	87	87	9
Synth Bass	CM266	Reso Bass 4	87	87	10
Synth Bass	CM267	Acid Bass 1	87	87	11
Synth Bass	CM268	Acid Bass 2	87	87	12
Synth Bass	CM269	Acid Bass 3	87	87	13
Synth Bass	CM270	TB Bass 1	87	87	14
Synth Bass	CM271	TB Bass 2	87	87	15
Synth Bass	CM272	Flat Bass	87	87	16
Synth Bass	CM273	Sub Bass	87	87	17
Synth Bass	CM274	Sub Bass Atk	87	87	18
Synth Bass	CM275	Garage Bass	87	87	19
Synth Bass	CM276	Synth Bass 2	87	87	20
Synth Bass	CM277	Synth Bass 5	87	87	21
Synth Bass	CM278	Synth Bass 4	87	87	22

Category	No.	ToneName	MSB	LSB	PC
Synth Bass	CM279	Synth Bass 6	87	87	23
Synth Bass	CM280	Rubber Syn Bs	87	87	24
Synth Bass	CM281	Attack Pulse	87	87	25
Synth Bass	CM282	Seq Bass	87	87	26
Synth Bass	CM283	106 Bass 1	87	87	27
Synth Bass	CM284	106 Bass 2	87	87	28
Synth Bass	CM285	Juno Bass	87	87	29
Synth Bass	CM286	Filter Env Bs	87	87	30
Synth Bass	CM287	Unison Syn Bs	87	87	31
Synth Bass	CM288	Unison Syn Bs w	87	87	32
Synth Bass	CM289	Alpha Bass	87	87	33
Synth Bass	CM290	Alpha Bass w	87	87	34
Synth Bass	CM291	Detune Bs	87	87	35
Synth Bass	CM292	Detune Bs w	87	87	36
Synth Bass	CM293	Ramp Bass	87	87	37
Synth Bass	CM294	Ramp Bass Atk	87	87	38
Synth Bass	CM295	Pedal Bass 1	87	87	39
Synth Bass	CM296	Pedal Bass 2	87	87	40
Synth Bass	CM297	Compu Bass 2	87	87	41
Synth Bass	CM298	Sqr Bass w	87	87	42
Synth Bass	CM299	Modular Bs 1	87	87	43
Synth Bass	CM300	Modular Bs 2	87	87	44
Synth Bass	CM301	Synth Bass 7	87	87	45
Synth Bass	CM302	Pedal Bass 3	87	87	46
Synth Bass	CM303	Monster Bass 1	87	87	47
Synth Bass	CM304	Monster Bass 2	87	87	48
Synth Bass	CM305	Growl Bass 1	87	87	49
Synth Bass	CM306	Growl Bass 2	87	87	50
Pulsating	PR186	Ice Dust	71	97	58
Pulsating	PR187	House Moves	71	97	59
Pulsating	PR188	Chordy Wave	71	97	60
Pulsating	PR189	Fluctuations	71	97	61
Pulsating	PR190	Ripples	71	97	62
Pulsating	PR191	JP Never Dies	71	97	63
Pulsating	PR192	Byzantine Wave	71	97	64
Pulsating	PR193	Sliced Saw	71	97	65
Pulsating	PR194	Talking S&H	71	97	66
Pulsating	PR195	Pulsating Oohs	71	97	67
Pulsating	PR196	Unstable Space	71	97	68
Pulsating	PR197	ChordonBleu Reso	71	97	69

other

Category	No.	ToneName	MSB	LSB	PC
E.Organ	PR198	B.Organ	71	97	70
E.Organ	PR199	Dist B.Organ	71	97	71
E.Organ	PR200	Soft Jazz Organ	71	97	72
E.Organ	PR201	Whisper Organ	71	97	73
E.Organ	PR202	Gospel Organ	71	97	74
E.Organ	PR203	Full Draw	71	97	75
E.Organ	PR204	Lower Organ	71	97	76
E.Organ	PR205	Light Organ	71	97	77
E.Organ	PR206	Perc Jazz Organ	71	97	78
E.Organ	PR207	Perc Pop Organ	71	97	79
E.Organ	PR208	Surf's Up!	71	97	80

GO:KEYS 3 / GO:KEYS 5 Tone List

Category	No.	ToneName	MSB	LSB	PC
E.Organ	PR209	Organesque	71	97	81
E.Organ	PR210	Happy 60s	71	97	82
E.Organ	PR211	96 Years	71	97	83
E.Organ	PR212	Glory Us Rok	71	97	84
E.Organ	CM105	Organ 1	87	85	105
E.Organ	CM106	Organ 1 Rtry	87	85	106
E.Organ	CM107	Tremolo Organ	87	85	107
E.Organ	CM108	Tremolo Organ w	87	85	108
E.Organ	CM109	60s Organ	87	85	109
E.Organ	CM110	60s Organ Cho	87	85	110
E.Organ	CM111	Organ 2	87	85	111
E.Organ	CM112	Organ 2 Rtry	87	85	112
E.Organ	CM113	Ana Organ 1	87	85	113
E.Organ	CM114	Ana Organ 1 Rtry	87	85	114
E.Organ	CM115	Ana Organ 2	87	85	115
E.Organ	CM116	Ana Organ 3	87	85	116
E.Organ	CM117	Ana Organ 4	87	85	117
E.Organ	CM118	Perc.Organ 1	87	85	118
E.Organ	CM119	Perc.Organ 1Rtry	87	85	119
E.Organ	CM120	Chorus Organ	87	85	120
E.Organ	CM121	Perc.Organ 2	87	85	121
E.Organ	CM122	E.Organ 1	87	85	122
E.Organ	CM123	E.Organ 1 w	87	85	123
E.Organ	CM124	E.Organ 1 Rtry	87	85	124
E.Organ	CM125	E.Organ 2	87	85	125
E.Organ	CM126	E.Organ 2 Trem	87	85	126
E.Organ	CM127	E.Organ 3	87	85	127
E.Organ	CM128	Mad Organ	87	85	128
E.Organ	CM129	Rock Organ 1	87	86	1
E.Organ	CM130	Rock Organ Amp	87	86	2
E.Organ	CM131	Rock Organ 2	87	86	3
E.Organ	CM132	Rock Organ w	87	86	4
E.Organ	CM133	Full Organ Rtry	87	86	5
E.Organ	CM134	Full Organ OD	87	86	6
E.Organ	CM135	Rotary Organ	87	86	7
E.Organ	CM136	Rotary Organ Cho	87	86	8
Pipe Organ	PR213	Pos Org O /Mod	71	97	85
Pipe Organ	PR214	Soft Pipe Organ	71	97	86
Pipe Organ	PR215	Positive Organ	71	97	87
Pipe Organ	PR216	Classical Organ	71	97	88
Pipe Organ	PR217	Grand Organ	71	97	89
Pipe Organ	CM137	Church Organ 1	87	86	9
Pipe Organ	CM138	Church Organ 1 w	87	86	10
Pipe Organ	CM139	Church Organ 2	87	86	11
Pipe Organ	CM140	Church Organ 2 w	87	86	12
Pipe Organ	CM141	Church Organ 3	87	86	13
Pipe Organ	CM142	Church Organ 3 w	87	86	14
Pipe Organ	CM145	Puff Organ	87	86	17
Pipe Organ	CM146	Puff Organ w	87	86	18
Reed Organ	CM143	Reed Organ	87	86	15
Reed Organ	CM144	Reed Organ w	87	86	16
Harpsichord	PR218	Elegant Harpsi	71	97	90
Harpsichord	PR219	Harpsi 8'+4'	71	97	91
Harpsichord	CM049	Harpsichord	87	85	49
Harpsichord	CM050	Coupled Harpsi.	87	85	50
Harpsichord	CM051	Harpsichord w	87	85	51
Harpsichord	CM052	Harpsichord w 2	87	85	52
Harpsichord	CM053	Harpsichord o	87	85	53

Category	No.	ToneName	MSB	LSB	PC
Clav	PR220	Harpsy Clav	71	97	92
Clav	PR221	Clav White	71	97	93
Clav	PR222	Clav Phase	71	97	94
Clav	CM054	Clav 1	87	85	54
Clav	CM055	Clav 1 w	87	85	55
Clav	CM056	Clav 1 Phaser	87	85	56
Clav	CM057	Clav 2	87	85	57
Clav	CM058	Clav 2 w	87	85	58
Clav	CM059	Pulse Clav 1	87	85	59
Clav	CM060	Pulse Clav 1 w	87	85	60
Clav	CM061	Pulse Clav 1 w 2	87	85	61
Clav	CM062	Pulse Clav 2	87	85	62
Clav	CM063	Biting Clav	87	85	63
Clav	CM064	Analog Clav	87	85	64
Celesta	PR223	Pure Celesta	71	97	95
Celesta	CM065	Celesta	87	85	65
Celesta	CM066	Celesta w	87	85	66
Accordion	PR224	Chamber Accord	71	97	96
Accordion	PR225	Nostalgic Accord	71	97	97
Accordion	PR226	Bright Musette	71	97	98
Accordion	CM147	Accordion 1	87	86	19
Accordion	CM148	Accordion 1 w	87	86	20
Accordion	CM149	Accordion 2	87	86	21
Accordion	CM150	Accordion It	87	86	22
Accordion	CM151	Vodkakordion	87	86	23
Accordion	CM154	Bandoneon	87	86	26
Accordion	CM155	Bandoneon w	87	86	27
Harmonica	PR227	Blues Reed	71	97	99
Harmonica	CM152	Harmonica	87	86	24
Harmonica	CM153	Harmonica w	87	86	25
Bell	PR228	Concert Tubular	71	97	100
Bell	PR229	XMod2 Soft Bell	71	97	101
Bell	PR230	Vintage Bell Imp	71	97	102
Bell	PR231	Synth Bell 1	71	97	103
Bell	PR232	Tube RingMod	71	97	104
Bell	CM097	Tubular Bells	87	85	97
Bell	CM098	Tubular Bells w	87	85	98
Bell	CM099	Church Bell	87	85	99
Bell	CM100	Church Bell w	87	85	100
Bell	CM101	Carillon	87	85	101
Bell	CM102	Carillon w	87	85	102
Bell	CM754	Tinkle Bell	87	90	114
Bell	CM755	Tinkle Bell w	87	90	115
Bell	CM756	Agogo	87	90	116
Bell	CM757	Agogo w	87	90	117
Mallet	PR233	Solid Marimba	71	97	105
Mallet	PR234	Soft Mallet	71	97	106
Mallet	PR235	Jazz Vibe	71	97	107
Mallet	PR236	Fine Xylophone	71	97	108
Mallet	PR237	Glockenspiel 2	71	97	109
Mallet	PR238	Fat SynMallet	71	97	110
Mallet	PR239	Warm Steel Drums	71	97	111
Mallet	PR240	Glamour	71	97	112
Mallet	PR241	Resonant Santur	71	97	113
Mallet	CM067	Glockenspiel	87	85	67
Mallet	CM068	Glockenspiel w	87	85	68
Mallet	CM073	Vibraphone	87	85	73
Mallet	CM074	Vibraphone w	87	85	74

GO:KEYS 3 / GO:KEYS 5 Tone List

Category	No.	ToneName	MSB	LSB	PC
Mallet	CM075	Vibraphone w 2	87	85	75
Mallet	CM076	Vibraphone Trem	87	85	76
Mallet	CM077	Jazz Vib	87	85	77
Mallet	CM078	Jazz Vib w	87	85	78
Mallet	CM079	Marimba	87	85	79
Mallet	CM080	Marimba w	87	85	80
Mallet	CM081	Marimba w 2	87	85	81
Mallet	CM082	Bs Marimba 1	87	85	82
Mallet	CM083	Bs Marimba 2	87	85	83
Mallet	CM084	Xylophone 1	87	85	84
Mallet	CM085	Xylophone 1 w	87	85	85
Mallet	CM086	Xylophone 1 w 2	87	85	86
Mallet	CM087	Xylophone 2	87	85	87
Mallet	CM088	Kalimbells	87	85	88
Mallet	CM089	Pops Seq 2	87	85	89
Mallet	CM090	Pops Seq 2 w	87	85	90
Mallet	CM091	Pops Seq 2 Atk	87	85	91
Mallet	CM092	Pops Seq 3	87	85	92
Mallet	CM093	Pops Seq 3 Atk	87	85	93
Mallet	CM094	Ethno Keys	87	85	94
Mallet	CM095	Ethno Keys Dly	87	85	95
Mallet	CM096	Toy Box	87	85	96
Mallet	CM103	Santur	87	85	103
Mallet	CM104	Santur w	87	85	104
Mallet	CM325	Yang Qin	87	87	69
Mallet	CM326	Yang Qin w	87	87	70
Ac.Guitar	PR242	Bright Nylon/Sld	71	97	114
Ac.Guitar	PR243	Steel Guitar/Sld	71	97	115
Ac.Guitar	PR244	Steel Guitar/Hrm	71	97	116
Ac.Guitar	PR245	Folk Pad	71	97	117
Ac.Guitar	PR246	Ac Gt Dream	71	97	118
Ac.Guitar	CM156	Nylon Gtr 1	87	86	28
Ac.Guitar	CM157	Ukulele	87	86	29
Ac.Guitar	CM158	Nylon Gtr o	87	86	30
Ac.Guitar	CM159	Nylon Gtr 2	87	86	31
Ac.Guitar	CM160	Nylon Gtr w	87	86	32
Ac.Guitar	CM161	Nylon Gtr Amp	87	86	33
Ac.Guitar	CM162	Steel-str.Gtr	87	86	34
Ac.Guitar	CM163	Steel-str.Gtr w	87	86	35
Ac.Guitar	CM164	Steel-str.GtrAmp	87	86	36
Ac.Guitar	CM165	Steel-str.GtrDst	87	86	37
Ac.Guitar	CM166	Stl Gtr Trem	87	86	38
Ac.Guitar	CM167	12-str.Guitar	87	86	39
Ac.Guitar	CM168	12-str.Guitar w	87	86	40
Ac.Guitar	CM169	Mandolin	87	86	41
Ac.Guitar	CM170	Steel+Body	87	86	42
Ac.Guitar	CM171	Reso Guitar w	87	86	43
Ac.Guitar	CM172	Reso Guitar Amp	87	86	44
E.Guitar	PR247	JC ST Guitar	71	97	119
E.Guitar	PR248	ChoCleanGtr Nz	71	97	120
E.Guitar	PR249	Nice Oct Guitar	71	97	121
E.Guitar	PR250	Space Mute	71	97	122
E.Guitar	CM173	Jazz Guitar	87	86	45
E.Guitar	CM174	Jazz Guitar w	87	86	46
E.Guitar	CM175	Jazz Guitar Atk	87	86	47
E.Guitar	CM176	Hawaiian Gtr	87	86	48
E.Guitar	CM177	Clean Guitar	87	86	49
E.Guitar	CM178	Clean Guitar w	87	86	50

Category	No.	ToneName	MSB	LSB	PC
E.Guitar	CM179	Clean Gtr Chorus	87	86	51
E.Guitar	CM180	Chorus Gtr 1	87	86	52
E.Guitar	CM181	Soft Clean Gtr	87	86	53
E.Guitar	CM182	Soft Clean Gtr w	87	86	54
E.Guitar	CM183	Soft Clean Atk	87	86	55
E.Guitar	CM184	Soft Dist Gtr	87	86	56
E.Guitar	CM185	Mid Tone Gtr	87	86	57
E.Guitar	CM186	Mid Tone Gtr Dly	87	86	58
E.Guitar	CM187	Mid Tone GtrTrem	87	86	59
E.Guitar	CM188	Muted Guitar	87	86	60
E.Guitar	CM189	Muted Guitar w	87	86	61
E.Guitar	CM190	Muted Guitar Atk	87	86	62
E.Guitar	CM191	Muted Guitar Dst	87	86	63
E.Guitar	CM192	Funk Guitar 1	87	86	64
E.Guitar	CM193	Funk Guitar 2	87	86	65
E.Guitar	CM194	Chorus Gtr 2	87	86	66
E.Guitar	CM195	Chorus Gtr2 Echo	87	86	67
E.Guitar	CM196	Chorus Gtr2 Step	87	86	68
Dist.Guitar	PR251	OD Gtr Nz	71	97	123
Dist.Guitar	PR252	Dist Gtr Nz	71	97	124
Dist.Guitar	PR253	Dist Jumper	71	97	125
Dist.Guitar	PR254	Luminous DistGtr	71	97	126
Dist.Guitar	PR255	Searing Lead Gtr	71	97	127
Dist.Guitar	PR256	E Lead Flamer	71	97	128
Dist.Guitar	CM197	Overdrive Gtr 1	87	86	69
Dist.Guitar	CM198	Overdrive Gtr 2	87	86	70
Dist.Guitar	CM199	Overdrive Chorus	87	86	71
Dist.Guitar	CM200	Guitar Pinch	87	86	72
Dist.Guitar	CM201	Distortion Gtr 1	87	86	73
Dist.Guitar	CM202	Distortion Gtr 2	87	86	74
Dist.Guitar	CM203	Distortion Gtr 3	87	86	75
Dist.Guitar	CM204	Distortion Gtr 4	87	86	76
Dist.Guitar	CM205	Distortion Gtr 5	87	86	77
Dist.Guitar	CM206	Gtr Feedback 1	87	86	78
Dist.Guitar	CM207	Dist.Rhy Gtr	87	86	79
Dist.Guitar	CM208	Dist.Rhy Gtr Amp	87	86	80
Dist.Guitar	CM209	Gtr Harmonics	87	86	81
Dist.Guitar	CM210	Gtr Harmonics w	87	86	82
Dist.Guitar	CM211	Gtr Feedback 2	87	86	83
Dist.Guitar	CM212	Gtr Feedback 2 w	87	86	84
Ac.Bass	PR257	Mild Ac.Bass	71	98	1
Ac.Bass	PR258	Bass+Cymbal	71	98	2
Ac.Bass	CM213	Acoustic Bass	87	86	85
Ac.Bass	CM214	Acoustic Bass w	87	86	86
E.Bass	PR259	Comp'd JzBs /Slp	71	98	3
E.Bass	PR260	Fretless Bs Nz	71	98	4
E.Bass	PR261	Pick Bs Nz	71	98	5
E.Bass	PR262	Slap Bass Nz	71	98	6
E.Bass	CM215	Fingered Bass	87	86	87
E.Bass	CM216	FingeredBass Atk	87	86	88
E.Bass	CM217	Finger Slap	87	86	89
E.Bass	CM218	Finger Slap Atk	87	86	90
E.Bass	CM219	Picked Bass	87	86	91
E.Bass	CM220	Picked Bass Atk1	87	86	92
E.Bass	CM221	Picked Bass Atk2	87	86	93
E.Bass	CM222	Fretless Bass	87	86	94
E.Bass	CM223	Fretless Bass w	87	86	95
E.Bass	CM224	Slap Bass 1	87	86	96

GO:KEYS 3 / GO:KEYS 5 Tone List

Category	No.	ToneName	MSB	LSB	PC
E.Bass	CM225	Slap Bass 1 Atk	87	86	97
E.Bass	CM226	Slap Bass 2	87	86	98
E.Bass	CM227	Slap Bass 2 Amp	87	86	99
Plucked/Stroke	PR263	Harpiness	71	98	7
Plucked/Stroke	PR264	Delayed Harp	71	98	8
Plucked/Stroke	PR265	SpkPop Pluck Key	71	98	9
Plucked/Stroke	PR266	Dusk Harp	71	98	10
Plucked/Stroke	PR267	Bright Sitar	71	98	11
Plucked/Stroke	PR268	Kalimba Cho	71	98	12
Plucked/Stroke	CM069	Music Box	87	85	69
Plucked/Stroke	CM070	Music Box w	87	85	70
Plucked/Stroke	CM071	Pops Seq 1	87	85	71
Plucked/Stroke	CM072	Pops Seq 1 Atk	87	85	72
Plucked/Stroke	CM323	Harp	87	87	67
Plucked/Stroke	CM324	Aerial Harp	87	87	68
Plucked/Stroke	CM734	Sitar 1	87	90	94
Plucked/Stroke	CM735	Sitar 1 w	87	90	95
Plucked/Stroke	CM736	Sitar 2	87	90	96
Plucked/Stroke	CM737	Sitar 2 w	87	90	97
Plucked/Stroke	CM738	Banjo	87	90	98
Plucked/Stroke	CM739	Banjo w	87	90	99
Plucked/Stroke	CM740	Shamisen	87	90	100
Plucked/Stroke	CM741	Shamisen w	87	90	101
Plucked/Stroke	CM742	Koto	87	90	102
Plucked/Stroke	CM743	Koto w	87	90	103
Plucked/Stroke	CM744	Taisho Koto	87	90	104
Plucked/Stroke	CM745	Taisho Koto w	87	90	105
Plucked/Stroke	CM746	Kalimba	87	90	106
Plucked/Stroke	CM747	Kalimba w	87	90	107
Orchestral	PR269	Orch Str Brass	71	98	13
Orchestral	PR270	Orchestra Brass	71	98	14
Ensemble Brass	PR271	Light Brass Sect	71	98	15
Ensemble Brass	PR272	Pop Brass Sect	71	98	16
Ensemble Brass	PR273	Soft Brass Sect	71	98	17
Ensemble Brass	PR274	Swelling Horns	71	98	18
Ensemble Brass	CM399	French Horn 1	87	88	15
Ensemble Brass	CM400	French Horn 1 w	87	88	16
Ensemble Brass	CM403	Brass 1	87	88	19
Ensemble Brass	CM404	Brass 1 w	87	88	20
Ensemble Brass	CM405	Brass 2	87	88	21
Ensemble Brass	CM406	Brass Atk	87	88	22
Ensemble Brass	CM407	Brass Atk w	87	88	23
Solo Brass	PR275	Clear Trumpet	71	98	19
Solo Brass	PR276	HM Mute Tp	71	98	20
Solo Brass	PR277	Soft Trombone	71	98	21
Solo Brass	CM382	Trumpet	87	87	126
Solo Brass	CM383	Trumpet Echo	87	87	127
Solo Brass	CM384	Dark Trumpet	87	87	128
Solo Brass	CM385	Dark Trumpet w	87	88	1
Solo Brass	CM386	Romantic Tp	87	88	2
Solo Brass	CM387	Romantic Tp Echo	87	88	3
Solo Brass	CM388	Trombone 1	87	88	4
Solo Brass	CM389	Trombone 1 w	87	88	5
Solo Brass	CM390	Trombone 2	87	88	6
Solo Brass	CM391	Bright Tb	87	88	7
Solo Brass	CM392	Bright Tb w	87	88	8
Solo Brass	CM393	Tuba	87	88	9
Solo Brass	CM394	Tuba Atk	87	88	10

Category	No.	ToneName	MSB	LSB	PC
Solo Brass	CM395	Mute Trumpet 1	87	88	11
Solo Brass	CM396	Mute Trumpet 1 w	87	88	12
Solo Brass	CM397	Mute Trumpet 2	87	88	13
Solo Brass	CM398	Mute Trumpet 2 w	87	88	14
Solo Brass	CM401	French Horn 2	87	88	17
Solo Brass	CM402	FrenchHorn2 Echo	87	88	18
Wind	PR278	Clarinet Vib	71	98	22
Wind	PR279	Fine Oboe	71	98	23
Wind	PR280	English Horn/vsw	71	98	24
Wind	PR281	Good Old Day	71	98	25
Wind	PR282	Mild Winds	71	98	26
Wind	PR283	Asian Wind	71	98	27
Wind	CM452	Oboe	87	88	68
Wind	CM453	Oboe w	87	88	69
Wind	CM454	English Horn	87	88	70
Wind	CM455	Bassoon	87	88	71
Wind	CM456	Clarinet	87	88	72
Wind	CM748	Bagpipe	87	90	108
Wind	CM749	Bagpipe w	87	90	109
Wind	CM752	Shanai	87	90	112
Wind	CM753	Shanai w	87	90	113
Flute	PR284	Soloistic Flute	71	98	28
Flute	PR285	Be Happy Flute	71	98	29
Flute	PR286	Pop Flute	71	98	30
Flute	PR287	LoFi Flute	71	98	31
Flute	PR288	Sine Flute	71	98	32
Flute	CM457	Piccolo	87	88	73
Flute	CM458	Flute	87	88	74
Flute	CM459	Flute w	87	88	75
Flute	CM460	Flute Echo	87	88	76
Flute	CM462	Pan Flute	87	88	78
Flute	CM463	Pan Flute w	87	88	79
Flute	CM464	Pan Flute Dly	87	88	80
Flute	CM465	Bottle Blow	87	88	81
Flute	CM466	Bottle Blow w	87	88	82
Flute	CM467	Bottle Blow Dly	87	88	83
Flute	CM468	Shakuhachi	87	88	84
Flute	CM469	Shakuhachi w	87	88	85
Flute	CM470	Shakuhachi Amp	87	88	86
Sax	PR289	Dynamic Sop Sax	71	98	33
Sax	PR290	Dynamic Alto Sax	71	98	34
Sax	PR291	Dynamic Tnr Sax	71	98	35
Sax	CM444	Soprano Sax	87	88	60
Sax	CM445	Soprano Sax Amp	87	88	61
Sax	CM446	Alto Sax	87	88	62
Sax	CM447	Alto Sax Amp	87	88	63
Sax	CM448	Tenor Sax	87	88	64
Sax	CM449	Tenor Sax Amp	87	88	65
Sax	CM450	Baritone Sax	87	88	66
Sax	CM451	Baritone Sax Atk	87	88	67
Recorder	PR292	TenorRecorder	71	98	36
Recorder	PR293	Twin Air Lead	71	98	37
Recorder	CM461	Recorder	87	88	77
Recorder	CM471	Whistle	87	88	87
Recorder	CM472	Whistle Dly	87	88	88
Recorder	CM473	Ocarina	87	88	89
Recorder	CM474	Ocarina Echo	87	88	90
Vox/Choir	PR294	Syn Voice Lead	71	98	38

GO:KEYS 3 / GO:KEYS 5 Tone List

Category	No.	ToneName	MSB	LSB	PC
Vox/Choir	PR295	LqFunk Vox Lead	71	98	39
Vox/Choir	PR296	Choir Aahs	71	98	40
Vox/Choir	PR297	Wide Choir Aahs	71	98	41
Vox/Choir	PR298	Angels Voices	71	98	42
Vox/Choir	PR299	VP-330 Vox	71	98	43
Vox/Choir	CM348	Choir 1	87	87	92
Vox/Choir	CM349	Choir 2	87	87	93
Vox/Choir	CM350	Choir 3	87	87	94
Vox/Choir	CM352	Humming	87	87	96
Vox/Choir	CM353	Synth Voice	87	87	97
Vox/Choir	CM354	Analog Voice 1	87	87	98
Vox/Choir	CM355	Analog Voice 2	87	87	99
Vox/Choir	CM358	Aerial Choir	87	87	102
Vox/Choir	CM359	Aerial Choir w	87	87	103
Vox/Choir	CM360	DJ Soft Vox	87	87	104
Vox/Choir	CM361	DJ Soft Vox w	87	87	105
Vox/Choir	CM362	Syn Vox	87	87	106
Vox/Choir	CM363	Syn Vox w	87	87	107
Vox/Choir	CM364	VP-330 Choir	87	87	108
Vox/Choir	CM365	VP-330 Choir w	87	87	109
Vox/Choir	CM366	FXM Voice	87	87	110
Vox/Choir	CM367	Cat Voice	87	87	111
Vox/Choir	CM368	Cat Voice Wah	87	87	112
Scat	PR300	Jazz Scat Layer	71	98	44
Scat	PR301	Jazz Voice Doo	71	98	45
Scat	PR302	Jazz Voice Dat	71	98	46
Scat	PR303	Jazz Voice Bap	71	98	47
Scat	PR304	Jazz Voice Dow	71	98	48
Scat	CM351	Voice Doos	87	87	95
Scat	CM356	Jazz Scat	87	87	100
Scat	CM357	Jazz Scat w	87	87	101
Hit	PR305	Philly Hit	71	98	49
Hit	PR306	Mix Hit	71	98	50
Hit	PR307	Metal Hit	71	98	51
Hit	PR308	Rave Stab	71	98	52
Hit	PR309	Rotary Syn Min7	71	98	53
Hit	PR310	ModCtrl DeepEcho	71	98	54
Hit	PR311	JUNO Stab	71	98	55
Hit	PR312	JUNO Stab 2	71	98	56
Hit	PR313	1Note Squ Maj7	71	98	57
Hit	PR314	1Note PhaserEP2	71	98	58
Hit	CM369	Orchestra Hit	87	87	113
Hit	CM370	Bass Hit	87	87	114
Hit	CM371	Bass Hit w	87	87	115
Hit	CM372	6th Hit	87	87	116
Hit	CM373	6th Hit w	87	87	117
Hit	CM374	Euro Hit	87	87	118
Hit	CM375	Euro Hit w	87	87	119
Hit	CM376	Cheezy Movie	87	87	120
Hit	CM377	Cheezy Movie w	87	87	121
Hit	CM378	Tao Hit	87	87	122
Hit	CM379	Tao Hit w	87	87	123
Hit	CM380	House Hit	87	87	124
Hit	CM381	House Hit w	87	87	125
Sound FX	CM774	Gtr Fret Noise	87	91	6
Sound FX	CM775	Gtr Cut Noise	87	91	7
Sound FX	CM776	Bass String Slap	87	91	8
Sound FX	CM777	Breath Noise	87	91	9

Category	No.	ToneName	MSB	LSB	PC
Sound FX	CM778	Flute Key Click	87	91	10
Sound FX	CM779	Seashore	87	91	11
Sound FX	CM780	Rain	87	91	12
Sound FX	CM781	Thunder	87	91	13
Sound FX	CM782	Thunder Dly	87	91	14
Sound FX	CM783	Wind	87	91	15
Sound FX	CM784	Stream	87	91	16
Sound FX	CM785	Stream w	87	91	17
Sound FX	CM786	Bubble 1	87	91	18
Sound FX	CM787	Bubble 1 w	87	91	19
Sound FX	CM788	Bubble 2	87	91	20
Sound FX	CM789	FX Scene	87	91	21
Sound FX	CM790	Tuned Winds	87	91	22
Sound FX	CM791	Tuned Winds w	87	91	23
Sound FX	CM792	Sand Noise	87	91	24
Sound FX	CM793	Bird 1	87	91	25
Sound FX	CM794	Dog	87	91	26
Sound FX	CM795	Horse Gallop	87	91	27
Sound FX	CM796	Bird 2	87	91	28
Sound FX	CM797	Telephone 1	87	91	29
Sound FX	CM798	Telephone 2	87	91	30
Sound FX	CM799	Door Creaking	87	91	31
Sound FX	CM800	Door	87	91	32
Sound FX	CM801	Scratch	87	91	33
Sound FX	CM802	Wind Chimes	87	91	34
Sound FX	CM803	FX Close	87	91	35
Sound FX	CM804	Helicopter	87	91	36
Sound FX	CM805	Car Engine	87	91	37
Sound FX	CM806	Car Stop	87	91	38
Sound FX	CM807	Car Pass	87	91	39
Sound FX	CM808	Car Crash	87	91	40
Sound FX	CM809	Siren	87	91	41
Sound FX	CM810	Train	87	91	42
Sound FX	CM811	Jetplane	87	91	43
Sound FX	CM812	Jetplane Dly	87	91	44
Sound FX	CM813	Starship	87	91	45
Sound FX	CM814	Starship Dly	87	91	46
Sound FX	CM815	Burst Noise	87	91	47
Sound FX	CM816	Passing By	87	91	48
Sound FX	CM817	FX Pass 1	87	91	49
Sound FX	CM818	FX Pass 2	87	91	50
Sound FX	CM819	FX Pass 3	87	91	51
Sound FX	CM820	FX Pass 4	87	91	52
Sound FX	CM821	FX Pass 5	87	91	53
Sound FX	CM822	Poly Sweep Nz	87	91	54
Sound FX	CM823	Reso Sweep Dn	87	91	55
Sound FX	CM824	Applause	87	91	56
Sound FX	CM825	Applause w	87	91	57
Sound FX	CM826	Laughing	87	91	58
Sound FX	CM827	Screaming	87	91	59
Sound FX	CM828	Punch	87	91	60
Sound FX	CM829	Heart Beat	87	91	61
Sound FX	CM830	Footsteps	87	91	62
Sound FX	CM831	Gun Shot	87	91	63
Sound FX	CM832	Machine Gun	87	91	64
Sound FX	CM833	Laser Gun	87	91	65
Sound FX	CM834	Explosion	87	91	66
Sound FX	CM835	Explosion Dly	87	91	67

GO:KEYS 3 / GO:KEYS 5 Tone List

Category	No.	ToneName	MSB	LSB	PC
Sound FX	CM836	Explosion Dist	87	91	68
Sound FX	CM837	FX Hit w	87	91	69
Stack	PR315	Emotion Quotient	71	98	59
Stack	PR316	Truly Moving	71	98	60
Drums	CD001	Standard Kit	86	65	1
Drums	CD002	Room Kit	86	65	2
Drums	CD003	Power Kit	86	65	3
Drums	CD004	Electric Kit	86	65	4
Drums	CD005	Analog Kit	86	65	5
Drums	CD006	Jazz Kit	86	65	6
Drums	CD007	Brush Kit	86	65	7
Drums	CD008	Orchestra Kit	86	65	8
Drums	CD009	SFX Kit	86	65	9
Drums	CD010	Standard Kit w	86	65	10
Drums	CD011	Room Kit w	86	65	11
Drums	CD012	Power Kit w	86	65	12
Drums	CD013	Electric Kit w	86	65	13
Drums	CD014	Analog Kit w	86	65	14
Drums	CD015	Jazz Kit w	86	65	15
Drums	CD016	Brush Kit w	86	65	16
Drums	CD017	Orchestra Kit w	86	65	17
Drums	CD018	SFX Kit w	86	65	18
Drums	CD019	Studio Kit	86	65	19
Drums	CD020	Studio Kit w	86	65	20
Drums	CD021	Pop Kit	86	65	21
Drums	CD022	Pop Kit w	86	65	22
Drums	CD023	Pop Kit Lim	86	65	23
Drums	CD024	90's Kit	86	65	24
Drums	CD025	90's Kit comp	86	65	25
Drums	CD026	90's Kit w comp	86	65	26
Drums	CD027	80's Kit	86	65	27
Drums	CD028	80's Kit comp	86	65	28
Drums	CD029	80's Kit w comp	86	65	29
Drums	CD030	EDM Kit	86	65	30
Drums	CD031	EDM Kit w	86	65	31
Drums	CD032	EDM Kit Lim	86	65	32
Drums	CD033	Drum&Bass Kit	86	65	33
Drums	CD034	Drum&Bass Kit	86	65	34
Drums	CD035	Drum&Bass KitLim	86	65	35
Drums	CD036	Techno Kit	86	65	36
Drums	CD037	Techno Kit w	86	65	37
Drums	CD038	House Kit	86	65	38
Drums	CD039	House Kit w	86	65	39
Drums	CD040	HipHop Kit	86	65	40
Drums	CD041	HipHop Kit comp	86	65	41
Drums	CD042	HipHop Kit w cmp	86	65	42
Drums	CD043	R&B Kit	86	65	43
Drums	CD044	R&B Kit w	86	65	44
Drums	CD045	TR-909	86	65	45
Drums	CD046	TR-909 comp	86	65	46
Drums	CD047	TR-909 w comp	86	65	47
Drums	CD048	TR-808	86	65	48
Drums	CD049	TR-808 comp	86	65	49
Drums	CD050	TR-808 w comp	86	65	50
Drums	CD051	TR-707&727	86	65	51
Drums	CD052	TR-707&727 comp	86	65	52
Drums	CD053	TR-707&727 w cmp	86	65	53
Drums	CD054	CR-78	86	65	54

Category	No.	ToneName	MSB	LSB	PC
Drums	CD055	CR-78 comp	86	65	55
Drums	CD056	CR-78 w comp	86	65	56
Drums	CD057	TR-606	86	65	57
Drums	CD058	TR-606 comp	86	65	58
Drums	CD059	TR-606 w comp	86	65	59
Drums	CD060	TR-626	86	65	60
Drums	CD061	TR-626 comp	86	65	61
Drums	CD062	TR-626 w comp	86	65	62
Drums	CD063	Kick	86	65	63
Drums	CD064	Kick w	86	65	64
Drums	CD065	Snare	86	65	65
Drums	CD066	Snare w	86	65	66
Drums	CD067	RimStickClapTom	86	65	67
Drums	CD068	RimStickClapTm w	86	65	68
Drums	CD069	HiHat Cymbal	86	65	69
Drums	CD070	HiHat Cymbal w	86	65	70
Drums	CD071	Other Perc 1	86	65	71
Drums	CD072	Other Perc 1 w	86	65	72
Drums	CD073	Other Perc 2	86	65	73
Drums	CD074	Other Perc 2 w	86	65	74
Percussion	PR317	Bonus Percs	71	98	61
Percussion	CM327	Timpani	87	87	71
Percussion	CM328	Timpani w	87	87	72
Percussion	CM329	Timpani Low	87	87	73
Percussion	CM330	Timpani Atk	87	87	74
Percussion	CM758	Steel Drums	87	90	118
Percussion	CM759	Steel Drums w	87	90	119
Percussion	CM760	Steel Drums w 2	87	90	120
Percussion	CM761	Woodblock	87	90	121
Percussion	CM762	Castanets	87	90	122
Percussion	CM763	Taiko	87	90	123
Percussion	CM764	Concert BD	87	90	124
Percussion	CM765	Concert BD w	87	90	125
Percussion	CM766	MelodicTom 1	87	90	126
Percussion	CM767	MelodicTom 2	87	90	127
Percussion	CM768	Synth Drum	87	90	128
Percussion	CM769	Synth Drum w	87	91	1
Percussion	CM770	TR-808 Tom	87	91	2
Percussion	CM771	Elec.Perc.	87	91	3
Percussion	CM772	Reverse Cym	87	91	4
Percussion	CM773	Reverse Cym Atk	87	91	5

Symbol	Explanation
PR	Preset
CM	Common
CD	Common Drums