




RD-2000 EX

Sound List

Contents

Tone List	3
CONCERT	3
STUDIO	3
VINTAGE	4
MODERN	4
CLAV	5
ORGAN	6
STRINGS	6
PAD/CHOIR	7
BASS	8
OTHER	9

Program List	14
A	14
B	14
C	14
D	14
E	15
F	15
G	15
H	15
I	16
J	16
K	16
L	16
M	17
N	17
O	17

Rhythm Pattern List	18
----------------------------------	-----------

Rhythm Set List	20
------------------------------	-----------

Tone List

CONCERT

Sub Category	Number	TONE Name		MSB	LSB	PC
CONCERT PIANO	S01	Stage Grand	(*1)	84	16	1
	S02	Deep Concert	(*1)	84	16	2
	S03	Eastcoast Studio	(*1)	84	16	3
	S04	Contemp Concerto	(*1)	84	16	4
	S05	Symphony Hall	(*1)	84	16	5
	S06	Bold Beauty	(*1)	84	16	6
	S07	Aco Grand1	(*1)	84	16	7
	S08	Aco Grand2	(*1)	84	16	8
	S09	Aco Grand3	(*1)	84	16	9
	S10	Aco Grand4	(*1)	84	16	10
	S11	Aco Grand 5	(*1)	84	16	11
	S12	Aco Grand 6	(*1)	84	16	12
	S13	Aco Grand 7	(*1)	84	16	13
	S14	Aco Grand 8	(*1)	84	16	14
	S15	Aco Grand 9	(*1)	84	16	15
	S16	Aco Grand 10	(*1)	84	16	16
	S17	at Stage	(*1)	84	16	17
	SA01	German Concert		84	17	1
	SA02	Bold Grand		84	17	2
	SA03	Calm Focus		84	17	3
	SA04	Open Warm		84	17	4
	SA05	Open Warm 2		84	17	5
	SA06	Studio Pop		84	17	6
	SA07	Studio Rock		84	17	7
	SA08	Ballad Warm		84	17	8
	SA09	Bright & Clear		84	17	9
	SA10	Feelin' Hopping		84	17	10
	SA11	Short Stick		84	17	11
	SA12	Quiet Phrase		84	17	12
	SA13	Bright Baby		84	17	13
	SA14	Deep Open		84	17	14
	SA15	Presence		84	17	15
	SA16	Water Piano		84	17	16
	SA17	Low Lifted Cncrt		84	17	17
	SB01	Recital Upright		84	18	1
	SB02	Pop Studio Pno		84	18	2
	SB03	Gentle Dream		84	18	3
	SB04	Parlor Upright		84	18	4
	SB05	Reso-swell Uprrt		84	18	5
	SB06	Open-Reso		84	18	6
	SB07	Rock Upright		84	18	7
	SB08	Reverie Piano		84	18	8
	SB09	Etude Dreamer		84	18	9
	SB10	Bright Sky Piano		84	18	10
	SB11	Open Aire		84	18	11
	SB12	Faraway Harmony		84	18	12
	SB13	Parlor Pound		84	18	13
	SB14	Resonant Closet		84	18	14
0001	Concert Grand	(*2)	84	0	1	
0002	Bright Concert	(*2)	84	0	2	
0003	Mellow Concert	(*2)	84	0	3	
0004	Rock Concert Grd	(*2)	84	0	4	
0005	Comp ConcertGrd	(*2)	84	0	5	
0006	Concert Grd Mono	(*2)	84	0	6	
0007	NX Concert Grand	(*2)	84	0	7	
0008	Bright NX Concrtr	(*2)	84	0	8	
0009	Mellow NX Concrtr	(*2)	84	0	9	
0010	Rock NX Concert	(*2)	84	0	10	
0011	Comp NX Concert	(*2)	84	0	11	
0012	NX Concert Mono	(*2)	84	0	12	
0013	Brilliant Grand	(*2)	84	0	13	
0014	Hard Brill Grand	(*2)	84	0	14	
0015	Soft Brill Grand	(*2)	84	0	15	
0016	Rock Brill Grand	(*2)	84	0	16	

Sub Category	Number	TONE Name	MSB	LSB	PC	
CONCERT PIANO	0017	Comp Brill Grand	(*2)	84	0	17
	0018	Brill Grand Mono	(*2)	84	0	18
	0019	St.Piano 1		84	0	19
	0020	St.Piano 2		84	0	20
	0021	St.Piano 3		84	0	21
	0022	St.Piano 4		84	0	22
	0023	St.Piano 5		84	0	23
	0024	Piano 1		84	0	24
	0025	Piano 1 w		84	0	25
	0026	European Pf		84	0	26
	0027	Stage Piano		84	0	27

*1 Piano Designer and Indiv.Voicing can be used

*2 Piano Designer, Indiv.Voicing, and Sym.Resonance can be used

STUDIO

Sub Category	Number	TONE Name	MSB	LSB	PC	
STUDIO PIANO	0028	Upright Piano	(*2)	84	0	28
	0029	Bright Upright	(*2)	84	0	29
	0030	Mellow Upright	(*2)	84	0	30
	0031	Rock Upright Pno	(*2)	84	0	31
	0032	Comp Upright Pno	(*2)	84	0	32
	0033	UprightPianoMono	(*2)	84	0	33
	0034	Studio Grand	(*2)	84	0	34
	0035	Bright Studio	(*2)	84	0	35
	0036	Mellow Studio	(*2)	84	0	36
	0037	Rock StudioGrand	(*2)	84	0	37
	0038	Comp Studio Grd	(*2)	84	0	38
	0039	StudioGrand Mono	(*2)	84	0	39
	0040	Piano 2		84	0	40
	0041	Piano 2 w		84	0	41
HONKY-TONK	0042	Honky-tonk Pno 1	(*2)	84	0	42
	0043	Honky-tonk Pno 2	(*2)	84	0	43
	0044	Honky-tonk Pno 3	(*2)	84	0	44
HONKY-TONK	0045	Honky-tonk Pno 4	(*2)	84	0	45
	0046	Honky Tonk		84	0	46
	0047	Honky-tonk		84	0	47
	0048	Honky-tonk w		84	0	48
SA PIANO	0049	SA Piano		84	0	49
	0050	Modulated SA Pno		84	0	50
	0051	Bright SA Piano		84	0	51
	0052	Comp SA Piano		84	0	52
	0053	Phaser SA Piano		84	0	53
	0054	Lo-Fi SA Piano		84	0	54
SYNTH PIANO	0055	JD Piano		84	0	55
	0056	Bright JD Piano		84	0	56
	0057	Rock JD Piano		84	0	57
	0058	Comp JD Piano		84	0	58
	0059	Comp JD Piano2		84	0	59
	0060	Detuned JD Piano		84	0	60
	0061	Chorus JD Piano		84	0	61
	0062	Phaser JD Piano		84	0	62
	0063	Lo-Fi JD Piano		84	0	63
	0064	Brite Piano		84	0	64
	0065	Pop Piano 1		84	0	65
	0066	Pop Piano 2		84	0	66
	0067	Pop Piano 3		84	0	67
	0068	LoFi Piano		84	0	68

*2 Piano Designer, Indiv.Voicing, and Sym.Resonance can be used

VINTAGE

Sub Category	Number	TONE Name		MSB	LSB	PC
TINE E.PIANO	2001	1975 Tine EP.	(*3)	84	8	90
	2002	1979 Tine EP.	(*3)	84	8	91
	2003	1975 Mellow EP	(*3)	84	8	92
	2004	1979 Bright EP	(*3)	84	8	93
	2005	1975 Clarity EP	(*3)	84	8	94
	2006	NYC Chorus EP	(*3)	84	8	95
	2007	1975 Phased EP	(*3)	84	8	96
	2008	1979 Phased EP	(*3)	84	8	97
	2009	1979 Envelope EP	(*3)	84	8	98
	2010	1975 Sweet Echo	(*3)	84	8	99
	2011	1979 Flying Echo	(*3)	84	8	100
	2012	1975 ModDelay EP	(*3)	84	8	101
	2013	1975 Driven EP	(*3)	84	8	102
	2014	1979 Comp EP	(*3)	84	8	103
TINE E.PIANO	0069	Tine E.Piano	(*3)	84	0	69
	0070	Silver Top EP.	(*3)	84	0	70
	0071	Tine EP Mkl.	(*3)	84	0	71
	0072	Tine EP MkII.	(*3)	84	0	72
	0073	Dyno E.Piano.	(*3)	84	0	73
	0074	Small Case Tine	(*3)	84	0	74
	0075	Soft Tine EP	(*3)	84	0	75
	0076	Chorus Tine EP	(*3)	84	0	76
	0077	Chorus Tine EP2	(*3)	84	0	77
	0078	Chorus Dyno EP	(*3)	84	0	78
	0079	Tremolo Cho Tine	(*3)	84	0	79
	0080	Phaser Tine EP	(*3)	84	0	80
	0081	Phaser Dyno EP	(*3)	84	0	81
	0082	Trem Phaser Tine	(*3)	84	0	82
	0083	Trem Phaser Dyno	(*3)	84	0	83
	0084	Rotary Tine EP	(*3)	84	0	84
	0085	TouchWah TineEP	(*3)	84	0	85
	0086	Auto Wah Tine EP	(*3)	84	0	86
TINE E.PIANO	0087	Echo Tine EP	(*3)	84	0	87
	0088	Echo->Trem Tine	(*3)	84	0	88
	0089	Echo->RotaryTine	(*3)	84	0	89
	0090	Comp Tine EP	(*3)	84	0	90
	0091	Comp Tine EP2	(*3)	84	0	91
	0092	Comp Silver Top	(*3)	84	0	92
	0093	Driven Tine EP	(*3)	84	0	93
	0094	Driven SilverTop	(*3)	84	0	94
	0095	Stage EP 1		84	0	95
	0096	Stage EP 2		84	0	96
	0097	Stage EP Trm		84	0	97
	0098	Tremolo EP 1		84	0	98
	0099	E.Piano 3		84	0	99
	0100	E.Piano 4		84	0	100
	0101	E.Piano 5		84	0	101
0102	E.Piano 6		84	0	102	
0103	E.Piano 7		84	0	103	
0104	E.Piano 8		84	0	104	
0105	Dyno EP		84	0	105	
0106	Dyno EP Trm		84	0	106	
0107	Tremolo EP 2		84	0	107	
0108	Back2the60s		84	0	108	
0109	Tine EP		84	0	109	
0110	E.Piano 1		84	0	110	
0111	St.Soft EP		84	0	111	

Sub Category	Number	TONE Name	MSB	LSB	PC
REED E.PIANO	0112	Reed E.Piano (*3)	84	0	112
	0113	Round Reed EP (*3)	84	0	113
	0114	Driven Reed EP (*3)	84	0	114
	0115	Driven Reed EP2 (*3)	84	0	115
	0116	Comp Reed EP (*3)	84	0	116
	0117	Comp Reed EP2 (*3)	84	0	117
	0118	Rotary Reed EP (*3)	84	0	118
	0119	Tremolo Reed EP (*3)	84	0	119
	0120	Chorus Reed EP (*3)	84	0	120
	0121	Phaser Reed EP (*3)	84	0	121
	0122	Echo Reed EP (*3)	84	0	122
	0123	Echo->Trem Reed (*3)	84	0	123
	0124	TouchWah ReedEP (*3)	84	0	124
	0125	AutoWah Reed EP (*3)	84	0	125
	0126	Pnet Tee	84	0	126
	0127	R&B Pnet	84	0	127
REED E.PIANO	0128	Wurly EP	84	0	128
	0129	Wurly EP Trm	84	1	1
	0130	Curly Wurly	84	1	2
E.GRAND	0131	Super Wurly	84	1	3
	0132	Wurly	84	1	4
	0133	E.Grand 1	84	1	5
	0134	E.Grand 2	84	1	6
	0135	E.Grand 3	84	1	7
	0136	Piano 3	84	1	8
	0137	Piano 3 w	84	1	9

*3 Some of the parameters of “**Making Detailed Settings for the E. Piano Tones**” (RD-2000EX Parameter Guide PDF) are shown in the Tone Designer screen.

MODERN

Sub Category	Number	TONE Name	MSB	LSB	PC	
SA E.PIANO	2015	RD-1000 Piano1	84	8	104	
	2016	RD-1000 Piano2	84	8	105	
	2017	RD-1000 Piano3	84	8	106	
	2018	RD-1000 Harpsi	84	8	107	
	2019	RD-1000 Clav	84	8	108	
	2020	RD-1000 Vibra.	84	8	109	
	2021	RD-1000 E.Piano1	84	8	110	
SA E.PIANO	2022	RD-1000 E.Piano2	84	8	111	
	2023	RD-1000 Cho Pno	84	8	112	
	2024	RD-1000 Cho EP1	84	8	113	
	2025	RD-1000 Cho EP2	84	8	114	
	0138	SA E.Piano	(*3)	84	1	10
	0139	SA E.Piano2	(*3)	84	1	11
	0140	SA E.Piano3	(*3)	84	1	12
	0141	SA E.Piano4	(*3)	84	1	13
	0142	SA E.Piano5	(*3)	84	1	14
	0143	SA EP 1		84	1	15
FM E.PIANO	0144	SA EP 2		84	1	16
	0145	Psy EP		84	1	17
	0146	FM E.Piano	(*3)	84	1	18
	0147	Woody FM E.Piano	(*3)	84	1	19
	0148	Bright FM EP	(*3)	84	1	20
	0149	Detuned FM EP	(*3)	84	1	21
	0150	Tremolo FM EP	(*3)	84	1	22
	0151	EP Legend 3		84	1	23
	0152	80's EP		84	1	24
	0153	FM EP 1		84	1	25
0154	FM EP 2		84	1	26	

Sub Category	Number	TONE Name	MSB	LSB	PC
MODERN E.PIANO	0155	Hit EP	84	1	27
	0156	EP Legend 1	84	1	28
	0157	EP Belle	84	1	29
	0158	Sinus EP	84	1	30
	0159	Spirit Tines	84	1	31
	0160	E.Piano 2	84	1	32
	0161	Detuned EP	84	1	33
	0162	St.FM EP	84	1	34
	0163	EP Legend 2	84	1	35
	0164	EP Phase	84	1	36
	0165	Rox Piano 1	84	1	37
	0166	Rox Piano 2	84	1	38
	0167	Crummy Piano	84	1	39
	0168	Rox Lute	84	1	40

*3 Some of the parameters of “**Making Detailed Settings for the E. Piano Tones**” (RD-2000EX Parameter Guide PDF) are shown in the Tone Designer screen.

CLAV

Sub Category	Number	TONE Name	MSB	LSB	PC	
CLAV	0169	Clav CB	(*4)	84	1	41
	0170	Clav CA	(*4)	84	1	42
	0171	Phaser Clav	(*4)	84	1	43
	0172	Phaser Clav2	(*4)	84	1	44
	0173	Touch Wah Clav	(*4)	84	1	45
	0174	Auto Wah Clav	(*4)	84	1	46
	0175	Auto Wah Clav2	(*4)	84	1	47
	0176	Comp Clav	(*4)	84	1	48
	0177	Comp Clav2	(*4)	84	1	49
	0178	Chorus Clav	(*4)	84	1	50
	0179	Chorus Clav2	(*4)	84	1	51
	0180	Chorus Clav3	(*4)	84	1	52
	0181	Driven Clav	(*4)	84	1	53
	0182	Driven Clav2	(*4)	84	1	54
	0183	Clav CB Medium	(*4)	84	1	55
	0184	Clav CA Medium	(*4)	84	1	56
	0185	Clav CB Brillia	(*4)	84	1	57
	0186	Clav CA Brillia	(*4)	84	1	58
	0187	Clav CB Combo	(*4)	84	1	59
	0188	Clav CA Combo	(*4)	84	1	60
	0189	Clav		84	1	61
	0190	Clav 2		84	1	62
CLAV	0191	Pulse Clav		84	1	63
	0192	Pulse Clav 2		84	1	64
	0193	Sweepin Clav		84	1	65
	0194	Analog Clav		84	1	66
	0195	Biting Clav		84	1	67
	0196	Pulse Clv St		84	1	68
HARPSICHORD	0197	Natural Hps.		84	1	69
	0198	Harpsichord		84	1	70
	0199	Harpsichord2		84	1	71
	0200	Coupled Hps		84	1	72
	0201	Harpsi w		84	1	73
	0202	Harpsi o		84	1	74
	0203	Rox Harpsi		84	1	75
	0204	VX Harpsi		84	1	76
CELESTA	0205	Celesta		84	1	77
	0206	Farf Celeste		84	1	78

Sub Category	Number	TONE Name	MSB	LSB	PC
BELL	0207	Music Box	84	1	79
	0208	Music Box 2	84	1	80
	0209	Kalimbells	84	1	81
	0210	D50 Fantasy	84	1	82
	0211	D50 Bell	84	1	83
	0212	Fantasia	84	1	84
	0213	Org Bell	84	1	85
	0214	Dreambell	84	1	86
	0215	FM Sparkles	84	1	87
	0216	FM Syn Bell	84	1	88
	0217	FM Heaven	84	1	89
	0218	Dreaming Bel	84	1	90
	0219	Analog Bell	84	1	91
	0220	Music Bells	84	1	92
BELL	0221	Bell 1	84	1	93
	0222	Bell 2	84	1	94
	0223	Crystal	84	1	95
	0224	Tinkle Bell	84	1	96
	0225	Icy Keys	84	1	97
	0226	TubularBells	84	1	98
	0227	TubularBell2	84	1	99
	0228	Church Bell	84	1	100
	0229	Carillon	84	1	101
	0230	Carillon 2	84	1	102
	0231	Tower Bell	84	1	103
	0232	Bell Ring	84	1	104
MALLET	0233	Vibraphone	84	1	105
	0234	Vibraphone 2	84	1	106
	0235	VibraphoneTr	84	1	107
	0236	Vibraphone w	84	1	108
	0237	Tremolo Vib	84	1	109
	0238	Jazz Vib	84	1	110
	0239	Marimba	84	1	111
	0240	Marimba 2	84	1	112
	0241	Marimba 3	84	1	113
	0242	Marimba w	84	1	114
	0243	BsMarimba 1	84	1	115
	0244	BsMarimba 2	84	1	116
	0245	Xylophone	84	1	117
	0246	Xylophone 2	84	1	118
MALLET	0247	Xylophone 3	84	1	119
	0248	Ethno Keys	84	1	120
	0249	Glockenspiel	84	1	121
	0250	Steel Drums	84	1	122
	0251	Steel Drums2	84	1	123
	0252	Soft StdDrm	84	1	124
	0253	Toy Box	84	1	125
	0254	Sine Mallet	84	1	126

*4 The parameters of “**Making Detailed Settings for the CLAV Tones**” (RD-2000EX Parameter Guide PDF) are shown in the Tone Designer screen.

ORGAN

Sub Category	Number	TONE Name	MSB	LSB	PC
E.ORGAN	0255	TW-Organ 1	84	1	127
	0256	TW-Organ 2	84	1	128
	0257	TW-Organ 3	84	2	1
	0258	TW-Organ 4	84	2	2
	0259	TW-Organ 5	84	2	3
	0260	TW-Organ 6	84	2	4
	0261	TW-Organ 7	84	2	5
	0262	TW-Organ 8	84	2	6
	0263	TW-Organ 9	84	2	7
	0264	TW-Organ 10	84	2	8
	0265	Rock Organ 1	84	2	9
	0266	Rock Organ 2	84	2	10
	0267	Rock Organ 3	84	2	11
	0268	Rock Organ 4	84	2	12
	0269	Rock Organ 5	84	2	13
	0270	RotaryOrgan1	84	2	14
	0271	RotaryOrgan2	84	2	15
	0272	Perc. Organ	84	2	16
	0273	Perc.Organ 2	84	2	17
	0274	Perc.Organ 3	84	2	18
	0275	Perc.Organ 4	84	2	19
	0276	Organ 1	84	2	20
	0277	Trem. Organ	84	2	21
	0278	Organ 2	84	2	22
	0279	Chorus Organ	84	2	23
	0280	Organ 3	84	2	24
	0281	Animal Mod	84	2	25
	0282	Rising Sun	84	2	26
	0283	Surf Monkeys	84	2	27
	0284	Palisades	84	2	28
	0285	Kitchen Soul	84	2	29
	0286	BreakOnThru	84	2	30
	0287	Calif.Sun	84	2	31
	0288	Steppin' VX	84	2	32
	0289	Costello+Mod	84	2	33
	0290	Archie's Mod	84	2	34
	0291	Telstar VX	84	2	35
	0292	The Sham	84	2	36
	0293	Crummy Organ	84	2	37
	0294	VX Religion	84	2	38
	0295	Farfi Combo	84	2	39
	0296	Iron Farf	84	2	40
	0297	Dancin' Queen	84	2	41
	0298	Farf Lite	84	2	42
	0299	Wooly Farfy	84	2	43
	0300	Clark Farf	84	2	44
	0301	Pacemaker	84	2	45
	0302	Rox Organ P	84	2	46
	0303	Rox Organ Ph	84	2	47
	0304	Rox Organ PH	84	2	48
	0305	Rox Organ L	84	2	49
	0306	60's Organ	84	2	50
	0307	70's E.Org 1	84	2	51
	0308	70's E.Org 2	84	2	52

Sub Category	Number	TONE Name	MSB	LSB	PC
E.ORGAN	0309	70's E.Organ	84	2	53
	0310	E.Organ 1	84	2	54
	0311	E.Organ 2	84	2	55
	0312	E.Organ 3	84	2	56
	0313	E.Organ 4	84	2	57
	0314	E.Organ 5	84	2	58
	0315	E.Organ 6	84	2	59
	0316	E.Organ 7	84	2	60
	0317	Theater Org	84	2	61
	0318	Ana Organ 1	84	2	62
	0319	Ana Organ 2	84	2	63
	0320	Ana Organ 3	84	2	64
PIPE ORGAN	0321	Ana Organ 4	84	2	65
	0322	Ana Organ 5	84	2	66
	0323	Puff Organ	84	2	67
PIPE ORGAN	0324	Nason Flute	84	2	68
	0325	Massive Pipe	84	2	69
	0326	Mid Pipe Org	84	2	70
PIPE ORGAN	0327	Grand Pipes	84	2	71
	0328	Church Org 1	84	2	72
	0329	Church Org 2	84	2	73
	0330	Church Org 3	84	2	74
	0331	Reed Organ	84	2	75
ACCORDION	0332	Accordion Fr	84	2	76
	0333	Accordion It	84	2	77
	0334	AccordionIt2	84	2	78
	0335	Musette	84	2	79
	0336	Vodkakordion	84	2	80
HARMONICA	0337	Bandoneon	84	2	81
	0338	Harmonica	84	2	82
	0339	Harmonica 2	84	2	83

STRINGS

Sub Category	Number	TONE Name	MSB	LSB	PC
ENSEMBLE STRINGS	0340	Slow FullStrings	84	2	84
	0341	Full Strings	84	2	85
	0342	GX Strings	84	2	86
	0343	Mood Strings	84	2	87
	0344	Slow Strings	84	2	88
	0345	DecayStrings	84	2	89
	0346	Strings	84	2	90
	0347	Strings 2	84	2	91
	0348	Strings 3	84	2	92
	0349	Strings 4	84	2	93
	0350	Strings 5	84	2	94
	0351	Strings 6	84	2	95
	0352	Stage Str 1	84	2	96
	0353	Stage Str 2	84	2	97
	0354	Pop Str	84	2	98
	0355	Hall Strings	84	2	99
	0356	Marc.Str	84	2	100
	0357	StringsStacc	84	2	101
	0358	Oct Strings	84	2	102
	0359	Tremolo Str	84	2	103
	0360	Tron Strings	84	2	104
	0361	Tron Strings2	84	2	105
	0362	Symphonic Tron	84	2	106
	0363	Moody Tron	84	2	107
	0364	TapeStrings1	84	2	108
	0365	TapeStrings2	84	2	109
ENSEMBLE STRINGS	0366	Hybrid Str	84	2	110
	0367	PizzicatoStr	84	2	111
	0368	Pizz 1	84	2	112
	0369	Pizz 2	84	2	113

Sub Category	Number	TONE Name	MSB	LSB	PC
SOLO STRINGS	0370	Violin	84	2	114
	0371	Violin 2	84	2	115
	0372	Slow Violin	84	2	116
	0373	Bright Vln	84	2	117
	0374	Viola	84	2	118
	0375	Cello	84	2	119
SOLO STRINGS	0376	Bright Vc	84	2	120
	0377	Contrabass	84	2	121
	0378	Fiddle	84	2	122
	0379	Tron Violins	84	2	123
	0380	Tron Cello	84	2	124
ORCHESTRAL	0381	Orchestra	84	2	125
	0382	Orc.Unison 1	84	2	126
	0383	Orc.Unison 2	84	2	127
	0384	Full Orc	84	2	128

PAD/CHOIR

Sub Category	Number	TONE Name	MSB	LSB	PC
SYNTH PAD/STR	0385	Wide Soft Pad	84	3	1
	0386	Silky Way	84	3	2
	0387	CalmChoirPad	84	3	3
	0388	Decay Choir Pad	84	3	4
	0389	Soft Pad 1	84	3	5
	0390	Soft Pad 2	84	3	6
	0391	Soft Pad 3	84	3	7
	0392	Soft Pad 4	84	3	8
	0393	Soft Pad 5	84	3	9
	0394	Soft Pad 6	84	3	10
	0395	Soft Pad 7	84	3	11
	0396	Soft Pad 8	84	3	12
	0397	Soft Pad 9	84	3	13
	0398	Soft Pad 10	84	3	14
	0399	Dreamheaven	84	3	15
	0400	Oct Heaven	84	3	16
	0401	VintageStr 1	84	3	17
	0402	VintageStr 2	84	3	18
	0403	VintageStr 3	84	3	19
	0404	VintageStr 4	84	3	20
	0405	VintageStr 5	84	3	21
	0406	VintageStr 6	84	3	22
	0407	VintageStr 7	84	3	23
	0408	JX Strings	84	3	24
	0409	JP Strings 1	84	3	25
	0410	JP Strings 2	84	3	26
	0411	106 Strings	84	3	27
	0412	Sol Strings	84	3	28
	0413	Rhapsody STR	84	3	29
	0414	PWM Str 1	84	3	30
	0415	PWM Str 2	84	3	31
	0416	PWM Str 3	84	3	32
	0417	Fading Str	84	3	33
	0418	ParadisePad	84	3	34
	0419	80s Strings	84	3	35
	0420	Stringship	84	3	36
	0421	Airy Pad	84	3	37
	0422	Neo RS-202	84	3	38

Sub Category	Number	TONE Name	MSB	LSB	PC
SYNTH PAD/STR	0423	Sawtooth Str	84	3	39
	0424	Syn.Strings1	84	3	40
	0425	Syn.Strings2	84	3	41
	0426	Syn.Strings3	84	3	42
	0427	Pulse Pad	84	3	43
	0428	Hollow Pad 1	84	3	44
	0429	WarmHeaven 1	84	3	45
	0430	WarmHeaven 2	84	3	46
	0431	Heaven Pad 1	84	3	47
	0432	Heaven Pad 2	84	3	48
	0433	Heaven Pad 3	84	3	49
	0434	Heaven Pad 4	84	3	50
	0435	FineWinePad1	84	3	51
	0436	FineWinePad2	84	3	52
	0437	5th Pad 1	84	3	53
	0438	5th Pad 2	84	3	54
	0439	Nu Epic Pad	84	3	55
	0440	Angelis Pad	84	3	56
	0441	TrnsSweepPad	84	3	57
	0442	Giant Sweep	84	3	58
	0443	Voyager	84	3	59
	0444	Digital Pad	84	3	60
	0445	NuSoundtrack	84	3	61
	0446	Xadecimal	84	3	62
	0447	Strobe Pad	84	3	63
	0448	BUBBLE 2	84	3	64
	0449	BUBBLE 3	84	3	65
	0450	Soft PWM Pad	84	3	66
	0451	Org Pad	84	3	67
	0452	Hollow Pad 2	84	3	68
	0453	SavannaPad 1	84	3	69
	0454	SavannaPad 2	84	3	70
	0455	SavannaPad 3	84	3	71
	0456	PWM Pad 2	84	3	72
	0457	Str Machine	84	3	73
	0458	Reso Pad	84	3	74
	0459	BPF Pad	84	3	75
	0460	Sweep Pad	84	3	76
	0461	Sweep Pad 2	84	3	77
	0462	Sweep Pad 3	84	3	78
	0463	Sweep Pad 4	84	3	79
	0464	Scoop Pad 1	84	3	80
	0465	Scoop Pad 2	84	3	81
	0466	Brite Wine	84	3	82
	0467	Wine Pad	84	3	83
	0468	Warm Pad	84	3	84
	0469	Sine Pad	84	3	85
	0470	Bowed Glass	84	3	86
	0471	Metal Pad	84	3	87
	0472	Halo Pad	84	3	88
	0473	Soundtrack	84	3	89
	0474	Star Theme	84	3	90
SYNTH BELLPAD	0475	Air Key 1	84	3	91
	0476	Air Key 2	84	3	92
	0477	Sweet Keys	84	3	93
	0478	Soft Bell	84	3	94
	0479	Stacc Heaven	84	3	95
	0480	DigitalDream	84	3	96
	0481	Analog Dream	84	3	97
	0482	Harp Pad	84	3	98
	0483	Ice Rain	84	3	99
	0484	Atmosphere	84	3	100
SYNTH BELLPAD	0485	Brightness	84	3	101
	0486	Dreaming Box	84	3	102

Tone List

Sub Category	Number	TONE Name	MSB	LSB	PC
VOX CHOIR	0487	Large Choir	84	3	103
	0488	GX Choir	84	3	104
	0489	Choir Aahs	84	3	105
	0490	Chorus Aahs	84	3	106
	0491	Choir Pad	84	3	107
	0492	Angels Choir	84	3	108
	0493	Aerial Choir	84	3	109
	0494	Voice Oohs	84	3	110
	0495	Doo Pad	84	3	111
	0496	Humming	84	3	112
	0497	Humming 2	84	3	113
	0498	Humming 3	84	3	114
	0499	Gospel Hum	84	3	115
	0500	Decay Choir	84	3	116
	0501	Vox Pad 1	84	3	117
	0502	Vox Pad 2	84	3	118
	0503	Dreamvox 1	84	3	119
	0504	Dreamvox 2	84	3	120
	0505	80s Vox	84	3	121
	0506	SynVox	84	3	122
	0507	SynVox 2	84	3	123
	0508	SynVox 3	84	3	124
	0509	Mini Vox	84	3	125
	0510	Chipmunk	84	3	126
	0511	Sample Opera	84	3	127
	0512	Sad Ceremony	84	3	128
	0513	5th Voice	84	4	1
	0514	Sop Vox	84	4	2
	0515	Analog Voice	84	4	3
	0516	Space Voice	84	4	4
	0517	Itopia	84	4	5
	0518	Tron Choir	84	4	6
	0519	Tron Vox	84	4	7
SCAT	0520	Jazz Scat 1	84	4	8
	0521	Jazz Scat 2	84	4	9

BASS

Sub Category	Number	TONE Name	MSB	LSB	PC
AC.BASS	0522	Acoustic Bs	84	4	10
	0523	Acoustic Bs2	84	4	11
	0524	Acoustic Bs3	84	4	12
	0525	String Slap	84	4	13
E.BASS	0526	Fingered Bs	84	4	14
	0527	Fingered Bs2	84	4	15
	0528	Fingered Bs3	84	4	16
	0529	Fingered Bs4	84	4	17
E.BASS	0530	Pick Bass	84	4	18
	0531	Picked Bass	84	4	19
	0532	Fretless Bs	84	4	20
	0533	FretlessBs 2	84	4	21
	0534	FretlessBs 3	84	4	22
	0535	Finger Slap	84	4	23
	0536	Finger Slap2	84	4	24
	0537	Slap Bass 1	84	4	25
	0538	Slap Bass 2	84	4	26
	0539	Return2Base!	84	4	27

Sub Category	Number	TONE Name	MSB	LSB	PC
SYNTH BASS	0540	MG Bass 1	84	4	28
	0541	MG Bass 2	84	4	29
	0542	MG Bass 3	84	4	30
	0543	Modular Bs 1	84	4	31
	0544	Modular Bs 2	84	4	32
	0545	PWM Bass 1	84	4	33
	0546	PWM Bass 2	84	4	34
	0547	Big Mini	84	4	35
	0548	Fat Analog	84	4	36
	0549	Spike Bass	84	4	37
	0550	SH Bass	84	4	38
	0551	Intrusive Bs	84	4	39
	0552	Synth Bass 1	84	4	40
	0553	Synth Bass 2	84	4	41
	0554	Synth Bass 3	84	4	42
	0555	Synth Bass 4	84	4	43
	0556	Synth Bass 5	84	4	44
	0557	Synth Bass 6	84	4	45
	0558	Synth Bass 7	84	4	46
	0559	Synth Bass 8	84	4	47
	0560	Synth Bass 9	84	4	48
	0561	Synth Bass10	84	4	49
	0562	Synth Bass11	84	4	50
	0563	Synth Bass12	84	4	51
	0564	Synth Bass13	84	4	52
	0565	Synth Bass14	84	4	53
	0566	Reso Bass 1	84	4	54
	0567	Reso Bass 2	84	4	55
	0568	Reso Bass 3	84	4	56
	0569	Reso Bass 4	84	4	57
	0570	Reso Bass 5	84	4	58
	0571	Reso Bass 6	84	4	59
	0572	Reso Bass 7	84	4	60
	0573	Reso Bass 8	84	4	61
	0574	Reso Bass 9	84	4	62
	0575	Reso Bass 10	84	4	63
	0576	Acid Bass	84	4	64
	0577	Acid Bass 2	84	4	65
	0578	Acid Bass 3	84	4	66
	0579	Acid Bass 4	84	4	67
	0580	Acid Bass 5	84	4	68
	0581	Acid Bass 6	84	4	69
	0582	Acid Bass 7	84	4	70
	0583	TB Bass 1	84	4	71
	0584	TB Bass 2	84	4	72
	0585	TB Bass 3	84	4	73
	0586	TB Bass 4	84	4	74
	0587	Alpha Bass 1	84	4	75
	0588	Alpha Bass 2	84	4	76
	0589	Alpha ResoBs	84	4	77
	0590	Nu Saw Bass	84	4	78
	0591	Nu RnB SawBs	84	4	79
	0592	Storm Bass	84	4	80
	0593	Detune Bass	84	4	81
	0594	Gashed Bass	84	4	82
	0595	Hi-Energy Bs	84	4	83
	0596	Pedal Bass 1	84	4	84
	0597	Pedal Bass 2	84	4	85
	0598	Monster Bass	84	4	86
	0599	JunoSqr Bs 1	84	4	87
	0600	JunoSqr Bs 2	84	4	88

Sub Category	Number	TONE Name	MSB	LSB	PC
SYNTH BASS	0601	101 Bass	84	4	89
	0602	106 Bass 1	84	4	90
	0603	106 Bass 2	84	4	91
	0604	Compu Bass 1	84	4	92
	0605	Compu Bass 2	84	4	93
	0606	Triangle Bs	84	4	94
	0607	Muffled Bass	84	4	95
	0608	Garage Bass	84	4	96
	0609	TransistorBs	84	4	97
	0610	Fazee Bass	84	4	98
	0611	Brite Bass	84	4	99
	0612	Saw Bass	84	4	100
	0613	Sub Bass	84	4	101
	0614	Ramp Bass	84	4	102
	0615	Fat Bass 1	84	4	103
	0616	Fat Bass 2	84	4	104
	0617	Fat Bass 3	84	4	105
	0618	Flat Bass	84	4	106
	0619	Electro Rubb	84	4	107
	0620	80s Bass	84	4	108
	0621	SynthBass101	84	4	109
	0622	Clav Bass	84	4	110
	0623	Hammer Bass	84	4	111
	0624	SynSlap Bass	84	4	112
	0625	Rubber Bass	84	4	113
	0626	Attack Pulse	84	4	114
AC.GUITAR	0627	Nylon Gtr 1	84	4	115
	0628	Nylon Gtr 2	84	4	116
	0629	Nylon Gtr 3	84	4	117
	0630	Nylon Gtr 4	84	4	118
	0631	Nylon Gtr 5	84	4	119
	0632	Nylon Gtr 6	84	4	120
	0633	Wet Nyln Gtr	84	4	121
	0634	Folk Gtr 1	84	4	122
	0635	Folk Gtr 2	84	4	123
	0636	Folk Gtr 3	84	4	124
AC.GUITAR	0637	Latin Gtr	84	4	125
	0638	Ukulele	84	4	126
	0639	Ukulele 2	84	4	127
	0640	Nylon Gtr 1o	84	4	128
	0641	Steel-str.Gt	84	5	1
	0642	12-str. Gtr	84	5	2
	0643	Steel + Body	84	5	3
	0644	Gt FretNoise	84	5	4
E.GUITAR	0645	Clean Gtr 1	84	5	5
	0646	Clean Gtr 2	84	5	6
	0647	Clean Gtr 3	84	5	7
	0648	Jazz Guitar	84	5	8
	0649	Jazz Guitar2	84	5	9
	0650	Pick E.Gtr	84	5	10
	0651	Funk Guitar	84	5	11
	0652	Funk Guitar2	84	5	12
	0653	Wet E.Gtr	84	5	13
	0654	Pedal Steel	84	5	14
	0655	Pedal Steel2	84	5	15
	0656	Clean Guitar	84	5	16
	0657	Chorus Gtr	84	5	17
	0658	Mid Tone Gtr	84	5	18
	0659	Muted Guitar	84	5	19
	0660	Funk Pop	84	5	20
E.GUITAR	0661	Jazz Man	84	5	21
	0662	Gt Cut Noise	84	5	22

Sub Category	Number	TONE Name	MSB	LSB	PC
DIST GUITAR	0663	Overdrive Gt	84	5	23
	0664	OverdriveGt2	84	5	24
	0665	Guitar Pinch	84	5	25
	0666	Dist Gtr 1	84	5	26
	0667	Dist Gtr 2	84	5	27
	0668	Dist Gtr 3	84	5	28
	0669	DistortionGt	84	5	29
	0670	Gt Feedback1	84	5	30
	0671	Dist Rtm Gtr	84	5	31
	0672	Gt Harmonics	84	5	32
	0673	Gt Feedback2	84	5	33
PLUCKED STROKE	0674	Kalimba	84	5	34
	0675	Harp	84	5	35
	0676	Yang Qin	84	5	36
	0677	Sitar Pad	84	5	37
	0678	Mandolin	84	5	38
	0679	Sitar 1	84	5	39
	0680	Sitar 2	84	5	40
	0681	Sitar 3	84	5	41
	0682	Banjo	84	5	42
	0683	Shamisen	84	5	43
	0684	Koto	84	5	44
	0685	Taisho Koto	84	5	45
	0686	Aerial Harp	84	5	46
	0687	LostParadise	84	5	47
	0688	Indian FrtlS	84	5	48
	0689	Santur	84	5	49
	0690	Santur 2	84	5	50
	0691	Santur 3	84	5	51

OTHER

Sub Category	Number	TONE Name	MSB	LSB	PC
ENSEMBLE BRASS	0692	Brass 1	84	5	52
	0693	Brass 2	84	5	53
	0694	Brass 3	84	5	54
	0695	Brass 4	84	5	55
	0696	Brass 5	84	5	56
	0697	Brass 6	84	5	57
	0698	F.Horn Sect	84	5	58
SOLO BRASS	0699	Trumpet	84	5	59
	0700	Trumpet 2	84	5	60
	0701	Dark Trumpet	84	5	61
	0702	MuteTrumpet1	84	5	62
	0703	MuteTrumpet2	84	5	63
	0704	Trombone 1	84	5	64
	0705	Trombone 2	84	5	65
	0706	Bright Tb	84	5	66
	0707	Tuba	84	5	67
	0708	Fr.Horn	84	5	68
WOODWINDS	0709	French Horn	84	5	69
	0710	Oboe	84	5	70
	0711	English Horn	84	5	71
	0712	Bassoon	84	5	72
	0713	Bassoon 2	84	5	73
	0714	Clarinet	84	5	74
	0715	Bagpipe	84	5	75
	0716	Shanai	84	5	76

Tone List

Sub Category	Number	TONE Name	MSB	LSB	PC
FLUTE	0717	Piccolo	84	5	77
	0718	Flute	84	5	78
	0719	Flute 2	84	5	79
	0720	Strawberry Flute	84	5	80
	0721	Pan Flute	84	5	81
	0722	Pan Flute 2	84	5	82
	0723	Pan Pipes 1	84	5	83
	0724	Pan Pipes 2	84	5	84
	0725	Bottle Blow	84	5	85
	0726	Shakuhachi	84	5	86
	0727	Shakuhachi 2	84	5	87
	0728	Breath Noise	84	5	88
	0729	Fl.Key Click	84	5	89
SAX	0730	Soprano Sax	84	5	90
	0731	Soprano Sax2	84	5	91
	0732	Alto Sax	84	5	92
	0733	Tenor Sax	84	5	93
	0734	Tenor Sax 2	84	5	94
	0735	BreathyTenor	84	5	95
RECORDER	0736	Baritone Sax	84	5	96
	0737	Recorder	84	5	97
	0738	Whistle	84	5	98
	0739	Ocarina	84	5	99
SYNTH LEAD	0740	Ocarina 2	84	5	100
	0741	Juno SQR	84	5	101
	0742	Saw Lead 1	84	5	102
	0743	Saw Lead 2	84	5	103
	0744	Saw Lead 3	84	5	104
	0745	Saw Lead 4	84	5	105
	0746	Saw Lead 5	84	5	106
	0747	Saw Lead 6	84	5	107
	0748	Saw Lead 7	84	5	108
	0749	Saw Lead 8	84	5	109
	0750	Saw Lead 9	84	5	110
	0751	Saw Lead 10	84	5	111
	0752	GR300 Lead 1	84	5	112
	0753	GR300 Lead 2	84	5	113
	0754	Classic GR	84	5	114
	0755	Bright GR	84	5	115
	0756	Fat GR Lead	84	5	116
	0757	MODified Ld	84	5	117
	0758	Syn Lead 1	84	5	118
	0759	Syn Lead 2	84	5	119
	0760	Syn Lead 3	84	5	120
	0761	Syn Lead 4	84	5	121
	0762	Syn Lead 5	84	5	122
	0763	Syn Lead 6	84	5	123
	0764	Syn Lead 7	84	5	124
	0765	Pro Fat Ld 1	84	5	125
	0766	Pro Fat Ld 2	84	5	126
	0767	JupiterLead1	84	5	127
	0768	JupiterLead2	84	5	128
	0769	Porta Lead	84	6	1
	0770	Classic Lead	84	6	2
	0771	On Air	84	6	3
	0772	Wormy Lead	84	6	4
	0773	Waspy Lead	84	6	5
	0774	Brite ResoLd	84	6	6
	0775	Brass Lead	84	6	7
	0776	Legato Tkno	84	6	8
	0777	Follow Me	84	6	9

Sub Category	Number	TONE Name	MSB	LSB	PC
SYNTH LEAD	0778	Octa Juice	84	6	10
	0779	Juicy Jupe	84	6	11
	0780	Octa Saw	84	6	12
	0781	Vintager 1	84	6	13
	0782	Vintager 2	84	6	14
	0783	Sync Lead	84	6	15
	0784	Octa Sync	84	6	16
	0785	Leading Sync	84	6	17
	0786	A Leader	84	6	18
	0787	Hot Coffee	84	6	19
	0788	Hot Sync	84	6	20
	0789	Synchro Lead	84	6	21
	0790	Space Solo	84	6	22
	0791	Squareheads	84	6	23
	0792	Mod Lead	84	6	24
	0793	Alpha Spit	84	6	25
	0794	Air Lead	84	6	26
	0795	Pulstar Lead	84	6	27
	0796	Therasaw	84	6	28
	0797	Warmy Lead	84	6	29
	0798	ResoSawLead	84	6	30
	0799	Soft Reso Ld	84	6	31
	0800	Reso Lead 1	84	6	32
	0801	Reso Lead 2	84	6	33
	0802	Reso Lead 3	84	6	34
	0803	Reso Lead 4	84	6	35
	0804	Reso Lead 5	84	6	36
	0805	Juicy Lead	84	6	37
	0806	DC Triangle	84	6	38
	0807	Soft Lead 1	84	6	39
	0808	Soft Lead 2	84	6	40
	0809	Soft Lead 3	84	6	41
	0810	Soft Lead 4	84	6	42
	0811	Soft Lead 5	84	6	43
	0812	Soft Lead 6	84	6	44
	0813	Soft Lead 7	84	6	45
	0814	Soft Lead 8	84	6	46
	0815	Soft Lead 9	84	6	47
	0816	Soft Lead 10	84	6	48
	0817	Tri Lead	84	6	49
	0818	Pulse Lead 1	84	6	50
	0819	Pulse Lead 2	84	6	51
	0820	Pulse Lead 3	84	6	52
	0821	Pulse Lead 4	84	6	53
	0822	Simple Tri	84	6	54
	0823	Simple Sine	84	6	55
	0824	Whistle Ld 1	84	6	56
	0825	Whistle Ld 2	84	6	57
	0826	Square Pipe	84	6	58
	0827	CosmicDrops1	84	6	59
	0828	Spooky Lead	84	6	60
	0829	Pure Lead	84	6	61
	0830	303 NRG	84	6	62
	0831	Round SQR	84	6	63
	0832	Brite SQR	84	6	64
	0833	Square SAW	84	6	65
	0834	Simple SQR	84	6	66
	0835	Sqr Lead	84	6	67
	0836	Atk Lead	84	6	68
	0837	Octa Square	84	6	69
	0838	CS Lead	84	6	70

Sub Category	Number	TONE Name	MSB	LSB	PC
SYNTH LEAD	0839	Mini Growl	84	6	71
	0840	Hoover Again	84	6	72
	0841	Tranceformer	84	6	73
	0842	Ramp Lead 1	84	6	74
	0843	Ramp Lead 2	84	6	75
	0844	Sine Lead 1	84	6	76
	0845	Sine Lead 2	84	6	77
	0846	Dance Saws 1	84	6	78
	0847	Resoform	84	6	79
	0848	Dance Saws 2	84	6	80
	0849	Square Wave	84	6	81
	0850	MG Square	84	6	82
	0851	2600 Sine	84	6	83
	0852	Saw Wave	84	6	84
	0853	OB2 Saw	84	6	85
	0854	Doctor Solo	84	6	86
	0855	Natural Lead	84	6	87
	0856	Syn.Calliope	84	6	88
	0857	Chiffer Lead	84	6	89
	0858	Charang	84	6	90
	0859	Wire Lead	84	6	91
	0860	Solo Vox	84	6	92
	0861	5th Saw Wave	84	6	93
	0862	Bass & Lead	84	6	94
	0863	Delayed Lead	84	6	95
SYNTH BRASS	0864	80s Brass 1	84	6	96
	0865	80s Brass 2	84	6	97
	0866	80s Brass 3	84	6	98
	0867	80s Brass 4	84	6	99
	0868	80s Brass 5	84	6	100
	0869	80s Brass 6	84	6	101
	0870	80s Brass 7	84	6	102
	0871	80s Brass 8	84	6	103
	0872	Soft SynBrs1	84	6	104
	0873	Soft SynBrs2	84	6	105
	0874	Warm SynBrs	84	6	106
	0875	Brite SynBrs	84	6	107
	0876	Express Brs	84	6	108
	0877	EuroExpress1	84	6	109
	0878	JP Brass 1	84	6	110
	0879	JP Brass 2	84	6	111
	0880	Juno Brass	84	6	112
	0881	Ox Brass	84	6	113
	0882	Reso Brass	84	6	114
	0883	Wide SynBrs	84	6	115
	0884	106 Brass	84	6	116
	0885	Octa Brass	84	6	117
	0886	Poly Brass 1	84	6	118
	0887	Poly Brass 2	84	6	119
	0888	Dual Saw Brs	84	6	120
	0889	Jump Poly	84	6	121
	0890	Reso Key 1	84	6	122
	0891	EuroExpress2	84	6	123
	0892	Ox Synth	84	6	124
	0893	VintageBrs 1	84	6	125
	0894	VintageBrs 2	84	6	126
	0895	VintageBrs 3	84	6	127
	0896	VintageBrs 4	84	6	128
	0897	JP Brass	84	7	1
	0898	Oct SynBrass	84	7	2
	0899	Jump Brass	84	7	3
SYNTH BRASS	0900	Synth Brass1	84	7	4
	0901	Synth Brass2	84	7	5
	0902	SynBrass sfz	84	7	6
	0903	Velo Brass	84	7	7
SYNTH POLY KEY	0904	Syn Mallet	84	7	8
	0905	Heaven Key	84	7	9

Sub Category	Number	TONE Name	MSB	LSB	PC
SYNTH POLY KEY	0906	PWM Pad 1	84	7	10
	0907	Poly Synth	84	7	11
	0908	Dream Trance	84	7	12
	0909	Dream Saws	84	7	13
	0910	Dream Pulse	84	7	14
	0911	Trance Synth	84	7	15
	0912	Trancy	84	7	16
	0913	Trance Keys	84	7	17
	0914	Trance Saws	84	7	18
	0915	Auto Trance1	84	7	19
	0916	Super Saws 1	84	7	20
	0917	Analog Saws	84	7	21
	0918	Uni-G	84	7	22
	0919	Digitalless	84	7	23
	0920	Bustranza	84	7	24
	0921	Super Saws 2	84	7	25
	0922	Poly Synth 2	84	7	26
	0923	Poly Synth 3	84	7	27
	0924	Poly Synth 4	84	7	28
	0925	Poly Synth 5	84	7	29
	0926	Poly Synth 6	84	7	30
	0927	Poly Synth 7	84	7	31
	0928	Juno Saw Key	84	7	32
	0929	Saw Key 1	84	7	33
	0930	Saw Key 2	84	7	34
	0931	Waspy Synth	84	7	35
	0932	Vintage Key	84	7	36
	0933	Ju-D Fifts	84	7	37
	0934	Reso Key 2	84	7	38
	0935	Fat Synth	84	7	39
	0936	DOC Stack	84	7	40
	0937	2 Saws	84	7	41
	0938	Hi Saw Band	84	7	42
	0939	Brite Synth	84	7	43
	0940	RAVtune	84	7	44
	0941	Pipe Key	84	7	45
	0942	Shroomy	84	7	46
	0943	AnalogDays 1	84	7	47
	0944	Sync Key	84	7	48
	0945	Detune Ramp	84	7	49
	0946	Reso Saw	84	7	50
	0947	EuroExpress3	84	7	51
	0948	Sweep Saw	84	7	52
SYNTH FX	0949	Shimmer Pad	84	7	53
	0950	BUBBLE 1	84	7	54
	0951	CosmicDrops2	84	7	55
	0952	Enigmatic	84	7	56
	0953	Planetz	84	7	57
	0954	Sci-Fi	84	7	58
	0955	ResoSweep Dn	84	7	59
	0956	Jet Noise	84	7	60
	0957	Brandish	84	7	61
	0958	909 Fx	84	7	62
	0959	Zap	84	7	63
	0960	PolySweep Nz	84	7	64

Tone List

Sub Category	Number	TONE Name	MSB	LSB	PC
SYNTH FX	0961	Passing By	84	7	65
	0962	Lazer Points	84	7	66
	0963	Crystal Fx	84	7	67
	0964	Crystal Ice	84	7	68
	0965	Mad Noise	84	7	69
	0966	Robot Sci-Fi	84	7	70
	0967	Computer 1	84	7	71
	0968	Computer 2	84	7	72
	0969	S&H Noise	84	7	73
	0970	S&H Ramp	84	7	74
	0971	S&H PWM	84	7	75
	0972	S&H Saw 1	84	7	76
	0973	S&H Saw 2	84	7	77
	0974	Electrostar	84	7	78
	0975	Alpha Said	84	7	79
	0976	FX Ramp	84	7	80
	0977	Goblin	84	7	81
SYNTH SEQ PAD	0978	Echo Drops	84	7	82
	0979	Echo Bell	84	7	83
	0980	Analog Seq	84	7	84
	0981	Seq Pop	84	7	85
	0982	Periscope	84	7	86
	0983	Major 7	84	7	87
	0984	Juno-D Maj7	84	7	88
	0985	Sweet House	84	7	89
	0986	Detune Saws	84	7	90
	0987	Melodic Drum	84	7	91
PULSATING	0988	Detune Seq	84	7	92
	0989	SequencedSaw	84	7	93
	0990	Echo Pan	84	7	94
	0991	PanninFormnt	84	7	95
	0992	Fairy's Song	84	7	96
	0993	Atmospherics	84	7	97
	0994	StrobeBell 1	84	7	98
	0995	StrobeBell 2	84	7	99
	0996	Flying Pad 1	84	7	100
	0997	Flying Pad 2	84	7	101
	0998	Flying Pad 3	84	7	102
	0999	Flying Pad 4	84	7	103
	1000	Flying Pad 5	84	7	104
	1001	Sine Magic	84	7	105
	1002	Pulsatron	84	7	106
	1003	Motion Bass	84	7	107
	1004	Trance Splt	84	7	108
	1005	Rhythmic 5th	84	7	109
	1006	Rhythmic 1	84	7	110
	1007	Rhythmic 2	84	7	111
	1008	Mega Sync 1	84	7	112
	1009	StrobeBell 3	84	7	113
	1010	Strobe 1	84	7	114
	1011	Strobe 2	84	7	115
	1012	Strobe 3	84	7	116
	1013	Strobe 4	84	7	117
	1014	LFO Saw	84	7	118
	1015	Keep Going	84	7	119
	1016	Keep Running	84	7	120
	1017	Electrons	84	7	121
	1018	BriskVortex	84	7	122
	1019	LFO Vox	84	7	123
	1020	Pulsasaw	84	7	124
PULSATING	1021	Arposphere	84	7	125
	1022	Mega Sync 2	84	7	126

Sub Category	Number	TONE Name	MSB	LSB	PC
BEAT GROOVE	1023	Compusonic 1	84	7	127
	1024	Compusonic 2	84	7	128
	1025	Compusonic 3	84	8	1
	1026	Compusonic 4	84	8	2
	1027	Compusonic 5	84	8	3
	1028	AnalogDays 2	84	8	4
	1029	Groove 007	84	8	5
	1030	Juno Pop	84	8	6
	1031	Auto Trance2	84	8	7
	1032	In Da Groove	84	8	8
HIT	1033	80s Beat	84	8	9
	1034	Cheezy Movie	84	8	10
	1035	Mod Chord	84	8	11
	1036	Housechord	84	8	12
	1037	OrchestraHit	84	8	13
	1038	Bass Hit	84	8	14
	1039	6th Hit	84	8	15
	1040	Euro Hit	84	8	16
SOUND FX	1041	Seashore	84	8	17
	1042	Rain	84	8	18
	1043	Thunder	84	8	19
	1044	Wind	84	8	20
	1045	Stream	84	8	21
	1046	Bubble	84	8	22
	1047	Bird 1	84	8	23
	1048	Dog	84	8	24
	1049	Horse Gallop	84	8	25
	1050	Bird 2	84	8	26
	1051	Telephone 1	84	8	27
	1052	Telephone 2	84	8	28
	1053	DoorCreaking	84	8	29
	1054	Door	84	8	30
	1055	Scratch	84	8	31
	1056	Scratch 2	84	8	32
	1057	Wind Chimes	84	8	33
SOUND FX	1058	Helicopter	84	8	34
	1059	Car Engine	84	8	35
	1060	Car Stop	84	8	36
	1061	Car Pass	84	8	37
	1062	Car Crash	84	8	38
	1063	Siren	84	8	39
	1064	Train	84	8	40
	1065	Jetplane	84	8	41
	1066	Starship	84	8	42
	1067	Burst Noise	84	8	43
	1068	Applause	84	8	44
	1069	Laughing	84	8	45
	1070	Screaming	84	8	46
	1071	Punch	84	8	47
	1072	Heart Beat	84	8	48
	1073	Footsteps	84	8	49
	1074	Gun Shot	84	8	50
	1075	Machine Gun	84	8	51
	1076	Laser Gun	84	8	52
	1077	Explosion	84	8	53
	1078	GM2 SFX	84	8	54

Sub Category	Number	TONE Name	MSB	LSB	PC
PERCUSSION	1079	Timpani	84	8	55
	1080	Ride Cymbal	84	8	56
	1081	Castanets	84	8	57
	1082	Taiko	84	8	58
	1083	Concert BD	84	8	59
	1084	Melo. Tom 1	84	8	60
	1085	Melo. Tom 2	84	8	61
	1086	Synth Drum	84	8	62
	1087	808 Tom	84	8	63
	1088	Elec Perc	84	8	64
	1089	Reverse Cymb	84	8	65
DRUMS	1090	Agogo	84	8	66
	1091	Woodblock	84	8	67
	1092	Standard 1	84	8	68
	1093	Standard 2	84	8	69
	1094	Standard 3	84	8	70
	1095	Rock Kit	84	8	71
	1096	Jazz Kit	84	8	72
	1097	Brush Kit	84	8	73
	1098	Machine Kit	84	8	74
	1099	R&B T-Analog	84	8	75
	1100	R&B Mini Kit	84	8	76
	1101	HipHop Kit	84	8	77
	1102	R&B Kit	84	8	78
	1103	Dance Kit 1	84	8	79
	1104	Dance Kit 2	84	8	80
	1105	Dance Kit 3	84	8	81
	1106	GM2 STANDARD	84	8	82
	1107	GM2 ROOM	84	8	83
	1108	GM2 POWER	84	8	84
	1109	GM2 ELECTRIC	84	8	85
	1110	GM2 ANALOG	84	8	86
	1111	GM2 JAZZ	84	8	87
	1112	GM2 BRUSH	84	8	88
	1113	GM2 ORCHSTRA	84	8	89

Program List

A

Bank-Num	PROGRAM Name	MSB	LSB	PC
A-01	Solo Jazz Grand	84	64	1
A-02	Honest EP Trem	84	64	2
A-03	FC1 Cry Wah Clav	84	64	3
A-04	Piano + ChoirPad	84	64	4
A-05	Tine EP Menu	84	64	5
A-06	1979 Envelope EP	84	64	6
A-07	1975 Flanger EP	84	64	7
A-08	Studio A Grand	84	64	8
A-09	Phaser Bright EP	84	64	9
A-10	1975 EP Burner	84	64	10
A-11	1975 Soul Ballad	84	64	11
A-12	INITIAL PROGRAM	84	64	12
A-13	INITIAL PROGRAM	84	64	13
A-14	INITIAL PROGRAM	84	64	14
A-15	INITIAL PROGRAM	84	64	15
A-16	INITIAL PROGRAM	84	64	16
A-17	INITIAL PROGRAM	84	64	17
A-18	INITIAL PROGRAM	84	64	18
A-19	INITIAL PROGRAM	84	64	19
A-20	INITIAL PROGRAM	84	64	20

B

Bank-Num	PROGRAM Name	MSB	LSB	PC
B-01	1975 Phased EP	84	64	21
B-02	1979 Sp Echo EP	84	64	22
B-03	Resonant Grand	84	64	23
B-04	1975 M-Phaser EP	84	64	24
B-05	1975 UNI-V EP	84	64	25
B-06	Norwegian Grand	84	64	26
B-07	SR Tine 1979	84	64	27
B-08	SR Tine 1975	84	64	28
B-09	DEMO Stage Grand	84	64	29
B-10	DEMO 1975 Tine	84	64	30
B-11	DEMO 1979 Tine	84	64	31
B-12	INITIAL PROGRAM	84	64	32
B-13	INITIAL PROGRAM	84	64	33
B-14	INITIAL PROGRAM	84	64	34
B-15	INITIAL PROGRAM	84	64	35
B-16	INITIAL PROGRAM	84	64	36
B-17	INITIAL PROGRAM	84	64	37
B-18	INITIAL PROGRAM	84	64	38
B-19	INITIAL PROGRAM	84	64	39
B-20	INITIAL PROGRAM	84	64	40

C

Bank-Num	PROGRAM Name	MSB	LSB	PC
C-01	Piano + Strings	84	64	41
C-02	MFX Tine EP Menu	84	64	42
C-03	Funky Keys Split	84	64	43
C-04	Nice SA E.Piano	84	64	44
C-05	an old Friend...	84	64	45
C-06	Piano + FM EP	84	64	46
C-07	R&B Tine EP Set	84	64	47
C-08	Bs+Ride / Grand	84	64	48
C-09	INITIAL PROGRAM	84	64	49
C-10	INITIAL PROGRAM	84	64	50
C-11	INITIAL PROGRAM	84	64	51
C-12	INITIAL PROGRAM	84	64	52
C-13	INITIAL PROGRAM	84	64	53
C-14	INITIAL PROGRAM	84	64	54
C-15	INITIAL PROGRAM	84	64	55
C-16	INITIAL PROGRAM	84	64	56
C-17	INITIAL PROGRAM	84	64	57
C-18	INITIAL PROGRAM	84	64	58
C-19	INITIAL PROGRAM	84	64	59
C-20	INITIAL PROGRAM	84	64	60

D

Bank-Num	PROGRAM Name	MSB	LSB	PC
D-01	Isn't she ...?	84	64	61
D-02	SlapBs/TWahClav	84	64	62
D-03	Maze of Love	84	64	63
D-04	Silver Top Menu	84	64	64
D-05	1978 ElectricPNO	84	64	65
D-06	StarDust Fantasy	84	64	66
D-07	RvrsPno & Pad	84	64	67
D-08	Telephone Piano	84	64	68
D-09	INITIAL PROGRAM	84	64	69
D-10	INITIAL PROGRAM	84	64	70
D-11	INITIAL PROGRAM	84	64	71
D-12	INITIAL PROGRAM	84	64	72
D-13	INITIAL PROGRAM	84	64	73
D-14	INITIAL PROGRAM	84	64	74
D-15	INITIAL PROGRAM	84	64	75
D-16	INITIAL PROGRAM	84	64	76
D-17	INITIAL PROGRAM	84	64	77
D-18	INITIAL PROGRAM	84	64	78
D-19	INITIAL PROGRAM	84	64	79
D-20	INITIAL PROGRAM	84	64	80

E

Bank-Num	PROGRAM Name	MSB	LSB	PC
E-01	Small Jazz Club	84	64	81
E-02	Rock Organ	84	64	82
E-03	R&B Ballad	84	64	83
E-04	Dyno EP Menu	84	64	84
E-05	Healing Piano	84	64	85
E-06	E.Bass /OrganFst	84	64	86
E-07	CmpPno/AnalogStr	84	64	87
E-08	DEMO Concert Grd	84	64	88
E-09	INITIAL PROGRAM	84	64	89
E-10	INITIAL PROGRAM	84	64	90
E-11	INITIAL PROGRAM	84	64	91
E-12	INITIAL PROGRAM	84	64	92
E-13	INITIAL PROGRAM	84	64	93
E-14	INITIAL PROGRAM	84	64	94
E-15	INITIAL PROGRAM	84	64	95
E-16	INITIAL PROGRAM	84	64	96
E-17	INITIAL PROGRAM	84	64	97
E-18	INITIAL PROGRAM	84	64	98
E-19	INITIAL PROGRAM	84	64	99
E-20	INITIAL PROGRAM	84	64	100

F

Bank-Num	PROGRAM Name	MSB	LSB	PC
F-01	Dist L-Org	84	64	101
F-02	Rox Collection	84	64	102
F-03	Wafting Piano	84	64	103
F-04	Garbage EP	84	64	104
F-05	Dream Keys	84	64	105
F-06	E.Bass /OrganSlv	84	64	106
F-07	SuperLight Piano	84	64	107
F-08	DEMO Tine EP	84	64	108
F-09	INITIAL PROGRAM	84	64	109
F-10	INITIAL PROGRAM	84	64	110
F-11	INITIAL PROGRAM	84	64	111
F-12	INITIAL PROGRAM	84	64	112
F-13	INITIAL PROGRAM	84	64	113
F-14	INITIAL PROGRAM	84	64	114
F-15	INITIAL PROGRAM	84	64	115
F-16	INITIAL PROGRAM	84	64	116
F-17	INITIAL PROGRAM	84	64	117
F-18	INITIAL PROGRAM	84	64	118
F-19	INITIAL PROGRAM	84	64	119
F-20	INITIAL PROGRAM	84	64	120

G

Bank-Num	PROGRAM Name	MSB	LSB	PC
G-01	FC1 PedalWahClav	84	64	121
G-02	TransistorOrgans	84	64	122
G-03	BrightRainyWaltz	84	64	123
G-04	E.Bass/RockPiano	84	64	124
G-05	WaterRing Piano	84	64	125
G-06	DynoEP /SoloLead	84	64	126
G-07	DEMO ToneColor 1	84	64	127
G-08	DEMO ToneColor 2	84	64	128
G-09	INITIAL PROGRAM	84	65	1
G-10	INITIAL PROGRAM	84	65	2
G-11	INITIAL PROGRAM	84	65	3
G-12	INITIAL PROGRAM	84	65	4
G-13	INITIAL PROGRAM	84	65	5
G-14	INITIAL PROGRAM	84	65	6
G-15	INITIAL PROGRAM	84	65	7
G-16	INITIAL PROGRAM	84	65	8
G-17	INITIAL PROGRAM	84	65	9
G-18	INITIAL PROGRAM	84	65	10
G-19	INITIAL PROGRAM	84	65	11
G-20	INITIAL PROGRAM	84	65	12

H

Bank-Num	PROGRAM Name	MSB	LSB	PC
H-01	Reed EP Menu	84	65	13
H-02	History of Tine	84	65	14
H-03	Symphonic Grand	84	65	15
H-04	LA Brass Rock	84	65	16
H-05	E.Bass/RockOrgan	84	65	17
H-06	Re:Milian ScPno	84	65	18
H-07	DEMO Upright Pno	84	65	19
H-08	DEMO SA Piano	84	65	20
H-09	INITIAL PROGRAM	84	65	21
H-10	INITIAL PROGRAM	84	65	22
H-11	INITIAL PROGRAM	84	65	23
H-12	INITIAL PROGRAM	84	65	24
H-13	INITIAL PROGRAM	84	65	25
H-14	INITIAL PROGRAM	84	65	26
H-15	INITIAL PROGRAM	84	65	27
H-16	INITIAL PROGRAM	84	65	28
H-17	INITIAL PROGRAM	84	65	29
H-18	INITIAL PROGRAM	84	65	30
H-19	INITIAL PROGRAM	84	65	31
H-20	INITIAL PROGRAM	84	65	32

Program List

I

Bank-Num	PROGRAM Name	MSB	LSB	PC
I-01	Bright FM EP	84	65	33
I-02	Piano + SA EP	84	65	34
I-03	Piano + Choir	84	65	35
I-04	TW-Org w/ LHBass	84	65	36
I-05	+StrgsVelo>High1	84	65	37
I-06	FranDoll ScPiano	84	65	38
I-07	DEMO JD Piano	84	65	39
I-08	DEMO Reed EP	84	65	40
I-09	INITIAL PROGRAM	84	65	41
I-10	INITIAL PROGRAM	84	65	42
I-11	INITIAL PROGRAM	84	65	43
I-12	INITIAL PROGRAM	84	65	44
I-13	INITIAL PROGRAM	84	65	45
I-14	INITIAL PROGRAM	84	65	46
I-15	INITIAL PROGRAM	84	65	47
I-16	INITIAL PROGRAM	84	65	48
I-17	INITIAL PROGRAM	84	65	49
I-18	INITIAL PROGRAM	84	65	50
I-19	INITIAL PROGRAM	84	65	51
I-20	INITIAL PROGRAM	84	65	52

K

Bank-Num	PROGRAM Name	MSB	LSB	PC
K-01	Too Deep Delay!	84	65	73
K-02	JD Piano Menu	84	65	74
K-03	SA Piano Layer	84	65	75
K-04	WitchOfMilkyWay	84	65	76
K-05	+StrgsVelo>High2	84	65	77
K-06	Wedding	84	65	78
K-07	SynPad/TwinBrass	84	65	79
K-08	DEMO FM E.Piano	84	65	80
K-09	INITIAL PROGRAM	84	65	81
K-10	INITIAL PROGRAM	84	65	82
K-11	INITIAL PROGRAM	84	65	83
K-12	INITIAL PROGRAM	84	65	84
K-13	INITIAL PROGRAM	84	65	85
K-14	INITIAL PROGRAM	84	65	86
K-15	INITIAL PROGRAM	84	65	87
K-16	INITIAL PROGRAM	84	65	88
K-17	INITIAL PROGRAM	84	65	89
K-18	INITIAL PROGRAM	84	65	90
K-19	INITIAL PROGRAM	84	65	91
K-20	INITIAL PROGRAM	84	65	92

J

Bank-Num	PROGRAM Name	MSB	LSB	PC
J-01	Tron Split	84	65	53
J-02	Piano + Pad	84	65	54
J-03	Misty as Last.Bs	84	65	55
J-04	SA Piano Menu	84	65	56
J-05	E.Bass / Tine EP	84	65	57
J-06	Grand Piano Menu	84	65	58
J-07	DEMO Tremolo EP	84	65	59
J-08	DEMO SA E.Piano	84	65	60
J-09	INITIAL PROGRAM	84	65	61
J-10	INITIAL PROGRAM	84	65	62
J-11	INITIAL PROGRAM	84	65	63
J-12	INITIAL PROGRAM	84	65	64
J-13	INITIAL PROGRAM	84	65	65
J-14	INITIAL PROGRAM	84	65	66
J-15	INITIAL PROGRAM	84	65	67
J-16	INITIAL PROGRAM	84	65	68
J-17	INITIAL PROGRAM	84	65	69
J-18	INITIAL PROGRAM	84	65	70
J-19	INITIAL PROGRAM	84	65	71
J-20	INITIAL PROGRAM	84	65	72

L

Bank-Num	PROGRAM Name	MSB	LSB	PC
L-01	SynthBrass Ens	84	65	93
L-02	Sweet House Set	84	65	94
L-03	Electro Split	84	65	95
L-04	4-Space Ballad	84	65	96
L-05	DaNCe	84	65	97
L-06	Dream Slice Pad	84	65	98
L-07	Pontyfy	84	65	99
L-08	Trance Synth	84	65	100
L-09	INITIAL PROGRAM	84	65	101
L-10	INITIAL PROGRAM	84	65	102
L-11	INITIAL PROGRAM	84	65	103
L-12	INITIAL PROGRAM	84	65	104
L-13	INITIAL PROGRAM	84	65	105
L-14	INITIAL PROGRAM	84	65	106
L-15	INITIAL PROGRAM	84	65	107
L-16	INITIAL PROGRAM	84	65	108
L-17	INITIAL PROGRAM	84	65	109
L-18	INITIAL PROGRAM	84	65	110
L-19	INITIAL PROGRAM	84	65	111
L-20	INITIAL PROGRAM	84	65	112

M

Bank-Num	PROGRAM Name	MSB	LSB	PC
M-01	INITIAL PROGRAM	84	65	113
M-02	INITIAL PROGRAM	84	65	114
M-03	INITIAL PROGRAM	84	65	115
M-04	INITIAL PROGRAM	84	65	116
M-05	INITIAL PROGRAM	84	65	117
M-06	INITIAL PROGRAM	84	65	118
M-07	INITIAL PROGRAM	84	65	119
M-08	INITIAL PROGRAM	84	65	120
M-09	INITIAL PROGRAM	84	65	121
M-10	INITIAL PROGRAM	84	65	122
M-11	INITIAL PROGRAM	84	65	123
M-12	INITIAL PROGRAM	84	65	124
M-13	INITIAL PROGRAM	84	65	125
M-14	INITIAL PROGRAM	84	65	126
M-15	INITIAL PROGRAM	84	65	127
M-16	INITIAL PROGRAM	84	65	128
M-17	INITIAL PROGRAM	84	66	1
M-18	INITIAL PROGRAM	84	66	2
M-19	INITIAL PROGRAM	84	66	3
M-20	INITIAL PROGRAM	84	66	4

O

Bank-Num	PROGRAM Name	MSB	LSB	PC
O-01	INITIAL PROGRAM	84	66	25
O-02	INITIAL PROGRAM	84	66	26
O-03	INITIAL PROGRAM	84	66	27
O-04	INITIAL PROGRAM	84	66	28
O-05	INITIAL PROGRAM	84	66	29
O-06	INITIAL PROGRAM	84	66	30
O-07	INITIAL PROGRAM	84	66	31
O-08	INITIAL PROGRAM	84	66	32
O-09	INITIAL PROGRAM	84	66	33
O-10	INITIAL PROGRAM	84	66	34
O-11	INITIAL PROGRAM	84	66	35
O-12	INITIAL PROGRAM	84	66	36
O-13	INITIAL PROGRAM	84	66	37
O-14	INITIAL PROGRAM	84	66	38
O-15	INITIAL PROGRAM	84	66	39
O-16	INITIAL PROGRAM	84	66	40
O-17	INITIAL PROGRAM	84	66	41
O-18	INITIAL PROGRAM	84	66	42
O-19	INITIAL PROGRAM	84	66	43
O-20	INITIAL PROGRAM	84	66	44

N

Bank-Num	PROGRAM Name	MSB	LSB	PC
N-01	INITIAL PROGRAM	84	66	5
N-02	INITIAL PROGRAM	84	66	6
N-03	INITIAL PROGRAM	84	66	7
N-04	INITIAL PROGRAM	84	66	8
N-05	INITIAL PROGRAM	84	66	9
N-06	INITIAL PROGRAM	84	66	10
N-07	INITIAL PROGRAM	84	66	11
N-08	INITIAL PROGRAM	84	66	12
N-09	INITIAL PROGRAM	84	66	13
N-10	INITIAL PROGRAM	84	66	14
N-11	INITIAL PROGRAM	84	66	15
N-12	INITIAL PROGRAM	84	66	16
N-13	INITIAL PROGRAM	84	66	17
N-14	INITIAL PROGRAM	84	66	18
N-15	INITIAL PROGRAM	84	66	19
N-16	INITIAL PROGRAM	84	66	20
N-17	INITIAL PROGRAM	84	66	21
N-18	INITIAL PROGRAM	84	66	22
N-19	INITIAL PROGRAM	84	66	23
N-20	INITIAL PROGRAM	84	66	24

Rhythm Pattern List

No	Pattern name	Drum set
000	Metronome	Standard 1
001	8-Beat Pop1	Standard 1
002	8-Beat Pop2	Jazz Kit
003	8-Beat Pop3	Standard 1
004	8-Beat Pop4	Standard 1
005	8-Beat Pop5	Standard 1
006	16-Beat Pop1	Standard 2
007	16-Beat Pop2	Standard 2
008	16-Beat Pop3	Standard 2
009	16-Beat Funk	Standard 2
010	16-Bt Fusion1	Standard 2
011	16-Bt Fusion2	Standard 2
012	8-Beat Rock1	Standard 2
013	8-Beat Rock2	Standard 2
014	16Beat Rock1	Standard 2
015	16Beat Rock2	Standard 2
016	Pop Ballad	Standard 2
017	Ballad 1	Machine Kit
018	Ballad 2	Machine Kit
019	Ballad 3	Machine Kit
020	Piano R&B 1	Jazz Kit
021	Piano R&B 2	Standard 3
022	Pop 1-1	Standard 1
023	Pop 1-2	Standard 1
024	Pop 1-3	Standard 1
025	Pop 1-4	Standard 1
026	Pop 2-1	Standard 1
027	Pop 2-2	Standard 1
028	Pop 2-3	Standard 1
029	Pop 2-4	Standard 1
030	Pop 2-5	Standard 1
031	Pop 3-1	Standard 1
032	Pop 3-2	Standard 1
033	Pop 3-3	Standard 1
034	Pop 3-4	Standard 1
035	Pop 4-1	Standard 1
036	Pop 4-2	Standard 1
037	Pop 5-1	Standard 1
038	Pop 5-2	Standard 1
039	Pop 5-3	Standard 1
040	Pop 5-4	Standard 1
041	Pop 5-5	Standard 1
042	Pop 6-1	Standard 1
043	Pop 6-2	Standard 1
044	Pop 7-1	Standard 1
045	Pop 7-2	Standard 1
046	Pop 7-3	Standard 1
047	Pop 7-4	Standard 1
048	West Coast	Standard 2
049	Big Beat 1	Standard 2
050	Big Beat 2	Standard 2
051	Big Beat 3	Standard 2
052	Funk 1	Standard 3
053	Funk 2	Standard 3
054	Funk 3	Standard 3
055	Pop Funk 1	Standard 3

No	Pattern name	Drum set
056	Pop Funk 2	Standard 3
057	Pop Funk 3	Standard 3
058	R&B 1	R&B Mini Kit
059	R&B 2	R&B Mini Kit
060	R&B 3	R&B Mini Kit
061	R&B 4	R&B Mini Kit
062	R&B 5	R&B Mini Kit
063	R&B 6	R&B Mini Kit
064	R&B 7	R&B Mini Kit
065	R&B 8	R&B Mini Kit
066	R&B 9	R&B Mini Kit
067	R&B 10	R&B Mini Kit
068	R&B 11	R&B Mini Kit
069	R&B 12	R&B Mini Kit
070	R&B 13	R&B Mini Kit
071	R&B 14	R&B Mini Kit
072	R&B 15	R&B Mini Kit
073	R&B 16	R&B Mini Kit
074	R&B 17	R&B Mini Kit
075	R&B 18	R&B Mini Kit
076	R&B Pop 1	Standard 2
077	R&B Pop 2	Standard 2
078	R&B Pop 3	Standard 2
079	R&B Pop 4	Standard 2
080	R&B Pop 5	Standard 2
081	R&B Pop 6	Standard 2
082	Rockaballad	Standard 3
083	Shuffle 1	Standard 3
084	Shuffle 2	Standard 3
085	ShufflePop1	Standard 2
086	ShufflePop2	Standard 2
087	ShufflePop3	Standard 2
088	ShufflePop4	Standard 2
089	ShufflePop5	Standard 2
090	Slow Beat	Standard 2
091	StraightRock	Standard 1
092	Back Beat 1	Jazz Kit
093	Back Beat 2	R&B Mini Kit
094	Back Beat 3	R&B Mini Kit
095	Back Beat 4	R&B Mini Kit
096	Back Beat 5	R&B Mini Kit
097	Back Beat 6	R&B Mini Kit
098	Back Beat 7	R&B Mini Kit
099	Back Beat 8	R&B Mini Kit
100	Back Beat 9	R&B Mini Kit
101	Back Beat10	R&B Mini Kit
102	Jazz 1	Jazz Kit
103	Jazz 2	Jazz Kit
104	Jazz 3	Jazz Kit
105	Jazz 4	Jazz Kit
106	Jazz 5	Jazz Kit
107	Swing 1	Jazz Kit
108	Swing 2	Jazz Kit
109	Swing 3	Jazz Kit
110	Swing 4	Jazz Kit
111	Combo	Jazz Kit

No	Pattern name	Drum set
112	Free Jazz	Jazz Kit
113	Acid Jazz	R&B Kit
114	Motown	Standard 3
115	Gospel 1	Standard 3
116	Gospel 2	Standard 3
117	Blues 1	Standard 1
118	Blues 2	Standard 1
119	Power Fusion	Standard 1
120	PowerfulRock	Standard 1
121	Progressive	Standard 1
122	Rock 1	Standard 1
123	Rock 2	Standard 1
124	Rock 3	Standard 1
125	Rock 4	Standard 1
126	Rock 5	Standard 1
127	Rock 6	Standard 1
128	Rock 7	Standard 1
129	Rock 8	Standard 1
130	Rock 9	Standard 1
131	Rock 10	Standard 1
132	Rock 11	Standard 1
133	Rock 12	Standard 1
134	Rock 13	Standard 1
135	Rock 14	Standard 1
136	Rock 15	Standard 1
137	Rock 16	Standard 1
138	Rock 17	Standard 1
139	Rock 18	Standard 1
140	Rock 19	Standard 1
141	Rock 20	Standard 1
142	Rock 21	Standard 1
143	Rock 22	Standard 1
144	Rock 23	Standard 1
145	Rock 24	Standard 1
146	Rock 25	Standard 1
147	Rock 26	Standard 1
148	Rock 27	Standard 1
149	Rock 28	Standard 1
150	Rock 29	Standard 1
151	Latin Dance	Standard 1
152	Latin Pop 1	Standard 3
153	Latin Pop 2	Standard 3
154	Latin Pop 3	Standard 3
155	Latin Pop 4	Standard 3
156	Latin Pop 5	Standard 3
157	Latin Pop 6	Standard 3
158	Salsa 1	Standard 3
159	Salsa 2	Standard 3
160	Samba	Standard 3
161	Reggae	Standard 2
162	Fast Bossa	Standard 3
163	BossaNova 1	Standard 2
164	BossaNova 2	Standard 2
165	Mambo	Standard 3
166	ElecDance 1	Machine Kit
167	ElecDance 2	Machine Kit

No	Pattern name	Drum set
168	ElecDance 3	Dance Kit 1
169	ElecDance 4	Dance Kit 1
170	ElecDance 5	Machine Kit
171	ElecDance 6	Machine Kit
172	ElecDance 7	Machine Kit
173	ElecDance 8	Machine Kit
174	Dance	HipHop Kit
175	Rap 1	Dance Kit 3
176	Rap 2	Dance Kit 3
177	Hip Hop 1	Machine Kit
178	Hip Hop 2	Machine Kit
179	Hip Hop 3	Machine Kit
180	Hip Hop 4	Machine Kit
181	Hip Hop 5	Machine Kit
182	Techno	Machine Kit
183	Polka 1	Standard 3
184	Polka 2	Standard 3
185	Simple Waltz	Jazz Kit
186	Pop Waltz 1	Jazz Kit
187	Pop Waltz 2	Jazz Kit
188	Pop Waltz 3	Jazz Kit
189	Pop Waltz 4	Jazz Kit
190	Metro (2/4)	Standard 1
191	Metro (3/4)	Standard 1
192	Metro (4/4)	Standard 1
193	Metro (5/4)	Standard 1
194	Metro (6/4)	Standard 1
195	Metro (7/4)	Standard 1
196	Metro (5/8)	Standard 1
197	Metro (6/8)	Standard 1
198	Metro (7/8)	Standard 1
199	Metro (9/8)	Standard 1
200	Metro (12/8)	Standard 1

Rhythm Set List

* [EXC] : Percussion sound of the same number will not be heard at the same time.

		Standard 1 MSB: 84/LSB: 8/PC: 68	Standard 2 MSB: 84/LSB: 8/PC: 69	Standard 3 MSB: 84/LSB: 8/PC: 70	Rock Kit MSB: 84/LSB: 8/PC: 71	Jazz Kit MSB: 84/LSB: 8/PC: 72
C1	23	22 MC500 Beep1	MC500 Beep1	MC500 Beep1	MC500 Beep1	MC500 Beep1
		MC500 Beep2	MC500 Beep2	MC500 Beep2	MC500 Beep2	MC500 Beep2
		Concert SD	Concert SD	Concert SD	Concert SD	Concert SD
	24	25 Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll
	26	Snap	Snap	Snap	Snap	Snap
		27 High Q	High Q	High Q	High Q	High Q
	28	Slap	Slap	Slap	Slap	Slap
		Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]
	29	30 Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]
	31	Sticks	Sticks	Sticks	Sticks	Sticks
C2		32 Square Click	Square Click	Square Click	Square Click	Square Click
	33	Metron Click	Metron Click	Metron Click	Metron Click	Metron Click
		34 Metron Bell	Metron Bell	Metron Bell	Metron Bell	Metron Bell
	35	Kick Drum 2	Kick Drum 2	Kick Drum 2	Power Kick2	Jazz Kick 2
		Kick Drum 1	Kick Drum 1	Kick Drum 1	Power Kick1	Jazz Kick 1
	36	37 Side Stick	Side Stick	Side Stick	Side Stick	Side Stick
	38	Reg.Snr 2	Snare 1	Snare 1	Power Snare1	Jazz Snare1
		39 Hand Clap	Hand Clap	Hand Clap	Hand Clap	Hand Clap
	40	Reg.Snr 1	Snare 2	Snare 2	Power Snare2	Jazz Snare2
		Reg.F.Tom	Low Tom 2	Low Tom 2	Low Tom 1	Low Tom 2
C3	41	42 ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]
		Reg.L.Tom	Low Tom 1	Low Tom 1	Low Tom 2	Low Tom 1
	43	44 Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]
		Reg.M.Tom	Mid Tom 2	Mid Tom 2	Mid Tom 1	Mid Tom 2
	45	46 Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]
		Reg.M.Tom	Mid Tom 1	Mid Tom 1	Mid Tom 2	Mid Tom 1
	47	Reg.H.Tom	High Tom 2	High Tom 2	High Tom 1	High Tom 2
	48	49 CrashCymbal1	CrashCymbal1	CrashCymbal1	CrashCymbal1	CrashCymbal1
		Reg.H.Tom	High Tom 1	High Tom 1	High Tom 2	High Tom 1
	50	51 Ride Cymbal1	Ride Cymbal1	Ride Cymbal1	Ride Cymbal1	Ride Cymbal1
C4	52	China Cymbal	China Cymbal	China Cymbal	China Cymbal	China Cymbal
		Ride Bell	Ride Bell	Ride Bell	Ride Bell	Ride Bell
	53	54 Tambourine	Tambourine	Tambourine	Tambourine	Tambourine
		SplashCymbal	SplashCymbal	SplashCymbal	SplashCymbal	SplashCymbal
	55	56 Cowbell	Cowbell	Cowbell	Cowbell	Cowbell
		CrashCymbal2	CrashCymbal2	CrashCymbal2	CrashCymbal2	CrashCymbal2
	57	58 Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap
		Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2
	59	High Bongo	High Bongo	High Bongo	High Bongo	High Bongo
	60	61 Low Bongo	Low Bongo	Low Bongo	Low Bongo	Low Bongo
C5	62	MuteHi Conga	MuteHi Conga	MuteHi Conga	MuteHi Conga	MuteHi Conga
		63 OpenHi Conga	OpenHi Conga	OpenHi Conga	OpenHi Conga	OpenHi Conga
	64	Low Conga	Low Conga	Low Conga	Low Conga	Low Conga
		High Timbale	High Timbale	High Timbale	High Timbale	High Timbale
	65	66 Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale
		High Agogo	High Agogo	High Agogo	High Agogo	High Agogo
	67	68 Low Agogo	Low Agogo	Low Agogo	Low Agogo	Low Agogo
		Cabasa	Cabasa	Cabasa	Cabasa	Cabasa
	69	70 Maracas	Maracas	Maracas	Maracas	Maracas
	71	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]
C6		Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]
	72	73 Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]
		Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]
	74	75 Claves	Claves	Claves	Claves	Claves
		Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock
	76	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock
	77	78 Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]
		Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]
	79	80 MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]
		OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]
C7	81	82 Shaker	Shaker	Shaker	Shaker	Shaker
		Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
	83	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree
	84	85 Castanets	Castanets	Castanets	Castanets	Castanets
		Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]
	86	87 Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]
	88	Applause	Applause	Applause	Applause	Applause
		SnareGhost1	SnareGhost1	SnareGhost1	SnareGhost1	SnareGhost1
	89	90 SnareGhost2	SnareGhost2	SnareGhost2	SnareGhost2	SnareGhost2
		Hand Clap1	Hand Clap1	Hand Clap1	Hand Clap1	Hand Clap1
C8	91	92 Hand Clap2	Hand Clap2	Hand Clap2	Hand Clap2	Hand Clap2
		Scratch1	Scratch1	Scratch1	Scratch1	Scratch1
	93	94 Scratch2	Scratch2	Scratch2	Scratch2	Scratch2
		Scratch3	Scratch3	Scratch3	Scratch3	Scratch3
	95	Hit1	Hit1	Hit1	Hit1	Hit1
	96	97 Hit2	Hit2	Hit2	Hit2	Hit2
		Hit3	Hit3	Hit3	Hit3	Hit3
	98	99 Hit4	Hit4	Hit4	Hit4	Hit4
		Hit5	Hit5	Hit5	Hit5	Hit5
	100	Low Tom1	Low Tom1	Low Tom1	Low Tom1	Low Tom1
C8	101	102 Low Tom2	Low Tom2	Low Tom2	Low Tom2	Low Tom2
		Cajon1	Cajon1	Cajon1	Cajon1	Cajon1
	103	104 Cajon2	Cajon2	Cajon2	Cajon2	Cajon2
		Syn Burst Nz	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz
	105	106 Sweep Down	Sweep Down	Sweep Down	Sweep Down	Sweep Down
		Laser	Laser	Laser	Laser	Laser
	107	Syn Back Nz	Syn Back Nz	Syn Back Nz	Syn Back Nz	Syn Back Nz
	108					

* [EXC] : Percussion sound of the same number will not be heard at the same time.

	Brush Kit MSB: 84/LSB: 8/PC: 73	Machine Kit MSB: 84/LSB: 8/PC: 74	R&B T-Analog MSB: 84/LSB: 8/PC: 75	R&B Mini Kit MSB: 84/LSB: 8/PC: 76	HipHop Kit MSB: 84/LSB: 8/PC: 77
C1	22 MC500 Beep1	MC500 Beep1	MC500 Beep1	MC500 Beep1	MC500 Beep1
	23 MC500 Beep2	MC500 Beep2	MC500 Beep2	MC500 Beep2	MC500 Beep2
	24 Concert SD	Concert SD	Concert SD	Concert SD	Concert SD
	25 Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll
	26 Snap	Snap	Snap	Snap	Snap
C2	27 High Q	High Q	High Q	High Q	High Q
	28 Slap	Slap	Slap	Slap	Mix Kick1
	29 Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Analog Kick1
	30 Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Mix Snare4
	31 Sticks	Sticks	Sticks	Sticks	Analog Kick2
C3	32 Square Click	Square Click	Square Click	Square Click	Mix Snare3
	33 Metron Click	Metron Click	Metron Click	Metron Click	Mix Kick2
	34 Metron Bell	Metron Bell	Metron Bell	Metron Bell	HH Shaker [EXC 1]
	35 Jazz Kick 2	Ana.Kick 1	Ana.Kick 1	Kick 2	Mix Kick4
	36 Jazz Kick 1	Ana.Kick 2	Ana.Kick 2	Kick 1	Mix Kick3
C4	37 Side Stick	Ana.Rim Shot	Ana.Rim Shot	Side Stick	TR808 Rim
	38 Brush Tap	Ana.Snare	Ana.Snare	Snare 1	Mix Snare1
	39 Brush Slap	Hand Clap	Hand Clap	Hand Clap	TR808 Clap
	40 Brush Swirl	Elec.Snare	Elec.Snare	Snare 2	Mix Snare2
	41 Low Tom 2	Ana.Low Tom2	Ana.Low Tom2	Reg.F.Tom	Tom1
C5	42 ClosedHi-hat [EXC 1]	Ana.Cl HH 1 [EXC 1]	Ana.Cl HH 1 [EXC 1]	ClosedHi-hat [EXC 1]	TR808 ClHH [EXC 1]
	43 Low Tom 1	Ana.Low Tom1	Ana.Low Tom1	Reg.L.Tom	Tom2
	44 Pedal Hi-hat [EXC 1]	Ana.Cl HH 2 [EXC 1]	Ana.Cl HH 2 [EXC 1]	Pedal Hi-hat [EXC 1]	Noise ClHH [EXC 1]
	45 Mid Tom 2	Ana.Mid Tom2	Ana.Mid Tom2	Reg.M.Tom	Tom3
	46 Open Hi-hat [EXC 1]	Ana.Open HH [EXC 1]	Ana.Open HH [EXC 1]	Open Hi-hat [EXC 1]	TR808 OpHH [EXC 1]
C6	47 Mid Tom 1	Ana.Mid Tom1	Ana.Mid Tom1	Reg.M.Tom	Tom4
	48 High Tom 2	Ana.Hi Tom2	Ana.Hi Tom2	Reg.H.Tom	Tom5
	49 CrashCymbal1	Ride Cymbal1	Ride Cymbal1	CrashCymbal1	TR909 Cym
	50 High Tom 1	Ana.Hi Tom1	Ana.Hi Tom1	Reg.H.Tom	Tom6
	51 Ride Cymbal1	Ana.Cymbal	Ana.Cymbal	Ride Cymbal1	TR808 Cym
C7	52 China Cymbal	China Cymbal	China Cymbal	China Cymbal	China Cymbal
	53 Ride Bell	Ride Bell	Ride Bell	China Cymbal	Rock Rd Edge
	54 Tambourine	Tambourine	Tambourine	Tambourine	Mix Perc
	55 SplashCymbal	SplashCymbal	SplashCymbal	SplashCymbal	Mix Crash1
	56 Cowbell	Ana.Cowbell	Ana.Cowbell	Cowbell	Ana.Cowbell
C8	57 CrashCymbal2	CrashCymbal	CrashCymbal	CrashCymbal2	Mix Crash2
	58 Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	Roll FX
	59 Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cym
	60 High Bongo	High Bongo	High Bongo	High Bongo	High Bongo
	61 Low Bongo	Low Bongo	Low Bongo	Low Bongo	Low Bongo
C9	62 MuteHi Conga	Ana.Hi Conga	Ana.Hi Conga	MuteHi Conga	MuteHi Conga
	63 OpenHi Conga	Ana.MidConga	Ana.MidConga	OpenHi Conga	OpenHi Conga
	64 Low Conga	Ana.LowConga	Ana.LowConga	Low Conga	Low Conga
	65 High Timbale	High Timbale	High Timbale	High Timbale	High Timbale
	66 Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale
C10	67 High Agogo	High Agogo	High Agogo	High Agogo	High Agogo
	68 Low Agogo	Low Agogo	Low Agogo	Low Agogo	Low Agogo
	69 Cabasa	Cabasa	Cabasa	Cabasa	Cabasa
	70 Maracas	Ana.Maracas	Ana.Maracas	Maracas	Maracas
	71 ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]
C11	72 Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]
	73 Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]
	74 Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]
	75 Claves	Ana.Claves	Ana.Claves	Claves	Claves
	76 Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock
C12	77 LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock
	78 Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]
	79 Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]
	80 MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]
	81 OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]
C13	82 Shaker	Shaker	Shaker	Shaker	Shaker
	83 Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
	84 Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree
	85 Castanets	Castanets	Castanets	Castanets	Castanets
	86 Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]
C14	87 Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]
	88 Applause	Applause	Applause	Applause	Applause
	89 SnareGhost1	SnareGhost1	SnareGhost1	SnareGhost1	SnareGhost1
	90 SnareGhost2	SnareGhost2	SnareGhost2	SnareGhost2	SnareGhost2
	91 Hand Clap1	Hand Clap1	Hand Clap1	Hand Clap1	Hand Clap1
C15	92 Hand Clap2	Hand Clap2	Hand Clap2	Hand Clap2	Hand Clap2
	93 Scratch1	Scratch1	Scratch1	Scratch1	Scratch1
	94 Scratch2	Scratch2	Scratch2	Scratch2	Scratch2
	95 Scratch3	Scratch3	Scratch3	Scratch3	Scratch3
	96 Hit1	Hit1	Hit1	Hit1	Hit1
C16	97 Hit2	Hit2	Hit2	Hit2	Hit2
	98 Hit3	Hit3	Hit3	Hit3	Hit3
	99 Hit4	Hit4	Hit4	Hit4	Hit4
	100 Hit5	Hit5	Hit5	Hit5	Hit5
	101 Low Tom1	Low Tom1	Low Tom1	Low Tom1	Low Tom1
C17	102 Low Tom2	Low Tom2	Low Tom2	Low Tom2	Low Tom2
	103 Cajon1	Cajon1	Cajon1	Cajon1	Cajon1
	104 Cajon2	Cajon2	Cajon2	Cajon2	Cajon2
	105 Syn Burst Nz	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz
	106 Sweep Down	Sweep Down	Sweep Down	Sweep Down	Sweep Down
C18	107 Laser	Laser	Laser	Laser	Laser
	108 Syn Back Nz	Syn Back Nz	Syn Back Nz	Syn Back Nz	Syn Back Nz

Rhythm Set List

* [EXC] : Percussion sound of the same number will not be heard at the same time.

	R&B Kit MSB: 84/LSB: 8/PC: 78	Dance Kit 1 MSB: 84/LSB: 8/PC: 79	Dance Kit 2 MSB: 84/LSB: 8/PC: 80	Dance Kit 3 MSB: 84/LSB: 8/PC: 81
C1	22 MC500 Beep1	MC500 Beep1	MC500 Beep1	MC500 Beep1
	MC500 Beep2	MC500 Beep2	MC500 Beep2	MC500 Beep2
	Concert SD	Concert SD	Concert SD	Concert SD
	25 Snare Roll	Snare Roll	Snare Roll	Snare Roll
	26 Snap	Snap	Snap	Snap
	27 High Q	High Q	High Q	High Q
	28 TR808 Kick	TR909 Kick	SH32 Kick1	TR808 Kick
	HH Kick	SH32 Kick1	TR909 Kick1	Mix Kick1
	29 30 Mix Snare2	AnalogSnare	AnalogSnare1	TR909 Snare1
	Mix Kick4	Analog Kick	Analog Kick1	Mix Kick2
C2	31 32 Short Snare2	TR808 Snare	TR808 Snare	TR909 Snare2
	Mix Kick3	SH32 Kick2	SH32 Kick2	Mix Kick3
	34 TR808 Cl HH [EXC 1]	Syn ClHH1 [EXC 1]	Pedal Hihat [EXC 1]	Thin ClHH [EXC 1]
	Mix Kick1	Mix Kick2	TR909 Kick2	TR909 Kick
	Mix Kick2	Mix Kick1	Analog Kick2	Analog Kick
	37 Soft Stick	Mix Rim	Synth Rim	Mix Rim
	38 Short Snare1	Mix Snare1	DistNz Snare	Mix Snare2
	39 Hand Clap	TR808 Clap	TR808 Clap	Mix Clap
	Mix Snare1	Mix Snare2	DistNz Snare	Mix Snare1
	TR808 Tom1	Mix Tom1	Deep Tom1	Mix Tom1
C3	41 42 Cl Hihat1 [EXC 1]	Mix ClHH1 [EXC 1]	Syn ClHH1 [EXC 1]	Mix ClHH1 [EXC 1]
	TR808 Tom2	Mix Tom2	Deep Tom2	Mix Tom2
	44 Cl Hihat2 [EXC 1]	Mix ClHH2 [EXC 1]	Syn ClHH2 [EXC 1]	Mix ClHH2 [EXC 1]
	TR808 Tom3	Mix Tom3	Deep Tom3	Mix Tom3
	46 Op Hihat [EXC 1]	Op Hihat [EXC 1]	Syn OpHH [EXC 1]	Op Hihat [EXC 1]
	TR808 Tom4	Mix Tom4	Deep Tom4	Mix Tom4
	TR808 Tom5	Mix Tom5	Deep Tom5	Mix Tom5
	49 TR909 Cym	Mix Crash	TR808 OpHH	Mix Crash
	TR808 Tom6	Mix Tom6	Deep Tom6	Mix Tom6
	51 TR808 Cym	Rock Rd Edge	Wide Syn Cym	Rock Rd Edge
C4	52 China Cymbal	China Cymbal	TR808 Cym1	China Cymbal
	Rock Rd Edge	Ride Cymbal	Ride Cym1	Ride Cymbal
	53 54 Mix Hat	Tambourine	Castanet	Tambourine
	Mix Crash1	Syn Splash	TR808 Cym2	Splash Cym
	56 Ana.Cowbell	Cowbell	TR808Cowbell	Cowbell
	Mix Crash2	Concert Cym	Ride Cym2	Concert Cym
	58 Vibra-slap	Vibraslap	Syn Cowbell	Vibraslap
	Ride Cym	TR808 Cym	Ride Cym3	Syn China
	High Bongo	High Bongo	High Bongo	High Bongo
	61 Low Bongo	Low Bongo	Low Bongo	Low Bongo
C5	MuteHi Conga	MuteHi Conga	MuteHi Conga	MuteHi Conga
	63 OpenHi Conga	OpenHi Conga	OpenHi Conga	OpenHi Conga
	Low Conga	Low Conga	Low Conga	Low Conga
	High Timbale	High Timbale	High Timbale	High Timbale
	66 Low Timbale	Low Timbale	Low Timbale	Low Timbale
	High Agogo	High Agogo	High Agogo	High Agogo
	68 Low Agogo	Low Agogo	Low Agogo	Low Agogo
	Cabasa	Cabasa	Cabasa	Cabasa
	70 Maracas	Maracas	Maracas	Maracas
	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]
C6	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]
	73 Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]
	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]
	75 Claves	Claves	Claves	Claves
	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock
	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock
	78 Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]
	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]
	80 MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]
	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]
C7	82 Shaker	Shaker	Shaker	Shaker
	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
	Bell Tree	Bell Tree	Bell Tree	Bell Tree
	85 Castanets	Castanets	Castanets	Castanets
	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]
	87 Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]
	Applause	Applause	Applause	Applause
	SnareGhost1	SnareGhost1	SnareGhost1	SnareGhost1
	90 SnareGhost2	SnareGhost2	SnareGhost2	SnareGhost2
	Hand Clap1	Hand Clap1	Hand Clap1	Hand Clap1
C8	92 Hand Clap2	Hand Clap2	Hand Clap2	Hand Clap2
	Scratch1	Scratch1	Scratch1	Scratch1
	94 Scratch2	Scratch2	Scratch2	Scratch2
	Scratch3	Scratch3	Scratch3	Scratch3
	Hit1	Hit1	Hit1	Hit1
	97 Hit2	Hit2	Hit2	Hit2
	Hit3	Hit3	Hit3	Hit3
	99 Hit4	Hit4	Hit4	Hit4
	Hit5	Hit5	Hit5	Hit5
	Low Tom1	Low Tom1	Low Tom1	Low Tom1
C9	102 Low Tom2	Low Tom2	Low Tom2	Low Tom2
	Cajon1	Cajon1	Cajon1	Cajon1
	104 Cajon2	Cajon2	Cajon2	Cajon2
	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz
	106 Sweep Down	Sweep Down	Sweep Down	Sweep Down
	Laser	Laser	Laser	Laser
	107 Syn Back Nz	Syn Back Nz	Syn Back Nz	Syn Back Nz

* [EXC] : Percussion sound of the same number will not be heard at the same time.

	GM2 STANDARD MSB: 84/LSB: 8/PC: 82	GM2 ROOM MSB: 84/LSB: 8/PC: 83	GM2 POWER MSB: 84/LSB: 8/PC: 84	GM2 ELECTRIC MSB: 84/LSB: 8/PC: 85	GM2 ANALOG MSB: 84/LSB: 8/PC: 86
C2	27 High Q	High Q	High Q	High Q	High Q
	28 Slap	Slap	Slap	Slap	Slap
	29 Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]
	30 Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]
	31 Sticks	Sticks	Sticks	Sticks	Sticks
	32 Square Click	Square Click	Square Click	Square Click	Square Click
	33 Metron Click	Metron Click	Metron Click	Metron Click	Metron Click
	34 Metron Bell	Metron Bell	Metron Bell	Metron Bell	Metron Bell
	35 Kick Drum 2	Kick Drum 2	Kick Drum 2	Kick Drum 2	Kick Drum 2
	36 Kick Drum 1	Kick Drum 1	Power Kick	Elec.Kick	Ana.Kick
C3	37 Side Stick	Side Stick	Side Stick	Side Stick	Ana.Rim Sho
	38 Aco.Snare	Aco.Snare	PowerSnare	E.SnareDrum1	Ana.Snare
	39 Hand Clap	Hand Clap	Hand Clap	Hand Clap	Hand Clap
	40 Elec.Snare	Elec.Snare	Elec.Snare	E.SnareDrum2	Elec.Snare
	41 Low Tom 2	Room LowTom2	PowerLowTom2	E.Low Tom 2	Ana.Low Tom2
	42 ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	Ana.ClosedHH [EXC 1]
	43 Low Tom 1	Room LowTom1	PowerLowTom1	E.Low Tom 1	Ana.Low Tom1
	44 Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Ana.ClosedHH [EXC 1]
	45 Mid Tom 2	Room MidTom2	PowerMidTom2	E.Mid Tom 2	Ana.Mid Tom2
	46 Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Ana.Open HH [EXC 1]
C4	47 Mid Tom 1	Room MidTom1	PowerMidTom1	E.Mid Tom 1	Ana.Mid Tom1
	48 High Tom 2	Room HiTom2	PowerHiTom2	E.Hi Tom 2	Ana.Hi Tom2
	49 CrashCymbal1	CrashCymbal1	CrashCymbal1	CrashCymbal1	Ana.Cymbal
	50 High Tom 1	Room Hi Tom1	Power HiTom1	E.Hi Tom 1	Ana.Hi Tom1
	51 Ride Cymbal1	Ride Cymbal1	Ride Cymbal1	Ride Cymbal1	Ride Cymbal1
	52 China Cymbal	China Cymbal	China Cymbal	Reverse Cym.	China Cymbal
	53 Ride Bell	Ride Bell	Ride Bell	Ride Bell	Ride Bell
	54 Tambourine	Tambourine	Tambourine	Tambourine	Tambourine
	55 SplashCymbal	SplashCymbal	SplashCymbal	SplashCymbal	SplashCymbal
	56 Cowbell	Cowbell	Cowbell	Cowbell	Ana.Cowbell
C5	57 CrashCymbal2	CrashCymbal2	CrashCymbal2	CrashCymbal2	CrashCymbal2
	58 Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap
	59 Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2
	60 High Bongo	High Bongo	High Bongo	High Bongo	High Bongo
	61 Low Bongo	Low Bongo	Low Bongo	Low Bongo	Low Bongo
	62 MuteHi Conga	MuteHi Conga	MuteHi Conga	MuteHi Conga	Ana.Hi Conga
	63 OpenHi Conga	OpenHi Conga	OpenHi Conga	OpenHi Conga	Ana.MidConga
	64 Low Conga	Low Conga	Low Conga	Low Conga	Ana.LowConga
	65 High Timbale	High Timbale	High Timbale	High Timbale	High Timbale
	66 Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale
C6	67 High Agogo	High Agogo	High Agogo	High Agogo	High Agogo
	68 Low Agogo	Low Agogo	Low Agogo	Low Agogo	Low Agogo
	69 Cabasa	Cabasa	Cabasa	Cabasa	Cabasa
	70 Maracas	Maracas	Maracas	Maracas	Ana.Maracas
	71 ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]
	72 Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]
	73 Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]
	74 Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]
	75 Claves	Claves	Claves	Claves	Ana.Claves
	76 Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock
C7	77 LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock
	78 Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]
	79 Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]
	80 MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]
	81 OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]
	82 Shaker	Shaker	Shaker	Shaker	Shaker
	83 Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
	84 Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree
	85 Castanets	Castanets	Castanets	Castanets	Castanets
	86 Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]
C8	87 Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]
	88 -	-	-	-	-

Rhythm Set List

* [EXC] : Percussion sound of the same number will not be heard at the same time.

	GM2 JAZZ MSB: 84/LSB: 8/PC: 87	GM2 BRUSH MSB: 84/LSB: 8/PC: 88	GM2 ORCHSTRA MSB: 84/LSB: 8/PC: 89	GM2 SFX MSB: 84/LSB: 8/PC: 54
	27 High Q	High Q	ClosedHi-hat [EXC 1]	–
28	Slap	Slap	Pedal Hi-hat [EXC 1]	–
	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Open Hi-hat [EXC 1]	–
29	30 Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Ride Cymbal1	–
31	Sticks	Sticks	Sticks	–
	32 Square Click	Square Click	Square Click	–
33	Metron Click	Metron Click	Metron Click	–
	34 Metron Bell	Metron Bell	Metron Bell	–
35	Jazz Kick 2	Jazz Kick 2	Concert BD 2	–
	Jazz Kick 1	Jazz Kick 1	Concert BD 1	–
C2	37 Side Stick	Side Stick	Side Stick	–
38	Aco.Snare	Brush Tap	Concert SD	–
	39 Hand Clap	Brush Slap	Castanets	High Q
40	Elec.Snare	Brush Swirl	Concert SD	Slap
	Low Tom 2	Low Tom 2	Timpani F	Scratch Push [EXC 7]
41	42 ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	Timpani F#	Scratch Pull [EXC 7]
43	Low Tom 1	Low Tom 1	Timpani G	Sticks
	44 Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Timpani G#	Square Click
45	Mid Tom 2	Mid Tom 2	Timpani A	Metron Click
	46 Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Timpani A#	Metron Bell
47	Mid Tom 1	Mid Tom 1	Timpani B	GtFret Noise
	High Tom 2	High Tom 2	Timpani c	Cut Noise Up
C3	49 CrashCymbal1	CrashCymbal1	Timpani c#	Cut Noise Dw
50	High Tom 1	High Tom 1	Timpani d	Slap St.Bass
	51 Ride Cymbal1	Ride Cymbal1	Timpani d#	Fl.Key Click
52	China Cymbal	China Cymbal	Timpani e	Laughing
	Ride Bell	Ride Bell	Timpani f	Scream
53	54 Tambourine	Tambourine	Tambourine	Punch
55	SplashCymbal	SplashCymbal	SplashCymbal	Heart Beat
	56 Cowbell	Cowbell	Cowbell	Footsteps 1
57	CrashCymbal2	CrashCymbal2	Concert Cym2	Footsteps 2
	58 Vibra-slap	Vibra-slap	Vibra-slap	Applause
59	Ride Cymbal2	Ride Cymbal2	Concert Cym1	Door Creak
	High Bongo	High Bongo	High Bongo	Door
C4	61 Low Bongo	Low Bongo	Low Bongo	Scratch
62	MuteHi Conga	MuteHi Conga	MuteHi Conga	Wind Chimes
	63 OpenHi Conga	OpenHi Conga	OpenHi Conga	Car Engine
64	Low Conga	Low Conga	Low Conga	Car Stop
	High Timbale	High Timbale	High Timbale	Car Pass
65	66 Low Timbale	Low Timbale	Low Timbale	Car Crash
67	High Agogo	High Agogo	High Agogo	Siren
	68 Low Agogo	Low Agogo	Low Agogo	Train
69	Cabasa	Cabasa	Cabasa	Jetplane
	70 Maracas	Maracas	Maracas	Helicopter
71	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	Starship
	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Gun Shot
C5	73 Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Machine Gun
74	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	LaserGun
	75 Claves	Claves	Claves	Explosion
76	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Dog
	LowWoodBlock	LowWoodBlock	LowWoodBlock	Horse Gallop
77	78 Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Birds
79	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Rain
	80 MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	Thunder
81	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	Wind
	82 Shaker	Shaker	Shaker	Seashore
83	Jingle Bell	Jingle Bell	Jingle Bell	Stream
	Bell Tree	Bell Tree	Bell Tree	Bubble
C6	85 Castanets	Castanets	Castanets	–
86	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	–
	87 Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	–
88	–	–	Applause	–