

# SD-50 Sound list / SD-50 音色一覧

## Tone category / 音色カテゴリー

Main Category	Category
Piano	Ac.Piano
	Pop Piano
	E.Grand Piano
E.Piano	E.Piano 1
	E.Piano2
Organ	E.Organ
	Pipe Organ
	Reed Organ
Other Keyboards	Harpsichord
	Clav
	Celesta
Accordion/Harmonica	Accordion
	Harmonica
Bell/Mallet	Bell
	Mallet
Guitar	Ac.Guitar
	E.Guitar
	Dist.Guitar
Bass	Ac.Bass
	E.Bass
	Synth Bass
Other Plucked/Stroke	Plucked/Stroke
Strings	Solo Strings
	Ensemble Strings
	Orchestral
Brass	Solo Brass
	Ensemble Brass
Sax/Wind	Wind
	Flute
	Sax
	Recorder
Vox/Choir	Vox/Choir
	Scat
Synthesizer	Synth Lead
	Synth Brass
	Synth Pad/Strings
	Synth Bellpad
	Synth PolyKey
	Synth FX
Phrase/FX	Synth Seq/Pop
	Phrase
	Pulsating
	Beat&Groove
	Hit
Drums/Percussion	Sound FX
	Drums
	Percussion

## Solo group / ソロ・グループ

#	Tone Name	MSB	LSB	PC	Category
001	Violin	89	64	41	Solo Strings
002	Trombone	89	64	58	Solo Brass
003	Shakuhachi	89	64	78	Flute

Copyright © 2010 ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

Roland is a registered trademark of Roland Corporation in the United States and/or other countries.

© 2010 ローランド株式会社

本書の一部、もしくは全部を無断で複写・転載することを禁じます。

Roland は、日本国およびその他の国におけるローランド株式会社の登録商標または商標です。

## GM2 group / GM2グループ

#	Tone Name	MSB	LSB	PC	Category
001	Piano 1	121	0	1	Ac.Piano
002	Piano 1 w	121	1		Ac.Piano
003	European Pf	121	2		Ac.Piano
004	Piano 2	121	0	2	Ac.Piano
005	Piano 2 w	121	1		Ac.Piano
006	Piano 3	121	0	3	E.Grand Piano
007	Piano 3 w	121	1		E.Grand Piano
008	Honky-tonk	121	0	4	Ac.Piano
009	Honky-tonk w	121	1		Ac.Piano
010	E.Piano 1	121	0	5	E.Piano1
011	St.Soft EP	121	1		E.Piano1
012	EP Legend 1	121	2		E.Piano2
013	Wurlly	121	3		E.Piano1
014	E.Piano 2	121	0	6	E.Piano2
015	Detuned EP	121	1		E.Piano2
016	St.FM EP	121	2		E.Piano2
017	EP Legend 2	121	3		E.Piano2
018	EP Phase	121	4		E.Piano2
019	Harpsichord	121	0	7	Harpsichord
020	Coupled Hps	121	1		Harpsichord
021	Harpsi w	121	2		Harpsichord
022	Harpsi o	121	3		Harpsichord
023	Clav	121	0	8	Clav
024	Pulse Clav	121	1		Clav
025	Celesta	121	0	9	Celesta
026	Glockenspiel	121	0	10	Mallet
027	Music Box	121	0	11	Bell
028	Vibraphone	121	0	12	Mallet
029	Vibraphone w	121	1		Mallet
030	Marimba	121	0	13	Mallet
031	Marimba w	121	1		Mallet
032	Xylophone	121	0	14	Mallet
033	TubularBells	121	0	15	Bell
034	Church Bell	121	1		Bell
035	Carillon	121	2		Bell
036	Santur	121	0	16	Plucked/Stroke
037	Organ 1	121	0	17	E.Organ
038	Trem. Organ	121	1		E.Organ
039	60's Organ	121	2		E.Organ
040	70's E.Organ	121	3		E.Organ
041	Organ 2	121	0	18	E.Organ
042	Chorus Organ	121	1		E.Organ
043	Perc. Organ	121	2		E.Organ
044	Organ 3	121	0	19	E.Organ
045	Church Org 1	121	0	20	Pipe Organ
046	Church Org 2	121	1		Pipe Organ
047	Church Org 3	121	2		Pipe Organ
048	Reed Organ	121	0	21	Reed Organ
049	Puff Organ	121	1		Pipe Organ
050	Accordion Fr	121	0	22	Accordion
051	Accordion It	121	1		Accordion

#	Tone Name	MSB	LSB	PC	Category
052	Harmonica	121	0	23	Harmonica
053	Bandoneon	121	0	24	Accordion
054	Nylon Gtr 1	121	0	25	Ac.Guitar
055	Ukulele	121	1		Ac.Guitar
056	Nylon Gtr 1o	121	2		Ac.Guitar
057	Nylon Gtr 2	121	3		Ac.Guitar
058	Steel-str.Gt	121	0	26	Ac.Guitar
059	12-str. Gtr	121	1		Ac.Guitar
060	Mandolin	121	2		Plucked/Stroke
061	Steel + Body	121	3		Ac.Guitar
062	Jazz Guitar	121	0	27	El.Guitar
063	Pedal Steel	121	1		El.Guitar
064	Clean Guitar	121	0	28	El.Guitar
065	Chorus Gtr	121	1		El.Guitar
066	Mid Tone Gtr	121	2		El.Guitar
067	Muted Guitar	121	0	29	El.Guitar
068	Funk Pop	121	1		El.Guitar
069	Funk Guitar	121	2		El.Guitar
070	Jazz Man	121	3		El.Guitar
071	Overdrive Gt	121	0	30	Dist.Guitar
072	Guitar Pinch	121	1		Dist.Guitar
073	DistortionGt	121	0	31	Dist.Guitar
074	Gt Feedback 1	121	1		Dist.Guitar
075	Dist Rtm Gtr	121	2		Dist.Guitar
076	Gt Harmonics	121	0	32	Dist.Guitar
077	Gt Feedback2	121	1		Dist.Guitar
078	Acoustic Bs	121	0	33	Ac.Bass
079	Fingered Bs	121	0	34	El.Bass
080	Finger Slap	121	1		El.Bass
081	Picked Bass	121	0	35	El.Bass
082	Fretless Bs	121	0	36	El.Bass
083	Slap Bass 1	121	0	37	El.Bass
084	Slap Bass 2	121	0	38	El.Bass
085	Synth Bass 1	121	0	39	Synth Bass
086	SynthBass101	121	1		Synth Bass
087	Acid Bass	121	2		Synth Bass
088	Clav Bass	121	3		Synth Bass
089	Hammer Bass	121	4		Synth Bass
090	Synth Bass 2	121	0	40	Synth Bass
091	SynSlap Bass	121	1		Synth Bass
092	Rubber Bass	121	2		Synth Bass
093	Attack Pulse	121	3		Synth Bass
094	Violin	121	0	41	Solo Strings
095	Slow Violin	121	1		Solo Strings
096	Viola	121	0	42	Solo Strings
097	Cello	121	0	43	Solo Strings
098	Contrabass	121	0	44	Solo Strings
099	Tremolo Str	121	0	45	Ensemble Strings
100	PizzicatoStr	121	0	46	Ensemble Strings
101	Harp	121	0	47	Plucked/Stroke
102	Yang Qin	121	1		Plucked/Stroke
103	Timpani	121	0	48	Percussion
104	Strings	121	0	49	Ensemble Strings

#	Tone Name	MSB	LSB	PC	Category
105	Orchestra	121	1		Orchestral
106	Oct Strings	121	2		Ensemble Strings
107	Slow Strings	121	0	50	Ensemble Strings
108	Syn.Strings1	121	0	51	Synth Pad/Strings
109	Syn.Strings3	121	1		Synth Pad/Strings
110	Syn.Strings2	121	0	52	Synth Pad/Strings
111	Choir Aahs	121	0	53	Vox/Choir
112	Chorus Aahs	121	1		Vox/Choir
113	Voice Oohs	121	0	54	Vox/Choir
114	Humming	121	1		Vox/Choir
115	SynVox	121	0	55	Vox/Choir
116	Analog Voice	121	1		Vox/Choir
117	OrchestraHit	121	0	56	Hit
118	Bass Hit	121	1		Hit
119	6th Hit	121	2		Hit
120	Euro Hit	121	3		Hit
121	Trumpet	121	0	57	Solo Brass
122	Dark Trumpet	121	1		Solo Brass
123	Trombone 1	121	0	58	Solo Brass
124	Trombone 2	121	1		Solo Brass
125	Bright Tb	121	2		Solo Brass
126	Tuba	121	0	59	Solo Brass
127	MuteTrumpet1	121	0	60	Solo Brass
128	MuteTrumpet2	121	1		Solo Brass
129	F.Horn Sect	121	0	61	Ensemble Brass
130	French Horn	121	1		Solo Brass
131	Brass 1	121	0	62	Ensemble Brass
132	Brass 2	121	1		Ensemble Brass
133	Synth Brass1	121	0	63	Synth Brass
134	JP Brass	121	1		Synth Brass
135	Oct SynBrass	121	2		Synth Brass
136	Jump Brass	121	3		Synth Brass
137	Synth Brass2	121	0	64	Synth Brass
138	SynBrass sfz	121	1		Synth Brass
139	Velo Brass	121	2		Synth Brass
140	Soprano Sax	121	0	65	Sax
141	Alto Sax	121	0	66	Sax
142	Tenor Sax	121	0	67	Sax
143	Baritone Sax	121	0	68	Sax
144	Oboe	121	0	69	Wind
145	English Horn	121	0	70	Wind
146	Bassoon	121	0	71	Wind
147	Clarinet	121	0	72	Wind
148	Piccolo	121	0	73	Flute
149	Flute	121	0	74	Flute
150	Recorder	121	0	75	Recorder
151	Pan Flute	121	0	76	Flute
152	Bottle Blow	121	0	77	Flute
153	Shakuhachi	121	0	78	Flute
154	Whistle	121	0	79	Recorder
155	Ocarina	121	0	80	Recorder
156	Square Wave	121	0	81	Synth Lead
157	MG Square	121	1		Synth Lead

#	Tone Name	MSB	LSB	PC	Category
158	2600 Sine	121	2		Synth Lead
159	Saw Wave	121	0	82	Synth Lead
160	OB2 Saw	121	1		Synth Lead
161	Doctor Solo	121	2		Synth Lead
162	Natural Lead	121	3		Synth Lead
163	SequencedSaw	121	4		Synth Seq/Pop
164	Syn.Calliope	121	0	83	Synth Lead
165	Chiffer Lead	121	0	84	Synth Lead
166	Charang	121	0	85	Synth Lead
167	Wire Lead	121	1		Synth Lead
168	Solo Vox	121	0	86	Synth Lead
169	5th Saw Wave	121	0	87	Synth Lead
170	Bass & Lead	121	0	88	Synth Lead
171	Delayed Lead	121	1		Synth Lead
172	Fantasia	121	0	89	Synth Bellpad
173	Warm Pad	121	0	90	Synth Pad/Strings
174	Sine Pad	121	1		Synth Pad/Strings
175	Poly Synth	121	0	91	Synth PolyKey
176	Space Voice	121	0	92	Vox/Choir
177	Itopia	121	1		Vox/Choir
178	Bowed Glass	121	0	93	Synth Pad/Strings
179	Metal Pad	121	0	94	Synth Pad/Strings
180	Halo Pad	121	0	95	Synth Pad/Strings
181	Sweep Pad	121	0	96	Synth Pad/Strings
182	Ice Rain	121	0	97	Synth Bellpad
183	Soundtrack	121	0	98	Synth Pad/Strings
184	Crystal	121	0	99	Bell
185	Syn Mallet	121	1		Synth PolyKey
186	Atmosphere	121	0	100	Synth Bellpad
187	Brightness	121	0	101	Synth Bellpad
188	Goblin	121	0	102	Synth FX
189	Echo Drops	121	0	103	Synth FX
190	Echo Bell	121	1		Synth FX
191	Echo Pan	121	2		Synth Seq/Pop
192	Star Theme	121	0	104	Synth Pad/Strings
193	Sitar 1	121	0	105	Plucked/Stroke
194	Sitar 2	121	1		Plucked/Stroke
195	Banjo	121	0	106	Plucked/Stroke
196	Shamisen	121	0	107	Plucked/Stroke
197	Koto	121	0	108	Plucked/Stroke
198	Taisho Koto	121	1		Plucked/Stroke
199	Kalimba	121	0	109	Plucked/Stroke
200	Bagpipe	121	0	110	Wind
201	Fiddle	121	0	111	Solo Strings
202	Shanai	121	0	112	Wind
203	Tinkle Bell	121	0	113	Bell
204	Agogo	121	0	114	Percussion
205	Steel Drums	121	0	115	Mallet
206	Woodblock	121	0	116	Percussion
207	Castanets	121	1		Percussion
208	Taiko	121	0	117	Percussion
209	Concert BD	121	1		Percussion
210	Melo. Tom 1	121	0	118	Percussion

#	Tone Name	MSB	LSB	PC	Category
211	Melo. Tom 2	121	1		Percussion
212	Synth Drum	121	0	119	Percussion
213	808 Tom	121	1		Percussion
214	Elec Perc	121	2		Percussion
215	Reverse Cymb	121	0	120	Percussion
216	Gt FretNoise	121	0	121	Ac.Guitar
217	Gt Cut Noise	121	1		El.Guitar
218	String Slap	121	2		Ac.Bass
219	Breath Noise	121	0	122	Flute
220	Fl.Key Click	121	1		Flute
221	Seashore	121	0	123	Sound FX
222	Rain	121	1		Sound FX
223	Thunder	121	2		Sound FX
224	Wind	121	3		Sound FX
225	Stream	121	4		Sound FX
226	Bubble	121	5		Sound FX
227	Bird 1	121	0	124	Sound FX
228	Dog	121	1		Sound FX
229	Horse Gallop	121	2		Sound FX
230	Bird 2	121	3		Sound FX
231	Telephone 1	121	0	125	Sound FX
232	Telephone 2	121	1		Sound FX
233	DoorCreaking	121	2		Sound FX
234	Door	121	3		Sound FX
235	Scratch	121	4		Sound FX
236	Wind Chimes	121	5		Sound FX
237	Helicopter	121	0	126	Sound FX
238	Car Engine	121	1		Sound FX
239	Car Stop	121	2		Sound FX
240	Car Pass	121	3		Sound FX
241	Car Crash	121	4		Sound FX
242	Siren	121	5		Sound FX
243	Train	121	6		Sound FX
244	Jetplane	121	7		Sound FX
245	Starship	121	8		Sound FX
246	Burst Noise	121	9		Sound FX
247	Applause	121	0	127	Sound FX
248	Laughing	121	1		Sound FX
249	Screaming	121	2		Sound FX
250	Punch	121	3		Sound FX
251	Heart Beat	121	4		Sound FX
252	Footsteps	121	5		Sound FX
253	Gun Shot	121	0	128	Sound FX
254	Machine Gun	121	1		Sound FX
255	Laser Gun	121	2		Sound FX
256	Explosion	121	3		Sound FX

## PRESET group/ プリセット・グループ

#	Tone Name	MSB	LSB	PC	Category
001	St.Piano 1	87	0	1	Ac.Piano
002	St.Piano 2	87	0	2	Ac.Piano
003	St.Piano 3	87	0	3	Ac.Piano
004	St.Piano 4	87	0	4	Ac.Piano
005	St.Piano 5	87	0	5	Ac.Piano
006	Brite Piano	87	0	6	Ac.Piano
007	Stage Piano	87	0	7	Ac.Piano
008	Honky Tonk	87	0	8	Ac.Piano
009	Pop Piano 1	87	0	9	Pop Piano
010	Pop Piano 2	87	0	10	Pop Piano
011	Pop Piano 3	87	0	11	Pop Piano
012	Stage EP 1	87	0	12	E.Piano1
013	Stage EP 2	87	0	13	E.Piano1
014	Stage EP Trm	87	0	14	E.Piano1
015	Tremolo EP 1	87	0	15	E.Piano1
016	E.Piano 3	87	0	16	E.Piano1
017	E.Piano 4	87	0	17	E.Piano1
018	E.Piano 5	87	0	18	E.Piano1
019	E.Piano 6	87	0	19	E.Piano1
020	E.Piano 7	87	0	20	E.Piano1
021	E.Piano 8	87	0	21	E.Piano1
022	Dyno EP	87	0	22	E.Piano1
023	Dyno EP Trm	87	0	23	E.Piano1
024	Tremolo EP 2	87	0	24	E.Piano1
025	Back2the60s	87	0	25	E.Piano1
026	Tine EP	87	0	26	E.Piano1
027	SA EP 1	87	0	27	E.Piano1
028	SA EP 2	87	0	28	E.Piano1
029	Psy EP	87	0	29	E.Piano1
030	Wurly EP	87	0	30	E.Piano1
031	Wurly EP Trm	87	0	31	E.Piano1
032	Curly Wurly	87	0	32	E.Piano1
033	Super Wurly	87	0	33	E.Piano1
034	EP Legend 3	87	0	34	E.Piano2
035	EP Belle	87	0	35	E.Piano2
036	80's EP	87	0	36	E.Piano2
037	FM EP 1	87	0	37	E.Piano2
038	FM EP 2	87	0	38	E.Piano2
039	Sinus EP	87	0	39	E.Piano2
040	Spirit Tines	87	0	40	E.Piano2
041	Harpsichord2	87	0	41	Harpsichord
042	Clav 2	87	0	42	Clav
043	Pulse Clav 2	87	0	43	Clav
044	Sweepin Clav	87	0	44	Clav
045	Analog Clav	87	0	45	Clav
046	Biting Clav	87	0	46	Clav
047	Pulse Clv St	87	0	47	Clav
048	FM Sparkles	87	0	48	Bell

#	Tone Name	MSB	LSB	PC	Category
049	FM Syn Bell	87	0	49	Bell
050	FM Heaven	87	0	50	Bell
051	D50 Fantasy	87	0	51	Synth Bellpad
052	D50 Bell	87	0	52	Synth Bellpad
053	Dreaming Bel	87	0	53	Bell
054	Analog Bell	87	0	54	Bell
055	Music Box 2	87	0	55	Bell
056	Music Bells	87	0	56	Bell
057	Kalimbells	87	0	57	Bell
058	Bell 1	87	0	58	Bell
059	Bell 2	87	0	59	Bell
060	Icy Keys	87	0	60	Bell
061	Toy Box	87	0	61	Mallet
062	Carillon 2	87	0	62	Bell
063	Tower Bell	87	0	63	Bell
064	TubularBell2	87	0	64	Bell
065	Bell Ring	87	0	65	Bell
066	Dreambell	87	0	66	Synth Bellpad
067	Dreaming Box	87	0	67	Synth Bellpad
068	Vibraphone 2	87	0	68	Mallet
069	VibraphoneTr	87	0	69	Mallet
070	Tremolo Vib	87	0	70	Mallet
071	Marimba 2	87	0	71	Mallet
072	Marimba 3	87	0	72	Mallet
073	Steel Drums2	87	0	73	Mallet
074	Xylophone 2	87	0	74	Mallet
075	Xylophone 3	87	0	75	Mallet
076	Ethno Keys	87	0	76	Mallet
077	Rock Organ 1	87	0	77	E.Organ
078	Rock Organ 2	87	0	78	E.Organ
079	Rock Organ 3	87	0	79	E.Organ
080	Rock Organ 4	87	0	80	E.Organ
081	Rock Organ 5	87	0	81	E.Organ
082	RotaryOrgan1	87	0	82	E.Organ
083	RotaryOrgan2	87	0	83	E.Organ
084	Perc.Organ 2	87	0	84	E.Organ
085	Perc.Organ 3	87	0	85	E.Organ
086	Perc.Organ 4	87	0	86	E.Organ
087	E.Organ 1	87	0	87	E.Organ
088	E.Organ 2	87	0	88	E.Organ
089	E.Organ 3	87	0	89	E.Organ
090	E.Organ 4	87	0	90	E.Organ
091	E.Organ 5	87	0	91	E.Organ
092	E.Organ 6	87	0	92	E.Organ
093	E.Organ 7	87	0	93	E.Organ
094	70's E.Org 1	87	0	94	E.Organ
095	70's E.Org 2	87	0	95	E.Organ
096	Grand Pipes	87	0	96	Pipe Organ
097	AccordionIt2	87	0	97	Accordion
098	Musette	87	0	98	Accordion
099	Vodkakordion	87	0	99	Accordion

#	Tone Name	MSB	LSB	PC	Category
100	Harmonica 2	87	0	100	Harmonica
101	Nylon Gtr 3	87	0	101	Ac.Guitar
102	Nylon Gtr 4	87	0	102	Ac.Guitar
103	Nylon Gtr 5	87	0	103	Ac.Guitar
104	Nylon Gtr 6	87	0	104	Ac.Guitar
105	Wet NylN Gtr	87	0	105	Ac.Guitar
106	Ukulele 2	87	0	106	Ac.Guitar
107	Folk Gtr 1	87	0	107	Ac.Guitar
108	Folk Gtr 2	87	0	108	Ac.Guitar
109	Folk Gtr 3	87	0	109	Ac.Guitar
110	Latin Gtr	87	0	110	Ac.Guitar
111	Santur 2	87	0	111	Plucked/Stroke
112	Santur 3	87	0	112	Plucked/Stroke
113	Aerial Harp	87	0	113	Plucked/Stroke
114	LostParadise	87	0	114	Plucked/Stroke
115	Sitar 3	87	0	115	Plucked/Stroke
116	Indian Frtls	87	0	116	Plucked/Stroke
117	Clean Gtr 1	87	0	117	El.Guitar
118	Clean Gtr 2	87	0	118	El.Guitar
119	Clean Gtr 3	87	0	119	El.Guitar
120	Jazz Guitar2	87	0	120	El.Guitar
121	Pick E.Gtr	87	0	121	El.Guitar
122	Funk Guitar2	87	0	122	El.Guitar
123	Wet E.Gtr	87	0	123	El.Guitar
124	OverdriveGt2	87	0	124	Dist.Guitar
125	Dist Gtr 1	87	0	125	Dist.Guitar
126	Dist Gtr 2	87	0	126	Dist.Guitar
127	Dist Gtr 3	87	0	127	Dist.Guitar
128	Acoustic Bs2	87	0	128	Ac.Bass
129	Acoustic Bs3	87	1	1	Ac.Bass
130	Fingered Bs2	87	1	2	El.Bass
131	Fingered Bs3	87	1	3	El.Bass
132	Fingered Bs4	87	1	4	El.Bass
133	Pick Bass	87	1	5	El.Bass
134	FretlessBs 2	87	1	6	El.Bass
135	FretlessBs 3	87	1	7	El.Bass
136	Finger Slap2	87	1	8	El.Bass
137	Return2Base!	87	1	9	El.Bass
138	MG Bass 1	87	1	10	Synth Bass
139	MG Bass 2	87	1	11	Synth Bass
140	MG Bass 3	87	1	12	Synth Bass
141	Modular Bs 1	87	1	13	Synth Bass
142	Modular Bs 2	87	1	14	Synth Bass
143	PWM Bass 1	87	1	15	Synth Bass
144	PWM Bass 2	87	1	16	Synth Bass
145	Big Mini	87	1	17	Synth Bass
146	Fat Analog	87	1	18	Synth Bass
147	Spike Bass	87	1	19	Synth Bass
148	SH Bass	87	1	20	Synth Bass
149	Intrusive Bs	87	1	21	Synth Bass
150	Synth Bass 3	87	1	22	Synth Bass

#	Tone Name	MSB	LSB	PC	Category
151	Synth Bass 4	87	1	23	Synth Bass
152	Synth Bass 5	87	1	24	Synth Bass
153	Synth Bass 6	87	1	25	Synth Bass
154	Synth Bass 7	87	1	26	Synth Bass
155	Synth Bass 8	87	1	27	Synth Bass
156	Synth Bass 9	87	1	28	Synth Bass
157	Synth Bass10	87	1	29	Synth Bass
158	Synth Bass11	87	1	30	Synth Bass
159	Synth Bass12	87	1	31	Synth Bass
160	Synth Bass13	87	1	32	Synth Bass
161	Synth Bass14	87	1	33	Synth Bass
162	Reso Bass 1	87	1	34	Synth Bass
163	Reso Bass 2	87	1	35	Synth Bass
164	Reso Bass 3	87	1	36	Synth Bass
165	Reso Bass 4	87	1	37	Synth Bass
166	Reso Bass 5	87	1	38	Synth Bass
167	Reso Bass 6	87	1	39	Synth Bass
168	Reso Bass 7	87	1	40	Synth Bass
169	Reso Bass 8	87	1	41	Synth Bass
170	Acid Bass 2	87	1	42	Synth Bass
171	Acid Bass 3	87	1	43	Synth Bass
172	Acid Bass 4	87	1	44	Synth Bass
173	Alpha Bass 1	87	1	45	Synth Bass
174	TB Bass 1	87	1	46	Synth Bass
175	TB Bass 2	87	1	47	Synth Bass
176	Alpha Bass 2	87	1	48	Synth Bass
177	Alpha ResoBs	87	1	49	Synth Bass
178	Nu Saw Bass	87	1	50	Synth Bass
179	Nu RnB SawBs	87	1	51	Synth Bass
180	Storm Bass	87	1	52	Synth Bass
181	Detune Bass	87	1	53	Synth Bass
182	Gashed Bass	87	1	54	Synth Bass
183	Hi-Energy Bs	87	1	55	Synth Bass
184	Pedal Bass 1	87	1	56	Synth Bass
185	Monster Bass	87	1	57	Synth Bass
186	JunoSqr Bs 1	87	1	58	Synth Bass
187	JunoSqr Bs 2	87	1	59	Synth Bass
188	101 Bass	87	1	60	Synth Bass
189	106 Bass 1	87	1	61	Synth Bass
190	106 Bass 2	87	1	62	Synth Bass
191	Compu Bass 1	87	1	63	Synth Bass
192	Compu Bass 2	87	1	64	Synth Bass
193	Triangle Bs	87	1	65	Synth Bass
194	Muffled Bass	87	1	66	Synth Bass
195	Garage Bass	87	1	67	Synth Bass
196	TransistorBs	87	1	68	Synth Bass
197	Fazee Bass	87	1	69	Synth Bass
198	Mood Strings	87	1	70	Ensemble Strings
199	Strings 2	87	1	71	Ensemble Strings
200	Strings 3	87	1	72	Ensemble Strings
201	Strings 4	87	1	73	Ensemble Strings

#	Tone Name	MSB	LSB	PC	Category
202	Strings 5	87	1	74	Ensemble Strings
203	Stage Str 1	87	1	75	Ensemble Strings
204	Stage Str 2	87	1	76	Ensemble Strings
205	Pop Str	87	1	77	Ensemble Strings
206	Marc.Str	87	1	78	Ensemble Strings
207	StringsStacc	87	1	79	Ensemble Strings
208	Pizz 1	87	1	80	Ensemble Strings
209	Pizz 2	87	1	81	Ensemble Strings
210	TapeStrings1	87	1	82	Ensemble Strings
211	TapeStrings2	87	1	83	Ensemble Strings
212	Hybrid Str	87	1	84	Ensemble Strings
213	Violin 2	87	1	85	Solo Strings
214	Orc.Unison 1	87	1	86	Orchestral
215	Orc.Unison 2	87	1	87	Orchestral
216	Bassoon 2	87	1	88	Wind
217	Flute 2	87	1	89	Flute
218	Pan Flute 2	87	1	90	Flute
219	Pan Pipes 1	87	1	91	Flute
220	Shakuhachi 2	87	1	92	Flute
221	Ocarina 2	87	1	93	Recorder
222	Trumpet 2	87	1	94	Solo Brass
223	Fr.Horn	87	1	95	Solo Brass
224	Brass 3	87	1	96	Ensemble Brass
225	Brass 4	87	1	97	Ensemble Brass
226	Brass 5	87	1	98	Ensemble Brass
227	Brass 6	87	1	99	Ensemble Brass
228	80s Brass 1	87	1	100	Synth Brass
229	80s Brass 2	87	1	101	Synth Brass
230	80s Brass 3	87	1	102	Synth Brass
231	80s Brass 4	87	1	103	Synth Brass
232	80s Brass 5	87	1	104	Synth Brass
233	80s Brass 6	87	1	105	Synth Brass
234	80s Brass 7	87	1	106	Synth Brass
235	80s Brass 8	87	1	107	Synth Brass
236	Soft SynBrs1	87	1	108	Synth Brass
237	Warm SynBrs	87	1	109	Synth Brass
238	Brite SynBrs	87	1	110	Synth Brass
239	Express Brs	87	1	111	Synth Brass
240	EuroExpress1	87	1	112	Synth Brass
241	JP Brass 1	87	1	113	Synth Brass
242	Juno Brass	87	1	114	Synth Brass
243	Ox Brass	87	1	115	Synth Brass
244	Reso Brass	87	1	116	Synth Brass
245	Wide SynBrs	87	1	117	Synth Brass
246	Soft SynBrs2	87	1	118	Synth Brass
247	JP Brass 2	87	1	119	Synth Brass
248	106 Brass	87	1	120	Synth Brass
249	Octa Brass	87	1	121	Synth Brass
250	Poly Brass 1	87	1	122	Synth Brass
251	Dual Saw Brs	87	1	123	Synth Brass
252	Soprano Sax2	87	1	124	Sax

#	Tone Name	MSB	LSB	PC	Category
253	BreathyTenor	87	1	125	Sax
254	Tenor Sax 2	87	1	126	Sax
255	Saw Lead 1	87	1	127	Synth Lead
256	Saw Lead 2	87	1	128	Synth Lead
257	Saw Lead 3	87	2	1	Synth Lead
258	Saw Lead 4	87	2	2	Synth Lead
259	Saw Lead 5	87	2	3	Synth Lead
260	Saw Lead 6	87	2	4	Synth Lead
261	Saw Lead 7	87	2	5	Synth Lead
262	Saw Lead 8	87	2	6	Synth Lead
263	Saw Lead 9	87	2	7	Synth Lead
264	GR300 Lead 1	87	2	8	Synth Lead
265	GR300 Lead 2	87	2	9	Synth Lead
266	Classic GR	87	2	10	Synth Lead
267	Bright GR	87	2	11	Synth Lead
268	Fat GR Lead	87	2	12	Synth Lead
269	MODified Ld	87	2	13	Synth Lead
270	Syn Lead 1	87	2	14	Synth Lead
271	Syn Lead 2	87	2	15	Synth Lead
272	Syn Lead 3	87	2	16	Synth Lead
273	Syn Lead 4	87	2	17	Synth Lead
274	Syn Lead 5	87	2	18	Synth Lead
275	Syn Lead 6	87	2	19	Synth Lead
276	Syn Lead 7	87	2	20	Synth Lead
277	Pro Fat Ld 1	87	2	21	Synth Lead
278	JupiterLead1	87	2	22	Synth Lead
279	JupiterLead2	87	2	23	Synth Lead
280	Porta Lead	87	2	24	Synth Lead
281	Classic Lead	87	2	25	Synth Lead
282	On Air	87	2	26	Synth Lead
283	Pro Fat Ld 2	87	2	27	Synth Lead
284	Wormy Lead	87	2	28	Synth Lead
285	Waspy Lead	87	2	29	Synth Lead
286	Brite ResoLd	87	2	30	Synth Lead
287	Brass Lead	87	2	31	Synth Lead
288	Legato Tkno	87	2	32	Synth Lead
289	Follow Me	87	2	33	Synth Lead
290	Octa Juice	87	2	34	Synth Lead
291	Juicy Jupe	87	2	35	Synth Lead
292	Octa Saw	87	2	36	Synth Lead
293	Vintager 1	87	2	37	Synth Lead
294	Vintager 2	87	2	38	Synth Lead
295	Sync Lead	87	2	39	Synth Lead
296	Octa Sync	87	2	40	Synth Lead
297	Leading Sync	87	2	41	Synth Lead
298	A Leader	87	2	42	Synth Lead
299	Hot Coffee	87	2	43	Synth Lead
300	Hot Sync	87	2	44	Synth Lead
301	Synchro Lead	87	2	45	Synth Lead
302	Space Solo	87	2	46	Synth Lead
303	Squareheads	87	2	47	Synth Lead

#	Tone Name	MSB	LSB	PC	Category
304	Mod Lead	87	2	48	Synth Lead
305	Alpha Spit	87	2	49	Synth Lead
306	Air Lead	87	2	50	Synth Lead
307	Pulstar Lead	87	2	51	Synth Lead
308	Therasaw	87	2	52	Synth Lead
309	Warmy Lead	87	2	53	Synth Lead
310	ResoSawLead	87	2	54	Synth Lead
311	Soft Reso Ld	87	2	55	Synth Lead
312	Reso Lead 1	87	2	56	Synth Lead
313	Reso Lead 2	87	2	57	Synth Lead
314	Reso Lead 3	87	2	58	Synth Lead
315	Reso Lead 4	87	2	59	Synth Lead
316	Reso Lead 5	87	2	60	Synth Lead
317	Juicy Lead	87	2	61	Synth Lead
318	DC Triangle	87	2	62	Synth Lead
319	Soft Lead 1	87	2	63	Synth Lead
320	Soft Lead 2	87	2	64	Synth Lead
321	Soft Lead 3	87	2	65	Synth Lead
322	Soft Lead 4	87	2	66	Synth Lead
323	Soft Lead 5	87	2	67	Synth Lead
324	Soft Lead 6	87	2	68	Synth Lead
325	Soft Lead 7	87	2	69	Synth Lead
326	Soft Lead 8	87	2	70	Synth Lead
327	Soft Lead 9	87	2	71	Synth Lead
328	Soft Lead 10	87	2	72	Synth Lead
329	Tri Lead	87	2	73	Synth Lead
330	Pulse Lead 1	87	2	74	Synth Lead
331	Pulse Lead 2	87	2	75	Synth Lead
332	Simple Tri	87	2	76	Synth Lead
333	Simple Sine	87	2	77	Synth Lead
334	Whistle Ld 1	87	2	78	Synth Lead
335	Whistle Ld 2	87	2	79	Synth Lead
336	Square Pipe	87	2	80	Synth Lead
337	CosmicDrops1	87	2	81	Synth Lead
338	Spooky Lead	87	2	82	Synth Lead
339	Pure Lead	87	2	83	Synth Lead
340	303 NRG	87	2	84	Synth Lead
341	Round SQR	87	2	85	Synth Lead
342	Brite SQR	87	2	86	Synth Lead
343	Square SAW	87	2	87	Synth Lead
344	Simple SQR	87	2	88	Synth Lead
345	Sqr Lead	87	2	89	Synth Lead
346	Atk Lead	87	2	90	Synth Lead
347	Octa Square	87	2	91	Synth Lead
348	CS Lead	87	2	92	Synth Lead
349	Mini Growl	87	2	93	Synth Lead
350	Hoover Again	87	2	94	Synth Lead
351	Tranceformer	87	2	95	Synth Lead
352	Dream Trance	87	2	96	Synth PolyKey
353	Dream Saws	87	2	97	Synth PolyKey
354	Dream Pulse	87	2	98	Synth PolyKey

#	Tone Name	MSB	LSB	PC	Category
355	Trance Synth	87	2	99	Synth PolyKey
356	Trancy	87	2	100	Synth PolyKey
357	Trance Keys	87	2	101	Synth PolyKey
358	Trance Saws	87	2	102	Synth PolyKey
359	Auto Trance1	87	2	103	Synth PolyKey
360	Super Saws 1	87	2	104	Synth PolyKey
361	Analog Saws	87	2	105	Synth PolyKey
362	Uni-G	87	2	106	Synth PolyKey
363	Digitaless	87	2	107	Synth PolyKey
364	Bustranza	87	2	108	Synth PolyKey
365	Jump Poly	87	2	109	Synth Brass
366	Super Saws 2	87	2	110	Synth PolyKey
367	Poly Synth 2	87	2	111	Synth PolyKey
368	Poly Synth 3	87	2	112	Synth PolyKey
369	Poly Synth 4	87	2	113	Synth PolyKey
370	Poly Synth 5	87	2	114	Synth PolyKey
371	Poly Synth 6	87	2	115	Synth PolyKey
372	Poly Synth 7	87	2	116	Synth PolyKey
373	Juno Saw Key	87	2	117	Synth PolyKey
374	Saw Key 1	87	2	118	Synth PolyKey
375	Saw Key 2	87	2	119	Synth PolyKey
376	Waspy Synth	87	2	120	Synth PolyKey
377	Juno SQR	87	2	121	Synth Lead
378	Vintage Key	87	2	122	Synth PolyKey
379	Ju-D Fifths	87	2	123	Synth PolyKey
380	Reso Key 1	87	2	124	Synth Brass
381	Reso Key 2	87	2	125	Synth PolyKey
382	Fat Synth	87	2	126	Synth PolyKey
383	EuroExpress2	87	2	127	Synth Brass
384	DOC Stack	87	2	128	Synth PolyKey
385	2 Saws	87	3	1	Synth PolyKey
386	Hi Saw Band	87	3	2	Synth PolyKey
387	Brite Synth	87	3	3	Synth PolyKey
388	PWM Pad 1	87	3	4	Synth PolyKey
389	Ox Synth	87	3	5	Synth Brass
390	RAVtune	87	3	6	Synth PolyKey
391	Analog Seq	87	3	7	Synth Seq/Pop
392	Seq Pop	87	3	8	Synth Seq/Pop
393	Periscope	87	3	9	Synth Seq/Pop
394	Major 7	87	3	10	Synth Seq/Pop
395	Heaven Key	87	3	11	Synth PolyKey
396	Heaven Pad 1	87	3	12	Synth Pad/Strings
397	Heaven Pad 2	87	3	13	Synth Pad/Strings
398	Dreamvox 1	87	3	14	Vox/Choir
399	Dreamvox 2	87	3	15	Vox/Choir
400	Dreamheaven	87	3	16	Synth Pad/Strings
401	Air Key 1	87	3	17	Synth Bellpad
402	Sweet Keys	87	3	18	Synth Bellpad
403	Pipe Key	87	3	19	Synth PolyKey
404	Soft Bell	87	3	20	Synth Bellpad
405	Air Key 2	87	3	21	Synth Bellpad



#	Tone Name	MSB	LSB	PC	Category
406	Oct Heaven	87	3	22	Synth Pad/Strings
407	Stacc Heaven	87	3	23	Synth Bellpad
408	DigitalDream	87	3	24	Synth Bellpad
409	Analog Dream	87	3	25	Synth Bellpad
410	Harp Pad	87	3	26	Synth Bellpad
411	Sitar Pad	87	3	27	Plucked/Stroke
412	Soft Pad 1	87	3	28	Synth Pad/Strings
413	Soft Pad 2	87	3	29	Synth Pad/Strings
414	Soft Pad 3	87	3	30	Synth Pad/Strings
415	Soft Pad 4	87	3	31	Synth Pad/Strings
416	Soft Pad 5	87	3	32	Synth Pad/Strings
417	Soft Pad 6	87	3	33	Synth Pad/Strings
418	Soft Pad 7	87	3	34	Synth Pad/Strings
419	Soft Pad 8	87	3	35	Synth Pad/Strings
420	Soft Pad 9	87	3	36	Synth Pad/Strings
421	Soft Pad 10	87	3	37	Synth Pad/Strings
422	VintageStr 1	87	3	38	Synth Pad/Strings
423	VintageStr 2	87	3	39	Synth Pad/Strings
424	VintageStr 3	87	3	40	Synth Pad/Strings
425	VintageStr 4	87	3	41	Synth Pad/Strings
426	VintageStr 5	87	3	42	Synth Pad/Strings
427	VintageStr 6	87	3	43	Synth Pad/Strings
428	VintageStr 7	87	3	44	Synth Pad/Strings
429	JX Strings	87	3	45	Synth Pad/Strings
430	JP Strings 1	87	3	46	Synth Pad/Strings
431	JP Strings 2	87	3	47	Synth Pad/Strings
432	106 Strings	87	3	48	Synth Pad/Strings
433	PWM Str 1	87	3	49	Synth Pad/Strings
434	PWM Str 2	87	3	50	Synth Pad/Strings
435	Fading Str	87	3	51	Synth Pad/Strings
436	ParadisePad	87	3	52	Synth Pad/Strings
437	80s Strings	87	3	53	Synth Pad/Strings
438	Stringship	87	3	54	Synth Pad/Strings
439	Airy Pad	87	3	55	Synth Pad/Strings
440	Neo RS-202	87	3	56	Synth Pad/Strings
441	Sawtooth Str	87	3	57	Synth Pad/Strings
442	Pulse Pad	87	3	58	Synth Pad/Strings
443	Hollow Pad 1	87	3	59	Synth Pad/Strings
444	WarmHeaven 1	87	3	60	Synth Pad/Strings
445	WarmHeaven 2	87	3	61	Synth Pad/Strings
446	Heaven Pad 3	87	3	62	Synth Pad/Strings
447	Heaven Pad 4	87	3	63	Synth Pad/Strings
448	FineWinePad1	87	3	64	Synth Pad/Strings
449	FineWinePad2	87	3	65	Synth Pad/Strings
450	5th Pad 1	87	3	66	Synth Pad/Strings
451	5th Pad 2	87	3	67	Synth Pad/Strings
452	Nu Epic Pad	87	3	68	Synth Pad/Strings
453	Angelis Pad	87	3	69	Synth Pad/Strings
454	TrnsSweepPad	87	3	70	Synth Pad/Strings
455	Giant Sweep	87	3	71	Synth Pad/Strings
456	Voyager	87	3	72	Synth Pad/Strings

#	Tone Name	MSB	LSB	PC	Category
457	Digital Pad	87	3	73	Synth Pad/Strings
458	NuSoundtrack	87	3	74	Synth Pad/Strings
459	Xadecimal	87	3	75	Synth Pad/Strings
460	PanninFormnt	87	3	76	Pulsating
461	Fairy's Song	87	3	77	Pulsating
462	Atmospherics	87	3	78	Pulsating
463	Strobe Pad	87	3	79	Synth Pad/Strings
464	StrobeBell 1	87	3	80	Pulsating
465	StrobeBell 2	87	3	81	Pulsating
466	Flying Pad 1	87	3	82	Pulsating
467	Flying Pad 2	87	3	83	Pulsating
468	Flying Pad 3	87	3	84	Pulsating
469	Flying Pad 4	87	3	85	Pulsating
470	Flying Pad 5	87	3	86	Pulsating
471	Jazz Scat 1	87	3	87	Scat
472	Jazz Scat 2	87	3	88	Scat
473	Choir Pad	87	3	89	Vox/Choir
474	Angels Choir	87	3	90	Vox/Choir
475	Aerial Choir	87	3	91	Vox/Choir
476	Doo Pad	87	3	92	Vox/Choir
477	Humming 2	87	3	93	Vox/Choir
478	Humming 3	87	3	94	Vox/Choir
479	Gospel Hum	87	3	95	Vox/Choir
480	Vox Pad 1	87	3	96	Vox/Choir
481	Vox Pad 2	87	3	97	Vox/Choir
482	80s Vox	87	3	98	Vox/Choir
483	SynVox 2	87	3	99	Vox/Choir
484	SynVox 3	87	3	100	Vox/Choir
485	Mini Vox	87	3	101	Vox/Choir
486	Chipmunk	87	3	102	Vox/Choir
487	Sample Opera	87	3	103	Vox/Choir
488	Sad Ceremony	87	3	104	Vox/Choir
489	Enigmatic	87	3	105	Synth FX
490	Planetz	87	3	106	Synth FX
491	Shimmer Pad	87	3	107	Synth FX
492	Sci-Fi	87	3	108	Synth FX
493	ResoSweep Dn	87	3	109	Synth FX
494	Jet Noise	87	3	110	Synth FX
495	Brandish	87	3	111	Synth FX
496	909 Fx	87	3	112	Synth FX
497	Zap	87	3	113	Synth FX
498	PolySweep Nz	87	3	114	Synth FX
499	Passing By	87	3	115	Synth FX
500	Lazer Points	87	3	116	Synth FX
501	CosmicDrops2	87	3	117	Synth FX
502	Crystal Fx	87	3	118	Synth FX
503	Crystal Ice	87	3	119	Synth FX
504	Mad Noise	87	3	120	Synth FX
505	Robot Sci-Fi	87	3	121	Synth FX
506	Computer 1	87	3	122	Synth FX
507	Computer 2	87	3	123	Synth FX

#	Tone Name	MSB	LSB	PC	Category
508	S&H Noise	87	3	124	Synth FX
509	S&H Ramp	87	3	125	Synth FX
510	S&H PWM	87	3	126	Synth FX
511	S&H Saw 1	87	3	127	Synth FX
512	S&H Saw 2	87	3	128	Synth FX
513	Org Bell	87	4	1	Synth Bellpad
514	Soft StIDrm	87	4	2	Mallet
515	Jazz Vib	87	4	3	Mallet
516	BsMarimba 1	87	4	4	Mallet
517	BsMarimba 2	87	4	5	Mallet
518	Sine Mallet	87	4	6	Mallet
519	Ana Organ 1	87	4	7	E.Organ
520	Ana Organ 2	87	4	8	E.Organ
521	Ana Organ 3	87	4	9	E.Organ
522	Ana Organ 4	87	4	10	E.Organ
523	Ana Organ 5	87	4	11	E.Organ
524	Pedal Steel2	87	4	12	El.Guitar
525	TB Bass 3	87	4	13	Synth Bass
526	TB Bass 4	87	4	14	Synth Bass
527	Acid Bass 5	87	4	15	Synth Bass
528	Acid Bass 6	87	4	16	Synth Bass
529	Acid Bass 7	87	4	17	Synth Bass
530	Brite Bass	87	4	18	Synth Bass
531	Pedal Bass 2	87	4	19	Synth Bass
532	Saw Bass	87	4	20	Synth Bass
533	Reso Bass 9	87	4	21	Synth Bass
534	Reso Bass 10	87	4	22	Synth Bass
535	Sub Bass	87	4	23	Synth Bass
536	Ramp Bass	87	4	24	Synth Bass
537	Fat Bass 1	87	4	25	Synth Bass
538	Fat Bass 2	87	4	26	Synth Bass
539	Fat Bass 3	87	4	27	Synth Bass
540	Flat Bass	87	4	28	Synth Bass
541	Electro Rubb	87	4	29	Synth Bass
542	80s Bass	87	4	30	Synth Bass
543	Bright Vln	87	4	31	Solo Strings
544	Bright Vc	87	4	32	Solo Strings
545	Strings 6	87	4	33	Ensemble Strings
546	Hall Strings	87	4	34	Ensemble Strings
547	Full Orc	87	4	35	Orchestral
548	Pan Pipes 2	87	4	36	Flute
549	VintageBrs 1	87	4	37	Synth Brass
550	VintageBrs 2	87	4	38	Synth Brass
551	VintageBrs 3	87	4	39	Synth Brass
552	VintageBrs 4	87	4	40	Synth Brass
553	Poly Brass 2	87	4	41	Synth Brass
554	Pulse Lead 3	87	4	42	Synth Lead
555	Pulse Lead 4	87	4	43	Synth Lead
556	Ramp Lead 1	87	4	44	Synth Lead
557	Ramp Lead 2	87	4	45	Synth Lead
558	Saw Lead 10	87	4	46	Synth Lead

#	Tone Name	MSB	LSB	PC	Category
559	Sine Lead 1	87	4	47	Synth Lead
560	Sine Lead 2	87	4	48	Synth Lead
561	Cheezy Movie	87	4	49	Hit
562	Mod Chord	87	4	50	Hit
563	Housechord	87	4	51	Hit
564	5th Voice	87	4	52	Vox/Choir
565	Juno-D Maj7	87	4	53	Synth Seq/Pop
566	Sweet House	87	4	54	Synth Seq/Pop
567	Detune Saws	87	4	55	Synth Seq/Pop
568	Electrostar	87	4	56	Synth FX
569	Dance Saws1	87	4	57	Synth Lead
570	Resoform	87	4	58	Synth Lead
571	Melodic Drum	87	4	59	Synth Seq/Pop
572	Alpha Said	87	4	60	Synth FX
573	Shroomy	87	4	61	Synth PolyKey
574	Detune Seq	87	4	62	Synth Seq/Pop
575	LoFi Piano	87	4	63	Ac.Piano
576	FX Ramp	87	4	64	Synth FX
577	BUBBLE 1	87	4	65	Synth FX
578	BUBBLE 2	87	4	66	Synth Pad/Strings
579	BUBBLE 3	87	4	67	Synth Pad/Strings
580	Scratch 2	87	4	68	Sound FX
581	AnalogDays 1	87	4	69	Synth PolyKey
582	Dance Saws 2	87	4	70	Synth Lead
583	Sync Key	87	4	71	Synth PolyKey
584	Detune Ramp	87	4	72	Synth PolyKey
585	Reso Saw	87	4	73	Synth PolyKey
586	EuroExpress3	87	4	74	Synth PolyKey
587	Soft PWM Pad	87	4	75	Synth Pad/Strings
588	Org Pad	87	4	76	Synth Pad/Strings
589	Hollow Pad 2	87	4	77	Synth Pad/Strings
590	SavannaPad 1	87	4	78	Synth Pad/Strings
591	SavannaPad 2	87	4	79	Synth Pad/Strings
592	SavannaPad 3	87	4	80	Synth Pad/Strings
593	PWM Str 3	87	4	81	Synth Pad/Strings
594	PWM Pad 2	87	4	82	Synth Pad/Strings
595	Str Machine	87	4	83	Synth Pad/Strings
596	Reso Pad	87	4	84	Synth Pad/Strings
597	BPF Pad	87	4	85	Synth Pad/Strings
598	Sweep Saw	87	4	86	Synth PolyKey
599	Sweep Pad 2	87	4	87	Synth Pad/Strings
600	Sweep Pad 3	87	4	88	Synth Pad/Strings
601	Sweep Pad 4	87	4	89	Synth Pad/Strings
602	Scoop Pad 1	87	4	90	Synth Pad/Strings
603	Scoop Pad 2	87	4	91	Synth Pad/Strings
604	Brite Wine	87	4	92	Synth Pad/Strings
605	Wine Pad	87	4	93	Synth Pad/Strings
606	Sop Vox	87	4	94	Vox/Choir
607	Sine Magic	87	4	95	Pulsating
608	Pulsatron	87	4	96	Pulsating
609	Motion Bass	87	4	97	Pulsating

#	Tone Name	MSB	LSB	PC	Category
610	Trance Splt	87	4	98	Pulsating
611	Rhythmic 5th	87	4	99	Pulsating
612	Rhythmic 1	87	4	100	Pulsating
613	Rhythmic 2	87	4	101	Pulsating
614	Mega Sync 1	87	4	102	Pulsating
615	StrobeBell 3	87	4	103	Pulsating
616	Strobe 1	87	4	104	Pulsating
617	Strobe 2	87	4	105	Pulsating
618	Strobe 3	87	4	106	Pulsating
619	Strobe 4	87	4	107	Pulsating
620	LFO Saw	87	4	108	Pulsating
621	Keep Going	87	4	109	Pulsating
622	Keep Running	87	4	110	Pulsating
623	Electrons	87	4	111	Pulsating
624	BriskVortex	87	4	112	Pulsating
625	LFO Vox	87	4	113	Pulsating
626	Pulsasaw	87	4	114	Pulsating
627	Arposphere	87	4	115	Pulsating
628	Mega Sync 2	87	4	116	Pulsating
629	Compusonic 1	87	4	117	Beat&Groove
630	Compusonic 2	87	4	118	Beat&Groove
631	Compusonic 3	87	4	119	Beat&Groove
632	Compusonic 4	87	4	120	Beat&Groove
633	Compusonic 5	87	4	121	Beat&Groove
634	AnalogDays 2	87	4	122	Beat&Groove
635	Groove 007	87	4	123	Beat&Groove
636	Juno Pop	87	4	124	Beat&Groove
637	Auto Trance2	87	4	125	Beat&Groove
638	In Da Groove	87	4	126	Beat&Groove
639	80s Beat	87	4	127	Beat&Groove
640	Ride Cymbal	87	4	128	Percussion

# SD-50 Drum set list / SD-50 ドラム・セット一覧

Category	#	Rhythm Name	MSB	LSB	PC
GM2	1	GM2 STANDARD	120	0	1
	2	GM2 ROOM	120	0	9
	3	GM2 POWER	120	0	17
	4	GM2 ELECTRIC	120	0	25
	5	GM2 ANALOG	120	0	26
	6	GM2 JAZZ	120	0	33
	7	GM2 BRUSH	120	0	41
	8	GM2 ORCHSTRA	120	0	49
	9	GM2 SFX	120	0	57

Category	#	Rhythm Name	MSB	LSB	PC
Other	1	Standard 1	86	0	1
	2	Standard 2	86	0	2
	3	Standard 3	86	0	3
	4	Rock Kit	86	0	4
	5	Jazz Kit	86	0	5
	6	Brush Kit	86	0	6
	7	Machine Kit	86	0	7
	8	R&B T-Analog	86	0	8
	9	R&B Mini Kit	86	0	9
	10	HipHop Kit	86	0	10
	11	R&B Kit	86	0	11
	12	Dance Kit 1	86	0	12
	13	Dance Kit 2	86	0	13
	14	Dance Kit 3	86	0	14

\* [EXC] : Percussion sound of the same number will not be heard at the same time. / 同じ番号の音は同時になりません。

	GM2 STANDARD MSB:120/LSB:0/PC:001	GM2 ROOM MSB:120/LSB:0/PC:009	GM2 POWER MSB:120/LSB:0/PC:017	GM2 ELECTRIC MSB:120/LSB:0/PC:025	GM2 ANALOG MSB:120/LSB:0/PC:026
	27	High Q	High Q	High Q	High Q
C2	28	Slap	Slap	Slap	Slap
		Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]
	29	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]
	30	Sticks	Sticks	Sticks	Sticks
	31	Square Click	Square Click	Square Click	Square Click
	32	Metron Click	Metron Click	Metron Click	Metron Click
	33	Metron Bell	Metron Bell	Metron Bell	Metron Bell
	34	Kick Drum 2	Kick Drum 2	Kick Drum 2	Kick Drum 2
	35	Kick Drum 1	Kick Drum 1	Power Kick	Elec.Kick
	36	Side Stick	Side Stick	Side Stick	Ana.Rim Sho
	37	Aco.Snare	Aco.Snare	PowerSnare	E.SnareDrum1
	38	Hand Clap	Hand Clap	Hand Clap	Hand Clap
	39	Elec.Snare	Elec.Snare	Elec.Snare	E.SnareDrum2
	40	Low Tom 2	Room LowTom2	PowerLowTom2	E.Low Tom 2
	41	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	E.Low Tom 1
	42	Low Tom 1	Room LowTom1	PowerLowTom1	Ana.Low Tom1
	43	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Ana.ClosedHH [EXC 1]
	44	Mid Tom 2	Room MidTom2	PowerMidTom2	E.Mid Tom 2
	45	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Ana.Mid Tom2
	46	Mid Tom 1	Room MidTom1	PowerMidTom1	Ana.Mid Tom1
	47	High Tom 2	Room Hi Tom2	PowerHiTom2	E.Hi Tom 2
C3	48	CrashCymbal1	CrashCymbal1	CrashCymbal1	Ana.Cymbal1
	49	High Tom 1	Room Hi Tom1	PowerHiTom1	Ana.Hi Tom1
	50	Ride Cymbal1	Ride Cymbal1	Ride Cymbal1	Ana.Hi Tom1
	51	China Cymbal	China Cymbal	China Cymbal	Ride Cymbal1
	52	Ride Bell	Ride Bell	Ride Bell	Reverse Cym.
	53	Tambourine	Tambourine	Tambourine	Ride Bell
	54	SplashCymbal	SplashCymbal	SplashCymbal	Tambourine
	55	Cowbell	Cowbell	Cowbell	SplashCymbal
	56	CrashCymbal2	CrashCymbal2	CrashCymbal2	Ana.Cowbell
	57	Vibra-slap	Vibra-slap	Vibra-slap	CrashCymbal2
	58	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Vibra-slap
	59	High Bongo	High Bongo	High Bongo	Ride Cymbal2
C4	60	Low Bongo	Low Bongo	Low Bongo	High Bongo
	61	MuteHi Conga	MuteHi Conga	MuteHi Conga	Low Bongo
	62	OpenHi Conga	OpenHi Conga	OpenHi Conga	MuteHi Conga
	63	Low Conga	Low Conga	Low Conga	Ana.Hi Conga
	64	High Timbale	High Timbale	High Timbale	OpenHi Conga
	65	Low Timbale	Low Timbale	Low Timbale	Ana.LowConga
	66	High Agogo	High Agogo	High Agogo	High Timbale
	67	Low Agogo	Low Agogo	Low Agogo	Low Timbale
	68	Cabasa	Cabasa	Cabasa	High Agogo
	69	Maracas	Maracas	Maracas	Low Agogo
	70	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	Cabasa
	71	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Ana.Maracas
C5	72	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	ShortWhistle [EXC 2]
	73	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Whistle [EXC 2]
	74	Claves	Claves	Claves	Short Guiro [EXC 3]
	75	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Long Guiro [EXC 3]
	76	LowWoodBlock	LowWoodBlock	LowWoodBlock	Ana.Claves
	77	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Hi WoodBlock
	78	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	LowWoodBlock
	79	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	Mute Cuica [EXC 4]
	80	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	Open Cuica [EXC 4]
	81	Shaker	Shaker	Shaker	MuteTriangle [EXC 5]
	82	Jingle Bell	Jingle Bell	Jingle Bell	OpenTriangle [EXC 5]
	83	Bell Tree	Bell Tree	Bell Tree	Shaker
C6	84	Castanets	Castanets	Castanets	Jingle Bell
	85	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Bell Tree
	86	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Bell Tree
	87	-	-	-	Castanets
	88	-	-	-	Mute Surdo [EXC 6]
		-	-	-	Open Surdo [EXC 6]

\* [EXC] : Percussion sound of the same number will not be heard at the same time. / 同じ番号の音は同時になりません。

	GM2 JAZZ MSB:120/LSB:0/PC:033	GM2 BRUSH MSB:120/LSB:0/PC:041	GM2 ORCHSTRA MSB:120/LSB:0/PC:049	GM2 SFX MSB:120/LSB:0/PC:057	
	27	High Q	High Q	ClosedHi-hat [EXC 1]	
28	Slap	Slap	Pedal Hi-hat [EXC 1]	—	
	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Open Hi-hat [EXC 1]	—	
29	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Ride Cymbal1	—	
31	Sticks	Sticks	Sticks	—	
	32	Square Click	Square Click	—	
33	Metron Click	Metron Click	Metron Click	—	
	34	Metron Bell	Metron Bell	—	
35	Jazz Kick 2	Jazz Kick 2	Concert BD 2	—	
	Jazz Kick 1	Jazz Kick 1	Concert BD 1	—	
C2	36	Side Stick	Side Stick	—	
	37	Aco.Snare	Brush Tap	—	
38	Hand Clap	Brush Slap	Castanets	High Q	
	39	Elec.Snare	Brush Swirl	Concert SD	Slap
40	Low Tom 2	Low Tom 2	Timpani F	Scratch Push [EXC 7]	
	42	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	Timpani F#	Scratch Pull [EXC 7]
43	Low Tom 1	Low Tom 1	Timpani G	Sticks	
	44	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Timpani G#	Square Click
45	Mid Tom 2	Mid Tom 2	Timpani A	Metron Click	
	46	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Timpani A#	Metron Bell
47	Mid Tom 1	Mid Tom 1	Timpani B	GtFret Noise	
C3	48	High Tom 2	High Tom 2	Timpani c	Cut Noise Up
	49	CrashCymbal1	CrashCymbal1	Timpani c#	Cut Noise Dw
50	High Tom 1	High Tom 1	Timpani d	Slap St.Bass	
	51	Ride Cymbal1	Ride Cymbal1	Timpani d#	FlKey Click
52	China Cymbal	China Cymbal	Timpani e	Laughing	
	Ride Bell	Ride Bell	Timpani f	Scream	
53	54	Tambourine	Tambourine	Punch	
55	SplashCymbal	SplashCymbal	SplashCymbal	Heart Beat	
	56	Cowbell	Cowbell	Footsteps 1	
57	CrashCymbal2	CrashCymbal2	Concert Cym2	Footsteps 2	
	58	Vibra-slap	Vibra-slap	Applause	
59	Ride Cymbal2	Ride Cymbal2	Concert Cym1	Door Creak	
C4	60	High Bongo	High Bongo	Door	
	61	Low Bongo	Low Bongo	Scratch	
62	MuteHi Conga	MuteHi Conga	MuteHi Conga	Wind Chimes	
	63	OpenHi Conga	OpenHi Conga	Car Engine	
64	Low Conga	Low Conga	Low Conga	Car Stop	
	High Timbale	High Timbale	High Timbale	Car Pass	
65	66	Low Timbale	Low Timbale	Car Crash	
67	High Agogo	High Agogo	High Agogo	Siren	
	68	Low Agogo	Low Agogo	Train	
69	Cabasa	Cabasa	Cabasa	Jetplane	
	70	Maracas	Maracas	Helicopter	
71	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	Starship	
C5	72	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Gun Shot	
	73	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Machine Gun	
74	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Lasergun	
	75	Claves	Claves	Explosion	
76	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Dog	
	LowWoodBlock	LowWoodBlock	LowWoodBlock	Horse Gallop	
77	78	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Birds	
79	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Rain	
	80	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	Thunder	
81	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	Wind	
	82	Shaker	Shaker	Seashore	
83	Jingle Bell	Jingle Bell	Jingle Bell	Stream	
C6	84	Bell Tree	Bell Tree	Bubble	
	85	Castanets	Castanets	—	
86	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	—	
	87	Open Surdo [EXC 6]	Open Surdo [EXC 6]	—	
88	—	—	Applause	—	

\* [EXC] : Percussion sound of the same number will not be heard at the same time. / 同じ番号の音は同時になりません。

	Standard 1 MSB:86/LSB:0/PC001	Standard 2 MSB:86/LSB:0/PC002	Standard 3 MSB:86/LSB:0/PC003	Rock Kit MSB:86/LSB:0/PC004	Jazz Kit MSB:86/LSB:0/PC005
22	MC500 Beep1	MC500 Beep1	MC500 Beep1	MC500 Beep1	MC500 Beep1
23	MC500 Beep2	MC500 Beep2	MC500 Beep2	MC500 Beep2	MC500 Beep2
24	Concert SD	Concert SD	Concert SD	Concert SD	Concert SD
25	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll
26	Snap	Snap	Snap	Snap	Snap
27	High Q	High Q	High Q	High Q	High Q
28	Slap	Slap	Slap	Slap	Slap
29	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]
30	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]
31	Sticks	Sticks	Sticks	Sticks	Sticks
32	Square Click	Square Click	Square Click	Square Click	Square Click
33	Metron Click	Metron Click	Metron Click	Metron Click	Metron Click
34	Metron Bell	Metron Bell	Metron Bell	Metron Bell	Metron Bell
35	Kick Drum 2	Kick Drum 2	Kick Drum 2	Power Kick2	Jazz Kick 2
36	Kick Drum 1	Kick Drum 1	Kick Drum 1	Power Kick1	Jazz Kick 1
37	Side Stick	Side Stick	Side Stick	Side Stick	Side Stick
38	Reg.Snr 2	Snare 1	Snare 1	Power Snare 1	Jazz Snare 1
39	Hand Clap	Hand Clap	Hand Clap	Hand Clap	Hand Clap
40	Reg.Snr 1	Snare 2	Snare 2	Power Snare2	Jazz Snare2
41	Reg.F.Tom	Low Tom 2	Low Tom 2	Low Tom1	Low Tom 2
42	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]	ClosedHi-hat [EXC 1]
43	Reg.L.Tom	Low Tom 1	Low Tom 1	Low Tom2	Low Tom 1
44	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]	Pedal Hi-hat [EXC 1]
45	Reg.M.Tom	Mid Tom 2	Mid Tom 2	Mid Tom 1	Mid Tom 2
46	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]	Open Hi-hat [EXC 1]
47	Reg.M.Tom	Mid Tom 1	Mid Tom 1	Mid Tom2	Mid Tom 1
48	Reg.H.Tom	High Tom 2	High Tom 2	High Tom1	High Tom 2
49	CrashCymbal1	CrashCymbal1	CrashCymbal1	CrashCymbal 1	CrashCymbal1
50	Reg.H.Tom	High Tom 1	High Tom 1	High Tom2	High Tom 1
51	Ride Cymbal1	Ride Cymbal1	Ride Cymbal1	Ride Cymbal 1	Ride Cymbal1
52	China Cymbal	China Cymbal	China Cymbal	China Cymbal	China Cymbal
53	Ride Bell	Ride Bell	Ride Bell	Ride Bell	Ride Bell
54	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine
55	SplashCymbal	SplashCymbal	SplashCymbal	SplashCymbal	SplashCymbal
56	Cowbell	Cowbell	Cowbell	Cowbell	Cowbell
57	CrashCymbal2	CrashCymbal2	CrashCymbal2	CrashCymbal2	CrashCymbal2
58	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap
59	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2
60	High Bongo	High Bongo	High Bongo	High Bongo	High Bongo
61	Low Bongo	Low Bongo	Low Bongo	Low Bongo	Low Bongo
62	MuteHi Conga	MuteHi Conga	MuteHi Conga	MuteHi Conga	MuteHi Conga
63	OpenHi Conga	OpenHi Conga	OpenHi Conga	OpenHi Conga	OpenHi Conga
64	Low Conga	Low Conga	Low Conga	Low Conga	Low Conga
65	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale
66	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale
67	High Agogo	High Agogo	High Agogo	High Agogo	High Agogo
68	Low Agogo	Low Agogo	Low Agogo	Low Agogo	Low Agogo
69	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa
70	Maracas	Maracas	Maracas	Maracas	Maracas
71	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]
72	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]
73	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]
74	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]
75	Claves	Claves	Claves	Claves	Claves
76	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock
77	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock
78	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]
79	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]
80	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]
81	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]
82	Shaker	Shaker	Shaker	Shaker	Shaker
83	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
84	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree
85	Castanets	Castanets	Castanets	Castanets	Castanets
86	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]
87	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]
88	Applause	Applause	Applause	Applause	Applause
89	SnareGhost1	SnareGhost1	SnareGhost1	SnareGhost1	SnareGhost1
90	SnareGhost2	SnareGhost2	SnareGhost2	SnareGhost2	SnareGhost2
91	Hand Clap 1	Hand Clap1	Hand Clap 1	Hand Clap 1	Hand Clap 1
92	Hand Clap 2	Hand Clap2	Hand Clap 2	Hand Clap 2	Hand Clap 2
93	Scratch 1	Scratch1	Scratch 1	Scratch 1	Scratch 1
94	Scratch 2	Scratch2	Scratch 2	Scratch 2	Scratch 2
95	Scratch 3	Scratch3	Scratch 3	Scratch 3	Scratch 3
96	Hit 1	Hit 1	Hit 1	Hit 1	Hit 1
97	Hit 2	Hit 2	Hit 2	Hit 2	Hit 2
98	Hit 3	Hit 3	Hit 3	Hit 3	Hit 3
99	Hit 4	Hit 4	Hit 4	Hit 4	Hit 4
100	Hit 5	Hit 5	Hit 5	Hit 5	Hit 5
101	Low Tom 1	Low Tom 1	Low Tom 1	Low Tom 1	Low Tom 1
102	Low Tom 2	Low Tom 2	Low Tom 2	Low Tom 2	Low Tom 2
103	Cajon 1	Cajon 1	Cajon 1	Cajon 1	Cajon 1
104	Cajon 2	Cajon 2	Cajon 2	Cajon 2	Cajon 2
105	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz
106	Sweep Down	Sweep Down	Sweep Down	Sweep Down	Sweep Down
107	Laser	Laser	Laser	Laser	Laser
108	Syn Back Nz	Syn Back Nz	Syn Back Nz	Syn Back Nz	Syn Back Nz

\* [EXC] : Percussion sound of the same number will not be heard at the same time. / 同じ番号の音は同時になりません。

	Brush Kit MSB:120/LSB:0/PC:006	Machine Kit MSB:120/LSB:0/PC:007	R&B T-Analog MSB:120/LSB:0/PC:008	R&B Mini Kit MSB:120/LSB:0/PC:009	HipHop Kit MSB:120/LSB:0/PC:010
22	MC500 Beep1	MC500 Beep1	MC500 Beep1	MC500 Beep1	MC500 Beep1
23	MC500 Beep2	MC500 Beep2	MC500 Beep2	MC500 Beep2	MC500 Beep2
24	Concert SD	Concert SD	Concert SD	Concert SD	Concert SD
25	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll
26	Snap	Snap	Snap	Snap	Snap
27	High Q	High Q	High Q	High Q	High Q
28	Slap	Slap	Slap	Slap	Mix Kick1
29	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Scratch Push [EXC 7]	Analog Kick1
30	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Scratch Pull [EXC 7]	Mix Snare4
31	Sticks	Sticks	Sticks	Sticks	Analog Kick2
32	Square Click	Square Click	Square Click	Square Click	Mix Snare3
33	Metron Click	Metron Click	Metron Click	Metron Click	Mix Kick2
34	Metron Bell	Metron Bell	Metron Bell	Metron Bell	HH Shaker [EXC 1]
35	Jazz Kick 2	Ana.Kick 1	Ana.Kick 1	Kick 2	Mix Kick4
36	Jazz Kick 1	Ana.Kick 2	Ana.Kick 2	Kick 1	Mix Kick3
37	Side Stick	Ana.Rim Shot	Ana.Rim Shot	Side Stick	TR808 Rim
38	Brush Tap	Ana.Snare	Ana.Snare	Snare 1	Mix Snare 1
39	Brush Slap	Hand Clap	Hand Clap	Hand Clap	TR808 Clap
40	Brush Swirl	Elec.Snare	Elec.Snare	Snare 2	Mix Snare2
41	Low Tom 2	Ana.Low Tom2	Ana.Low Tom2	Reg.F.Tom	Tom1
42	ClosedHi-hat [EXC 1]	Ana.Ci HH 1 [EXC 1]	Ana.Ci HH 1 [EXC 1]	ClosedHi-hat [EXC 1]	TR808 CIHH [EXC 1]
43	Low Tom 1	Ana.Low Tom 1	Ana.Low Tom 1	Reg.L.Tom	Tom2
44	Pedal Hi-hat [EXC 1]	Ana.Ci HH 2 [EXC 1]	Ana.Ci HH 2 [EXC 1]	Pedal Hi-hat [EXC 1]	Noise CIHH [EXC 1]
45	Mid Tom 2	Ana.Mid Tom2	Ana.Mid Tom2	Reg.M.Tom	Tom3
46	Open Hi-hat [EXC 1]	Ana.Open HH [EXC 1]	Ana.Open HH [EXC 1]	Open Hi-hat [EXC 1]	TR808 OpHH [EXC 1]
47	Mid Tom 1	Ana.Mid Tom 1	Ana.Mid Tom 1	Reg.M.Tom	Tom4
48	High Tom 2	Ana.Hi Tom2	Ana.Hi Tom2	Reg.H.Tom	Tom5
49	CrashCymbal1	Ride Cymbal1	Ride Cymbal1	CrashCymbal1	TR909 Cym
50	High Tom 1	Ana.Hi Tom 1	Ana.Hi Tom 1	Reg.H.Tom	Tom6
51	Ride Cymbal 1	Ana.Cymbal	Ana.Cymbal	Ride Cymbal1	TR808 Cym
52	China Cymbal	China Cymbal	China Cymbal	China Cymbal	China Cymbal
53	Ride Bell	Ride Bell	Ride Bell	Ride Bell	Rock Rd Edge
54	Tambourine	Tambourine	Tambourine	Tambourine	Mix Perc
55	SplashCymbal	SplashCymbal	SplashCymbal	SplashCymbal	Mix Crash 1
56	Cowbell	Ana.Cowbell	Ana.Cowbell	Cowbell	Ana.Cowbell
57	CrashCymbal2	CrashCymbal	CrashCymbal	CrashCymbal2	Mix Crash2
58	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	Roll FX
59	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cym
60	High Bongo	High Bongo	High Bongo	High Bongo	High Bongo
61	Low Bongo	Low Bongo	Low Bongo	Low Bongo	Low Bongo
62	MuteHi Conga	Ana.Hi Conga	Ana.Hi Conga	MuteHi Conga	MuteHi Conga
63	OpenHi Conga	Ana.MidConga	Ana.MidConga	OpenHi Conga	OpenHi Conga
64	Low Conga	Ana.LowConga	Ana.LowConga	Low Conga	Low Conga
65	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale
66	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale
67	High Agogo	High Agogo	High Agogo	High Agogo	High Agogo
68	Low Agogo	Low Agogo	Low Agogo	Low Agogo	Low Agogo
69	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa
70	Maracas	Ana.Maracas	Ana.Maracas	Maracas	Maracas
71	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]
72	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]
73	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]
74	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]
75	Claves	Ana.Claves	Ana.Claves	Claves	Claves
76	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock
77	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock
78	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]
79	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]
80	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]
81	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]
82	Shaker	Shaker	Shaker	Shaker	Shaker
83	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
84	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree
85	Castanets	Castanets	Castanets	Castanets	Castanets
86	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]
87	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]
88	Applause	Applause	Applause	Applause	Applause
89	SnareGhost1	SnareGhost1	SnareGhost1	SnareGhost1	SnareGhost1
90	SnareGhost2	SnareGhost2	SnareGhost2	SnareGhost2	SnareGhost2
91	Hand Clap1	Hand Clap1	Hand Clap1	Hand Clap1	Hand Clap1
92	Hand Clap2	Hand Clap2	Hand Clap2	Hand Clap2	Hand Clap2
93	Scratch 1	Scratch 1	Scratch 1	Scratch 1	Scratch 1
94	Scratch 2	Scratch 2	Scratch 2	Scratch 2	Scratch 2
95	Scratch 3	Scratch 3	Scratch 3	Scratch 3	Scratch 3
96	Hit 1	Hit 1	Hit 1	Hit 1	Hit 1
97	Hit 2	Hit 2	Hit 2	Hit 2	Hit 2
98	Hit 3	Hit 3	Hit 3	Hit 3	Hit 3
99	Hit 4	Hit 4	Hit 4	Hit 4	Hit 4
100	Hit 5	Hit 5	Hit 5	Hit 5	Hit 5
101	Low Tom 1	Low Tom 1	Low Tom 1	Low Tom 1	Low Tom 1
102	Low Tom 2	Low Tom 2	Low Tom 2	Low Tom 2	Low Tom 2
103	Cajon 1	Cajon 1	Cajon 1	Cajon 1	Cajon 1
104	Cajon 2	Cajon 2	Cajon 2	Cajon 2	Cajon 2
105	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz
106	Sweep Down	Sweep Down	Sweep Down	Sweep Down	Sweep Down
107	Laser	Laser	Laser	Laser	Laser
108	Syn Back Nz	Syn Back Nz	Syn Back Nz	Syn Back Nz	Syn Back Nz



\* [EXC] : Percussion sound of the same number will not be heard at the same time. / 同じ番号の音は同時になりません。

	R&B Kit MSB:120/LSB:0/PC:011	Dance Kit 1 MSB:120/LSB:0/PC:012	Dance Kit 2 MSB:120/LSB:0/PC:013	Dance Kit 3 MSB:120/LSB:0/PC:014
22	MC500 Beep1	MC500 Beep1	MC500 Beep1	MC500 Beep1
23	MC500 Beep2	MC500 Beep2	MC500 Beep2	MC500 Beep2
24	Concert SD	Concert SD	Concert SD	Concert SD
25	Snare Roll	Snare Roll	Snare Roll	Snare Roll
26	Snap	Snap	Snap	Snap
27	High Q	High Q	High Q	High Q
28	TR808 Kick	TR909 Kick	SH32 Kick1	TR808 Kick
	HH Kick	SH32 Kick1	TR909 Kick1	Mix Kick1
29	Mix Snare2	AnalogSnare	AnalogSnare1	TR909 Snare1
30	Mix Kick4	Analog Kick	Analog Kick1	Mix Kick2
31	Short Snare2	TR808 Snare	TR808 Snare	TR909 Snare2
32	Mix Kick3	SH32 Kick2	SH32 Kick2	Mix Kick3
33	TR808 Cl HH [EXC 1]	Syn ClHH1 [EXC 1]	Pedal Hihat [EXC 1]	Thin ClHH [EXC 1]
34	Mix Kick1	Mix Kick2	TR909 Kick2	TR909 Kick
35	Mix Kick2	Mix Kick1	Analog Kick2	Analog Kick
36	Soft Stick	Mix Rim	Synth Rim	Mix Rim
37	Short Snare1	Mix Snare1	DistNz Snare	Mix Snare2
38	Hand Clap	TR808 Clap	TR808 Clap	Mix Clap
39	Mix Snare1	Mix Snare2	DistNz Snare	Mix Snare1
40	TR808 Tom1	Mix Tom1	Deep Tom1	Mix Tom1
41	Cl Hihat1 [EXC 1]	Mix ClHH1 [EXC 1]	Syn ClHH1 [EXC 1]	Mix ClHH1 [EXC 1]
42	TR808 Tom2	Mix Tom2	Deep Tom2	Mix Tom2
43	Cl Hihat2 [EXC 1]	Mix ClHH2 [EXC 1]	Syn ClHH2 [EXC 1]	Mix ClHH2 [EXC 1]
44	TR808 Tom3	Mix Tom3	Deep Tom3	Mix Tom3
45	Op Hihat [EXC 1]	Op Hihat [EXC 1]	Syn OpHH [EXC 1]	Op Hihat [EXC 1]
46	TR808 Tom4	Mix Tom4	Deep Tom4	Mix Tom4
47	TR808 Tom5	Mix Tom5	Deep Tom5	Mix Tom5
48	TR909 Cym	Mix Crash	TR808 OpHH	Mix Crash
49	TR808 Tom6	Mix Tom6	Deep Tom6	Mix Tom6
50	TR808 Cym	Rock Rd Edge	Wide Syn Cym	Rock Rd Edge
51	China Cymbal	China Cymbal	TR808 Cym1	China Cymbal
52	Rock Rd Edge	Ride Cymbal	Ride Cym1	Ride Cymbal
53	Mix Hat	Tambourine	Castanet	Tambourine
54	Mix Crash1	Syn Splash	TR808 Cym2	Splash Cym
55	Ana.Cowbell	Cowbell	TR808Cowbell	Cowbell
56	Mix Crash2	Concert Cym	Ride Cym2	Concert Cym
57	Vibra-slap	Vibraslap	Syn Cowbell	Vibraslap
58	Ride Cym	TR808 Cym	Ride Cym3	Syn China
59	High Bongo	High Bongo	High Bongo	High Bongo
60	Low Bongo	Low Bongo	Low Bongo	Low Bongo
61	MuteHi Conga	MuteHi Conga	MuteHi Conga	MuteHi Conga
62	OpenHi Conga	OpenHi Conga	OpenHi Conga	OpenHi Conga
63	Low Conga	Low Conga	Low Conga	Low Conga
64	High Timbale	High Timbale	High Timbale	High Timbale
65	Low Timbale	Low Timbale	Low Timbale	Low Timbale
66	High Agogo	High Agogo	High Agogo	High Agogo
67	Low Agogo	Low Agogo	Low Agogo	Low Agogo
68	Cabasa	Cabasa	Cabasa	Cabasa
69	Maracas	Maracas	Maracas	Maracas
70	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]	ShortWhistle [EXC 2]
71	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]	Long Whistle [EXC 2]
72	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]	Short Guiro [EXC 3]
73	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]	Long Guiro [EXC 3]
74	Claves	Claves	Claves	Claves
75	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock	Hi WoodBlock
76	LowWoodBlock	LowWoodBlock	LowWoodBlock	LowWoodBlock
77	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]	Mute Cuica [EXC 4]
78	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]	Open Cuica [EXC 4]
79	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]	MuteTriangle [EXC 5]
80	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]	OpenTriangle [EXC 5]
81	Shaker	Shaker	Shaker	Shaker
82	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
83	Bell Tree	Bell Tree	Bell Tree	Bell Tree
84	Castanets	Castanets	Castanets	Castanets
85	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]	Mute Surdo [EXC 6]
86	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]	Open Surdo [EXC 6]
87	Applause	Applause	Applause	Applause
88	SnareGhost1	SnareGhost1	SnareGhost1	SnareGhost1
89	SnareGhost2	SnareGhost2	SnareGhost2	SnareGhost2
90	Hand Clap1	Hand Clap1	Hand Clap1	Hand Clap1
91	Hand Clap2	Hand Clap2	Hand Clap2	Hand Clap2
92	Scratch1	Scratch1	Scratch1	Scratch1
93	Scratch2	Scratch2	Scratch2	Scratch2
94	Scratch3	Scratch3	Scratch3	Scratch3
95	Hit1	Hit1	Hit1	Hit1
96	Hit2	Hit2	Hit2	Hit2
97	Hit3	Hit3	Hit3	Hit3
98	Hit4	Hit4	Hit4	Hit4
99	Hit5	Hit5	Hit5	Hit5
100	Low Tom1	Low Tom1	Low Tom1	Low Tom1
101	Low Tom2	Low Tom2	Low Tom2	Low Tom2
102	Cajon1	Cajon1	Cajon1	Cajon1
103	Cajon2	Cajon2	Cajon2	Cajon2
104	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz	Syn Burst Nz
105	Sweep Down	Sweep Down	Sweep Down	Sweep Down
106	Laser	Laser	Laser	Laser
107	Syn Back Nz	Syn Back Nz	Syn Back Nz	Syn Back Nz
108				