

SE-02 Ver. 1.04 Additional Function

This document explains the added functionality for the SE-02 version 1.04. Please read this in conjunction with the Owner's Manual.

CV INPUT Jack Settings

Newly added parameters allow you to specify fine tune and key follow for the voltage that is input to the CV INPUT jack.

1. Set the mode select switch to "PATCH."
2. Press the [COMP] button and [PLAY] button to make them light.
 - * If you decide to cancel, press the [COMP] button and [PLAY] button once again to make them go dark.
3. Use the [15]–[16] buttons to select a parameter, and use the [VALUE] knob to edit the parameter's value. The display indicates the value.

Button	Parameter	Value	Explanation
[15]	CV Fine Tune	0–255	Finely adjusts the pitch relative to the voltage that is input to the CV INPUT jack.
[16]	CV Key Follow	0–255	Adjusts the width of pitch change relative to the voltage that is input to the CV INPUT jack.

Tips

Adjusting the CV INPUT jack's key follow setting will cause the tuning to change slightly. For this reason, you should adjust key follow first, and then use fine tune to specify the overall pitch.

* There is no need to execute the Write operation. CV Fine Tune and CV Key Follow are saved as settings for the entire system.

SE-02 Ver. 1.04追加機能のお知らせ

© 2017 ローランド株式会社

SE-02 のバージョン 1.04 で追加された機能について説明します。取扱説明書と合わせてお読みください。

CV INPUT 端子の設定

CV INPUT 端子に入力される電圧に対して、ファイン・チューンとキー・フォローを設定するパラメーターが追加されました。

1. モード選択スイッチを「PATCH」に合わせます。
2. [COMP] ボタンと [PLAY] ボタンを押して、点灯させます。
 - * キャンセルするときは、もう一度 [COMP] ボタンと [PLAY] ボタンを押して、消灯させます。
3. [15] ~ [16] ボタンを押してパラメーターを選び、[VALUE] つまみで値を設定します。ディスプレイに、設定値が表示されます。

ボタン	パラメーター	設定値	説明
[15]	CV Fine Tune	0 ~ 255	CV INPUT 端子に入力される電圧に対するピッチを微調整します。
[16]	CV Key Follow	0 ~ 255	CV INPUT 端子に入力される電圧に対するピッチの変化幅を調整します。

ヒント

CV INPUT 端子のキー・フォローを調節すると、チューニングが若干変動します。そのため、最初にキー・フォローを調節してからファイン・チューンで全体のピッチを設定すると良いでしょう。

* ライト操作は必要ありません。CV Fine Tune と CV Key Follow は、システム全体の設定として保存されます。



* 5 1 0 0 0 6 0 1 0 0 - 0 1 *