

Roland

EXPANSION BOARD

DANCE

SR-JV80-06

OWNER'S MANUAL

Thank you for choosing the Roland SR-JV80-06 "Dance Expansion" wave expansion board.

Your new expansion board comes stocked with a broad selection of Waveforms, Patches, and Rhythm Sets that are perfect for dance music in almost any style – whether it be hip-hop, house, techno, acid jazz, ragga, funk, R&B, rave, jungle or disco.

● Waveforms: 255 Kinds

Includes rhythm pattern phrase loops, one-shot voices, hits (stubs) & scratches, as well as sounds from the TR-808/909, TB-303, and SH-101 – classics in the realm of dance music.

Many of the Waveforms provided by this product were selected from sampling-use audio CD-ROMs by AMG (Advanced Media Group), which have won wide acclaim by many in the dance music field ("Black II Black", "Remix").

● Patches

255 kinds designed for the JV-1080 & XP-50; another 255 for the JV-80/880/90/1000.

● Rhythm Sets

Eight kinds designed for the JV-1080 & XP-50; another two for the JV-90/1000.

The Rhythm Sets in this expansion board cannot be used with the JV-80/880 or JD-990.

■ INSTALLING THE EXPANSION BOARD


* Turn off your instrument.

1. Remove the cover located on the bottom (or top) of your instrument.
2. Check that the plastic board holders are positioned as shown. Rotate them if necessary.
3. While positioning the holes on the board over the board holders, carefully insert the connector on the board into the socket on the main unit. Make sure the connector is securely connected, and that all three board holders project through the holes.
4. Use the supplied Installation Tool to turn the holders in the LOCK direction, so the board will be fastened in place.

(To remove the Expansion Board, turn the board holders in the UNLOCK direction, and lift up the board using the provided tool. Remove the board and secure the cover plate.)

5. Check if the Expansion Board is correctly installed.

If the "EXP" display cannot be selected (doesn't appear) in the Waveform Selection Screen (refer to the owner's manual of the instrument you use), remove the Expansion Board and install it properly.



Copyright © 1995 ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form without the permission of ROLAND CORPORATION.

本書の一部、もしくは全部を無断で複写・転載することを禁じます。

Special Thanks to:

patch programming: Garry Mason (at The Sound Bank) /AMG
 Steve McIntosh /AMG
 Lee Groves /AMG
 Eric Persing /Roland
 Christian Sales /Roland
 Ryeland Allison /Roland
 Roland Sound Project /Roland

data management: Roland Sound Project /Roland
 Eric Persing /Roland
 Matthew Wilkinson /AMG

and the many patient people who made this Card possible.

このたびは、ウェーブ・エクスパンション・ボード SR-JV80-06 「ダンス」をお買い上げいただきまして、まことにありがとうございます。

このエクスパンション・ボードには、Hip Hop, House, Techno, Acid Jazz, Ragga, Funk, R & B, Rave, Jungle, Discoなどの多種多様にわたるダンス・ミュージックに対応できるウェーブフォーム、パッチ、リズム・セットが内蔵されています。

●ウェーブフォーム：255種類

リズム・パターン・フレーズ・ループ、1ショットのボイス、ヒット(スタップ) & スクラッチ、ダンス定番のTR-808/909, TB-303, SH-101のサウンドなどが揃っています。

本製品のウェーブフォームは、ダンス・ミュージックの分野ですでに定評のあるAMG (Advanced Media Group) 社のサンプリング用オーディオCD-ROM 「Black II Black」, 「Remix」の中から大多数セレクトされています。

●パッチ

JV-1080, XP-50専用：255種類 JV-80/880/90/1000専用：255種類

●リズム・セット

JV-1080, XP-50専用：8種類 JV-90/1000専用：2種類

JV-80/880, JD-990では、エクスパンション・ボードのリズム・セットを使用することはできません。

■ エクスパンション・ボードの取り付けかた

* 使用機器の電源スイッチをオフにしてください。

1. 使用機器の低部、または上部にあるカバーをはずします。
2. 基板ホルダーを、図2のような向きに合わせます。
3. エクスパンション・ボードのコネクターを、本体のコネクターに完全に差し込みます。このとき3つの基板ホルダーの頭が、エクスパンション・ボードから出るようにします。
4. 付属の固定用具で基板ホルダーをLOCK方向に回し、エクスパンション・ボードを固定します。
エクスパンション・ボードの取りはずしは、基板ホルダーをUNLOCK方向に回し、固定用具を引っかけて取りはずします。
最後にカバーを取り付けます。
5. エクスパンション・ボードの取り付けが正しく行われたかを確認します。

ウェーブフォームの選択画面(使用機器の取扱説明書参照)で"EXP"が選べない(表示されない)ときは、もう一度エクスパンション・ボードをつけ直してください。

WAVEFORM LIST

No. Name	No. Name	No. Name	No. Name	No. Name	
Phrase Loop					
1 Easy R&B 83	51 Loop Kick	104 Tek Clap *	Hit & Scratch (FX)		206 Mg Slide U/D *
2 Caveman 83	52 Tick Kick *	105 Ol'Skool Clp *			207 Big Bang *
3 SoulShake 83	53 909 Kick 4 *	106 909 Rim *	154 Squeal 1 *	208 Sea Wolf *	
4 HipHop Jz 88	54 HipHop Kick *	107 Ragga Tom *	155 Squeal 2 *	209 Tape Stop *	
5 Homeboy 88	55 Bubbler Kick *	108 909 Tom Hi *	156 Multiphonics	210 DJ 1 *	
6 Gangsta 1 94	56 Knockout K *	109 909 Tom Mid *	157 Tpt Kiss *	211 DJ 2 *	
7 Gangsta 2 94	57 Massive Kick *	110 909 Tom Lo *	158 Tpt Gliss	212 DJ Loop	
8 DeepGrine 94	58 Explosion K *	111 HiHat Menu **	159 Stab Fall *	213 Wicked DJ *	
9 Nite'Hood 94	59 Leakage Kick *	112 707 Hi Hat **	160 Dance Hit *	214 Final Loop	
10 Party Jam 94	60 Solid Kick *	113 HiHats Rev **	161 Club Hit *	215 Spooky *	
11 S2S 909 94	61 Dance Kick *	114 909 Ride	162 Flychord	216 Rewind *	
12 Ragga 94	62 Krash Kick *	115 909 Crash *	163 Choralvibe	217 Zigzag *	
13 TopendSw 100	63 Pozer Kick *	116 HipHop Tamb *	164 Trance 5th *	218 Whoo-Whoo *	
14 Danger 100	64 606 Snare *	Human Voice		219 Hip Alarm	
15 Breakdwn 100	65 808 Snare *	117 Aaah! *	166 Ragga Hit *	220 Sci-Fi *	
16 Owl'Hood 100	66 Ragga Snare *	118 Girl Ah *	167 Maj 7th *	221 Cheers	
17 Lo-Fi 100	67 909 Bryt Sn *	119 Ahooh Yell *	168 Minor Hit *	222 60's Vinyl	
18 Soulmate 106	68 909 Fat Sn *	120 Oohh!! *	169 Major Hit *	223 10000 Volts	
19 SwingTmb 106	69 909 ShortSn *	121 Uhhh!! *	170 Mystic Pno *	224 Fizzzzzzz	
20 Squeeky 110	70 Hip Hop Sn 1 *	122 Breath in *	171 Kutt *	Bass	
21 Swingin' 110	71 New Jack Sn *	123 Madman *	172 Euro Hit *	225 Euro Bass	
22 Shufflin' 110	72 70's Snare *	124 Jam! *	173 Organ Hit *	226 NRG Bass	
23 Perc Jam 116	73 Old Rim *	125 Here We Go *	174 Org/Piano *	227 Power Bass	
24 Suprise 116	74 Jam Snare *	126 Oh Yeah ! *	175 Dub Hit *	228 Noiz Bass	
25 909Disco 120	75 Gated Shot *	127 Once Again *	176 Minor NRG *	229 Core Bass	
26 Caravan 120	76 Reggae Snare *	128 Bah *	177 Hardcore 1 *	230 Trance Bass	
27 Superfly 120	77 Sharp Shot *	129 And! *	178 Hardcore 2 *	231 Deep Bass	
28 DiscoCga 120	78 Trunc Snare *	130 Aaa! *	179 Power Chord *	232 TB-303 Bass	
29 808CowBl 124	79 Funk Snare *	131 Love *	180 Rave Hit *	233 SH-101 Bs 1	
30 909Swing 124	80 Noiz Snare *	132 Oooh Yeah! *	181 Scratch Hit *	234 SH-101 Bs 2	
31 Human Bt 124	81 Verb Snare *	133 Hey *	182 Vinyl Opera *	235 SH-101 Bs 3	
32 Mover 124	82 Lil'R&B Sn *	134 Baby *	183 Movin' Hit 1 *	236 Sine Loop	
33 Cruisin' 124	83 80's Snare *	135 Yeah-Yeah *	184 Movin' Hit 2 *	Menu	
34 Jungle 124	84 Compress Sn *	136 Ooooooooooooo *	185 2Tone Hit *	237 VOX Menu **	
35 Jazzy 130	85 Def Clap *	137 Whoooooooooooo *	186 Gangsta Hit *	238 RevVox Menu **	
36 909 Pump 130	86 Process Sn *	138 Aaaaaaaaaa *	187 Classic Hit *	239 Noiz Menu **	
37 Slammin' 130	87 Chord Snare *	139 No-No *	188 Section Hit *	240 Scrtch&Hits1 **	
38 HipHouse 130	88 Hip Hop Sn 2 *	140 Oh-no-no-no *	189 Intense Hit *	241 Scrtch&Hits2 **	
39 Fancy Sw 130	89 Glass Snare *	141 Ooo^^^^^^^^ *	190 Positive Hit *	242 Hit&FX Menu **	
40 HipNoKik 130	90 Iron Snare *	142 Aaaa^^^^^^^^ *	191 Vintage Hit *	243 Kick Set 1 **	
41 FastEuro 136	91 Ping Snare *	143 Funny *	192 Triumphant *	244 Kick Set 2 **	
42 Justice 136	92 Brick Snare *	144 Giggle *	193 Big Ol'Stab	245 Kick Set 3 **	
43 New Jack 136	93 Impact Snare *	145 Heavy Breath	194 Rev Ol'Stab	246 Snare Set 1 **	
44 Latin Bt 141	94 Space Snare *	Synth, Piano, Organ		247 Snare Set 2 **	
45 Darkman 154	95 Reverse Nz *	146 Acid Sync	195 String Gliss *	248 Snare Set 3 **	
Drums (Percussion)					196 Loop Bit 1 *
46 Gabba Kick *	96 Buzz Roll *	147 Analog	197 Loop Bit 2 *	249 Snare Set 4 **	
47 Rotterdam K *	97 Micro Buzz *	148 Euro Strings	198 Evil Bass *	250 Hat&tom Set **	
48 909 Kick 1 *	98 Super Fill *	149 Terminator	199 Mouth Music *	251 Cymbal Set **	
49 909 Kick 2 *	99 Flange Fill *	150 TerminatorLp	200 Hammer On *	252 Beat Menu 1 **	
50 909 Kick 3 *	100 Loose Fill **	151 House Piano	201 Short Funk *	253 Beat Menu 2 **	
	101 909 Clap **	152 50's Organ	202 Oct Slide **	254 Beat Menu 3 **	
	102 808 Clap **	153 Tong	203 Guitar Fill **	255 Beat Menu 4 **	
	103 Machine Clap *		204 Jz Gtr Fall **		
			205 Mg Slide Dwn *		

The number appearing next to the Wave name for Phrase Loops (83 to 154) is the Original B.P.M. (tempo).

- * Indicates One-shot Waveforms. They have a reversed sound assigned to the upper part on the keyboard.
- ** These are menu Waveforms. Many different Waveforms are provided, each one assigned to a different key.

Phrase Loop (フレーズ・ループ) のウェーブ・ネームについている83から154までの数字は、Original B.P.M. (テンポ) です。

- * 1ショットのウェーブフォームです。このウェーブフォームでは、鍵盤のアップパー・パートにリバース音が割り当てられています。
- ** メニュー・ウェーブフォームです。複数のウェーブフォームが、キーごとに割り当てられています。

Waveforms in the list which have "Rev" as part of their name are designed to play in reverse when sounding. However, on the JD-990, they will instead be sounded in the forward direction, since the instrument does not support reverse playback.

リストの中で、名前に"Rev"が付いているウェーブフォームはリバース(逆方向)再生で発音するようになっていますが、JD-990ではリバース再生ができないため、正方向再生で代用して発音します。

MENU WAVEFORM

Menu Waveforms provide multiple Waveforms, with each one assigned to a different key.

メニュー・ウェーブフォームは、キーごとに異なるウェーブフォームが割り当てられています。

Key	Wave#	Wave Name
111 HiHat Menu		
C	4	(closed)
C#	4	(closed)
D	4	(closed)
D#	4	(closed)
E	4	(open)
F	4	(open)
F#	4	(closed)
G	4	(closed)
G#	4	(closed)
A	4	(closed)
A#	4	(closed)
B	4	(closed)
C	5	(open)
C#	5	(open)
D	5	(open)
112 707 Hi Hat		
C	4	(closed)
C#	4	(open)
113 HiHats.Rev		
C	4	(closed)
C#	4	(open)
D	4	(closed)
D#	4	(closed)
E	4	(open)
F	4	(open)
F#	4	(closed)
G	4	(closed)
G#	4	(closed)
A	4	(closed)
A#	4	(closed)
B	4	(closed)
C	5	(open)
C#	5	(open)
D	5	(open)
237 VOX Menu		
C	4	117 Aaaah!
D	4	118 Girl Ah
E	4	120 Oohh!!
F	4	121 Uhhh!!
G	4	125 Here We Go
A	4	126 Oh Yeah!
B	4	129 And!
C	5	131 Love
D	5	132 Oooh Yeah!
E	5	133 Hey
F	5	134 Baby
G	5	135 Yeah-Yeah
A	5	136 Oooooooooo
B	5	137 Whooooooooo
C	6	139 No-No
D	6	144 Giggle

Key	Wave#	Wave Name
238 RevVox Menu		
C	4	127 Once Again
D	4	125 Here We Go
E	4	126 Oh Yeah!
F	4	134 Baby
G	4	133 Hey
A	4	135 Yeah-Yeah
B	4	139 No-No
C	5	131 Love
D	5	132 Oooh Yeah!
E	5	140 Oh-no-no-no
F	5	121 Uhhh!!
G	5	120 Oohh!!
A	5	119 Ahoo Yell
B	5	118 Girl Ah
C	6	128 Bah
D	6	141 Ooo^^^^^^
239 Noiz Menu		
C	4	222 60's Vinyl
D	4	199 Mouth Music
E	4	198 Evil Bass
F	4	182 Vinyl Opera
G	4	145 Heavy Breath
A	4	95 Reverse Nz
B	4	80 Noiz Snare
C	5	220 Sci-Fi
D	5	208 Sea Wolf
E	5	215 Spooky
F	5	122 Breath in
G	5	181 Scratch Hit
A	5	220 Sci-Fi
B	5	211 DJ 2
C	6	209 Tape Stop
D	6	25 909Disco 120
240 Scrtch&Hits1		
C	4	213 Wicked DJ
D	4	212 DJ Loop
E	4	181 Scratch Hit
F	4	197 Loop Bit 2
G	4	77 Sharp Shot
A	4	170 Mystic Pno
B	4	173 Organ Hit
C	5	168 Minor Hit
D	5	186 Gangsta Hit
E	5	188 Section Hit
F	5	196 Loop Bit 1
G	5	191 Vintage Hit
A	5	190 Positive Hit
B	5	189 Intense Hit
C	6	179 Power Chord
D	6	193 Big Ol'Stab

Key	Wave#	Wave Name
241 Scrtch&Hits2		
C	4	216 Rewind
D	4	213 Wicked DJ
E	4	212 DJ Loop
F	4	211 DJ 2
G	4	181 Scratch Hit
A	4	215 Spooky
B	4	205 Mg Slide Dwn
C	5	206 Mg Slide U/D
D	5	207 Big Bang
E	5	192 Triumphant
F	5	188 Section Hit
G	5	209 Tape Stop
A	5	191 Vintage Hit
B	5	208 Sea Wolf
C	6	203 Guitar Fill
D	6	159 Stab Fall
242 Hit&FX Menu		
C	4	213 Wicked DJ
D	4	212 DJ Loop
E	4	181 Scratch Hit
F	4	219 Hip Alarm
G	4	218 Whoo-Whoo
A	4	221 Cheers
B	4	220 Sci-Fi
C	5	222 60's Vinyl
D	5	223 10000 Volts
E	5	221 Cheers
F	5	220 Sci-Fi
G	5	196 Loop Bit 1
A	5	191 Vintage Hit
B	5	169 Major Hit
C	6	186 Gangsta Hit
D	6	193 Big Ol'Stab
243 Kick Set 1		
B	1	48 909 Kick 1
C	2	50 909 Kick 3
B	4	51 Loop Kick
C	5	57 Massive Kick
244 Kick Set 2		
B	1	49 909 Kick 2
C	2	53 909 Kick 4
B	4	58 Explosion K
C	5	63 Pozer Kick
245 Kick Set 3		
B	1	46 Gabba Kick
C	2	47 Rotterdam K
B	4	61 Dance Kick
C	5	52 Tick Kick

Key	Wave#	Wave Name
246 Snare Set 1		
C#	2	106 909 Rim
D	2	69 909 ShortSn
D#	2	101 909 Clap
E	2	72 70's Snare
C#	5	107 Ragga Tom
D	5	73 Old Rim
D#	5	102 808 Clap
E	5	70 Hip Hop Sn 1
247 Snare Set 2		
C#	2	106 909 Rim
D	2	71 New Jack Sn
D#	2	101 909 Clap
E	2	74 Jam Snare
C#	5	107 Ragga Tom
D	5	78 Trunc Snare
D#	5	104 Tek Clap
E	5	79 Funk Snare
248 Snare Set 3		
C#	2	106 909 Rim
D	2	85 Def Clap
D#	2	103 Machine Clap
E	2	90 Iron Snare
C#	5	107 Ragga Tom
D	5	94 Space Snare
D#	5	104 Tek Clap
E	5	95 Reverse Nz
249 Snare Set 4		
C#	2	106 909 Rim
D	2	89 Glass Snare
D#	2	102 808 Clap
E	2	80 Noiz Snare
C#	5	77 Sharp Shot
D	5	76 Reggae Snare
D#	5	85 Def Clap
E	5	96 Buzz Roll
250 Hat&tom Set		
F	2	110 909 Tom Lo
F#	2	111 HiHats (closed)
G	2	110 909 Tom Lo
G#	2	111 HiHats (closed)
A	2	109 909 Tom Mid
A#	2	111 HiHats (open)
B	2	109 909 Tom Mid
C	3	108 909 Tom Hi
F#	5	111 HiHats (closed)
C#	5	111 HiHats (closed)
A#	5	111 HiHats (open)

Key	Wave#	Wave Name
251 Cymbal Set		
C#	3	115 909 Crash
D	3	108 909 Tom Hi
D#	3	114 909 Ride
E	3	115 909 Crash
F#	3	116 HipHop Tamb
C#	6	115 909 Crash
D#	6	114 909 Ride
E	6	115 909 Crash
252 Beat Menu 1		
C	4	1 Easy R&B 83
D	4	2 Caveman 83
E	4	3 SoulShake 83
F	4	4 HipHop Jz 88
G	4	5 Homeboy 88
A	4	6 Gangsta 1 94
B	4	7 Gangsta 2 94
C	5	8 DeepGrine 94
D	5	9 Nite'Hood 94
E	5	10 Party Jam 94
F	5	11 S2S 909 94
G	5	12 Ragga 94
253 Beat Menu 2		
C	4	13 TopendSw 100
D	4	14 Danger 100
E	4	15 Breakdwn 100
F	4	16 Owl'Hood 100
G	4	17 Lo-Fi 100
A	4	18 Soulmate 106
B	4	19 SwingTmb 106
C	5	20 Squeaky 110
D	5	21 Swingin' 110
E	5	22 Shufflin' 110
F	5	23 Perc Jam 116
G	5	24 Suprise 116
254 Beat Menu 3		
C	4	25 909Disco 120
D	4	26 Caravan 120
E	4	27 Superfly 120
F	4	28 DiscoCga 120
G	4	29 808CowBl 124
A	4	30 909Swing 124
B	4	31 Human Bt 124
C	5	32 Mover 124
D	5	33 Cruisin' 124
E	5	34 Jungle 124
255 Beat Menu 4		
C	4	35 Jazzy 130
D	4	36 909 Pump 130
E	4	37 Slammin' 130
F	4	38 HipHouse 130
G	4	39 Fancy Sw 130
A	4	40 HipNoKik 130
B	4	41 FastEuro 136
C	5	42 Justice 136
D	5	43 New Jack 136
E	5	44 Latin Bt 141
F	5	45 Darkman 154

The Waveforms assigned to the 111 HiHat Menu, 112 707 Hi Hat and 113 HiHats.Rev keys are used only for the Menu Waveforms.

111 HiHat Menu, 112 707 Hi Hat, 113 HiHats.Revの各キーに割り当てられているウェーブフォームは、メニュー・ウェーブフォームのみで使用しています。

PATCH LIST for JV-80 / 880 / 90 / 1000

No. Name	No. Name	No. Name	No. Name	No. Name
1 Dance Again	52 Latin Bt 141 *	103 Ravin'Choir	154 ScratchMenu2 **	205 Warriors
2 Tune Up	53 Darkman 154 *	104 Random Hits	155 ScratchMenu3 **	206 Br.Jupiters
3 Odd FXM Loop	54 Beat Menu 1 **	105 Fizzy	156 Tape Spin	207 M+C Big Pad
4 Easy R&B 83 *	55 Beat Menu 2 **	106 Eurostab	157 Noise Menu **	208 Wonderous Pd
5 Caveman 83 *	56 Beat Menu 3 **	107 Triumph Stab	158 PiknMixnMod	209 Super OB
6 SoulShake 83 *	57 Beat Menu 4 **	108 Street Stab	159 Manic Shots	210 Eurostrings
7 HipHop Jz 88 *	58 Dance Piano	109 Kik x4	160 Sonic Stabs	211 Sweep Beat
8 Homeboy 88 *	59 Odd Piano.	110 Reverse Nz	161 Stylostab	212 Nice-n-Easy
9 Gangsta 1 94 *	60 House Piano	111 909 Tom	162 CutOff Snare	213 World Muzic
10 Gangsta 2 94 *	61 Bright Piano	112 HiHat Menu **	163 Selecta Drum	214 Tri-dent Brs
11 Nite'Hood 94 *	62 Velo Piano	113 Rev Cymbal	164 Trans Vox	215 Dance Brass
12 Party Jam 94 *	63 Simple Piano	114 Bang x2	165 Aaah!	216 Clix Bass
13 S2S 909 94 *	64 Night Moods	115 Ragga Hit	166 Aho0 Yell	217 System 100m
14 Ragga 94 *	65 50's Organ	116 Fly Chord	167 Oohh!!	218 Synbass Five
15 DeepGrine 94 *	66 Organ Tong	117 Ravin'Chords	168 Madman	219 Rawsaw Bass
16 TopendSw 100 *	67 Blob Tech	118 Powertechit	169 Oooh Yeah!	220 Groove Bass
17 Danger 100 *	68 Organic	119 Organ Hits 1	170 Bah	221 Metalrezo Bs
18 Breakdwn 100 *	69 Old Organ	120 Organ Hits 2	171 And!	222 VCF Bass
19 Owl'Hood 100 *	70 Mod Amb.Pipe	121 Choralvibe	172 Aaa!	223 Sharp Rezo
20 Lo-Fi 100 *	71 Notre Dame	122 Trancey	173 Hey	224 Technopop Bs
21 Soulmate 106 *	72 Legato Synth	123 Sharp Hit	174 Baby	225 Acid Tripper
22 SwingTmb 106 *	73 Summer Time	124 Mc Hit x3	175 Yeah-Yeah	226 Hood Bass
23 Squeeky 110 *	74 Def Lead	125 Kutt Hit	176 Oooooo0000	227 ZipnBoomBass
24 Swingin' 110 *	75 Minor Rave	126 Galaxy Hit	177 Whoooooo000	228 Housine Bs
25 Shufflin' 110 *	76 Major Rave	127 Reggae Chord	178 No-No	229 Coar Bass
26 Suprise1 116 *	77 Dance Lead	128 Saw Horn x2	179 Ooo^^^^^^	230 Anti-digital
27 Suprise2 116 *	78 Sync Lead	129 Rave Hit	180 Aaa^^^^^^	231 Dual VCF Bs
28 Perc Jam 116 *	79 HyperHiPass	130 Vinyl Opera	181 Laugh-Mix	232 Comic Bs
29 909Dsc01 120 *	80 Mono Raver	131 Movin'Hit	182 Vocamatic	233 TB-303 Bs 1
30 909Dsc02 120 *	81 Mod-Trance	132 2Tone Hit	183 Girl Ah!	234 TB-303 Bs 2
31 909Dsc03 120 *	82 Rave at home	133 Club Hit x4	184 Vox Menu **	235 SH101 Bs 1
32 Superfly 120 *	83 ResoLoot	134 Big O!'Stab	185 Rev Vox Menu **	236 SH101 Bs 2
33 DiscoCga 120 *	84 Square Tone	135 Loopbits x2	186 Here We Go!	237 SH101 Bs 3
34 Caravan 120 *	85 Triangular	136 Slide Fx x2	187 Outhere Pad	238 SH101 Bs 4
35 Jungle 1 124 *	86 JP Sub-Synth	137 Spooky	188 Tekno Voices	239 SH101 Bs 5
36 808CowBl 124 *	87 Saxy Jam	138 Section Hit	189 Old Strings	240 Jungle Bells
37 Jungle 2 124 *	88 Reso Pad	139 Gtr Fx x4	190 Dance String	241 How Odd?!
38 Cruisin' 124 *	89 Fat Stack	140 Breath Fx x4	191 Terminator	242 Hell House
39 909Swing 124 *	90 ResoSequence	141 Sax Fx x3	192 Sweep City	243 Construction
40 Human Bt 124 *	91 Common Synth	142 Tpt Fx x3	193 AmbientSweep	244 Nightmare!!!
41 Mover 124 *	92 NewAnalogEra	143 Scratch x4	194 Oper'Ambient	245 Flangehead
42 Jazzy 130 *	93 Monstrousnes	144 Scratch Loop	195 AmbientPad 1	246 Doublefunky
43 909 Pump 130 *	94 Sharpy	145 Stab Scratch	196 AmbientPad 2	247 Mystical
44 Slammin' 130 *	95 Dance Arp	146 Record Noize	197 Lunar Orbit	248 Sci-Fi Sweep
45 HipHouse 130 *	96 Oddigeree	147 Fizzzz	198 Fly-by Pad	249 Drum Set 1 **
46 Fancy Sw 130 *	97 Monstrousity	148 Hurray!	199 Cool Pad	250 Drum Set 2 **
47 HipNoKik 130 *	98 Arpeggio	149 Sci-Fi	200 Sync Pad	251 Drum Set 3 **
48 FastEuro 136 *	99 Dance Seq	150 Whoo-Whoo!	201 Urban Pad	252 Drum Set 4 **
49 Justice1 136 *	100 Fiesta	151 Zigzag	202 Deep Analog	253 Drum Set 5 **
50 Justice2 136 *	101 Trance Stab	152 Hip Alarm	203 Garage Pad	254 Drum Set 6 **
51 New Jack 136 *	102 Digistack	153 ScratchMenu1 **	204 UK Swing Pad	255 Drum Set 7 **

* Patches using Phrase Loop Waveforms. The number appearing next to the Wave name for Phrase Loops (83 to 154) is the B.P.M. (tempo) when played at the C4 key.

** These Patches use menu Waveforms.

* フレーズ・ループのウェーブフォームを使用したパッチです。パッチ・ネームについている83から154までの数字は、C4キーで演奏したときのB.P.M. (テンポ) です。

** これらのパッチは、メニュー・ウェーブフォームを使用して作られています。

- Refer to the owner's manual for your instrument for specific instructions on how to play Patches on the expansion board. On the JV-80/880 and JD-990, a "Load" of the Patches needs to be performed.
- On the JV-80/880/90/1000, you can select only the Patches which are designed to be used with those instruments.
- On the JD-990, you can use Patches designed to be used with the JV-80/880/90/1000 if you "Convert Load" them first. However, such Patches will sound slightly different than they would if played on the JV-80/880/90/1000.

- エクスパンション・ボードのパッチを発音させるときは、使用機器の取扱説明書にしたがって、実行してください。JV-80/880, JD-990では、パッチのロードを実行する必要があります。
- JV-80/880/90/1000では、JV-80/880/90/1000専用のパッチのみを選ぶことができます。
- JD-990で、JV-80/880/90/1000専用のパッチをコンバート・ロードして使用することができます。その場合、JV-80/880/90/1000で使用したときの音色とは多少異なります。

PATCH LIST for JV-1080, XP-50

No. Name	No. Name	No. Name	No. Name	No. Name
1 All night!	52 FastEuro 136 *	103 Arpeggio	154 Whoo-Whoo!	205 Deep Analog
2 Tune Up	53 Justice1 136 *	104 Dance Seq	155 Zigzag	206 Garage Pad
3 Acidic Grv	54 Justice2 136 *	105 Fiesta	156 Hip alarm	207 UK Swing Pad
4 Techno'Hood	55 New Jack 136 *	106 Trance Stab	157 ScratchMenu1 **	208 Warriors
5 Space Groove	56 Latin Bt 141 *	107 Digistack	158 ScratchMenu2 **	209 Br.Jupiters
6 Odd FXM Loop	57 Darkman 154 *	108 Ravin'Choir	159 ScratchMenu3 **	210 M+C Big Pad
7 Ultrarave	58 Beat Menu 1 **	109 Random Hits	160 Tape Spin	211 Wonderous Pd
8 Easy R&B 83 *	59 Beat Menu 2 **	110 Fizzy	161 Noise Menu **	212 Super OB
9 Caveman 83 *	60 Beat Menu 3 **	111 Eurostab	162 PknMixnMod	213 Eurostrings
10 SoulShake 83 *	61 Beat Menu 4 **	112 Triumph Stab	163 Manic Shots	214 Sweep Beat
11 HipHop Jz 88 *	62 Dance Split	113 Street Stab	164 Sonic Stabs	215 Nice-n-Easy
12 Homeboy 88 *	63 Dance Piano	114 Kik x4	165 Stylostab	216 World Muzic
13 Gangsta 1 94 *	64 Odd Piano	115 Reverse Nz	166 CutOff Snare	217 Tri-dent Brs
14 Gangsta 2 94 *	65 House Piano	116 909 Tom	167 Selecta Drum	218 Dance Brass
15 Nite'Hood 94 *	66 Bright Piano	117 HiHat Menu **	168 Trans Vox	219 Space Bass
16 Party Jam 94 *	67 Velo Piano	118 Rev Cymbal	169 Aaaa!	220 Clix Bass
17 S2S 909 94 *	68 Simple Piano	119 Bang x2	170 Ahooh Yell	221 System 100m
18 Ragga 94 *	69 Night Moods	120 Ragga Hit	171 Oohh!!	222 Synbass Five
19 DeepGrine 94 *	70 50's Organ	121 Fly Chord	172 Madmam	223 Rawsaw Bass
20 TopendSw 100 *	71 Organ Tong	122 Ravin'Chords	173 Oooh Yeah!	224 Groove Bass
21 Danger 100 *	72 Organic	123 Powertechit	174 Bah	225 Metalrezo Bs
22 Breakdwn 100 *	73 Old Organ	124 Organ Hits	175 And!	226 VCF Bass
23 Owl'Hood 100 *	74 Mod Amb.Pipe	125 Choralvibe	176 Aaa!	227 Sharp Rezo
24 Lo-Fi 100 *	75 Notre Dame	126 Trancey	177 Hey	228 Technopop Bs
25 Soulmate 106 *	76 Legato Synth	127 Sharp Hit	178 Baby	229 Acid Tripper
26 SwingTmb 106 *	77 Summer Time	128 Mc Hit x3	179 Yeah-Yeah	230 Hood Bass
27 Squeeky 110 *	78 Def Lead	129 Kutt Hit	180 Oooooooooo	231 Housine Bs
28 Swingin' 110 *	79 Minor Rave	130 Galaxy Hit	181 Whooooooooo	232 Anti-digital
29 Shufflin' 110 *	80 Major Rave	131 Reggae Chord	182 No-No	233 Dual VCF Bs
30 Suprise1 116 *	81 Dance Lead	132 Saw Horn x2	183 Ooo^^^^^^	234 Comic Bass
31 Suprise2 116 *	82 Sync Lead	133 Rave Hit	184 Aaaa^^^^^^	235 TB-303 Bs 1
32 Perc Jam 116 *	83 HyperHiPass	134 Vinyl Opera	185 Laugh-Mix	236 TB-303 Bs 2
33 909DSCO1 120 *	84 Mono Raver	135 Movin'Hit	186 Vocamatic	237 SH-101 Bs 1
34 909DSCO2 120 *	85 Mod-Trance 1	136 2Tone Hit	187 Girl Ah	238 SH-101 Bs 2
35 909DSCO3 120 *	86 Mod-Trance 2	137 Club Hit x4	188 Vox Menu **	239 SH-101 Bs 3
36 Superfly 120 *	87 Rave at home	138 Big Ol'Stab	189 Rev Vox Menu **	240 SH-101 Bs 4
37 DiscoCga 120 *	88 ResoLoot	139 Loopbits x2	190 Here We Go!	241 SH-101 Bs 5
38 Caravan 120 *	89 Square Tone	140 Slide Fx x2	191 Outhere Pad	242 How Odd?!
39 Jungle 1 124 *	90 Triangular	141 Spooky	192 Tekno Voices	243 Hell House
40 808CowBl 124 *	91 JP Sub-Synth	142 Section Hit	193 Old Strings	244 Nightmare!!!
41 Jungle 2 124 *	92 Saxy Jam	143 Gtr Fx x4	194 Dance String	245 Flangehead
42 Cruisin' 124 *	93 Reso Pad	144 Breath Fx x4	195 Terminator	246 Doublefunky
43 909Swing 124 *	94 Fat Stack	145 Sax Fx x3	196 AmbientSweep	247 Mystical
44 Human Bt 124 *	95 ResoSequence	146 Tpt Fx x3	197 Ambient BPF	248 Sci-Fi Sweep
45 Mover 124 *	96 Common Synth	147 Scratch x4	198 Oper'Ambient	249 Drum Set 1 **
46 Jazzy 130 *	97 NewAnalogEra	148 Scratch Loop	199 AmbientPad 1	250 Drum Set 2 **
47 909 Pump 130 *	98 Monstrousnes	149 Stab Scratch	200 AmbientPad 2	251 Drum Set 3 **
48 Slammin' 130 *	99 Sharpy	150 Record Noize	201 Lunar Orbit	252 Drum Set 4 **
49 HipHouse 130 *	100 Dance Arp	151 Fizzzz	202 Fly-by Pad	253 Drum Set 5 **
50 Fancy Sw 130 *	101 Oddigeree	152 Hurray!	203 Sync Pad	254 Drum Set 6 **
51 HipNoKik 130 *	102 Monstrously	153 Sci-Fi	204 Urban Pad	255 Drum Set 7 **

* Patches using Phrase Loop Waveforms. The number appearing next to the Wave name for Phrase Loops (83 to 154) is the B.P.M. (tempo) when played at the C4 key.

** These Patches use menu Waveforms.

* フレーズ・ループのウェーブフォームを使用したパッチです。パッチ・ネームについている83から154までの数字は、C4キーで演奏したときのB.P.M. (テンポ) です。

** これらのパッチは、メニュー・ウェーブフォームを使用して作られています。

- Refer to the owner's manual for your instrument for specific instructions on how to play Patches on the expansion board.
- On the JV-1080 and XP-50, you can select only the Patches which are designed to be used with the JV-1080 and XP-50.

- エクスパンション・ボードのパッチを発音させるときは、使用機器の取扱説明書にしたがって、実行してください。
- JV-1080, XP-50では、JV-1080, XP-50専用のパッチのみを選ぶことができます。

RhythmSet [A] RhythmSet [B]

Table with 3 columns: Note No., Wave Name, Wave Name. Rows include RhythmSet [A] and RhythmSet [B] entries.

909 Set

Table with 3 columns: Note No., Wave Name, Wave Name. Rows include 909 Set entries.

Ragga Set

Table with 3 columns: Note No., Wave Name, Wave Name. Rows include Ragga Set entries.

Cartoon/Rave!

Table with 3 columns: Note No., Wave Name, Wave Name. Rows include Cartoon/Rave! entries.

Soul Set

Table with 3 columns: Note No., Wave Name, Wave Name. Rows include Soul Set entries.

Hip-Hop Set

Table with 3 columns: Note No., Wave Name, Wave Name. Rows include Hip-Hop Set entries.

70s FunkSet

Table with 3 columns: Note No., Wave Name, Wave Name. Rows include 70s FunkSet entries.

Micro Set

Table with 3 columns: Note No., Wave Name, Wave Name. Rows include Micro Set entries.

All KicksSn

Table with 3 columns: Note No., Wave Name, Wave Name. Rows include All KicksSn entries.

Refer to the owner's manual for your instrument for specific instructions on how to play Rhythm Sets on the expansion board.

エクスパンション・ボードのリズム・セットを発音させるときは、使用機器の取扱説明書にしたがって実行してください。

On the JV-90/1000, you can select only the Rhythm Sets which are designed to be used with the JV-90/1000.

On the JV-1080 and XP-50, you can select only the Rhythm Sets which are designed to be used with the JV-1080 and XP-50.

On the JV-90/1000, you can select only the Rhythm Sets which are designed to be used with the JV-90/1000. On the JV-1080 and XP-50, you can select only the Rhythm Sets which are designed to be used with the JV-1080 and XP-50.

 Roland[®]

11075

UPC

11075



18981

Roland