



**Before using this unit, carefully read the sections entitled: "USING THE UNIT SAFELY" and "IMPORTANT NOTES" (p. 2; p. 4). These sections provide important information concerning the proper operation of the unit. Additionally, in order to feel assured that you have gained a good grasp of every feature provided by your new unit, Owner's manual should be read in its entirety. The manual should be saved and kept on hand as a convenient reference.**

この機器を正しくお使いいただくために、ご使用前に「安全上のご注意」(P.3) と「使用上のご注意」(P.4) をよくお読みください。また、この機器の優れた機能を十分ご理解いただくためにも、この取扱説明書をよくお読みください。取扱説明書は必要なときにすぐに見ることができるよう、手元に置いてください。

Thank you, and congratulations on your choice of the SRX-08 "SR-JV80 Collection Vol.3 Platinum Trax" Wave Expansion Board.

This expansion board contains all of the waveforms in the SR-JV80-11 Techno Collection, SR-JV80-12 HipHop Collection, and SR-JV80-19 Collection, along with specially selected dance FX sounds included in the 15 Special FX Collection. This board contains new Patches and Rhythm Sets which combine the waveforms in a manner that highlights the benefits of SRX Effects and Matrix Control. This board contains phrase loops and synth bass, synth sounds, different kinds of Hit & Stab, vocal phrases, and other sounds that can be used with dance music (Techno, House, HipHop, Trance, Drum 'n' Bass, BreakBeats, etc.).

- Patches: 448
- Rhythm Sets: 21
- Waveforms: 950

The waveforms included with this board are selected from CHRONIC MUSIC of the United States, the Spectrasonics CD-ROM "DISTORTED REALITY," and the "HOUSEWORX!," and "jam box" CD-ROMs produced by the German company ueberschall.

\* The parameter settings for Patches and Rhythm Sets are optimized for the Fantom series, XV series, MX-200, RD series with SRX slots, MC-909, VR-760, and G-70 models, so there are some minor differences in the sounds each instrument produces.

The included CD-ROM contains data reproducing the original sounds of the SR-JV80-11, SR-JV80-12, and SR-JV80-19. (Compatible models: Fantom, XV-5080, XV-5050, XV-3080, XV-88, XV-2020)

**This expansion board utilizes a new format. Check the system program version for your instrument, and if a relevant upgrade is available, upgrade your instrument using the appropriate system update program on the included CD-ROM. (See p. 23.)**  
This program applies to the SRX-01~09.

このたびは、ウェーブ・エクスパンション・ボード SRX-08 「SR-JV80 Collection Vol.3 Platinum Trax」をお買い上げいただき、まことにありがとうございます。

このエクスパンション・ボードは SR-JV80-11 Techno Collection、12 HipHop Collection、19 House Collection に搭載されていたウェーブフォームを完全収録、15 Special FX Collection に搭載されていたウェーブフォームの内、ダンス向け FX 音色を厳選して収録しています。

これらのウェーブフォームを組み合わせた SRX 仕様の Effect、Matrix Control を生かした新規 パッチ、リズム・セットを搭載しています。

フレーズループやシンセベース、シンセサウンド、各種 Hit & Stab、ボーカルフレーズ等のダンスマジック (Techno, House, HipHop, Trance, Drum 'n' Bass, BreakBeats, R&B, 等) に対応出来る音色を数多く収録しています。

- |            |        |
|------------|--------|
| • パッチ      | 448 種類 |
| • リズム・セット  | 21 種類  |
| • ウェーブフォーム | 950 種類 |

本製品に搭載されているウェーブフォームの一部は米国 CHRONIC MUSIC、Spectrasonics 社 CD-ROM 「DISTORTED REALITY」、ドイツ ueberschall 社 CD-ROM 「HOUSEWORX!」「jam box」からセレクトしています。

※ 各パッチ／リズム・セットは Fantom シリーズ、XV シリーズ、MX-200、SRX 対応の RD シリーズ、MC-909、VR-760 の各機種ごとに最適なパラメーター設定を行っていますので、それぞれ出音が異なることがあります。

付属の CD-ROM に SR-JV80-11、12、19 のオリジナル音色を再現するデータが収録されています。(対応機種: Fantom, XV-5080, XV-5050, XV-3080, XV-88, XV-2020)

このエクスパンション・ボードは新フォーマットを採用しています。お使いの機種のシステム・プログラム・バージョンをご確認の上、バージョン・アップ対象の場合は、付属 CD-ROM に収録されているシステム・アップデート・プログラムでバージョン・アップしてからご使用ください。(P.23をご覧ください。)  
このアップデートプログラムは SRX-01 ~ 09 で使用出来ます。

# USING THE UNIT SAFELY

## INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

### About WARNING and CAUTION Notices

<b> WARNING</b>	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
<b> CAUTION</b>	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

### About the Symbols

	The  symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
	The  symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
	The  symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

### ALWAYS OBSERVE THE FOLLOWING

#### WARNING

- Before using this unit, make sure to read the instructions below, and the Owner's Manual.



- Do not open or perform any internal modifications on the unit.



- Do not attempt to repair the unit, or replace parts within it (except when this manual provides specific instructions directing you to do so). Refer all servicing to your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" page.



- Never use or store the unit in places that are:
  - Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are
  - Damp (e.g., baths, washrooms, on wet floors); or are
  - Humid; or are
  - Exposed to rain; or are
  - Dusty; or are
  - Subject to high levels of vibration.



- Do not allow any objects (e.g., flammable material, coins, pins); or liquids of any kind (water, soft drinks, etc.) to penetrate the unit.



#### WARNING

- In households with small children, an adult should provide supervision until the child is capable of following all the rules essential for the safe operation of the unit.



- Protect the unit from strong impact.  
(Do not drop it!)



- Before installing the SRX-08, you must first always turn off the Fantom series/XV series/MX-200/RD series with SRX slots/MC-909/VR-760/G-70 and unplug its power cord.



- DO NOT play a CD-ROM disc on a conventional audio CD player. The resulting sound may be of a level that could cause permanent hearing loss. Damage to speakers or other system components may result.



#### CAUTION

- Never climb on top of, nor place heavy objects on the unit.



- Install the circuit board only into the specified unit (Fantom series/XV series/MX-200/RD series with SRX slots/MC-909/VR-760/G-70). Remove only the specified screws during the installation.



- Should you remove screws, make sure to put them in a safe place out of children's reach, so there is no chance of them being swallowed accidentally.



\* In the interest of product improvement, the specifications and/or contents of this package are subject to change without prior notice.

# 安全上のご注意

## 火災・感電・傷害を防止するには

### △警告と△注意の意味について

 <b>警告</b>	取扱いを誤った場合に、使用者が死亡または重傷を負う可能性が想定される内容を表わしています。
 <b>注意</b>	取扱いを誤った場合に、使用者が傷害を負う危険が想定される場合および物的損害のみの発生が想定される内容を表わしています。 ※物的損害とは、家屋・家財および家畜・ペットにかかる拡大損害を表わしています。

### 図記号の例

	△は、注意（危険、警告を含む）を表わしています。 具体的な注意内容は、△の中に描かれています。左図の場合は、「一般的な注意、警告、危険」を表わしています。
	○は、禁止（してはいけないこと）を表わしています。 具体的な禁止内容は、○の中に描かれています。左図の場合は、「分解禁止」を表わしています。
	●は、強制（必ずすること）を表わしています。 具体的な強制内容は、●の中に描かれています。左図の場合は、「電源プラグをコンセントから抜くこと」を表わしています。

-----以下の指示を必ず守ってください-----

- |   |
|---|
|  <b>警告</b> |
|---|
- この機器を使用する前に、以下の指示と取扱説明書をよく読んでください。  

  - この機器を分解したり、改造したりしないでください。  

  - 修理／部品の交換などで、取扱説明書に書かれていらないことは、絶対にしないでください。必ずお買い上げ店またはローランド・サービスに相談してください。  

  - 次のような場所での使用や保存はしないでください。
    - 温度が極端に高い場所（直射日光の当たる場所、暖房機器の近く、発熱する機器の上など）
    - 水気の近く（風呂場、洗面台、濡れた床など）  
や湿度の高い場所
    - 雨に漏れる場所
    - ホコリの多い場所
    - 振動の多い場所  
  

  - この機器に、異物（燃えやすいもの、硬貨、針金など）や液体（水、ジュースなど）を絶対に入れないでください。  
  


- |   |
|---|
|  <b>警告</b> |
|---|
- お子様のいるご家庭で使用する場合、お子様の取り扱いやいたずらに注意してください。必ず大人のかたが、監視／指導してあげてください。  

  - この機器を落としたり、この機器に強い衝撃を与えないでください。  

  - SRX-08 を取り付ける前に、Fantom シリーズ、XV シリーズ、MX-200、SRX 対応の RD シリーズ、MC-909、VR-760 の電源を切って電源プラグをコンセントから外してください。  

  - CD-ROM を、一般のオーディオ CD プレーヤーで再生しないで下さい。大音量によって耳を痛めたり、スピーカーを破損する恐れがあります。  


 <b>注意</b>
---

  - この機器の上に乗ったり、機器の上に重いものを置かないでください。  

  - 指定の機器（Fantom シリーズ、XV シリーズ、MX-200、SRX 対応の RD シリーズ、MC-909、VR-760）だけに取り付け、取り付け時には指定されたネジだけを外してください。  

  - ネジを外した場合は、小さなお子様が誤って飲み込んだりすることのないようお子様の手の届かないところへ保管してください。  


※ 製品の仕様および内容は、改良のため予告なく変更することがあります。

## IMPORTANT NOTES

When you purchase the SRX-08 expansion board from an authorized Roland dealer, the included sounds and samples are licensed, not sold, to you by Roland Corporation, for commercial use in music production, public performance, broadcast, etc.

You may use any of the included phrases and/or samples in a commercial or non-commercial recording without paying any additional license fees. However, you must strictly adhere to the following crediting guidelines on any music recording that utilize material from SRX-08.

Use of these SRX-08 sounds in Multimedia projects is limited to use within original musical compositions. Any other use of these sounds - such as sound effects or DLS sets is prohibited without an additional license from Roland Corporation and Spectrasonics.

Reproduction or duplication of this collection or any of the sound recording contained in the SRX-08, either as they exist on this expansion board or by any means of reformatting, mixing, filtering, re-synthesizing, processing or otherwise editing for use in another product or for re-sale, is strictly prohibited without the express written consent of Roland. All unauthorized giving, trading, lending, renting, re-issue, re-distribution or re-sale of the sounds included in the SRX-08 are expressly prohibited.

In Plain English: Be creative in your application of the SRX-08 sounds, and keep this library for your use only. DO NOT COPY IT. Roland constantly monitors other Soundware releases to check for copyright infringements, and will prosecute all piracy and copyright violations to the fullest extent of the law. THIS LIBRARY IS GUARANTEED TO BE 100% COPYRIGHT CLEAN.

In addition to the items listed under "USING THE UNIT SAFELY" on page 2, please read and observe the following:

### Handling CD-ROMs

- \* Avoid touching or scratching the shiny underside (encoded surface) of the disc. Damaged or dirty CD-ROM discs may not be read properly. Keep your discs clean using a commercially available CD cleaner.

### Handling the Board

To avoid the risk of damage to internal components that can be caused by static electricity, please carefully observe the following whenever you handle the board.

- \* Before you touch the board, always first grasp a metal object (such as a water pipe), so you are sure that any static electricity you might have been carrying has been discharged.
- \* When handling the board, grasp it only by its edges. Avoid touching any of the electronic components or connectors.
- \* Save the bag in which the board was originally shipped, and put the board back into it whenever you need to store or transport it.

French language for Canadian Safety Standard

Veuillez suivre attentivement les instructions suivantes quand vous manipulez la carte afin d'éviter tout risque d'endommagement des pièces internes par l'électricité statique.

- \* Toujours toucher un objet métallique relié à la terre (comme un tuyau par exemple) avant de manipuler la carte pour vous décharger de l'électricité statique que vous auriez pu accumuler.
- \* Lorsque vous manipulez la carte, la tenir par les côtés. Évitez de toucher aux composants ou aux connecteurs.
- \* Conservez le sachet d'origine dans lequel était la carte lors de l'envoi et remettez la carte dedans si vous devez la ranger ou la transporter.

## 使用上の注意

お客様が SRX-08 エクスパンション・ボード（以下、「本製品」といいます）をローランドの正規販売店からお買い上げになった時点で、本製品に含まれる音やサンプルは、ローランド株式会社から、お客様に対して、音楽制作、公共の場での演奏、放送などの商用目的のための使用を許諾したものであって、著作権を譲渡したものではありません。

お客様は、いかなる追加料金を支払うこともなく、本製品に含まれるあらゆるフレーズやサンプルを、商用あるいは非商用目的の録音に使用できます。ただし、お客様が本製品を使用して音楽の録音を行う際は、以下のことにご注意ください。

本製品に含まれる音をマルチメディア事業に用いることは、オリジナルの楽曲の作曲における使用に限られます。ローランド株式会社とスペクトラソニックス社からの別途の許可なしに、本製品に含まれる音を他の用途（例えば音響効果やダウンロード・サウンド（DLS）など）に、マルチメディア事業やビデオ・ゲームなどの中で使用することは禁止します。

本製品に含まれるいかなる録音物も、そのままの状態であれ、いかなる手段によって再構成、ミキシング、フィルター加工、再合成、加工処理、その他の編集作業をした状態であれ、ローランドの書面による許可なく、他の製品に含めたり再販売するために複製・複写することを禁止します。また、本製品に含まれるいかなる音も、許可なく贈与、取引、貸与、賃貸、再発行、再配布、再販売することを禁止します。

従って、本製品の音色は音楽制作の範囲でお使いいただくようお願いします。そして、本製品のライブラリーはお客様ご自身の個人的使用の目的の範囲でお使いください。本製品の音色データの複製・複写は禁止します。

ローランドは、著作権侵害がないかどうか、常時他のサウンド・ライブラリーの発売を把握しており、著作権侵害に対しては法的手段を行使する場合があります。

なお、本製品のライブラリーは第三者の著作権を一切侵害していないことを保証します。

3ページに記載されている「安全上の注意」以外に、次のことに注意してください。

### 修理について

- ※ お客様がこの機器を分解、改造された場合、以後の性能について保証できなくなります。また、修理をお断りする場合もあります。
- ※ 当社では、この製品の補修用性能部品（製品の機能を維持するために必要な部品）を、製造打切後 6 年間保有しています。この部品保有期間を修理可能の期間とさせていただきます。なお、保有期間が経過した後も、故障箇所によっては修理可能の場合がありますので、お買い上げ店、または最寄りのローランド・サービスにご相談ください。

### CD-ROM の取り扱い

- ※ ディスクの裏面（信号面）に触れたり、傷をつけたりしないでください。データの読み出しがうまくいかないことがあります。ディスクの汚れは、市販の CD 専用クリーナーでクリーニングしてください。

### 基板の取り扱い

この基板は、静電気により部品が破壊される恐れがあります。基板を取り扱うときは、次の点に注意してください。

- ※ 基板を持つときは、あらかじめ何らかの金属に触れて、体や衣類にたまっている静電気を放電してください。
- ※ 基板を持つときは、基板の縁を持ち、部品やコネクターの部分に直接手を触れないでください。
- ※ 基板を保管するとき、または輸送するときなどは、購入時に基板が入っていた袋（導電袋）に入れてください。




## INSTALLING THE WAVE EXPANSION BOARD

- \* Turn off your instrument.
1. Remove the cover located on the top (or rear) of your instrument.
  - \* When turning the unit upside-down, get a bunch of newspapers or magazines, and place them under the four corners or at both ends to prevent damage to the buttons and controls. Also, you should try to orient the unit so no buttons or controls get damaged.
  - \* When turning the unit upside-down, handle with care to avoid dropping it, or allowing it to fall or tip over.
  2. Insert the Wave Expansion Board connector into a connector for an SRX Series slot, while simultaneously inserting the board holders into the holes in the Wave Expansion Board.
  - \* Do not touch any of the printed circuit pathways or connection terminals.
  - \* Never use excessive force when installing a circuit board. If it doesn't fit properly on the first attempt, remove the board and try again.
  3. Use the supplied Installation Tool to turn the holders in the LOCK direction, so the board will be fastened in place.  
(To remove the Wave Expansion Board, turn the board holders in the UNLOCK direction, and lift up the board.)
  - \* When circuit board installation is complete, double-check your work.
  4. Using the screws removed in Step 1, refasten the cover in its original position.
  5. Check if the Wave Expansion Board is correctly installed.
  - \* If the "EXP" display cannot be selected (doesn't appear) in the Waveform Selection Screen (refer to the owner's manual of the instrument you use), remove the Wave Expansion Board and install it properly.

### French language

for Canadian Safety Standard

- \* Éteindre l'instrument.
1. Retirer le couvercle situé sur le dessus (ou à l'arrière) de l'instrument.
  2. Inserer le connecteur de la carte dans un des creneaux pour la série SRX tout en enfonçant les supports à carte dans les trous de celle-ci.
    - \* Ne pas toucher aux circuits imprimés ou aux connecteurs.
    - \* Ne jamais forcer lors de l'installation de la carte de circuits imprimés. Si la carte s'ajuste mal au premier essai, enlevez la carte et recommencez l'installation.
  3. Utiliser l'outil d'installation fourni pour tourner les clips de retenue vers la position de blocage (LOCK) de façon à ce que la carte soit retenue en place.  
(Pour retirer la carte d'expansion Wave, tourner les clips de retenue de la carte vers la position déblocage (UNLOCK) et retirer la carte en la soulevant.)
  - \* Quand l'installation de la carte de circuits imprimés est terminée, vérifiez si tout est bien installé.
  4. Remettre la plaque à sa place et la fixer à l'aide des vis enlevées à l'étape 1.
  5. S'assurer que la carte d'expansion Wave est installée correctement.
  - \* S'il est impossible de sélectionner l'affichage "EXP" (il n'apparaît pas) à l'écran de sélection Waveform (se reporter au guide du propriétaire de l'instrument utilisé), retirer la carte d'expansion Wave et la réinstaller correctement.



Position them as shown before you install the board.  
Avant l'installation, orienter les supports à carte tel qu'indiqué sur le schéma.  
取り付ける前に図のような向きに合わせます

## ウェーブ・エクスパンション・ボードの取り付けかた

- ※ 使用機器の電源スイッチをオフにしてください。
1. 使用機器の上部、または背面にあるカバーをはずします。
  - ※ 本体を裏返す際は、ボタン、つまみなどを破損しないように、新聞や雑誌などを重ねて本体の四隅や両端に敷いてください。また、その際、ボタン、つまみなどが破損しないような位置に配置してください。
  - ※ 本体を裏返す際は、落下や転倒を引き起こさないよう扱いにご注意ください。
  2. SRX シリーズ用のスロットのコネクターにウェーブ・エクスパンション・ボードのコネクターを差し込み、同時に基板ホルダーをウェーブ・エクスパンション・ボードの穴にはめ込みます。
  - ※ 回路部やコネクター部には手を触れないでください。
  - ※ 基板を無理に押し込まないでください。装着しにくい場合、いったん基板を外してやり直してください。
  3. 付属の固定用具で基板ホルダーをLOCK 方向に回し、ウェーブ・エクスパンション・ボードを固定します。  
(ウェーブ・エクスパンション・ボードを取り外すには、基板ホルダーをUNLOCK 方向に回してから取り外します。)
  - ※ 取り付けを終えたら、正しく取り付けられていることを再度確認してください。
  4. 手順 1 で外したネジで、カバーを元通りに取り付けます。
  5. ウェーブ・エクスパンション・ボードの取り付けが正しく行われたかを確認します。
  - ※ ウェーブフォームの選択画面（使用機器の取扱説明書参照）で“EXP”が選べない（表示されない）ときは、もう一度ウェーブ・エクスパンション・ボードをつけ直してください。

# Patch List (1)

## For Fantom series/XV series/MX-200

(BANK SELECT MSB : 93; LSB : 15 [No.001-128], LSB : 16 [No.129-256], LSB ; 17 [No.257-384], LSB;18 [No.385-448])

No.	Name	Voices	Category
1	Autopilot	4	BEAT&GROOVE #
2	ElasticHouse	5	BEAT&GROOVE #
3	Smash Beat	5	BEAT&GROOVE #
4	SawPortaLead	2	SOFT LEAD
5	Pure Bass	2	SYNTH BASS
6	Jazz Parrotz	6	TECHNO SYNTH
7	Nicer Slicer	4	PULSATING
8	Massivis	3	OTHER SYNTH
9	Trance Line1	5	OTHER SYNTH
10	Subtle Pads	4	BRIGHT PAD
11	Look Back	2	SOFT PAD
12	VesperTONE	4	SYNTH FX
13	Hit&Fx Menu	1	COMBINATION
14	Crowd 84	4	BEAT&GROOVE #
15	Hop Chop SRX	4	BEAT&GROOVE #
16	Skid 92	3	BEAT&GROOVE #
17	Predator 92	3	BEAT&GROOVE #
18	Scream! SRX	3	BEAT&GROOVE #
19	1978 116BPM	4	BEAT&GROOVE #
20	X-Tronic SRX	4	BEAT&GROOVE #
21	Trans SRX	4	BEAT&GROOVE #
22	AcidRiff 125	3	BEAT&GROOVE #
23	FullHous SRX	4	BEAT&GROOVE #
24	Funk E 125	4	BEAT&GROOVE #
25	Le Punk 125	4	BEAT&GROOVE #
26	TekOp SRX	4	BEAT&GROOVE #
27	Cauldron 138	4	BEAT&GROOVE #
28	Punkun 144	4	BEAT&GROOVE #
29	Blitzkrieg	4	BEAT&GROOVE #
30	Hauln 166	2	BEAT&GROOVE #
31	Antenna 61	3	BEAT&GROOVE #
32	Barry 76	3	BEAT&GROOVE #
33	Slipn 80	3	BEAT&GROOVE #
34	UndrTheStair	4	BEAT&GROOVE #
35	Slam 86	3	BEAT&GROOVE #
36	Only Human	4	BEAT&GROOVE #
37	BAD 88	3	BEAT&GROOVE #
38	Drama 89	4	BEAT&GROOVE #
39	Mon 90	3	BEAT&GROOVE #
40	McSick 90	4	BEAT&GROOVE #
41	Meanstreet	4	BEAT&GROOVE #
42	Meow 92	3	BEAT&GROOVE #
43	Blvd 96	3	BEAT&GROOVE #
44	Coder 98	3	BEAT&GROOVE #
45	iROBOT 120	4	BEAT&GROOVE
46	Lifeform 120	3	BEAT&GROOVE #
47	Haiti 120	4	BEAT&GROOVE #
48	Hiphouse 125	4	BEAT&GROOVE #
49	OW! 125	4	BEAT&GROOVE #
50	CHI 125	4	BEAT&GROOVE #
51	Miami 125	4	BEAT&GROOVE #
52	Swing 125	4	BEAT&GROOVE #
53	ObsessionSRX	4	BEAT&GROOVE #
54	PJ 144	3	BEAT&GROOVE #
55	Sky 160	4	BEAT&GROOVE #
56	Aerosol Can	4	BEAT&GROOVE
57	Triggroove	3	BEAT&GROOVE
58	De Final CUT	1	BEAT&GROOVE #
59	Chemicalspill	2	BEAT&GROOVE #
60	DerangedBeat	4	BEAT&GROOVE #
61	Cubit Dance	4	BEAT&GROOVE #
62	Multi Level	3	BEAT&GROOVE #
63	Random Beat	4	BEAT&GROOVE #
64	Sonic Beat	2	BEAT&GROOVE #
65	Fuzzy Wuzzy	2	BEAT&GROOVE #
66	Cyclone 125	2	BEAT&GROOVE #
67	Electrolux	8	BEAT&GROOVE #
68	Bongo Congo	2	BEAT&GROOVE #
69	Tricky Beat	5	BEAT&GROOVE #
70	Windmill 132	3	BEAT&GROOVE
71	SlamSymphony	3	COMBINATION
72	Time Pulse	3	COMBINATION #
73	TrainAComin	6	COMBINATION #
74	House Rules	3	COMBINATION #
75	Mother Ship	4	COMBINATION #
76	YankDoodlDo	4	COMBINATION
77	Elven Kbds	4	COMBINATION
78	DnB SRX	2	COMBINATION #
79	Beat Menu 1	1	BEAT&GROOVE
80	Beat Menu 2	1	BEAT&GROOVE
81	TarzanBottom	2	SYNTH BASS
82	Subporter	4	SYNTH BASS
83	Subsonics	3	SYNTH BASS
84	Sub Bass	1	SYNTH BASS
85	HiLo303/Mod	2	SYNTH BASS
86	Bass Ment 1	4	SYNTH BASS
87	Bass Ment 2	4	SYNTH BASS
88	TB SawBs SRX	1	SYNTH BASS
89	TB OwBs SRX	1	SYNTH BASS
90	Acidic Testz	4	SYNTH BASS

No.	Name	Voices	Category
91	Talk Bass	2	SYNTH BASS
92	VocoBass SRX	2	SYNTH BASS
93	Massive Bass	4	SYNTH BASS
94	TB Sqz SRX	2	SYNTH BASS
95	SQR Reso Bs	1	SYNTH BASS
96	SH-5 Synbass	1	SYNTH BASS
97	Juno Bs SRX	2	SYNTH BASS
98	SlippyBs SRX	2	SYNTH BASS
99	Arppy Bs SRX	2	SYNTH BASS
100	TB / SRX	3	SYNTH BASS
101	TB-notTB SRX	1	SYNTH BASS
102	Si<n>ck Bass	1	SYNTH BASS
103	Deep Fat Bas	2	SYNTH BASS
104	7 bit bass	2	SYNTH BASS
105	DistortObass	1	SYNTH BASS
106	Double Bass	2	SYNTH BASS
107	Killer Bass	1	SYNTH BASS
108	Dancer Bass	2	SYNTH BASS
109	Rava Bass	2	SYNTH BASS
110	Big Bad Bass	4	SYNTH BASS
111	Fat FM Bass	2	SYNTH BASS
112	JackYourBody	4	SYNTH BASS
113	Solid Bs SRX	2	SYNTH BASS
114	Thick Bass	3	SYNTH BASS
115	Deep Bass 2	3	SYNTH BASS
116	Bassamatazz	3	SYNTH BASS
117	Juno 6 Bass	2	SYNTH BASS
118	Da JubBs SRX	3	SYNTH BASS
119	Fizzle Bass	3	SYNTH BASS
120	Ringin' bass	2	SYNTH BASS
121	No Rez 4 You	2	SYNTH BASS
122	Boomer	2	SYNTH BASS
123	OrgAtk Bass	3	SYNTH BASS
124	WahBassMod X	4	SYNTH BASS
125	LFO SqzBass	1	SYNTH BASS
126	FallBend Bs	2	SYNTH BASS
127	Hocket Bass	2	BASS
128	FatBs / SRX	1	BASS
129	LoFi A.BsSRX	4	BASS
130	ProcesBs SRX	1	BASS
131	Solo flight	1	HARD LEAD
132	Euro mix SRX	3	HARD LEAD
133	Nitty Gritty	2	HARD LEAD
134	Alias Lead	2	HARD LEAD
135	Old Fi	3	HARD LEAD
136	Dist-O-Matic	1	HARD LEAD
137	Lead Dirt	2	HARD LEAD
138	RetroRave	3	HARD LEAD
139	Kreckle Lead	1	HARD LEAD
140	Outrage	1	HARD LEAD
141	HipassTB SRX	2	HARD LEAD
142	TB Squared	3	HARD LEAD
143	TB Saw	1	HARD LEAD
144	DistortedSaw	2	HARD LEAD
145	Nail Driver	4	HARD LEAD
146	Nasty 303	1	HARD LEAD
147	Dance Baby	4	HARD LEAD
148	5th Rave	3	HARD LEAD
149	Autu 101	3	HARD LEAD
150	Sine me in	4	SOFT LEAD
151	SoloSin SRX1	1	SOFT LEAD
152	SoloSin SRX2	1	SOFT LEAD
153	Piccolo solo	2	SOFT LEAD
154	Ana Flt SRX	1	SOFT LEAD
155	JUResLd SRX1	2	SOFT LEAD
156	Med Solo SRX	3	SOFT LEAD
157	MilkyWay SRX	3	SOFT LEAD
158	Shalot SRX	4	SOFT LEAD
159	3D Lead	1	SOFT LEAD
160	JUResLd SRX2	1	SOFT LEAD
161	Gringely	2	TECHNO SYNTH
162	EuroSteroidz	4	TECHNO SYNTH
163	Operator	2	TECHNO SYNTH
164	NeverStopRvn	4	TECHNO SYNTH
165	TheSteamRoks	4	TECHNO SYNTH
166	TechnoAttack	4	TECHNO SYNTH
167	Formantz	1	TECHNO SYNTH
168	SRX Talker	4	TECHNO SYNTH
169	Nanite Pops	4	TECHNO SYNTH
170	TechnoAmbint	8	TECHNO SYNTH
171	Ringywig	2	TECHNO SYNTH
172	OrganOran	2	TECHNO SYNTH
173	Piddlee-Dee	4	TECHNO SYNTH
174	Cool Beam	4	TECHNO SYNTH
175	First Synth	2	TECHNO SYNTH
176	Santaz House	4	TECHNO SYNTH
177	Sub Melodic	3	TECHNO SYNTH
178	Landing Crew	6	TECHNO SYNTH
179	Chime Blocks	4	TECHNO SYNTH
180	Chordon Bleu	4	TECHNO SYNTH

No.	Name	Voices	Category
181	Porter Rix	4	TECHNO SYNTH
182	PhenomenaSRX	4	TECHNO SYNTH
183	Club Hit	4	TECHNO SYNTH
184	ChrdMaj7 SRX	4	TECHNO SYNTH
185	ChrdMin7 SRX	4	TECHNO SYNTH
186	CordintheAct	5	PULSATING
187	MetroPoly	4	PULSATING
188	Lava Flow	1	PULSATING
189	Panorama	4	PULSATING
190	Nautilus	1	PULSATING
191	Sliced Bread	1	PULSATING
192	Time Machine	2	PULSATING
193	Ana Logic	1	PULSATING
194	Bass & More	1	PULSATING
195	In The Lab	2	PULSATING
196	Galaxia	3	PULSATING
197	Charmer	1	PULSATING
198	BrainWaveSRX	4	PULSATING
199	Replicants	1	PULSATING
200	Speak Delay	2	PULSATING
201	Location	3	PULSATING
202	Cyber SRX	3	PULSATING
203	EtheralitySRX	4	PULSATING
204	IceDream SRX	3	PULSATING
205	UpperStepper	2	PULSATING
206	Pedestrians	4	PULSATING
207	Starlite XV	4	OTHER SYNTH
208	Trance Line2	6	OTHER SYNTH
209	Eurosynth	2	OTHER SYNTH
210	Fat JP	3	OTHER SYNTH
211	EuroDnc SRX1	3	OTHER SYNTH
212	EuroDnc SRX2	3	OTHER SYNTH
213	XpressiveSRX	4	OTHER SYNTH
214	Organ-ized	3	OTHER SYNTH
215	Juno Pluck	2	OTHER SYNTH
216	Juno Plucked	2	OTHER SYNTH
217	Rubberized	3	OTHER SYNTH
218	Intense Vibe	4	OTHER SYNTH
219	Intense Euro	5	OTHER SYNTH
220	Generation e	4	OTHER SYNTH
221	NewSkool 70s	4	OTHER SYNTH
222	SyncDiffrent	2	OTHER SYNTH
223	Kill Eyeopee	3	OTHER SYNTH
224	FM Ringer	2	OTHER SYNTH
225	Live at 5	3	OTHER SYNTH
226	Octo	3	OTHER SYNTH
227	Alpha Fizz	2	OTHER SYNTH
228	FunkyJunoHrp	2	OTHER SYNTH
229	Steel Piano	2	OTHER SYNTH
230	Velorez 8000	3	OTHER SYNTH
231	JU Keys SRX	2	OTHER SYNTH
232	Euronal Syn	4	OTHER SYNTH
233	Daft	2	OTHER SYNTH
234	Neurotic Syn	5	OTHER SYNTH
235	Deep Forest	4	OTHER SYNTH
236	Pip Square	2	OTHER SYNTH
237	Funky Pluck	2	OTHER SYNTH
238	Tight TB	2	OTHER SYNTH
239	Saw Yr Point	2	OTHER SYNTH
240	Shortsawz	4	OTHER SYNTH
241	Tropical Syn	4	OTHER SYNTH
242	JU Pluck SRX	1	OTHER SYNTH
243	TB AtkDst	4	OTHER SYNTH
244	Amber	1	OTHER SYNTH
245	Vox Switcher	2	OTHER SYNTH
246	Juno Strings	2	BRIGHT PAD
247	DetuneSawStr	2	BRIGHT PAD
248	Wavebreaker	3	BRIGHT PAD
249	Vintage Pad	4	BRIGHT PAD
250	Glitz	4	BRIGHT PAD
251	Discrete	4	BRIGHT PAD
252	VntageRevSRX	3	BRIGHT PAD
253	Explore SRX	3	BRIGHT PAD
254	AfterPad SRX	3	BRIGHT PAD
255	Euro Strings	3	BRIGHT PAD
256	Powder	3	BRIGHT PAD
257	JU&JP PhsSRX	2	BRIGHT PAD
258	Lost In Time	4	SOFT PAD
259	Europad	3	SOFT PAD
260	Avalon SRX	4	SOFT PAD
261	Dreames SRX	3	SOFT PAD
262	SirenSng SRX	4	SOFT PAD
263	CricketChoir	3	SOFT PAD
264	TV Drama	3	SOFT PAD
265	Elven Times	4	SOFT PAD
266	TwilightPad	4	SOFT PAD
267	WarmerPd SRX	2	SOFT PAD
268	SoftStrngSRX	2	SOFT PAD
269	AlphaWavePad	3	SOFT PAD
270	Micromusic	7	SYNTH FX

# Patch List (2)

## For Fantom series/XV series/MX-200

(BANK SELECT MSB : 93; LSB : 15 [No.001-128], LSB : 16 [No.129-256], LSB ; 17 [No.257-384], LSB;18 [No.385-448])

No.	Name	Voices	Category
271	LittleDowners	4	SYNTH FX
272	Fulcanelli03	5	SYNTH FX
273	Galaxial	2	SYNTH FX
274	It's Outside	3	SYNTH FX
275	Alien Life	3	SYNTH FX
276	Prey 160	4	SYNTH FX
277	Transender	3	SYNTH FX
278	Steel Drone	3	SYNTH FX
279	Trissle	1	SYNTH FX
280	Dimensions	4	SYNTH FX
281	TuneBrethSRX	2	SYNTH FX
282	Sonic Saucer	2	SYNTH FX
283	Alter Native	5	SYNTH FX
284	Evolution	3	SYNTH FX
285	Outer Space	2	SYNTH FX
286	Hyperspace	7	SYNTH FX
287	WhaleUnitSRX	3	SYNTH FX
288	Orcafreq SRX	2	SYNTH FX
289	CrepedOutSRX	2	SYNTH FX
290	Bombay Drone	4	SYNTH FX
291	Fathoms SRX	2	SYNTH FX
292	MothrshipSRX	4	SYNTH FX
293	Cleaners	1	SYNTH FX
294	Vinylprelude	2	SYNTH FX
295	Turbine SRX	3	SYNTH FX
296	Thrilling	1	SYNTH FX
297	Bada Boing	6	SYNTH FX
298	Confused	3	SYNTH FX
299	Revolution#9	4	SYNTH FX
300	Bugstep Noot	3	SYNTH FX
301	Crotals	3	SYNTH FX
302	Big Bang *	3	SYNTH FX
303	South Sahara	4	SYNTH FX
304	MunchiesPt12	4	SYNTH FX
305	AlternSawSRX	1	SYNTH FX
306	ElectroJamSRX	2	SYNTH FX
307	Zaps	2	SYNTH FX
308	B-Movie	2	SYNTH FX
309	ScientistSRX	1	SYNTH FX
310	Siren	2	SYNTH FX
311	Sliderz SRX	4	SYNTH FX
312	Krashead	2	SYNTH FX
313	Iron Hit SRX	1	SYNTH FX
314	DrumMeltDown	4	SYNTH FX
315	TR Synhit	4	SYNTH FX
316	Pit People	5	SYNTH FX
317	Mad RHythM	1	SYNTH FX
318	ModrnLifeSRX	3	SYNTH FX
319	BigBang SRX	3	SYNTH FX
320	GateKeperSRX	3	SYNTH FX
321	UndrWaterSRX	3	SOUND FX
322	TheWetSet	7	SOUND FX
323	DJ stuff SRX	2	SOUND FX
324	Skratchy SRX	1	SOUND FX
325	78 RPM SRX	1	SOUND FX
326	3D Turntable	2	SOUND FX
327	RadioBrekSRX	1	SOUND FX
328	Faze Ct&Bass	1	HIT&STAB
329	Hse Stb 125	4	HIT&STAB
330	Full Force	4	HIT&STAB

No.	Name	Voices	Category
331	Soho Clubs	3	HIT&STAB
332	GarageChdSRX	4	HIT&STAB
333	Crap Stab	4	HIT&STAB
334	2am-11am	4	HIT&STAB
335	Hit&Run SRX	4	HIT&STAB
336	HIT in face	3	HIT&STAB
337	LoFi-Itz SRX	1	HIT&STAB
338	Next Stab	4	HIT&STAB
339	Brazzer LoFi	2	HIT&STAB
340	Big Stab SRX	4	HIT&STAB
341	30's Tpt SRX	1	HIT&STAB
342	BrsFall SRX	1	HIT&STAB
343	Slammer	4	HIT&STAB
344	Tribal Disco	3	HIT&STAB
345	DiscoStr Hit	1	HIT&STAB
346	Break HIT	3	HIT&STAB
347	Cwisp SRX	1	HIT&STAB
348	NYC Club SRX	4	HIT&STAB
349	Tape Stops	2	HIT&STAB
350	LoFi Subsine	1	HIT&STAB
351	Maj/Min /	3	HIT&STAB
352	Techno Logic	1	HIT&STAB
353	Slam Hit	4	HIT&STAB
354	Image BOOM!	2	HIT&STAB
355	Keep Clubing	4	HIT&STAB
356	Techno Riff1	3	HIT&STAB
357	MySweetHouse	4	HIT&STAB
358	LateNiteTunz	4	HIT&STAB
359	Moody Vibes	4	HIT&STAB
360	Exit 2	2	HIT&STAB
361	Massive	4	HIT&STAB
362	Techno Riff2	4	HIT&STAB
363	Metalsmith	4	HIT&STAB
364	Meteor Pelt	4	HIT&STAB
365	China White	4	HIT&STAB
366	NewTech D&B	3	HIT&STAB
367	Water Plug	4	HIT&STAB
368	Tribal Steel	4	HIT&STAB
369	Tech Pno SRX	4	AC.PIANO
370	LightPno SRX	2	AC.PIANO
371	90s Pno SRX	4	AC.PIANO
372	1FingrPnoSRX	4	AC.PIANO
373	Pf/Key Menu	1	COMBINATION
374	Substitute	2	EL.PIANO
375	HiphopEP SRX	2	EL.PIANO
376	Assembled	3	EL.PIANO
377	MellowTremSRX	1	EL.PIANO
378	Echo EP SRX	1	EL.PIANO
379	77GaragesSRX	1	EL.PIANO
380	Wurlpool	3	EL.PIANO
381	Lo Fi Wurli	2	EL.PIANO
382	Dance Organ	3	ORGAN
383	Juno Org SRX	2	ORGAN
384	Clubbed Organ	2	ORGAN
385	Pop B	2	ORGAN
386	Vel Syn Org	2	ORGAN
387	SpenderOrgan	4	ORGAN
388	Tines&Wheels	5	ORGAN
389	Thick Organ	2	ORGAN
390	1FingrOrgSRX	4	ORGAN

No.	Name	Voices	Category
391	Shorty Organ	2	ORGAN
392	1FingrShrOrg	4	ORGAN
393	Clav-ClubSRX	2	KEYBOARDS
394	DanceClavSRX	4	KEYBOARDS
395	CeremonyBell	5	BELL
396	AnaBells SRX	3	BELL
397	Guitar Stuff	1	EL.GUITAR
398	WahWahMelSRX	1	EL.GUITAR
399	GTRPowerSRX1	1	DIST.GUITAR
400	GTRPowerSRX2	1	DIST.GUITAR
401	FakeHead Hit	2	DIST.GUITAR
402	Distinctive	4	DIST.GUITAR
403	Gtr&BassMenu	1	COMBINATION
404	Pizz Xpress	4	STRINGS
405	Tek Pizz SRX	1	STRINGS
406	Stringy Stab	2	STRINGS
407	CS80Brass	1	SYNTH BRASS
408	Fat Brass	2	SYNTH BRASS
409	Talk Box SRX	1	VOX
410	TekMusic SRX	3	VOX
411	1.2.3.4. SRX	4	VOX
412	1234 x4 SRX	1	VOX
413	Baby...? SRX	3	VOX
414	Vox Menu 1	1	VOX
415	Vox Menu 2	1	VOX
416	MelodicDrums	4	DRUMS
417	Drumpeopled1	4	DRUMS
418	Drumpeopled2	4	DRUMS
419	Drumpeopled3	4	DRUMS
420	KitTek.drmFX	4	DRUMS
421	Hardcore Hit	4	DRUMS
422	Kick Menu 1	1	DRUMS
423	Kick Menu 2	1	DRUMS
424	Kick Menu 3	1	DRUMS
425	Snare Menu 1	1	DRUMS
426	Snare Menu 2	1	DRUMS
427	Snare Menu 3	1	DRUMS
428	Snare Menu 4	1	DRUMS
429	Snare Menu 5	1	DRUMS
430	HiHat Menu 1	1	DRUMS
431	HiHat Menu 2	1	DRUMS
432	HH&Cym Menu	1	DRUMS
433	Cymbal Menu	1	DRUMS
434	Tom Menu	2	DRUMS
435	Clap Menu	1	DRUMS
436	808 Chord	4	PERCUSSION
437	808 Conga 3D	2	PERCUSSION
438	Slow Chimes	2	PERCUSSION
439	Dirty Sox	2	PERCUSSION
440	ExtremPercus	4	PERCUSSION
441	Pure Tribal	3	PERCUSSION
442	TeknoTriangl	1	PERCUSSION
443	Tamb&SkrMenu	1	PERCUSSION
444	Cow&Kini Menu	1	PERCUSSION
445	Perc. Menu 1	1	PERCUSSION
446	Perc. Menu 2	1	PERCUSSION
447	Perc. Menu 3	1	PERCUSSION
448	Perc. Menu 4	1	PERCUSSION

/: Alternate sound obtained with Key Velocity

/Mod: Alternate sound obtained with Modulation (CC:01)

#: Patches using Phrase Loop Waveforms. The numbers included in the Patch name represent the recommended tempo (B.P.M.).

When playing patches on the expansion board, we recommend that you set all the EFFECTS ON/OFF settings on the Fantom series/XV series to "ON." If such settings are set to "OFF," you may not obtain the intended sound.

- \* Note that the Release Time has been set to a fairly long value for some of the patches. As a result, if your sound generator has been set so "Patch Remain" is "ON," the release portion of a previously sounding patch may continue to be heard even after switching to a new patch.
- \* Some of the patches use waveforms of the SR-JV80 series. For this reason, the upper end of the keyboard may not sound because of key range restrictions.
- \* Refer to the owner's manual for your instrument for specific instructions on how to play Patches on the expansion board.
- \* On the Fantom series/XV series/MX-200, you can not select only the patches which are designed to be used with the RD series (with SRX slots)/MC-909/VR-760/G-70.
- \* Some of the patch names shown in this list may appear differently on the display of the device being used, but the tones themselves remain unaffected.

/: Key Velocity による切替え音色

/Mod: Modulation (CC:01) による切替え音色

#: フレーズ・ループのウェーブフォームを使用したパッチです。パッチ・ネームに付いている数字は推奨テンポ (B.P.M.) です。

エクスパンション・ボードのパッチを発音させるときは、Fantomシリーズ/XVシリーズのEFFECTS ON/OFF の設定をすべて ON にして使用することをお勧めいたします。OFF に設定した場合、意図した音色にならないことがあります。

- \* パッチの中にはリリース・タイムが長く設定してあるパッチもありますので、音源のパッチ・リメイクが ON になっていると音色を切り替えても前のパッチのリリースが残る場合があります。
- \* パッチの中には SR-JV80 シリーズのウェーブフォームを使用しているため、上鍵域で発音の制限があり発音しない部分があります。
- \* エクスパンション・ボードのパッチを発音させるときは、使用機器の取扱説明書にしたがって、実行してください。
- \* Fantomシリーズ/XVシリーズ/MX-200 では、RD シリーズ (SRX 対応) /MC-909/VR-760 専用のパッチを選ぶことはできません。
- \* 一部のパッチの名前が、本リストと使用機器の画面表示とで異なる場合がありますが、音色自体に影響はありません。

# Patch List (3)

## For RD series (with SRX slots)/MC-909/VR-760/G-70

(BANK SELECT MSB : 93; LSB : 15 [No.001-128], LSB : 16 [No.129-256], LSB ; 17 [No.257-384], LSB;18 [No.385-448])

No.	Name	Voices	Category
1	Autopilot	4	BEAT&GROOVE #
2	ElasticHouse	5	BEAT&GROOVE #
3	Smash Beat	5	BEAT&GROOVE #
4	SawPortaLead	2	SOFT LEAD
5	Pure Bass	2	SYNTH BASS
6	Jazz Parrotz	6	TECHNO SYNTH
7	Nicer Slicer	4	PULSATING
8	Massivis	3	OTHER SYNTH
9	Trance Line1	5	OTHER SYNTH
10	Subtle Pads	4	BRIGHT PAD
11	Look Back	2	SOFT PAD
12	VesperTONE	4	SYNTH FX
13	Hit&Fx Menu	1	COMBINATION
14	Crowd 84	4	BEAT&GROOVE #
15	Hop Chop SRX	4	BEAT&GROOVE #
16	Skid 92	3	BEAT&GROOVE #
17	Predator 92	3	BEAT&GROOVE #
18	Scream! SRX	3	BEAT&GROOVE #
19	1978 116BPM	4	BEAT&GROOVE #
20	X-Tronic SRX	4	BEAT&GROOVE #
21	Trans SRX	4	BEAT&GROOVE #
22	AcidRiff 125	3	BEAT&GROOVE #
23	FullHous SRX	4	BEAT&GROOVE #
24	Funk E 125	4	BEAT&GROOVE #
25	Le Punk 125	4	BEAT&GROOVE #
26	TekOp SRX	4	BEAT&GROOVE #
27	Cauldron 138	4	BEAT&GROOVE #
28	Punkens 144	4	BEAT&GROOVE #
29	Blitzkrieg	4	BEAT&GROOVE #
30	Hauln 166	2	BEAT&GROOVE #
31	Antenna 61	3	BEAT&GROOVE #
32	Barry 76	3	BEAT&GROOVE #
33	Slipn 80	3	BEAT&GROOVE #
34	UndrTheStair	4	BEAT&GROOVE #
35	Slam 86	3	BEAT&GROOVE #
36	Only Human	4	BEAT&GROOVE #
37	BAD 88	3	BEAT&GROOVE #
38	Drama 89	4	BEAT&GROOVE #
39	Mon 90	3	BEAT&GROOVE #
40	McSick 90	4	BEAT&GROOVE #
41	Meanstreet	4	BEAT&GROOVE #
42	Meow 92	3	BEAT&GROOVE #
43	Blvd 96	3	BEAT&GROOVE #
44	Coder 98	3	BEAT&GROOVE #
45	iROBOT 120	4	BEAT&GROOVE
46	Lifeform 120	3	BEAT&GROOVE #
47	Haiti 120	4	BEAT&GROOVE #
48	Hiphouse 125	4	BEAT&GROOVE #
49	OW! 125	4	BEAT&GROOVE #
50	CHI 125	4	BEAT&GROOVE #
51	Miami 125	4	BEAT&GROOVE #
52	Swing 125	4	BEAT&GROOVE #
53	ObsessionSRX	4	BEAT&GROOVE #
54	PJ 144	3	BEAT&GROOVE #
55	Sky 160	4	BEAT&GROOVE #
56	Aerosol Can	4	BEAT&GROOVE
57	Triggroove	3	BEAT&GROOVE
58	De Final CUT	1	BEAT&GROOVE #
59	Chemicalspill	2	BEAT&GROOVE #
60	DerangedBeat	4	BEAT&GROOVE #
61	Cubit Dance	4	BEAT&GROOVE #
62	Multi Level	3	BEAT&GROOVE #
63	Random Beat	4	BEAT&GROOVE #
64	Sonic Beat	2	BEAT&GROOVE #
65	Fuzzy Wuzzy	2	BEAT&GROOVE #
66	Cyclone 125	2	BEAT&GROOVE #
67	Electrolux	8	BEAT&GROOVE #
68	Bongo Congo	2	BEAT&GROOVE #
69	Tricky Beat	5	BEAT&GROOVE #
70	Windmill 132	3	BEAT&GROOVE
71	SlamSymphony	3	COMBINATION
72	Time Pulse	3	COMBINATION #
73	TrainAComin	6	COMBINATION #
74	House Rules	3	COMBINATION #
75	Mother Ship	4	COMBINATION #
76	YankDoodlDo	4	COMBINATION
77	Elven Kbds	4	COMBINATION
78	DnB SRX	2	COMBINATION #
79	Beat Menu 1	1	BEAT&GROOVE
80	Beat Menu 2	1	BEAT&GROOVE
81	TarzanBottom	2	SYNTH BASS
82	Subporter	4	SYNTH BASS
83	Subsonics	3	SYNTH BASS
84	Sub Bass	1	SYNTH BASS
85	HiLo303/Mod	2	SYNTH BASS
86	Bass Ment 1	4	SYNTH BASS
87	Bass Ment 2	4	SYNTH BASS
88	TB SawBs SRX	1	SYNTH BASS
89	TB OwBs SRX	1	SYNTH BASS
90	Acidic Testz	4	SYNTH BASS

No.	Name	Voices	Category
91	Talk Bass	2	SYNTH BASS
92	VocoBass SRX	2	SYNTH BASS
93	Massive Bass	4	SYNTH BASS
94	TB Sqz SRX	2	SYNTH BASS
95	SQR Reso Bs	1	SYNTH BASS
96	SH-5 Synbass	1	SYNTH BASS
97	Juno Bs SRX	2	SYNTH BASS
98	SlippyBs SRX	2	SYNTH BASS
99	Arppy Bs SRX	2	SYNTH BASS
100	TB / SRX	3	SYNTH BASS
101	TB-notTB SRX	1	SYNTH BASS
102	Si<n>ck Bass	1	SYNTH BASS
103	Deep Fat Bs	2	SYNTH BASS
104	7 bit bass	2	SYNTH BASS
105	DistortObass	1	SYNTH BASS
106	Double Bass	2	SYNTH BASS
107	Killer Bass	1	SYNTH BASS
108	Dancer Bass	2	SYNTH BASS
109	Rava Bass	2	SYNTH BASS
110	Big Bad Bass	4	SYNTH BASS
111	Fat FM Bass	2	SYNTH BASS
112	JackYourBody	4	SYNTH BASS
113	Solid Bs SRX	2	SYNTH BASS
114	Thick Bass	3	SYNTH BASS
115	Deep Bass 2	3	SYNTH BASS
116	Bassamatazz	3	SYNTH BASS
117	Juno 6 Bass	2	SYNTH BASS
118	Da JubBs SRX	3	SYNTH BASS
119	Fizzle Bass	3	SYNTH BASS
120	Ringin' bass	2	SYNTH BASS
121	No Rez 4 You	2	SYNTH BASS
122	Boomer	2	SYNTH BASS
123	OrgAtk Bass	3	SYNTH BASS
124	WahBassMod X	4	SYNTH BASS
125	LFO SqzBass	1	SYNTH BASS
126	FallBend Bs	2	SYNTH BASS
127	Hocket Bass	2	BASS
128	FatBs / SRX	1	BASS
129	LoFi A.BsSRX	4	BASS
130	ProcesBs SRX	1	BASS
131	Solo flight	1	HARD LEAD
132	Euro mix SRX	3	HARD LEAD
133	Nitty Gritty	2	HARD LEAD
134	Alias Lead	2	HARD LEAD
135	Old Fi	3	HARD LEAD
136	Dist-O-Matic	1	HARD LEAD
137	Lead Dirt	2	HARD LEAD
138	RetroRave	3	HARD LEAD
139	Kreckle Lead	1	HARD LEAD
140	Outrage	1	HARD LEAD
141	HipassTB SRX	2	HARD LEAD
142	TB Squared	3	HARD LEAD
143	TB Saw	1	HARD LEAD
144	DistortedSaw	2	HARD LEAD
145	Nail Driver	4	HARD LEAD
146	Nasty 303	1	HARD LEAD
147	Dance Baby	4	HARD LEAD
148	5th Rave	3	HARD LEAD
149	Autu 101	3	HARD LEAD
150	Sine me in	4	SOFT LEAD
151	SoloSin SRX1	1	SOFT LEAD
152	SoloSin SRX2	1	SOFT LEAD
153	Piccolo solo	2	SOFT LEAD
154	Ana Flt SRX	1	SOFT LEAD
155	JUResLd SRX1	2	SOFT LEAD
156	Med Solo SRX	3	SOFT LEAD
157	MilkyWay SRX	3	SOFT LEAD
158	Shalot SRX	4	SOFT LEAD
159	3D Lead	1	SOFT LEAD
160	JUResLd SRX2	1	SOFT LEAD
161	Gringely	2	TECHNO SYNTH
162	EuroSteroidz	4	TECHNO SYNTH
163	Operator	2	TECHNO SYNTH
164	NeverStopRvn	4	TECHNO SYNTH
165	TheSteamRoks	4	TECHNO SYNTH
166	TechnoAttack	4	TECHNO SYNTH
167	Formantz	1	TECHNO SYNTH
168	SRX Talker	4	TECHNO SYNTH
169	Nanite Pops	4	TECHNO SYNTH
170	TechnoAmbint	5	TECHNO SYNTH
171	Ringywig	2	TECHNO SYNTH
172	OrganOran	2	TECHNO SYNTH
173	Piddlee-Dee	4	TECHNO SYNTH
174	Cool Beam	4	TECHNO SYNTH
175	First Synth	2	TECHNO SYNTH
176	Santaz House	4	TECHNO SYNTH
177	Sub Melodic	3	TECHNO SYNTH
178	Landing Crew	6	TECHNO SYNTH
179	Chime Blocks	4	TECHNO SYNTH
180	Chordon Bleu	4	TECHNO SYNTH

No.	Name	Voices	Category
181	Porter Rix	4	TECHNO SYNTH
182	PhenomenaSRX	4	TECHNO SYNTH
183	Club Hit	4	TECHNO SYNTH
184	ChrdMaj7 SRX	4	TECHNO SYNTH
185	ChrdMin7 SRX	4	TECHNO SYNTH
186	CordintheAct	4	PULSATING
187	MetroPoly	4	PULSATING
188	Lava Flow	1	PULSATING
189	Panorama	4	PULSATING
190	Nautilus	1	PULSATING
191	Sliced Bread	1	PULSATING
192	Time Machine	2	PULSATING
193	Ana Logic	1	PULSATING
194	Bass & More	1	PULSATING
195	In The Lab	2	PULSATING
196	Galaxia	3	PULSATING
197	Charmer	1	PULSATING
198	BrainWaveSRX	4	PULSATING
199	Replicants	1	PULSATING
200	Speak Delay	2	PULSATING
201	Location	3	PULSATING
202	Cyber SRX	3	PULSATING
203	EtheralitySRX	4	PULSATING
204	IceDream SRX	3	PULSATING
205	UpperStepper	2	PULSATING
206	Pedestrians	4	PULSATING
207	Starlite XV	4	OTHER SYNTH
208	Trance Line2	6	OTHER SYNTH
209	Eurosynth	2	OTHER SYNTH
210	Fat JP	3	OTHER SYNTH
211	EuroDnc SRX1	3	OTHER SYNTH
212	EuroDnc SRX2	3	OTHER SYNTH
213	XpressiveSRX	4	OTHER SYNTH
214	Organ-ized	3	OTHER SYNTH
215	Juno Pluck	2	OTHER SYNTH
216	Juno Plucked	2	OTHER SYNTH
217	Rubberized	3	OTHER SYNTH
218	Intense Vibe	4	OTHER SYNTH
219	Intense Euro	5	OTHER SYNTH
220	Generation e	4	OTHER SYNTH
221	NewSkool 70s	4	OTHER SYNTH
222	SyncDiffrent	2	OTHER SYNTH
223	Kill Eyeopee	3	OTHER SYNTH
224	FM Ringer	2	OTHER SYNTH
225	Live at 5	3	OTHER SYNTH
226	Octo	3	OTHER SYNTH
227	Alpha Fizz	2	OTHER SYNTH
228	FunkyJunoHrp	2	OTHER SYNTH
229	Steel Piano	2	OTHER SYNTH
230	Velorez 8000	3	OTHER SYNTH
231	JU Keys SRX	2	OTHER SYNTH
232	Euronal Syn	4	OTHER SYNTH
233	Daft	2	OTHER SYNTH
234	Neurotic Syn	5	OTHER SYNTH
235	Deep Forest	4	OTHER SYNTH
236	Pip Square	2	OTHER SYNTH
237	Funky Pluck	2	OTHER SYNTH
238	Tight TB	2	OTHER SYNTH
239	Saw Yr Point	2	OTHER SYNTH
240	Shortsawz	4	OTHER SYNTH
241	Tropical Syn	4	OTHER SYNTH
242	JU Pluck SRX	1	OTHER SYNTH
243	TB AtkDst	4	OTHER SYNTH
244	Amber	1	OTHER SYNTH
245	Vox Switcher	2	OTHER SYNTH
246	Juno Strings	2	BRIGHT PAD
247	DetuneSawStr	2	BRIGHT PAD
248	Wavebreaker	3	BRIGHT PAD
249	Vintage Pad	4	BRIGHT PAD
250	Glitz	4	BRIGHT PAD
251	Discrete	4	BRIGHT PAD
252	VntageRevSRX	3	BRIGHT PAD
253	Explore SRX	2	BRIGHT PAD
254	AfterPad SRX	3	BRIGHT PAD
255	Euro Strings	3	BRIGHT PAD
256	Powder	3	BRIGHT PAD
257	JU&JP PhsSRX	2	BRIGHT PAD
258	Lost In Time	4	SOFT PAD
259	Europad	3	SOFT PAD
260	Avalon SRX	4	SOFT PAD
261	Dreames SRX	2	SOFT PAD
262	SirenSng SRX	4	SOFT PAD
263	CricketChoir	3	SOFT PAD
264	TV Drama	3	SOFT PAD
265	Elven Times	4	SOFT PAD
266	TwilightPad	4	SOFT PAD
267	WarmerPd SRX	2	SOFT PAD
268	SoftStrngSRX	2	SOFT PAD
269	AlphaWavePad	3	SOFT PAD
270	Micromusic	7	SYNTH FX

# Patch List (4)

## For RD series (with SRX slots)/MC-909/VR-760/G-70

(BANK SELECT MSB : 93; LSB : 15 [No.001-128], LSB : 16 [No.129-256], LSB : 17 [No.257-384], LSB:18 [No.385-448])

No.	Name	Voices	Category
271	LittleDowners	4	SYNTH FX
272	Fulcanelli03	5	SYNTH FX
273	Galaxial	2	SYNTH FX
274	It's Outside	3	SYNTH FX
275	Alien Life	3	SYNTH FX
276	Prey 160	4	SYNTH FX
277	Transender	3	SYNTH FX
278	Steel Drone	3	SYNTH FX
279	Trissle	1	SYNTH FX
280	Dimensions	4	SYNTH FX
281	TuneBrethSRX	2	SYNTH FX
282	Sonic Saucer	2	SYNTH FX
283	Alter Native	5	SYNTH FX
284	Evolution	3	SYNTH FX
285	Outer Space	2	SYNTH FX
286	Hyperspace	6	SYNTH FX
287	WhaleUnitSRX	3	SYNTH FX
288	Orcafreq SRX	2	SYNTH FX
289	CrepedOutSRX	2	SYNTH FX
290	Bombay Drone	4	SYNTH FX
291	Fathoms SRX	2	SYNTH FX
292	MothrshipSRX	4	SYNTH FX
293	Cleaners	1	SYNTH FX
294	Vinylprelude	2	SYNTH FX
295	Turbine SRX	3	SYNTH FX
296	Thrilling	1	SYNTH FX
297	Bada Boing	6	SYNTH FX
298	Confused	3	SYNTH FX
299	Revolution#9	4	SYNTH FX
300	Bugstep Noot	3	SYNTH FX
301	Crotals	3	SYNTH FX
302	Big Bang *	3	SYNTH FX
303	South Sahara	4	SYNTH FX
304	MunchiesPt12	4	SYNTH FX
305	AlternSawSRX	1	SYNTH FX
306	ElectroJamSRX	2	SYNTH FX
307	Zaps	2	SYNTH FX
308	B-Movie	2	SYNTH FX
309	ScientistSRX	1	SYNTH FX
310	Siren	2	SYNTH FX
311	Sliderz SRX	4	SYNTH FX
312	Krashead	2	SYNTH FX
313	Iron Hit SRX	1	SYNTH FX
314	DrumMeltDown	4	SYNTH FX
315	TR Synhit	4	SYNTH FX
316	Pit People	3	SYNTH FX
317	Mad RHfThM	1	SYNTH FX
318	ModrnLifeSRX	3	SYNTH FX
319	BigBang SRX	3	SYNTH FX
320	GateKeperSRX	3	SYNTH FX
321	UndrWaterSRX	3	SOUND FX
322	TheWetSet	7	SOUND FX
323	DJ stuff SRX	2	SOUND FX
324	Skratchy SRX	1	SOUND FX
325	78 RPM SRX	1	SOUND FX
326	3D Turntable	2	SOUND FX
327	RadioBrekSRX	1	SOUND FX
328	Faze Ct&Bass	1	HIT&STAB
329	Hse Stb 125	4	HIT&STAB
330	Full Force	4	HIT&STAB

/: Alternate sound obtained with Key Velocity

/Mod: Alternate sound obtained with Modulation (CC:01)

#: Patches using Phrase Loop Waveforms. The numbers included in the Patch name represent the recommended tempo (B.P.M.).

- \* With some tones, tempos may change suddenly or noise may be produced. This occurs when the tempo is being synchronized, for example to multi-effects or chorus delay times. If the noise becomes noticeable, change the delay time value settings to something other than times corresponding to beats.
- \* Some of the patches use waveforms of the SR-JV80 series. For this reason, the upper end of the keyboard may not sound because of key range restrictions.
- \* On the RD series (with SRX slots)/MC-909/VR-760/G-70, you can not select only the patches which are designed to be used with the Fantom series/XV series/MX-200.
- \* Some of the patch names shown in this list may appear differently on the display of the device being used, but the tones themselves remain unaffected.

No.	Name	Voices	Category
331	Soho Clubs	3	HIT&STAB
332	GarageChdSRX	4	HIT&STAB
333	Crap Stab	4	HIT&STAB
334	2am-11am	4	HIT&STAB
335	Hit&Run SRX	4	HIT&STAB
336	HIT in face	3	HIT&STAB
337	LoFi-Itz SRX	1	HIT&STAB
338	Next Stab	4	HIT&STAB
339	Brazzer LoFi	2	HIT&STAB
340	Big Stab SRX	4	HIT&STAB
341	30's Tpt SRX	1	HIT&STAB
342	BrsFall SRX	1	HIT&STAB
343	Slammer	4	HIT&STAB
344	Tribal Disco	3	HIT&STAB
345	DiscoStr Hit	1	HIT&STAB
346	Break HIT	3	HIT&STAB
347	Cwisp SRX	1	HIT&STAB
348	NYC Club SRX	4	HIT&STAB
349	Tape Stops	2	HIT&STAB
350	LoFi Subsine	1	HIT&STAB
351	Maj/Min /	3	HIT&STAB
352	Techno Logic	1	HIT&STAB
353	Slam Hit	4	HIT&STAB
354	Image BOOM!	2	HIT&STAB
355	Keep Clubing	4	HIT&STAB
356	Techno Riff1	3	HIT&STAB
357	MySweetHouse	4	HIT&STAB
358	LateNiteTunz	4	HIT&STAB
359	Moody Vibes	4	HIT&STAB
360	Exit 2	2	HIT&STAB
361	Massive	4	HIT&STAB
362	Techno Riff2	4	HIT&STAB
363	Metalsmith	4	HIT&STAB
364	Meteor Pelt	3	HIT&STAB
365	China White	4	HIT&STAB
366	NewTech D&B	3	HIT&STAB
367	Water Plug	4	HIT&STAB
368	Tribal Steel	4	HIT&STAB
369	Tech Pno SRX	2	AC.PIANO
370	LightPno SRX	2	AC.PIANO
371	90s Pno SRX	4	AC.PIANO
372	1FingPnoSRX	4	AC.PIANO
373	Pf/Key Menu	1	COMBINATION
374	Substitute	2	EL.PIANO
375	HiphopEP SRX	2	EL.PIANO
376	Assembled	3	EL.PIANO
377	MellowTremSRX	1	EL.PIANO
378	Echo EP SRX	1	EL.PIANO
379	77GaragesSRX	1	EL.PIANO
380	Wurlpool	3	EL.PIANO
381	Lo Fi Wurli	2	EL.PIANO
382	Dance Organ	3	ORGAN
383	Juno Org SRX	2	ORGAN
384	Clubbed Organ	2	ORGAN
385	Pop B	2	ORGAN
386	Vel Syn Org	2	ORGAN
387	SpenderOrgan	4	ORGAN
388	Tines&Wheels	5	ORGAN
389	Thick Organ	2	ORGAN
390	1FingOrgSRX	4	ORGAN

No.	Name	Voices	Category
391	Shorty Organ	2	ORGAN
392	1FingrShrOrg	4	ORGAN
393	Clav-ClubSRX	2	KEYBOARDS
394	DanceClavSRX	2	KEYBOARDS
395	CeremonyBell	5	BELL
396	AnaBells SRX	3	BELL
397	Guitar Stuff	1	EL.GUITAR
398	WahWahMelSRX	1	EL.GUITAR
399	GTRPowerSRX1	1	DIST.GUITAR
400	GTRPowerSRX2	1	DIST.GUITAR
401	FakeHead Hit	2	DIST.GUITAR
402	Distinctive	3	DIST.GUITAR
403	Gtr&BassMenu	1	COMBINATION
404	Pizz Xpress	3	STRINGS
405	Tek Pizz SRX	1	STRINGS
406	Stringy Stab	2	STRINGS
407	CS80Brass	1	SYNTH BRASS
408	Fat Brass	2	SYNTH BRASS
409	Talk Box SRX	1	VOX
410	TekMusic SRX	3	VOX
411	1.2.3.4. SRX	4	VOX
412	1234 x4 SRX	1	VOX
413	Baby...? SRX	3	VOX
414	Vox Menu 1	1	VOX
415	Vox Menu 2	1	VOX
416	MelodicDrums	4	DRUMS
417	Drumpeopled1	4	DRUMS
418	Drumpeopled2	4	DRUMS
419	Drumpeopled3	4	DRUMS
420	KitTek.drmFX	4	DRUMS
421	Hardcore Hit	4	DRUMS
422	Kick Menu 1	1	DRUMS
423	Kick Menu 2	1	DRUMS
424	Kick Menu 3	1	DRUMS
425	Snare Menu 1	1	DRUMS
426	Snare Menu 2	1	DRUMS
427	Snare Menu 3	1	DRUMS
428	Snare Menu 4	1	DRUMS
429	Snare Menu 5	1	DRUMS
430	HiHat Menu 1	1	DRUMS
431	HiHat Menu 2	1	DRUMS
432	HH&Cym Menu	1	DRUMS
433	Cymbal Menu	1	DRUMS
434	Tom Menu	2	DRUMS
435	Clap Menu	1	DRUMS
436	808 Chord	4	PERCUSSION
437	808 Conga 3D	2	PERCUSSION
438	Slow Chimes	2	PERCUSSION
439	Dirty Sox	2	PERCUSSION
440	ExtremPercus	4	PERCUSSION
441	Pure Tribal	3	PERCUSSION
442	TeknoTriangl	1	PERCUSSION
443	Tamb&SkrMenu	1	PERCUSSION
444	Cow&Kini Menu	1	PERCUSSION
445	Perc. Menu 1	1	PERCUSSION
446	Perc. Menu 2	1	PERCUSSION
447	Perc. Menu 3	1	PERCUSSION
448	Perc. Menu 4	1	PERCUSSION

/: Key Velocity による切替え音色

/Mod : Modulation (CC:01) による切替え音色

#: フレーズ・ループのウェーブフォームを使用したパッチです。  
パッチ・ネームに付いている数字は推奨テンポ (B.P.M.) です。

\* 音色によっては、テンポを急激に変化させるとノイズが出る場合があります。これは、マルチエフェクトやコーラスのディレイ・タイムなどがテンボに同期している場合に発生します。ノイズが気になる場合は、ディレイ・タイムなどの設定を音符以外の値に変更してください。

\* パッチの中には SR-JV80 シリーズのウェーブフォームを使用しているため、上鍵域で発音の制限があり発音しない部分があります。

\* SRX 対応の RD シリーズ /MC-909/VR-760 では、Fantom シリーズ / XV シリーズ /MX-200 専用のパッチを選ぶことはできません。

\* 一部のパッチの名前が、本リストと使用機器の画面表示とで異なる場合がありますが、音色自体に影響はありません。

## Rhythm Set List

### For All Instruments

(BANK SELECT MSB: 92, LSB: 15)

No.	RhythmName	No.	RhythmName	No.	RhythmName	No.	RhythmName
1	Techno Kit 2	4	Trance Kit	7	R&B Kit 3	10	TR606/707Kit
2	HipHop Kit	5	DnB Kit	8	TR-909 Kit	11	Kick Menu
3	House Kit 2	6	BrekBeatsKit	9	TR-808 Kit	12	Snarel Menu

# Rhythm Set Key Assign (1)

For Fantom series/XV series/MX-200

Note No.	1. Techno Kit 2	2. HipHop Kit	3. House Kit 2	4. Trance Kit	5. DnB Kit	6. BrekBeats Kit	7. R&B Kit 3
28	Ninja Kick	Street Kick	Video Kick	TR909 Kick 2	Full Range K	Video Kick	Lo-Fi BD
29	Sim Kick	JungleKick 1	Optic Kick	Medium K2	Sub & Noiz K	DrctRehrsalK	ElectricKick
30	Fat Snare	Cut Hats Snr	Little SN	TR909 Snr 7	Raggia Snr 2	Flat Snare	DJ Snare
31	TR808 Kick 3	Wet Kick	Bottom 909 K	Plastic BD 1	Plastic BD 2	Slamn'Kick 1	TR808 Kick 3
32	TR707 Snr 1	TekRok Snare	TR909 Snr 4	TR909 Snr 4	Headz Snare	AllInOne SN	Macho Snare
33	TR909 Dst BD	Punchy K 2	Plastic BD 2	ElectricKick	Roll Kick	Full Range K	Medium K2
34	Clap Snare	Indus Snare	TR909 Snr 2	TR909 Snr 2	Roll Snare	DR Snare 2	Little SN
35	Full House K	Dance Kick 4	TR909 Kick 1	Plastic Kick	JungleKick 1	Dynamic K	Hicut K
C2	Plastic Kick	PurePhatKick	Culture Kick	Bottom K	JungleKick 2	Hall Kick 2	Direct K
	TR909 Rim	SideStiker	TR909 Rim	TR909 Rim	Real Rim	Lo-Fi Rim	Real Rim
	TR909 Snr 6	PurePhat Snr	TR808 Snr 1	TR909 Snr 6	Jungle Snr 1	HpHpJazzySnr	Headz Snare
	37	Claptail	TR707 Clap	TR909 Clap 2	Shot Clap	Real Clap 2	Real Clap 2
	39	TR909 Snr 5	Antigua Snr	TR909 Snr 1	Jungle Snr 4	Wooden SN	Urban Snare
	40	TR909 Tom 3	Natural Tom3	TR909 Tom 3	TR909 Tom 3	808 KickBs 1	Natural Tom3
	41	TR909 CHH 2	ShortNzMidHH	TR909 CHH 1	TR909 CHH 2	ShortNzMidHH	Natural Tom3
	42	TR707 Tom 3	Can Tom 3	TR909DstTom3	TR707 Tom 3	808 KickBs 2	Lil' Hat
	43	TR909 PHH 1	Overlord	TR909 PHH 1	TR909 PHH 1	Noizz HH	TR707 Tom 3
	44	TR909 Tom 2	Natural Tom2	TR909 Tom 2	TR909 Tom 2	808 KickBs 3	Can Tom 3
C3	45	TR909 OpHat	HipHopMedHat	TR909 OHH 2	TR909 OpHat	Hi Open HH	ShortOpen HH
	46	TR707 Tom 2	Can Tom 2	TR909DstTom2	TR707 Tom 2	808 KickBs 4	Natural Tom2
	47	TR909 Tom 1	Natural Tom1	TR909 Tom 1	TR909 Tom 1	TR707 Tom L	Can Tom 2
	48	TR909 Cymbal	Crash 1 Long	TR909 Crash	TR909 Cymbal	TR909 Cymbal	Natural Tom1
	49	TR707 Tom 1	Can Tom 1	TR909DstTom1	TR707 Tom 1	TR707 Tom H	Crash 1 Long
	50	TR909 Ride	Lo-Fi Ride	TR909 Ride	TR909 Ride	Ride 3	Can Tom 1
	51	Hi Crash	Hip Hop Ride	Hi Crash	Hi Crash	Crash 2 Long	Lo-Fi Ride
	52	TR909DsCrash	BD Scratch 1	TR909DsCrash	TR909DsCrash	Crash Zero	Hip Hop Ride
	53	Tamb.Short 2	BD Scratch 2	Tamb. Long 2	Tamb. Short 2	Tamb. Long 2	BD Scratch
	54	TR909DstRide	SD Scratch	Block	TR909DstRide	Ride 4	Tamb.Short 2
C4	55	Tambourine 2	Real Bell Hi	TR707Cowbell	Tambourine 2	Tamb. Short 2	SD Scratch
	56	57	TR808 Cymbal	Rave Stopper	TR808 Claves	Ride 3 Bell	Real Bell Hi
	58	TR808Cowbell	TR808Cowbell	Tin Cowbell	REV Cymbal	Tin Cowbell	Rave Stopper
	59	TR808 Claves	BasicScratch	High Claves	TR808Cowbell	Ride 4	TR808Cowbell
	60	Hip Kick	Break Kick	Punchy K 2	BasicScratch	HardTambourn	BasicScratch
	61	TR909 Rim	Real Rim	Plastic BD 2	High Claves	Stick Cymbal	Stick Cymbal
	62	TR909 Snr 2	HipHop Snr 3	TR909 Rim	Plastic BD 2	Thump Kick	Noizz 909 K
	63	TS Clap	Real Clap 2	HipHop Clap	TR909 Rim	High Rim SN	Noizz 909 K
	64	TR909 Snr 3	Rage Snare	Clap Stop	Urban Snare	Dry Comp SN	Lo-Fi Rim
	65	TR909 Tom 7	DR Disco Snr	DR Disco Snr	Real Clap 2	Shot Clap	Break Snr
C5	66	TR909 CHH 3	Noizz HH	TR909 Tom 7	Break Snr	DJ Snare	Poly Clap
	67	TR909 Tom 6	TR707CmpTom3	TR707CmpTom4	TR909 Tom 7	TR707CmpTom4	DR Snare 1
	68	TR909 PHH 2	Openopen HH	TR707CmpTom3	808 KickBs 5	ShortNzMidHH	TR707CmpTom4
	69	TR909 Tom 5	TR707CmpTom2	TR707CmpTom3	TR909 CHH 3	TR707CmpTom3	Noizz HH
	70	TR909 OHH 1	TR707CmpTom1	TR707CmpTom2	TR909 Tom 6	808 KickBs 6	TR707CmpTom3
	71	TR909 Tom 4	TR707CmpTom1	TR707CmpTom1	TR909 PHH 2	Junk Hat	Openopen HH
	72	FstAtkCngHi	MidRealConga	TR707CmpTom1	TR909 Tom 5	Noizz HH	TR707CmpTom2
	73	FstAtkCngMid	LowRealConga	FstAtkCngHi	TR909 Tom 5	TR707CmpTom2	TR707CmpTom2
	74	FstAtkCngLow	FstAtkCngHi	FstAtkCngLow	TR909 Tom 4	808 KickBs 7	TR707CmpTom1
	75	Conga Slap 2	FstAtkCngLow	Conga Slap 2	TR909 Tom 4	Cym OHH	Cym OHH
C6	76	Shot Perc.	FstAtkCngMid	FstAtkCngMid	TR909 Tom 4	808 KickBs 8	TR707CmpTom1
	77	Timbale 2 Hi	Timbale 2 Hi	Timbale 2 Hi	FstAtkCngLo	TR707CmpTom1	MidRealConga
	78	Timbale 2 Lo	Timbale 2 Lo	Timbale 2 Lo	FstAtkCngMid	LowRealConga	LowRealConga
	79	Funky Tri Hi	TR727AgogoHi	TR727AgogoHi	Timbale 2 Hi	FstAtkCngHi	FstAtkCngHi
	80	Funky Tri Lo	TR727AgogoLo	TR727AgogoLo	Timbale 2 Hi	FstAtkCngLow	FstAtkCngLow
	81	TechnoShaker	TechnoShaker	TechnoShaker	Timbale 2 Lo	FstAtkCngMid	FstAtkCngMid
	82	Dance Shaker	Dirty Shake	Dirty Shake	Timbale 2 Lo	Timbale 2 Hi	Timbale 2 Hi
	83	HighShakeDwn	B.Box Shaker	B.Box Shaker	TR727AgogoLo	Timbale 2 Lo	Timbale 2 Lo
	84	BrassVox Hit	Brass HitLp1	Mean Brs Hit	TR727AgogoLo	Funk Tri Lo	Timbale 2 Hi
	85	Organ Hit 2	Brass HitLp2	Stop Hit	TR727AgogoLo	Egg Shake	TR727AgogoLo
C7	86	Pure Psycho	Cuica Hit	Organ Hit 2	125:WahMute2	Egg Shake	TechnoShaker
	87	TAO Hit	Wah Gtr B	125:HousePf4	125:WahMute2	125:WahMute2	Dirty Shake
	88	P5 Noise 3	VibratingMtl	Techno Scene	125:HousePf4	125:OpenStr1	Dirty Shake
	89	Breath Hit	Droppin'	TAO Hit	116:Pf&Str 3	125:OpenStr1	BBox Shaker
	90	ElectricDunk	Oh!	Thin Beef	125:SlowWah1	125:OpenStr2	Singing Ahh
	91	Auu	Ouhouhooohou	Ahhhahh 2	Sax Lick 1	125:Dry Funk	Breath Hit
	92	High Claves	Breath	Breath	Ow!	MachineShout	Breath Hit
	93	Creepy 1	Jingle Bell	Eh	High Claves	BeatBox Kick	Cuica Hit
	94	Droppin'	Schelle	JUNO Blip 1	Block	Cuica Hit	TR727Quijada
	95	Hip Hop Alarm	MachineShout	JUNO Blip 2	Surdo mute	Sax Blast Lp	Mute Triangl
C8	96	MC500 Beep 1	ClassicHseHt	Analog Bird	Talkbox	Talkbox	Open Triangl
	97	MC500 Beep 2	Record Noiz	Pure Psycho	Sci-Fi 2	Sci-Fi 2	Metal
	98	TR808Cowbell	Metronome 2	MachineShout	Record Noiz	Record Noiz	Metronome 2
	99	Roll Snare	R8 Click	Guira 2	JUNO Blip 1	JUNO Blip 1	Metronome 2
	100	Metronome 2	R8 Click	Metronome 2	Metronome 2	Metronome 2	R8 Click
	101	R8 Click	Metronome 1	R8 Click	R8 Click	R8 Click	R8 Click
	102	Metronome 1	Metronome 1	Metronome 1	Metronome 1	Metronome 1	Metronome 1
	103	White Noise	81:Ring Kit	Nasalnoise	Sci-Fi 2	Sci-Fi 2	Metronome 1
C9	104	Hip Hop Ride	83:HmBeatBx1	Rise Up!	Tape Stop 2	Ping Pong	61:Slow Grv
	105	Mental Perc	86:Street 16	Drill Hit	HipHop Alarm	Toy Perc.	90:Swingdirt
	106	Air Gun	89:BuzyFunky	Thrill	Air Gun	Metal Box	91:Uptown
	107	Dr.Beat	91:Cruis'n	MetallicShot	Neon Hum	FX Triangle	94:Ya Mon
	108						96:Jane 2
	109						
	110						
	111						
	112						
	113						

\* On the Fantom series/XV series/MX-200, you can not select only the rhythm sets which are designed to be used with the RD series (with SRX slots)/MC-909/VR-760/G-70.

\* Fantom シリーズ/XV シリーズ/MX-200 では、RD シリーズ(SRX 対応) /MC-909/VR-760 専用のリズム・セットを選ぶことはできません。

# Rhythm Set Key Assign (2)

For Fantom series/XV series/MX-200

Note No.	8. TR-909 Kit	9. TR-808 Kit	10. TR606/ 707Kit	11. Kick Menu	12. Snare1 Menu	13. Snr2& RimMenu	14. HHat& TomMenu
28	Medium K2	TR606 Kick 1	TR606 Kick 1	TR606 Kick 1	TR606 Snr 1	--	CR78 CHH
29	TR606 Kick 2	TR606 Kick 2	TR606 Kick 2	TR606 Kick 2	TR606 Snr 2	--	TR606 CHH
30	TR909 Snr 7	TR808 Snr 3	TR808 Snr 3	TR707 Kick 1	TR606 Snr 3	--	TR707 CHH
31	Tekno Kick	TR808 Kick 1	TR808 Kick 1	TR707 Kick 3	TR606 Snr 4	--	808 HH
32	TR909 Snr 3	TR808 Snr 2	TR808 Snr 2	TR808 Kick 2	TR707 Snr 1	--	TR808 CHH 1
33	Punchy K 2	TR808 KickLp	TR808 KickLp	TR808 Kick 3	TR707 Snr 2	--	TR808 CHH 2
34	TR909 Snr 5	TR808 Snr 1	TR808 Snr 1	TR808 Kick 1	TR808 Snr 1	--	TR909 CHH 1
35	Full House K	TR808 Kick 2	TR606 Kick 1	TR808 KickLp	TR808 Snr 2	--	TR909 CHH 2
C2	Bottom K	TR808 Kick 3	TR606 Kick 2	Sub BD D#	TR808 Snr 5	DanceHallSnr	TR909 CHH 3
	TR909 Rim	TR808 Rim	30Hz Sub C	TR808 Snr 6	Deep Snare	Pop CHH	
	TR909 Snr 1	TR808 Snr 6	TR606 Snr 1	TR808 Snr 7	Fat Snare	Real Hat	
	TR909 Clap	TR909 Clap	HC2 Dry Clap	TR909 Kick 2	DR Snare 2	Ragga ClHat	
	TR909 Snr 6	TR808 Snr 7	TR606 Snr 2	Short Dry K	RealJazz Snr	Old Style HH	
	TR909 Tom 4	TR808 Tom 4	TR606 Tom 4	Medium K2	Sizzle Snr	Ragga Snr 3	
	TR909 CHH 1	TR808 CHH 1	TR808 CHH 1	Bottom K	TightBoomSnr	Closed8bitHH	
	TR909 Tom 3	TR808 Tom 3	TR606 Tom 3	Full House K	TR909 Snr 2	ShortNzMidHH	
	TR909 PHH 1	TR808 PHH	TR808 PHH	Tekno Kick	TR909 Snr 5	DR Disco Snr	
	TR909 Tom 2	TR808 Tom 2	TR606 Tom 2	ElectricKick	TR909 Snr 3	Mid Hat	
C3	TR909 OHH 2	TR808 OHH	TR808 OHH	Punchy K 1	TR909 Snr 4	Dance Snr 1	Hi Freq HH
	TR909 Tom 2	TR808 Tom 2	TR606 Tom 2	Punchy K 2	TR909 Snr 7	Big Snare	Bristol CHH
	TR909 Tom 1	TR808 Tom 1	TR606 Tom 1	Plastic BD 2	TR909 Snr 6	Real Snare	Overlord
	TR909 Crash	TR808 Cymbal	TR808 Cymbal	Plastic Kick	DJ Snare	Dry Comp SN	Lil' Hat
	TR909 Tom 1	TR808 Tom 1	TR606 Tom 1	Plastic BD 1	Macho Snare	Wooden SN	Garbage Hat
	TR909 Cymbal	TR606 Cym 2	TR606 Cym 2	50Hz K	Rage Snare	Tone&SynthSN	Ninja Hat
	TR909 Ride	TR909 Ride	TR909 Ride	Amsterdam BD	Indus Snare	Little SN	ShortOpen HH
	TR707 Ride	CR78 Tamb 2	CR78 Tamb 2	TR909 Dst BD	TooBig Snr	Cuttetd SN	Open Soft HH
	Tamb. Long 2	Tamb.Short 2	Tamb.Short 2	Noizzy 909 K	Back Rev SN	Live SN	Noizzz HH
	TR909DstRide	TalkingConga	TalkingConga	Bottom 909 K	Heavy SN	JazzClosedHH	
C4	Tin Cowbell	AnalogCwblHi	TR808Cowbell	Culture Kick	TekRok Snare	Scrap Snr	Full Ambi HH
	TR909 DstOHH	TR808 Claves	TR808 Claves	Optic Kick	Cruis'n Snr	High Rim SN	Junk Hat
	Real Bell Hi	AnalogCwblLo	TR707Cowbell	Lo-Fi BD	Slamn' Snr	Mid Rim SN	Open Hard HH
	TR909 Kick 2	TR808Claves2	TR808Claves2	Wet Kick	Clap Snare	Rim and SN	FastOpnSynHH
	TR909 Kick 1	Sub BD D#	TR707 Kick 1	HpHpJazzySnr	Wet Kick	Hi Open HH	
	Lo-Fi Rim	TR808 RimLng	TR808 Rim	Video Kick	TR808 Rim	VinylOpen HH	
	TR909 Snr 2	TR808 Snr 5	TR707 Snr 1	Ragga Snr 2	TR808 Rim 2	Openopen HH	
	TR909 Clap 2	TR909 Clap 2	TR707 Clap	JungleKick 1	Lo-Fi Snare	OpenDitherHH	
	TR909 Snr 4	TR808 Snr 4	TR707 Snr 2	Street Kick	Urban Snare		
	TR909DstTom4	TR606 Tom 4	TR707 Tom 4	TR707 Kick 2	TR909 Rim		
C5	TR909 CHH 2	TR808 CHH 1	TR808 CHH 1	R&B Snare	R&B Snare	Let It Go HH	
	TR909DstTom3	TR606 Tom 3	TR707 Tom 3	Turbo Kick	SideStiker	BeatBox Hat	
	TR909 PHH 2	TR808 PHH	TR707 PHH	Hicut K	Break Snr	CR78 Hat	
	TR909DstTom2	TR606 Tom 2	TR707 Tom 2	Full Range K	Real Rim		
	TR909 OHH 3	TR808 OHH	TR707 OHH	Jungle Snr 1	Bright Rim		
	TR909DstTom1	TR606 Tom 1	TR707 Tom 1	Jungle Snr 2	Ragga Rim 1		
	MidRealConga	AnalgCongaHi	Da Conga Hi	Sub & Noiz K	Jungle Snr 3		
	LowRealConga	AnalgCongaLo	Da Conga Mid	JungleKick 2	Ragga Rim 2		
	FstAtkCngHi	TR808 Conga2	Da Conga Mid	Jungle Snr 4			
	FstAtkCngLow	TR808 Conga2	Da Conga Mid	Lo-Fi Rim			
C6	FstAtkCngMid	TR808 Conga1	TR808 Conga2	Boon Kick	Headz Snare		
	Timbale 2 Hi	Timbale 2 Hi	TR808 Conga1	Timbale 2 Hi	Antigua Snr		
	Timbale 2 Lo	Timbale 2 Lo	Timbale 2 Hi	Slamn' Kick	TR606 DstOHH		
	TR727AgogoHi	TR727AgogoHi	Timbale 2 Lo	MC Snare			
	TR727AgogoLo	TR727AgogoLo	Timbale 2 Lo	Slamn' Kick			
	Egg Shake	HighShakeUp	TR727AgogoLo	DR Snare 1			
	Dirty Shake	Snake Shake	HighShakeUp	Urban Snare			
	B Box Shaker	Sand Shake	Snake Shake	TR808 OHH			
	Smear Hit 1	Techno Scene	Sand Shake	Trance Snr			
	Smear Hit 2	Pure Psycho	Techno Scene	TR909 OHH 1			
C7	LoFi MinorHt	TAO Hit	Pure Psycho	Techno Scene			
	Brass Hit Lp	Thin Beef	TAO Hit	Techno Scene			
	BrassVox Hit	Organ Hit 2	Thin Beef	Techno Scene			
	ShortStrings	Beam HiQ	Organ Hit 2	Techno Scene			
	Flex	Sci-Fi 2	Emergency	Techno Scene			
	Belltree	PC-2 Spacers	Bauw Hit	Emergency			
	Boing	Analog Bird	ClassicHseHt	Emergency			
	Metal Box	ElectronFall	P-Zing	Emergency			
	Panic	PC-2 Machine	EFX Tom Lp	Emergency			
	Cuica Hit	Mental Perc.	Air Gun	Emergency			
96	Metronome 2	Metronome 2	Ping Pong	Ping Pong	Ping Pong	Ping Pong	
97	R8 Click	R8 Click	Roll Kick	Roll Kick	Roll Kick	Roll Kick	
98	Metronome 1	Metronome 1	R8 Click	BeatBox Snr1	BeatBox Snr1	BeatBox Snr1	
99	125:AcctnShk	144:Tekno BD	Metronome 1	BeatBox Snr2	BeatBox Snr2	BeatBox Snr2	
100	125:DoublShk	144:Tekno BD	Metronome 1	Roll Snare	Roll Snare	Roll Snare	
101	125:Conga	120:TeknoBNG	144:Tekno BD	--	--	--	
102	125:Tamb Man	116:Elect'80	144:TeknoHAT	--	--	--	
103	125:StpBongo	120:Electro1	116:Elect'80	--	--	--	
			120:TeknoBNG	--	--	--	
			116:Elect'80	--	--	--	
			120:Electro1	--	--	--	

\* On the Fantom series/XV series/MX-200, you can not select only the rhythm sets which are designed to be used with the RD series (with SRX slots)/MC-909/VR-760/G-70.

\* Fantom シリーズ/XV シリーズ/MX-200 では、RD シリーズ(SRX 対応) /MC-909/VR-760 専用のリズム・セットを選ぶことはできません。

# Rhythm Set Key Assign (3)

For Fantom series/XV series/MX-200

Note No.	15. Cym& Clp Menu	16. Hit& StabMenu	17. Perc. Menu	18. Vox Menu	19. FX Menu	20. Beat Menu 1	21. Beat Menu 2
28	--	--	SynthCongaHi	VC A	JUNO Blip 1	--	--
29	--	--	SynthCongaLo	VC E	Beam HiQ	--	--
30	[30]	--	TR808 Conga2	VC I	JUNO Blip 2	--	--
31	--	--	TR808 Conga1	VC O	Sci-Fi 2	--	--
32	[32]	--	AnalgCongaHi	VC U	PC-2 Spacers	--	--
33	--	--	AnalgCongaLo	VC One	Analog Bird	--	--
34	[34]	--	MidRealConga	VC Two	ElectronFall	--	--
35	--	--	LowRealConga	VC Three	Retro UFO	--	--
C2	TR606 Cym 1	Brass Fall 2	Conga Slap 2	VC Four	PC-2 Machine	61:Slow Grv	125:Basic 1
36	TR606 Cym 2	Smear Hit 1	FstAtkCngHi	VC Music	Dr.Beat	75:BoomRvBel	125:Basic 2
37	TR606 DstCym	Smear Hit 2	FstAtkCngMid	VC Techno	Mental Perc	76:TrpHpKkn	125:ClypMania
38	[39]	TR808 Cymbal	LoFi MinorHt	FstAtkCngLow	VC Groove	May Day Perc	78:NinjaBrek
40	TR909 Crash	BrassVox Hit	Da Conga Hi	VC Dance	Jungle Beep	80:Thump Grv	125:LivZone1
41	TR909 Cymbal	Brass Hit Lp	Da Conga Mid	VC Funky	BD Scratch	80:MetallHead	125:LivZone2
42	TR909DsCrash	Mean Brs Hit	TalkingConga	VC Rhythm	SD Scratch	81:Ringn Kit	125:LivZone3
43	Ragga Crash	Stop Hit	Timbale 2 Hi	VC Machine	Tape Stop 2	83:Big & Bad	125:LivZone4
44	Crash Zero	Horny-Hit	Timbale 2 Lo	One	Rave Stopper	83:HmBeatBx1	125:LivZone5
45	Crash 1 Long	Techno Scene	TR808 Claves	Two	BasicScratch	83:Poing Snr	125:LpFabric
46	Crash 1 Mute	Pure Psycho	TR808Claves2	Three	Scratch Loop	85:Snr Wall	125:Purple
47	Crash 2 Long	TAO Hit	High Claves	Four	Record Noiz	86:Street 16	125:FullHous
C3	Crash 2 Mute	Thin Beef	Block	Yeah!	Turntable	86:Bubbles	125:4thFloor
48	Hi Crash	Organ Hit 2	Wood Plopp	Dirty Laugh	HipHop Alarm	88:TrenchTwn	125:Front
49	TR707 Ride	--	Surdo mute	Ow!	Emergency	88:Cut Hats	125:FatBrett
50	[51]	TR909 Ride	--	Surdo open	Canvas Laugh	88:GeigerCountr	88:Yo!
51	TR909DstRide	--	ShortGuira 1	Female Laugh	Fuse	88:Crackl'n	125:FatTrck1
52	Ride 3	--	ShortGuira 2	Pretty Aou!	Scraping	88:HmBeatBx2	125:BsWorx 1
53	[54]	Ride 3 Bell	Guira 1	Singing Ahh	Neon Hum	89:BuzyFunky	125:BsWorx 2
54	Ride 4	--	Guira 2	Hoo!	Buzzer	89:Slamn'Grv	125:Mid Beat
55	Stick Cymbal	--	TR727Quijada	Uuha	Toy Gun 1	90:Swingn	125:Offbt HH
56	Lo-Fi Ride	--	TechnoShaker	Whouw	Toy Gun 2	90:NoizyBoys	125:Tamb Man
57	[58]	High Cymbal	--	Dance Shaker	Eh	90:Swingdirt	125:AccntShk
58	Hip Hop Ride	--	Small Shake	Oh!	Breath Hit	91:NotopHpHp	125:DoublShk
C4	TR707 Clap	--	HighShakeUp	Ahhhhh 1	Bauw Hit	91:Cruis'n	125:Ganza
60	[61]	TR909 Clap	HighShakeDwn	Ahhhhh 2	ClassicHseHt	91:Uptown	125:Triangle
62	TR909 Clap 2	--	Snake Shake	Breath	Slice of Trp	91:BigBeauty	125:Conga
63	Real Clap 1	--	Shortie	Kick it!	Rattle Hit	92:Jazzman	125:ToneCong
64	Real Clap 2	--	Klick Shake	Come on!	P.Phatt Hit	92:Overring	125:StpBongo
65	Poly Clap	--	Open Shake	Funk!	P-Zing	92:Boom Town	125:FullBrz1
66	TS Clap	--	Egg Shake	Crazy!	Plock Drum	92:Too Big	125:HousePf1
67	Clap Stop	--	Dirty Shake	DJ!	VibratingMtl	94:Ya Mon	125:HousePf2
68	[68]	HC2 Dry Clap	Sand Shake	Go!	EFX Tom Lp	95:Head Bobn	125:HousePf3
69	Scratch Clap	--	Hit Shake	Stop!	Air Gun	95:Pure Phat	125:HousePf4
70	Comp Clap	--	B.Box Shaker	Good Eve	Panic	96:PlainJane	125:Pf&Str 1
71	Claptail	--	CR78 Cowbell	Say Yeah!	Tick	96:Jane 2	125:Pf&Str 2
C5	Funk Clap	--	TR707Cowbell	Scream!	High Cut	98:Funkster1	125:P&Str 3
72	HipHop Clap	--	TR808Cowbell	Baby!	Ping Pong	98:Funkster2	125:E-Groove
73	Crackhed	--	TR808 Cowbel	Get on Up	MachineShout	104:BigBottm	125:SlowWah1
74	[75]	MC Clap	SynthCowbell	MC!	Metal	104:Respect	125:SlowWah2
75	Shot Clap	--	AnalogCwblHi	Give it Up	Tuned 4 bit	104:Riddim	125:OpenStr1
76	Room Clap	--	AnalogCwblLo	Oh Yeah!	Toy Perc.	108:Gargle	125:OpenStr2
77	[78]	--	Tin Cowbell	Get Off	Metal Box	116:Elec'80	125:WahMute1
78	--	--	Real Bell Hi	Get Up	Metal Bang	120:Electro1	125:WahMute2
79	[80]	--	TR727 Agogo	Get On 1	MetallicShot	120:TeknoBNG	125:BendLick
80	--	--	ReverbCowbel	Get On 2	FX Triangle	132:Detroit	125:Dry Funk
81	[82]	--	HardTambourn	Dance	GlassBreakLp	132:Agogo	--
82	--	--	Tamb Short 2	Do It!	PCM Press	138:Electro2	--
C6	84	--	Tambourine 2	Jam !	ElectricDunk	144:Tekno BD	--
85	[85]	--	Tamb. Long 2	House Music	Thrill	144:TeknoHAT	--
86	--	--	CR78 Tamb 2	Come On	Drill Hit	160:Drum'nBs	--
87	[87]	--	Rattle Tamb	Tic	Sawing	184:Gabba	--
88	--	--	Tack+Tambrn	Tac	Turbine	--	--
89	[89]	--	TambourinHit	Tigidi	CompresStart	--	--
90	[90]	--	Tamb Hit&Shk	Tac Tac	CompresStop	--	--
91	--	--	NoizzyTambrn	Oh No !	Jack Hammer	--	--
92	[92]	--	Light Tambrn	Oh Yes !	MachineNoise	--	--
93	--	--	SuprHighTamb	Alright	Creepy 1	--	--
94	[94]	--	EffectTambrn	It's MyHouse	150:PhoneFrq	--	--
95	--	--	Jingle Bell	Higher	Distressed	--	--
C7	96	--	Schelle	Everybody	Tunnel Rain	--	--
97	[97]	--	Belltree	Ouhouhooohou	UK Station	--	--
98	--	--	Funky Tri	Auu	Heat Seeker	--	--
99	[99]	--	Flex	--	Droppin'	--	--
100	--	--	Noiz Perc.	--	Boing	--	--
101	--	--	Shot Perc.	--	Fireball	--	--
102	[102]	--	BeatBox Perc	--	Firebomb	--	--
103	--	--	--	--	--	--	--

\* On the Fantom series/XV series/MX-200, you can not select only the rhythm sets which are designed to be used with the RD series (with SRX slots)/MC-909/VR-760/G-70.

※ Fantom シリーズ/XV シリーズ/MX-200 では、RD シリーズ(SRX 対応) /MC-909/VR-760 専用のリズム・セットを選ぶことはできません。

# Rhythm Set Key Assign (4)

For RD series (with SRX slots)/MC-909/VR-760/G-70

Note No.	1. Techno Kit 2	2. HipHop Kit	3. House Kit 2	4. Trance Kit	5. DnB Kit	6. BrekBeats Kit	7. R&B Kit 3
28	Ninja Kick	Street Kick	Video Kick	TR909 Kick 2	Full Range K	Video Kick	Lo-Fi BD
29	Sim Kick	JungleKick 1	Optic Kick	Medium K2	Sub & Noiz K	DrctRehrsalK	ElectricKick
30	Fat Snare	Cut Hats Snr	Little SN	TR909 Snr 7	Ragga Snr 2	Flat Snare	DJ Snare
31	TR808 Kick 3	Wet Kick	Bottom 909 K	Plastic BD 1	Plastic BD 2	Slamn'Kick 1	TR808 Kick 3
32	TR707 Snr 1	TekRok Snare	TR909 Snr 4	TR909 Snr 4	Headz Snare	AllInOne SN	Macho Snare
33	TR909 Dst BD	Punchy K 2	Plastic BD 2	ElectricKick	Roll Kick	Full Range K	Medium K2
34	Clap Snare	Indus Snare	TR909 Snr 2	TR909 Snr 2	Roll Snare	DR Snare 2	Little SN
35	Full House K	Dance Kick 4	TR909 Kick 1	Plastic Kick	JungleKick 1	Dynamic K	Hicut K
C2	Plastic Kick	PurePhatKick	Culture Kick	Bottom K	JungleKick 2	Hall Kick 2	Direct K
	TR909 Rim	SideStiker	TR909 Rim	TR909 Rim	Real Rim	Lo-Fi Rim	Real Rim
	TR909 Snr 6	PurePhat Snr	TR808 Snr 1	TR909 Snr 6	Jungle Snr 1	HpHpJazzySnr	Headz Snare
	Claptail	TR707 Clap	TR909 Clap 2	TR909 Clap 2	Shot Clap	Real Clap 2	Real Clap 2
	TR909 Snr 5	Antigua Snr	TR909 Snr 1	TR909 Snr 1	Jungle Snr 4	Wooden SN	Urban Snare
	TR909 Tom 3	Natural Tom3	TR909 Tom 3	TR909 Tom 3	808 KickBs 1	Natural Tom3	Natural Tom3
	TR909 CHH 2	ShortNzMidHH	TR909 CHH 1	TR909 CHH 2	ShortNzMidHH	Lil' Hat	Mid Hat
	TR707 Tom 3	Can Tom 3	TR909DstTom3	TR707 Tom 3	808 KickBs 2	TR707 Tom 3	Can Tom 3
	TR909 PHH 1	Overlord	TR909 PHH 1	TR909 PHH 1	Noizz HH	Junk Hat	ShortOpen HH
	TR909 Tom 2	Natural Tom2	TR909 Tom 2	TR909 Tom 2	808 KickBs 3	Natural Tom2	Natural Tom2
C3	TR909 OpHat	HipHopMedHat	TR909 OHH 2	TR909 OpHat	Hi Open HH	Cym OHH	Openopen HH
	TR707 Tom 2	Can Tom 2	TR909DstTom2	TR707 Tom 2	808 KickBs 4	TR707 Tom 2	Can Tom 2
	TR909 Tom 1	Natural Tom1	TR909 Tom 1	TR909 Tom 1	TR707 Tom L	Natural Tom1	Natural Tom1
	TR909 Cymbal	Crash 1 Long	TR909 Crash	TR909 Cymbal	TR909 Cymbal	TR909 Cymbal	Crash 1 Long
	TR707 Tom 1	Can Tom 1	TR909DstTom1	TR707 Tom 1	TR707 Tom H	TR707 Tom 1	Can Tom 1
	TR909 Ride	Lo-Fi Ride	TR909 Ride	TR909 Ride	Ride 3	Ride 3	Lo-Fi Ride
	Hi Crash	Hip Hop Ride	Hi Crash	Hi Crash	Crash 2 Long	Crash 2 Long	Hip Hop Ride
	TR909DsCrash	BD Scratch 1	TR909DsCrash	TR909DsCrash	Crash Zero	Crash Zero	BD Scratch
	Tamb.Short 2	BD Scratch 2	Tamb. Long 2	Tamb. Short 2	Tamb. Long 2	Tamb. Hit&Shk	Tamb.Short 2
	TR909DstRide	SD Scratch	Block	TR909DstRide	Ride 4	Ride 4	SD Scratch
C4	Tambourine 2	Real Bell Hi	TR707Cowbell	Tambourine 2	Tamb. Short 2	Tin Cowbell	Real Bell Hi
	TR808 Cymbal	Rave Stopper	TR808 Claves	REV Cymbal	Tamb. Short 2	Ride 3 Bell	Rave Stopper
	TR808Cowbell	TR808Cowbell	Tin Cowbell	TR808Cowbell	Ride 3 Bell	Tin Cowbell	TR808Cowbell
	TR808 Claves	BasicScratch	High Claves	Echo Kick	HardTambourn	Ride 4	BasicScratch
	Hip Kick	Break Kick	Punchy K 2	Plastic BD 2	Stick Cymbal	Stick Cymbal	BasicScratch
	TR909 Rim	Real Rim	Ragga Rim 2	TR909 Rim	Thump Kick	Noizz 909 K	Noizz 909 K
	TR909 Snr 2	HipHop Snr 3	TR707 Snr 1	HipHop Clap	High Rim SN	Lo-Fi Rim	Lo-Fi Rim
	TS Clap	Real Clap 2	Clap Stop	TS Clap	Dry Comp SN	Break Snr	Break Snr
	TR909 Snr 3	Rage Snare	DR Disco Snr	TR909 Snr 3	Real Clap 2	Poly Clap	Poly Clap
	TR909 Tom 7	TR707CmpTom4	TR707CmpTom4	TR909 Tom 7	Break Snr	DR Snare 1	DR Snare 1
C5	TR909 CHH 3	Noizz HH	TR909 CHH 3	TR909 CHH 3	DJ Snare	TR707CmpTom4	TR707CmpTom4
	TR909 Tom 6	TR707CmpTom3	TR707CmpTom3	TR909 Tom 6	TR707CmpTom4	ShortNzMidHH	Noizz HH
	TR909 PHH 2	Openopen HH	TR909 PHH 2	TR909 PHH 2	TR707CmpTom3	TR707CmpTom3	Openopen HH
	TR909 Tom 5	TR707CmpTom2	TR707CmpTom2	TR909 Tom 5	TR707CmpTom2	TR707CmpTom2	TR707CmpTom2
	TR909 OHH 1	Cym OHH	TR707 OHH	TR909 OHH 1	TR707CmpTom1	TR707CmpTom1	Cym OHH
	TR909 Tom 4	TR707CmpTom1	TR707CmpTom1	TR909 Tom 4	TR707CmpTom1	TR707CmpTom1	TR707CmpTom1
	FstAtkCngHi	MidRealConga	MidRealConga	FstAtkCngHi	MidRealConga	MidRealConga	MidRealConga
	FstAtkCngMid	LowRealConga	LowRealConga	FstAtkCngMid	LowRealConga	LowRealConga	LowRealConga
	FstAtkCngLow	FstAtkCngHi	FstAtkCngHi	FstAtkCngLow	FstAtkCngHi	FstAtkCngHi	FstAtkCngHi
	Conga Slap 2	FstAtkCngLow	FstAtkCngLow	Conga Slap 2	FstAtkCngLow	FstAtkCngLow	FstAtkCngLow
C6	Shot Perc.	FstAtkCngMid	FstAtkCngMid	Shot Perc.	FstAtkCngMid	FstAtkCngMid	FstAtkCngMid
	Timbale 2 Hi	Timbale 2 Hi	Timbale 2 Hi	Timbale 2 Hi	Timbale 2 Hi	Timbale 2 Hi	Timbale 2 Hi
	Timbale 2 Lo	Timbale 2 Lo	Timbale 2 Lo	Timbale 2 Lo	Timbale 2 Lo	Timbale 2 Lo	Timbale 2 Lo
	Funky Tri Hi	TR727AgogoHi	TR727AgogoHi	TR727AgogoHi	TR727AgogoHi	Funky Tri Hi	TR727AgogoHi
	Funky Tri Lo	TR727AgogoLo	TR727AgogoLo	TR727AgogoLo	TR727AgogoLo	Funky Tri Lo	TR727AgogoLo
	TechnoShaker	TechnoShaker	TechnoShaker	Egg Shake	Egg Shake	Egg Shake	TechnoShaker
	Dance Shaker	Dirty Shake	Dirty Shake	Dance Shaker	Dirty Shake	Dirty Shake	Dirty Shake
	HighShakeDwn	B.Box Shaker	B.Box Shaker	HighShakeDwn	B.Box Shaker	B.Box Shaker	B.Box Shaker
	BrassVox Hit	Brass HitLp1	125:HousePf1	Mean Brs Hit	Stop Hit	125:WahMute1	125:HousePf2
	Organ Hit 2	Brass HitLp2	125:HousePf2	Organ Hit 2	125:WahMute2	125:HousePf2	125:HousePf4
C7	Pure Psycho	Cuica Hit	125:HousePf4	Techno Scene	116:Pf&Str 3	125:OpenStr1	125:E-Groove
	TAO Hit	Wah Gtr B	VibratingMtl	TAO Hit	125:SlowWah1	125:OpenStr2	125:SlowWah2
	P5 Noise 3	125:Dry Funk	Droppin'	Thin Beef	Sax Lick 1	125:Dry Funk	Belltree
	Breath Hit	Oh!	Ouhouhooohou	Ahhhhh 2	Ow!	MachineShout	Singing Ahh
	ElectricDunk	Auu	Breath	Breath	Hoo!	BeatBox Kick	Breath Hit
	Auu	High Claves	Jingle Bell	Eh	High Claves	Cuica Hit	TR727Quijada
	Beep 1	Creepy 1	Schelle	JUNO Blip 1	Block	Sax Blast Lp	FX Triangl S
	Beep 2	Droppin'	MachineShout	JUNO Blip 2	Surdo mute	Talkbox	FX Triangl L
	TR808Cowbell	Hip Hop Alarm	ClassicHseHt	Analog Bird	Surdo open	Sci-Fi 2	Metal
	Roll Snare	Record Noiz	Pure Psycho	MachineShout	Guria 2	Record Noiz	JUNO Blip 1
C8	--	--	--	--	--	--	--
	--	--	--	--	--	--	--
	--	--	--	--	--	--	--
	--	--	--	--	--	--	--
	91	Nasalnoise	81:Ringng Kit	125:SlowWah1	Nasalnoise	Sci-Fi 2	61:Slow Grv
	92	Hip Hop Ride	83:HmBeatBx1	125:Puristic	Rise Up!	Tape Stop 2	Ping Pong
	93	Mental Perc	86:Street 16	125:Conga	Drill Hit	HipHop Alarm	Toy Perc.
C9	94	Air Gun	89:BuzyFunky	125:Tamb Man	Thrill	Air Gun	Metal Box
	95	Dr.Beat	91:Cruis'n	125:Triangle	MetallicShot	Neon Hum	FX Triangle
	96	--	--	--	--	--	--
C10	97	--	--	--	--	--	--
	98	--	--	--	--	--	--
	99	Nasalnoise	81:Ringng Kit	125:SlowWah1	Nasalnoise	Sci-Fi 2	61:Slow Grv
	100	Hip Hop Ride	83:HmBeatBx1	125:Puristic	Rise Up!	Tape Stop 2	Ping Pong
	101	Mental Perc	86:Street 16	125:Conga	Drill Hit	HipHop Alarm	Toy Perc.
	102	Air Gun	89:BuzyFunky	125:Tamb Man	Thrill	Air Gun	Metal Box
	103	Dr.Beat	91:Cruis'n	125:Triangle	MetallicShot	Neon Hum	FX Triangle

\* On the RD series (with SRX slots)/MC-909/VR-760/G-70, you can not select only the rhythm sets which are designed to be used with the Fantom series/XV series/MX-200.

\* On the MC-909, you can use only the rhythm tones for the sixteen keys from note numbers 35 (B1) through 50 (D3).

※ SRX 対応のRDシリーズ/MC-909/VR-760では、Fantomシリーズ/XVシリーズ/MX-200専用のリズム・セットを選ぶことはできません。

※ MC-909では、Note No. 35 (B1)から50 (D3)までの16鍵分のリズム・トーンのみ使用できます。

# Rhythm Set Key Assign (5)

For RD series (with SRX slots)/MC-909/VR-760/G-70

Note No.	8. TR-909 Kit	9. TR-808 Kit	10. TR606/ 707Kit	11. Kick Menu	12. Snare1 Menu	13. Snr2& RimMenu	14. HHat& TomMenu
28	Medium K2	TR606 Kick 1	TR606 Kick 1	TR606 Kick 1	TR606 Snr 1	--	CR78 CHH
29	TR606 Kick 2	TR606 Kick 2	TR606 Kick 2	TR606 Kick 2	TR606 Snr 2	--	TR606 CHH
30	TR909 Snr 7	TR808 Snr 3	TR808 Snr 3	TR707 Kick 1	TR606 Snr 3	--	TR707 CHH
31	Tekno Kick	TR808 Kick 1	TR808 Kick 1	TR707 Kick 3	TR606 Snr 4	--	808 HH
32	TR909 Snr 3	TR808 Snr 2	TR808 Snr 2	TR808 Kick 2	TR707 Snr 1	--	TR808 CHH 1
33	Punchy K 2	TR808 KickLp	TR808 KickLp	TR808 Kick 3	TR707 Snr 2	--	TR808 CHH 2
34	TR909 Snr 5	TR808 Snr 1	TR808 Snr 1	TR808 Kick 1	TR808 Snr 1	--	TR909 CHH 1
35	Full House K	TR808 Kick 2	TR606 Kick 1	TR808 KickLp	TR808 Snr 2	--	TR909 CHH 2
C2	Bottom K	TR808 Kick 3	TR606 Kick 2	Sub BD D#	TR808 Snr 5	DanceHallSnr	TR909 CHH 3
	TR909 Rim	TR808 Rim	30Hz Sub C	TR808 Snr 6	Deep Snare	Pop CHH	
	TR909 Snr 1	TR808 Snr 6	TR606 Snr 1	TR808 Snr 7	Fat Snare	Real Hat	
	TR909 Clap	TR909 Clap	HC2 Dry Clap	TR909 Kick 2	TR808 Snr 3	DR Snare 2	Ragga ClHat
	TR909 Snr 6	TR808 Snr 7	TR606 Snr 2	Short Dry K	TR808 Snr 4	RealJazz Snr	Old Style HH
	TR909 Tom 4	TR808 Tom 4	TR606 Tom 4	Medium K2	Sizzle Snr	Ragga Snr 3	Closed8bitHH
	TR909 CHH 1	TR808 CHH 1	TR808 CHH 1	Bottom K	TR909 Snr 1	TightBoomSnr	ShortNzMidHH
	TR909 Tom 3	TR808 Tom 3	TR606 Tom 3	Full House K	TR909 Snr 2	DR Disco Snr	Mid Hat
	TR909 PHH 1	TR808 PHH	TR808 PHH	Tekno Kick	TR909 Snr 5	Dance Snr 1	Hi Freq HH
	TR909 Tom 2	TR808 Tom 2	TR606 Tom 2	ElectricKick	TR909 Snr 3	Big Snare	Bristol CHH
	TR909 OHH 2	TR808 OHH	TR808 OHH	Punchy K 1	TR909 Snr 4	Real Snare	Overlord
	TR909 Tom 2	TR808 Tom 2	TR606 Tom 2	Punchy K 2	TR909 Snr 7	Dry Comp SN	Lil' Hat
C3	TR909 Tom 1	TR808 Tom 1	TR606 Tom 1	Plastic BD 2	TR909 Snr 6	Wooden SN	Garbage Hat
	TR909 Crash	TR808 Cymbal	TR808 Cymbal	Plastic Kick	DJ Snare	Tone&SynthSN	Ninja Hat
	TR909 Tom 1	TR808 Tom 1	TR606 Tom 1	Plastic BD 1	Macho Snare	Little SN	ShortOpen HH
	TR909 Cymbal	TR606 Cym 2	TR606 Cym 2	50Hz K	Rage Snare	Cuttetd SN	Open Soft HH
	TR909 Ride	TR909 Ride	TR909 Ride	Amsterdam BD	Indus Snare	Live SN	Noizzz HH
	TR707 Ride	CR78 Tamb 2	CR78 Tamb 2	TR909 Dst BD	TooBig Snr	Back Rev SN	JazzClosedHH
	Tamb. Long 2	Tamb.Short 2	Tamb.Short 2	Noizzy 909 K	Overring Snr	Heavy SN	Full Ambi HH
	TR909DstRide	TalkingConga	TalkingConga	Bottom 909 K	TekRok Snare	Scrap Snr	Junk Hat
	Tin Cowbell	AnalogCwblHi	TR808Cowbell	Culture Kick	Cruis'n Snr	High Rim SN	Open Hard HH
	TR909 DstOHH	TR808 Claves	TR808 Claves	Optic Kick	Slamn' Snr	Mid Rim SN	FastOpnSynHH
	Real Bell Hi	AnalogCwblLo	TR707Cowbell	Lo-Fi BD	Clap Snare	Rim and SN	Hi Open HH
	TR909 Kick 2	TR808Claves2	TR808Claves2	Wet Kick	HpHpJazzySnr	TR808 Rim	VinylOpen HH
C4	TR909 Kick 1	Sub BD D#	TR707 Kick 1	Video Kick	Ragga Snr 2	TR808 Rim 2	Openopen HH
	Lo-Fi Rim	TR808 RimLng	TR808 Rim	JungleKick 1	Lo-Fi Snare	TR808 RimLng	OpenDitherHH
	TR909 Snr 2	TR808 Snr 5	TR707 Snr 1	Street Kick	Urban Snare	TR909 Rim	Let It Go HH
	TR909 Clap 2	TR909 Clap 2	TR707 Clap	TR707 Kick 2	R&B Snare	SideStiker	BeatBox Hat
	TR909 Snr 4	TR808 Snr 4	TR707 Snr 2	Turbo Kick	Break Snr	Real Rim	CR78 Hat
	TR909DstTom4	TR606 Tom 4	TR707 Tom 4	Hicut K	Jungle Snr 1	Bright Rim	TR606 PHH
	TR909 CHH 2	TR808 CHH 1	TR707 CHH	Full Range K	Jungle Snr 2	Ragga Rim 1	TR707 PHH
	TR909DstTom3	TR606 Tom 3	TR707 Tom 3	Sub & Noiz K	Jungle Snr 3	Ragga Rim 2	TR808 PHH
	TR909 PHH 2	TR808 PHH	TR707 PHH	JungleKick 2	Jungle Snr 4	Lo-Fi Rim	TR909 PHH 1
	TR909DstTom2	TR606 Tom 2	TR707 Tom 2	Jungle Kick	Jungle Snr 5	Sizzle Rim	TR909 PHH 2
	TR909 OHH 3	TR808 OHH	TR707 OHH	Hip Kick	Headz Snare	BeatBox Rim	Analog Shake
	TR909DstTom1	TR606 Tom 1	TR707 Tom 1	Ninja Kick	Antigua Snr	--	CR78 OHH
C5	MidRealConga	AnalgCongaHi	Da Conga Hi	Slamn Kick 1	MC Snare	--	TR606 DstOHH
	LowRealConga	AnalgCongaLo	Da Conga Mid	Slamn' Kick 2	DR Snare 1	--	TR707 OHH
	FstAtkCngHi	TR808 Conga2	TR808 Conga2	Dance Kick 4	HipHop Snr 3	--	TR808 OHH
	FstAtkCngLow	TR808 Conga2	TR808 Conga2	Break Kick	Machine Snr	--	808 Open HH
	FstAtkCngMid	TR808 Conga1	TR808 Conga1	Hall Kick 2	Flat Snare	--	TR909 OHH 1
	Timbale 2 Hi	Timbale 2 Hi	Timbale 2 Hi	Funky Kick	HipHop Snr 4	--	TR909 OHH 2
	Timbale 2 Lo	Timbale 2 Lo	Timbale 2 Lo	Too Big Kick	Dance Snr 2	--	TR909 OHH 3
	TR727AgogoHi	TR727AgogoHi	TR727AgogoHi	Hall Kick 1	Whack Snr 2	--	TR909 OpHat
	TR727AgogoLo	TR727AgogoLo	TR727AgogoLo	Boom Kick	Tiny SN	--	Vintage Hat
	Egg Shake	HighShakeUp	HighShakeUp	FarNear Kick	Hi Snare	--	TR909 DstOHH
	Dirty Shake	Snake Shake	Snake Shake	Thump Kick	Clap SN	--	R8 OHH
	B Box Shaker	Sand Shake	Sand Shake	PurePhatKick	Cut Hats Snr	--	Cym OHH
C6	Smear Hit 1	Techno Scene	Techno Scene	Sim Kick	PurePhat Snr	--	Rock OpHat
	Smear Hit 2	Pure Psycho	Pure Psycho	Lo-Fi Kick	AllInOne SN	--	HipHopMedHat
	LoFi MinorHt	TAO Hit	TAO Hit	Direct K	DistortedSnr	--	B.Box OpHat
	Brass Hit Lp	Thin Beef	Thin Beef	Tone K	ShrtDirectSN	--	TR606 Tom
	BrassVox Hit	Organ Hit 2	Organ Hit 2	Dynamic K	Tone Comp SN	--	TR606 Tom 2
	ShortStrings	Beam HiQ	Emergency	Clone K	Stick SN	--	TR606 CmpTom
	Flex	Sci-Fi 2	Bauw Hit	Open Cut K	Vintage SN	--	TR707 Tom
	Belltree	PC-2 Spacers	ClassicHseHt	1ToTheFloorK	Syn-SN	--	TR707 CmpTom
	Boing	Analog Bird	P-Zing	DrctRehrsak	CR78 Snare	--	TR808 Tom
	Metal Box	ElectronFall	EFX Tom Lp	Fat Clap K	Electro Snr	--	TR909 Tom
	Panic	PC-2 Machine	Air Gun	BeatBox Kick2	Sim Snare	--	TR909 DstTom
	Cuica Hit	Mental Perc.	Ping Pong	BeatBox Kick	Echo Snare	--	Deep Tom
C7	--	--	--	Roll Kick	BeatBox Snr1	--	Electro Tom
	--	--	--	--	BeatBox Snr2	--	Kick Tom
	--	--	--	--	Roll Snare	--	Garbage Tom
	--	--	--	--	--	--	Natural Tom
	125:AcntShk	144:Tekno BD	144:Tekno BD	--	--	--	Can Tom
	125:DoublShk	144:TeknoHAT	144:TeknoHAT	--	--	--	--
	125:Conga	120:TeknoBNG	120:TeknoBNG	--	--	--	--
	125:Tamb Man	116:Elect'80	116:Elect'80	--	--	--	--
	125:StpBongo	120:Electro1	120:Electro1	--	--	--	--

\* On the RD series (with SRX slots)/MC-909/VR-760/G-70, you can not select only the rhythm sets which are designed to be used with the Fantom series/XV series/MX-200.

\* On the MC-909, you can use only the rhythm tones for the sixteen keys from note numbers 35 (B1) through 50 (D3).

※ SRX 対応のRDシリーズ/MC-909/VR-760では、Fantomシリーズ/XVシリーズ/MX-200専用のリズム・セットを選ぶことはできません。

※ MC-909では、Note No. 35 (B1) から 50 (D3) までの 16 鍵分のリズム・トーンのみ使用できます。

# Rhythm Set Key Assign (6)

For RD series (with SRX slots)/MC-909/VR-760/G-70

Note No.	15. Cym& Clp Menu	16. Hit& StabMenu	17. Perc. Menu	18. Vox Menu	19. FX Menu	20. Beat Menu 1	21. Beat Menu 2
28	--	--	SynthCongaHi	VC A	JUNO Blip 1	--	--
29	--	--	SynthCongaLo	VC E	Beam HiQ	--	--
30	[L]	--	TR808 Conga2	VC I	JUNO Blip 2	--	--
31	--	--	TR808 Conga1	VC O	Sci-Fi 2	--	--
32	[L]	--	AnalgCongaHi	VC U	PC-2 Spacers	--	--
33	--	--	AnalgCongaLo	VC One	Analog Bird	--	--
34	[L]	--	MidRealConga	VC Two	ElectronFall	--	--
35	--	--	LowRealConga	VC Three	Retro UFO	--	--
C2	36	TR606 Cym 1	Brass Fall 2	VC Four	PC-2 Machine	61:Slow Grv	125:Basic 1
	37	TR606 Cym 2	Smear Hit 1	VC Music	Dr.Beat	75:BoomRvBel	125:Basic 2
	38	TR606 DstCym	Smear Hit 2	FstAtkCngMid	Mental Perc	76:TrpHpKkn	125:CplMania
	39	TR808 Cymbal	LoFi MinorHt	FstAtkCngLow	VC Groove	78:NinjaBrek	125:LowToEnd
	40	TR909 Crash	BrassVox Hit	Da Conga Hi	VC Dance	80:Thump Grv	125:LivZone1
	41	TR909 Cymbal	Brass Hit Lp	Da Conga Mid	VC Funky	80:MetaHead	125:LivZone2
	42	TR909DsCrash	Mean Brs Hit	TalkingConga	VC Rhythm	81:Ringn Kit	125:LivZone3
	43	Ragga Crash	Stop Hit	Timbale 2 Hi	VC Machine	83:Big & Bad	125:LivZone4
	44	Crash Zero	Horny-Hit	Timbale 2 Lo	One	83:HmBeatBx1	125:LivZone5
	45	Crash 1 Long	Techno Scene	TR808 Claves	Two	83:Poing Snr	125:LpFabric
	46	Crash 1 Mute	Pure Psycho	TR808Claves2	Three	85:Snr Wall	125:Purple
	47	Crash 2 Long	TAO Hit	High Claves	Four	86:Street 16	125:FullHous
C3	48	Crash 2 Mute	Thin Beef	Block	Yeah!	86:Bubbles	125:4thFloor
	49	Hi Crash	Organ Hit 2	Wood Plopp	Dirty Laugh	88:TrenchTwn	125:Front
	50	TR707 Ride	--	Surdo mute	Ow!	88:Cut Hats	125:FatBrett
	51	TR909 Ride	--	Surdo open	Canvas Laugh	88:Yo!	125:FatTrck1
	52	TR909DstRide	--	ShortGuira 1	Female Laugh	88:Crackl'n	125:FatTrck2
	53	Ride 3	--	ShortGuira 2	Pretty Aou!	88:HmBeatBx2	125:BsWorx 1
	54	Ride 3 Bell	--	Guira 1	Singing Ahh	89:BuzyFunky	125:BsWorx 2
	55	Ride 4	--	Guira 2	Hoo!	89:Slamn'Grv	125:Mid Beat
	56	Stick Cymbal	--	TR727Quijada	Uuha	90:Swingn	125:Offbt HH
	57	Lo-Fi Ride	--	TechnoShaker	Whouw	90:NoizyBoys	125:Tamb Man
	58	High Cymbal	--	Dance Shaker	Eh	90:Swingdirt	125:AccntShk
	59	Hip Hop Ride	--	Small Shake	Oh!	91:NotopHpHp	125:DoublShk
C4	60	TR707 Clap	--	HighShakeUp	Ahhhhh 1	91:Cruis'n	125:Ganza
	61	TR909 Clap	--	HighShakeDwn	Ahhhhh 2	91:Uptown	125:Triangle
	62	TR909 Clap 2	--	Snake Shake	Breath	91:BigBeauty	125:Conga
	63	Real Clap 1	--	Shortie	Kick it!	92:Jazzman	125:ToneCong
	64	Real Clap 2	--	Klick Shake	Come on!	92:Overring	125:StpBongo
	65	Poly Clap	--	Open Shake	Funk!	92:Boom Town	125:FullBrz1
	66	TS Clap	--	Egg Shake	Crazy!	92:Too Big	125:HousePf1
	67	Clap Stop	--	Dirty Shake	DJ!	94:Ya Mon	125:HousePf2
	68	HC2 Dry Clap	--	Sand Shake	Go!	95:Head Bobn	125:HousePf3
	69	Scratch Clap	--	Hit Shake	Stop!	95:Pure Phat	125:HousePf4
	70	Comp Clap	--	B.Box Shaker	Good Eve	96:PlainJane	125:Pf&Str 1
	71	Claptail	--	CR78 Cowbell	Say Yeah!	96:Jane 2	125:Pf&Str 2
C5	72	Funk Clap	--	TR707Cowbell	Scream!	98:Funkster1	125:P&Str 3
	73	HipHop Clap	--	TR808Cowbell	Baby!	98:Funkster2	125:E-Groove
	74	Crackhed	--	TR808 Cowbel	Get on Up	104:BigBottm	125:SlowWah1
	75	MC Clap	--	SynthCowbell	MC!	104:Respect	125:SlowWah2
	76	Shot Clap	--	AnalogCwblHi	Give it Up	104:Riddim	125:OpenStr1
	77	Room Clap	--	AnalogCwblLo	Oh Yeah!	108:Gargle	125:OpenStr2
	78	--	--	Tin Cowbell	Get Off	116:Elec'80	125:WahMute1
	79	--	--	Real Bell Hi	Get Up	120:Electro1	125:WahMute2
	80	--	--	TR727 Agogo	Get On 1	120:TeknoBNG	125:BendLick
	81	--	--	ReverbCowbel	Get On 2	132:Detroit	125:Dry Funk
	82	--	--	HardTambourn	Dance	132:Agogo	--
	83	--	--	Tamb Short 2	Do It!	138:Electro2	--
C6	84	--	--	Tambourine 2	Jam !	144:Tekno BD	--
	85	--	--	Tamb. Long 2	House Music	144:Thrill	144:TeknoHAT
	86	--	--	CR78 Tamb 2	Come On	160:Drill Hit	160:Drum'nBs
	87	--	--	Rattle Tamb	Tic	184:Sawing	184:Gabba
	88	--	--	Tack+Tambrn	Tac	184:Turbine	--
	89	--	--	TambourinHit	Tigidi	CompresStart	--
	90	--	--	Tamb Hit&Shk	Tac Tac	CompresStop	--
	91	--	--	NoizzyTambrn	Oh No !	Jack Hammer	--
	92	--	--	Light Tambrn	Oh Yes !	MachineNoise	--
	93	--	--	SuprHighTamb	Alright	Creepy 1	--
	94	--	--	EffectTambrn	It's MyHouse	150:PhoneFrq	--
	95	--	--	Jingle Bell	Higher	Distressed	--
C7	96	--	--	Schelle	Everybody	Tunnel Rain	--
	97	--	--	Belltree	Ouhouhoohou	UK Station	--
	98	--	--	Funky Tri	Auu	Heat Seeker	--
	99	--	--	Flex	--	Droppin'	--
	100	--	--	Noiz Perc.	--	Boing	--
	101	--	--	Shot Perc.	--	Fireball	--
	102	--	--	BeatBox Perc	--	Firebomb	--
	103	--	--	--	--	--	--

\* On the RD series (with SRX slots)/MC-909/VR-760/G-70, you can not select only the rhythm sets which are designed to be used with the Fantom series/XV series/MX-200.

\* On the MC-909, you can use only the rhythm tones for the sixteen keys from note numbers 35 (B1) through 50 (D3).

※ SRX 対応のRDシリーズ/MC-909/VR-760では、Fantomシリーズ/XVシリーズ/MX-200専用のリズム・セットを選ぶことはできません。

※ MC-909では、Note No. 35 (B1) から 50 (D3) までの 16 鍵分のリズム・トーンのみ使用できます。

# Waveform List (1)

No.	Name		No.	Name		No.	Name		No.	Name	
1	Phrase MENU1	**	61	DrumLp MENU1	**	121	JUNO Bass Lp		181	JUNO Synth	
2	Phrase MENU2	**	62	DrumLp MENU2	**	122	Moogish		182	JX Synth	
3	Phrase MENU3	**	63	125:Basic 1	***	123	JUNO Bass 2		183	Alpha Wave	
4	61:Slow Grv	***	64	125:Basic 2	***	124	JUNO Bs 2 Lp		184	Killer	
5	75:BoomRvBel	***	65	125:ClpMania	***	125	Big Saw Bass		185	Detuned Saw	
6	76:TrpHpKikn	***	66	125:LowToEnd	***	126	Big SawBs 2		186	Fat JP-6	
7	78:NinjaBrek	***	67	125:LivZone1	***	127	JUNO Sine Bs		187	Euro Dance	
8	80:Thump Grv	***	68	125:LivZone2	***	128	Octa Bass		188	Noisy 101	
9	80:MetalHead	***	69	125:LivZone3	***	129	Rave Bass		189	Daft Wave	
10	81:Ringn Kit	***	70	125:LivZone4	***	130	FM Pluck Bs		190	JP Siren	
11	83:Big & Bad	***	71	125:LivZone5	***	131	FM Slide Bs		191	Cold Dress	
12	83:HmBeatBx1	***	72	125:LpFabric	***	132	Solid Bass		192	Pizzy Techno	
13	83:Poing Snr	***	73	125:PuristcL	* ***	133	JUNO-60 Bass		193	Organ Pizz	
14	85:Homie	***	74	125:PuristcR	* ***	134	SH-5 Bass		194	Garage Org	
15	85:Snr Wall	***	75	125:FullHous	***	135	Dirty Bass		195	FM Club Org	
16	86:Street 16	***	76	125:4thFloor	***	136	Sub Bass		196	Org Chord	
17	86:Bubbles	***	77	125:Front	***	137	Jungle Bass		197	Org EP	
18	88:TrenchTwn	***	78	125:Fatbrett	***	138	Bass Gliss		198	Lo-Fi Wurly	
19	88:Cut Hats	***	79	125:FatTrck1	***	139	Bass Sustain		199	Pure EP	
20	88:Yo!	***	80	125:FatTrck2	***	140	Bass Short		200	Ac Piano1 A	
21	88:Crackl'n	***	81	125:BsWorx 1	***	141	Bass Slide		201	Ac Piano1 B	
22	88:HmBeatBx2	***	82	125:BsWorx 2	***	142	Bass Down		202	Ac Piano1 C	
23	89:BuzyFunky	***	83	125:Mid Beat	***	143	Bass Slap		203	Dist TekGtr1	
24	89:Slamn'Grv	***	84	125:Offbt HH	***	144	Hard Attack		204	Dist TekGtr2	
25	90:Swingn	***	85	Perc.Lp MENU 1	**	145	Square Low		205	Dist Gtr Chd	
26	90:NoizyBoys	***	86	125:Tamb Man	***	146	JUNO 60 Buzz		206	GTR FX MENU	**
27	90:Swingdirt	***	87	125:AcntShk	***	147	JUNO Pulse 5		207	Gtr FX MENU	**
28	91:NotopHpHp	***	88	125:DoublShk	***	148	Funky JUNO		208	Wah Gtr Lp 1	
29	91:Cruis'n	***	89	125:Ganza	***	149	Mellow JUNO		209	Wah Gtr Lp 2	
30	91:Uptown	***	90	125:Triangle	***	150	JUNO Strings		210	Wah Gtr A	
31	91:BigBeauty	***	91	125:Conga L	* ***	151	JUNO Str Lp		211	Wah Gtr B	
32	92:Jazzman	***	92	125:Conga R	* ***	152	Lo-Fi RoomTp		212	D.GtrUpwhine	
33	92:Overring	***	93	125:ToneCong	***	153	JP8000 Saw 1		213	Gtr Thumper	
34	92:Boom Town	***	94	125:StpBongo	***	154	JP8000 Saw 2		214	Hit MENU 1	**
35	92:Too Big	***	95	125:FullBrzl	***	155	JP-6 Saw		215	Hit MENU 2	**
36	94:Ya Mon	***	96	Pf/Key MENU	**	156	Techno Saw		216	Brass Fall 2	
37	95:Head Bobn	***	97	116:HousePf1	***	157	TB Saw		217	Smear Hit 1	
38	95:Pure Phat	***	98	116:HousePf2	***	158	TB Dst Saw		218	Smear Hit 2	
39	96:PlainJane	***	99	116:HousePf3	***	159	TB Solid Saw		219	LoFi MinorHt	
40	96:Jane 2	***	100	116:HousePf4	***	160	TB Reso Saw		220	BrassVox Hit	
41	98:Funkster1	***	101	116:Pf&Str 1	***	161	SH-1 Square		221	Brass Hit Lp	
42	98:Funkster2	***	102	116:Pf&Str 2	***	162	TB Square 1		222	Mean Brs Hit	
43	104:BigBottm	***	103	116:Pf&Str 3	***	163	TB Square 2		223	Sax Lick 1	
44	104:Respect	***	104	125:E-Groove	***	164	TB Square 3		224	Sax Lick 2	
45	104:Riddim	***	105	125:SlowWah1	***	165	Dist Square		225	Sax Cry	
46	108:Gargle	***	106	125:SlowWah2	***	166	TB Dst Sqr 1		226	Sax Blast	
47	Phrase MENU4	**	107	Dry Chord D#		167	TB Dst Sqr 2		227	Sax Blast Lp	
48	120:House 1	***	108	Dry Chord C#		168	TB Reso Sqr1		228	HipHop Alarm	
49	120:House 2	***	109	Dry Chord F		169	TB Reso Sqr2		229	Cuica Hit	
50	120:House 3	***	110	House Organ		170	TB Reso Sqr3		230	Breath Hit	
51	120:TeknoBNG	***	111	SubmarineSin		171	SH-1 Pulse		231	Bauw Hit	
52	144:Tekno BD	***	112	ShortStrings		172	JP8000 PWM		232	ClassicHseHt	
53	144:TeknoHAT	***	113	Gtr/Bs MENU	**	173	JP8000 FBK		233	JUNO Blip 1	
54	160:Drum'nBs	***	114	125:OpenStr1	***	174	260 Sub OSC		234	JUNO Blip 2	
55	184:Gabba	***	115	125:OpenStr2	***	175	Dist Synth		235	Sci-Fi 2	
56	132:Detroit	***	116	125:WahMute1	***	176	P5 Pipe		236	Slice of Trp	
57	132:Agogo	***	117	125:WahMute2	***	177	FM Garage		237	Rattle Hit	
58	116:Elect'80	***	118	125:BendLick	***	178	JUNO Pluck		238	P.Phatt Hit	
59	120:Electro1	***	119	125:Dry Funk	***	179	Funky Synth		239	BD Scratch	
60	138:Electro2	***	120	JUNO Bass 1		180	JUNO Bowing		240	SD Scratch	
									241	Tape Stop 2	
									242	BasicScratch	
									243	Scratch Loop	
									244	Record Noiz	
									245	Hit MENU 3	**
									246	Hit MENU 4	**
									247	Beam HiQ	
									248	Analog Bird	
									249	ElectronFall	
									250	Retro UFO	
									251	Jungle Beep	
									252	PC-2 Machine	
									253	Dr.Beat	
									254	Mental Perc	
									255	May Day Perc	
									256	PC-2 Spacers	
									257	Techno Scene	
									258	Pure Psycho	
									259	TAO Hit	
									260	Thin Beef	
									261	Organ Hit 2	
									262	Hit MENU 5	**
									263	Hit & Drum	
									264	Stop Hit	
									265	Horny-Hit	
									266	Mute Trumpet	
									267	Panic	
									268	INDUST. MENU	**
									269	PCM Press	
									270	ElectricDunk	
									271	Thrill	
									272	Drill Hit	
									273	MachineShout	
									274	Air Gun	
									275	Emergency	
									276	Buzzer	
									277	Tonality	
									278	EFX Tom Lp	
									279	Hip Hop Ride	
									280	P5 Noise 3	
									281	Toy Gun 1	
									282	Toy Gun 2	
									283	GeigerCountr	
									284	GlassBreakLp	
									285	Voice MENU 1	**
									286	Voice MENU 2	**
									287	Voice MENU 3	**
									288	Voice MENU 4	**
									289	Voice MENU 5	**
									290	1,2,3,4	
									291	Kick it!	
									292	Come on!	
									293	Funky!	
									294	Crazy!	
									295	DJ!	
									296	Go!	
									297	Stop!	
									298	Good Eve	
									299	Yeah!	
									300	Dirty Laugh	

# Waveform List (2)

No.	Name	No.	Name	No.	Name	No.	Name	
301	Female Laugh	361	Transolia	421	Ring Bass Lp	481	B.Box Shaker	
302	Ow!	362	Voyage	422	Orc.Cluster	482	Chiki!	
303	Pretty Aou!	363	Frontiers	423	Harpin'Piano	483	Ahhhhh	
304	Singing Ahh	364	Cruising	424	RollingChime	484	B.Box OpHat	
305	Oh Yeah!	365	Tunnel Rain	425	Thin Bells	485	Jungle Kick	
306	Hoo!	366	Rumble Rain	426	FX Bell 3	486	Hip Kick	
307	Say Yeah!	367	Bombay	427	Rave Stopper	487	Ninja Kick	
308	Scream!	368	Black Den	428	MachineNoise	488	Break Kick	
309	Baby!	369	Husky Chord	429	Gate Keeper	489	Funky Kick	
310	Get on Up	370	Phantasm	430	FootStepping	490	Slamn'Kick 1	
311	MC!	371	Fumes	431	Droppin'	491	Too Big Kick	
312	Give it Up	372	Temptation	432	P-Zing	492	Boom Kick	
313	Canvas Laugh	373	Creepy 1	433	Rubberized	493	FarNear Kick	
314	Uuha	374	Creepy 2	434	Pipe	494	Slamn'Kick 2	
315	Whouw	375	Elves	435	Boing	495	Hall Kick 1	
316	Eh	376	Fireflies	436	Metal Bang	496	Dance Kick 4	
317	Oh !	377	CrystalWaves	437	MetallicShot	497	Thump Kick	
318	Ahhhhh 1	378	Electroshock	438	Doorsqweek	498	PurePhatKick	
319	Ahhhhh 2	379	Snowflakes	439	Tomnoise	499	Hall Kick 2	
320	Breath	380	Steel Spires	440	Steam Blow	500	Plastic Kick	
321	Get Off	381	Rise Up!	441	Let Air Go!	501	ElectricKick	
322	Get On 1	382	Sea Whistle	442	Screetchy 1	502	TR808 KickLp	
323	Get Up	383	Lava Flow	443	Screetchy 2	503	TR707 Kick 3	
324	Get On 2	384	Sparkling	444	Tubuloid	504	Lo-Fi Kick	
325	Dance	385	Fuse	445	Slicer	505	Kick MENU 3 **	
326	Do It !	386	Turntable	446	Fuzzclapz	506	Kick MENU 4 **	
327	Jam !	387	UK Station	447	Brakes!	507	TR909 Kick 1	
328	House Music	388	ChinaStation	448	Fire Snare	508	TR909 Kick 2	
329	Come On	389	Crowding	449	Back Snatch	509	Plastic BD 1	
330	Oh No !	390	Nasalnoise	450	Phone	510	Plastic BD 2	
331	Oh Yes !	391	Gnashing	451	Sh.Burst	511	TR808 Kick 1	
332	Alright	392	Construction	452	Blasto Kick	512	TR808 Kick 2	
333	It's MyHouse	393	Construct. 2	453	O.D.Kick	513	TR808 Kick 3	
334	Higher	394	Turbine	454	Bowl Drop	514	TR606 Kick 1	
335	Everybody	395	Scraping	455	Cavern Tube	515	TR606 Kick 2	
336	Ouhouhooohou	396	Vacuum Pump	456	Fireball	516	TR707 Kick 1	
337	Tic	397	Sawing	457	Firebomb	517	TR707 Kick 2	
338	Tac	398	Air Pump	458	Firework	518	Culture Kick	
339	Tigidi	399	Soda Water	459	Hothead	519	Optic Kick	
340	Tac Tac	400	CompresStart	460	Metalicous	520	Lo-Fi BD	
341	Auu	401	CompresStop	461	Cluster Slam	521	Wet Kick	
342	VOCODER MENU **	402	Jack Hammer	462	Pit Hit	522	Video Kick	
343	Aah Formant	403	Propeller	463	Big Stinger	523	JungleKick 1	
344	Eeh Formant	404	Neon Hum	464	Mondo Blast	524	Street Kick	
345	Iih Formant	405	Buzz Hum	465	Ignite!	525	Turbo Kick	
346	Ooh Formant	406	Tcas Hum	466	Heat Seeker	526	JungleKick 2	
347	Uuh Formant	407	Oil Can Bow	467	Missile	527	Tekno Kick	
348	Dist Ooh Vox	408	Crank Shaft	468	Fly-By	528	Sim Kick	
349	Talkbox	409	Snarls	469	Psycho Alert	529	Amsterdam BD	
350	CricketChoir	410	Feed Me!	470	Distressed	530	TR909 Dst BD	
351	Wild Ways	411	Fuzzy Love	471	Afro Cheer	531	Roll Kick	
352	Psychedelics	412	Bad Dreams	472	Kick MENU 1 **	532	Kick MENU 5 **	
353	Taj Mahal	413	Dark Buzzord	473	Kick MENU 2 **	533	Kick MENU 6 **	
354	Ghandi Drone	414	SqualorDrone	474	BeatBox Kick	534	Punchy K 1	
355	Enigmatic	415	Air Raid!	475	BeatBox Hat	535	Punchy K 2	
356	Cleansing	416	180:CyberToy	***	476	BeatBox Snr1	536	Direct K
357	Frost Byte	417	150:PhoneFrq	***	477	BeatBox Snr2	537	Tone K
358	Iceland	418	160:Clockers	***	478	BeatBox Rim	538	Dynamic K
359	Columns	419	Phlange Hit		479	BeatBox Kik2	539	Clone K
360	Effervescent	420	Ring Bass		480	BeatBox Perc	540	Noizzy 909 K

# Waveform List (3)

No. Name	No. Name	No. Name	No. Name	No. Name
601 TR909 Snr 5	661 Ragga Rim 2	721 TR606 DstOHH	781 Scratch Clap	841 Conga Slap 2
602 TR909 Snr 6	662 Lo-Fi Rim	722 TR707 OHH	782 Comp Clap	842 FstAtkCngMid
603 TR909 Snr 7	663 Sizzle Rim	723 CR78 OHH	783 Claptail	843 FstAtkCngHi
604 TR808 Snr 1	664 Real Rim	724 R8 OHH	784 Clap MENU 3 **	844 FstAtkCngLow
605 TR808 Snr 2	665 Tom MENU 1 **	725 Cym OHH	785 Shot Clap	845 Da Conga Mid
606 TR808 Snr 3	666 TR606 Tom 2	726 HH MENU 1 **	786 Room Clap	846 Da Conga Hi
607 TR808 Snr 4	667 Electro Tom	727 HH MENU 2 **	787 Real Clap 1	847 AnalgCongaHi
608 TR606 Snr 1	668 Garbage Tom	728 Old Style HH	788 Real Clap 2	848 AnalgCongaLo
609 TR606 Snr 2	669 Tom MENU 2 **	729 ShortOpen HH	789 Poly Clap	849 SynthCongaHi
610 TR606 Snr 3	670 TR909 Tom	730 Closed8bitHH	790 TMB&SKR MENU **	850 SynthCongaLo
611 TR707 Snr 1	671 TR909 DstTom	731 ShortNzMidHH	791 Tambourine 2	851 TalkingConga
612 TR707 Snr 2	672 TR808 Tom	732 Mid Hat	792 Rattle Tamb	852 TambourinHit
613 CR78 Snare	673 TR606 Tom	733 Hi Freq HH	793 TechnoShaker	853 Tamb Hit&Shk
614 Headz Snare	674 TR606 CmpTom	734 808 HH	794 Dance Shaker	854 NoizzyTambrn
615 Deep Snare	675 TR707 Tom	735 OpenDitherHH	795 COW&RIM MENU **	855 Light Tambrn
616 Fat Snare	676 TR707 CmpTom	736 Open Soft HH	796 TR808Cowbell	856 SuprHighTamb
617 Antigua Snr	677 Deep Tom	737 Noizzz HH	797 TR707Cowbell	857 HardTambourn
618 MC Snare	678 Kick Tom	738 JazzClosedHH	798 CR78 Cowbell	858 EffectTambrn
619 DJ Snare	679 Natural Tom	739 Full Ambi HH	799 TR727 Agogo	859 Small Shake
620 Macho Snare	680 Can Tom	740 Open Hard HH	800 TR909 Rim	860 HighShakeUp
621 Clap Snare	681 HH/Cym MENU **	741 FastOpnSynHH	801 TR808 Rim	861 HighShakeDwn
622 Rage Snare	682 Overlord	742 Hi Open HH	802 TR808 RimLng	862 Snake Shake
623 Indus Snare	683 Real Hat	743 VinylOpen HH	803 TR808 Claves	863 Shortie
624 TekRok Snare	684 Lil' Hat	744 Openopen HH	804 Perc. MENU 1 **	864 Klick Shake
625 Jungle Snr 1	685 Garbage Hat	745 Vintage Hat	805 TR808Claves2	865 Open Shake
626 Jungle Snr 2	686 Ninja Hat	746 Let It Go HH	806 TR808 Cowbel	866 Egg Shake
627 Jungle Snr 3	687 Junk Hat	747 808 Open HH	807 Tamb.Short 2	867 Dirty Shake
628 Jungle Snr 4	688 Ragga ClHat	748 Cymbal MENU1 **	808 Tamb. Long 2	868 Sand Shake
629 SideStiker	689 Rock OpHat	749 TR606 Cym 1	809 CR78 Tamb 2	869 Hit Shake
630 Ragga Snr 2	690 HipHopMedHat	750 TR606 Cym 2	810 Jingle Bell	870 Analog Shake
631 Lo-Fi Snare	691 CR78 Hat	751 TR606 DstCym	811 Belltree	871 Noiz Perc.
632 Jungle Snr 5	692 TR909 OpHat	752 TR909 Ride	812 Funky Tri	872 Tick
633 Urban Snare	693 TR909 Cymbal	753 TR909DstRide	813 TR727Quijada	873 Ping Pong
634 Sim Snare	694 TR808 Cymbal	754 TR707 Ride	814 PERCUSS MENU **	874 Tack+Tambrn
635 Roll Snare	695 Ragga Crash	755 TR909 Crash	815 TR808 Conga1	875 Shot Perc.
636 Snare MENU 9 **	696 Lo-Fi Ride	756 TR909DsCrash	816 TR808 Conga2	876 High Cut
637 Snare MENU1 **	697 CHH MENU 1 **	757 Cymbal MENU2 **	817 Surdo mute	877 Wood Plopp
638 Dry Comp SN	698 CHH MENU 2 **	758 Crash Zero	818 Surdo open	878 Metal
639 ShrtDirectSN	699 TR909 CHH 1	759 Crash 1 Long	819 Perc. MENU 2 **	879 Tuned 4 bit
640 Tone Comp SN	700 TR909 CHH 2	760 Crash 1 Mute	820 Perc. MENU 3 **	880 Toy Perc.
641 Wooden SN	701 TR909 CHH 3	761 Crash 2 Long	821 Perc. MENU 4 **	881 FX Triangle
642 High Rim SN	702 TR808 CHH 1	762 Crash 2 Mute	822 Perc. MENU 5 **	882 Flex
643 Mid Rim SN	703 TR808 CHH 2	763 Hi Crash	823 Perc. MENU 6 **	883 Metal Box
644 Tone&SynthSN	704 TR606 CHH	764 Ride 3	824 ShortGuira 1	884 VibratingMtl
645 Tiny SN	705 TR707 CHH	765 Ride 3 Bell	825 ShortGuira 2	885 Plock Drum
646 Little SN	706 CR78 CHH	766 Ride 4	826 Guira 1	886 Sub BD D#
647 Clap SN	707 Pop CHH	767 Stick Cymbal	827 Guira 2	887 30Hz Sub C
648 Stick SN	708 Bristol CHH	768 High Cymbal	828 Schelle	888 REV WildWays
649 Vintage SN	709 PHH MENU **	769 Clap MENU 1 **	829 Tin Cowbell	889 REV FrostByt
650 Cutted SN	710 TR909 PHH 1	770 Funk Clap	830 ReverbCowbel	890 REV Elves
651 Rim and SN	711 TR909 PHH 2	771 HipHop Clap	831 Real Bell Hi	891 REV CrystlWv
652 AllInOne SN	712 TR808 PHH	772 Crackhed	832 AnalogCwblLo	892 REV Rise Up!
653 Syn-SN	713 TR606 PHH	773 MC Clap	833 AnalogCwblHi	893 REV Cnstrct2
654 Live SN	714 TR707 PHH	774 TR909 Clap 2	834 SynthCowbell	894 REV Turbine
655 Back Rev SN	715 OHH MENU **	775 Clap MENU 2 **	835 Block	895 REV Sawing
656 Heavy SN	716 TR909 OHH 1	776 TR909 Clap	836 High Claves	896 REV Air Pump
657 Rim MENU **	717 TR909 OHH 2	777 TS Clap	837 Timbale 2 Hi	897 REV SodaWatr
658 Bright Rim	718 TR909 OHH 3	778 Clap Stop	838 Timbale 2 Lo	898 REV CompStrt
659 Ragga Rim 1	719 TR909 DstOHH	779 TR707 Clap	839 LowRealConga	899 REV CompStop
660 TR808 Rim 2	720 TR808 OHH	780 HC2 Dry Clap	840 MidRealConga	900 REV OilCanBw

# Waveform List (4)

| No. Name         |
|------------------|------------------|------------------|------------------|------------------|
| 901 REV Feed Me! | 911 REV RollChme | 921 REV Boing    | 931 REV Sh.Burst | 941 REV ClustSlm |
| 902 REV FuzyLove | 912 REV ThinBels | 922 REV Mtl Bang | 932 REV BlastKik | 942 REV Pit Hit  |
| 903 REV BadDream | 913 REV RaveStop | 923 REV MtlcShot | 933 REV O.D.Kick | 943 REV BigSting |
| 904 REV DarkBuzz | 914 REV MachinNz | 924 REV Doorsqwk | 934 REV BowlDrop | 944 REV MondBlst |
| 905 REV SqualDrn | 915 REV GateKeep | 925 REV Tomnoise | 935 REV CaveTube | 945 REV Ignite!  |
| 906 REV CyberToy | 916 REV FootStep | 926 REV SteamBlw | 936 REV Fireball | 946 REV HeatSeek |
| 907 REV PhoneFrq | 917 REV Droppin' | 927 REV Scrtchy1 | 937 REV Firebomb | 947 REV Missile  |
| 908 REV Clockers | 918 REV P-Zing   | 928 REV Fire Snr | 938 REV Firework | 948 REV Fly-By   |
| 909 REV PhlNgHit | 919 REV Rubberiz | 929 REV BkSnatch | 939 REV Hothead  | 949 REV PsycAlrt |
| 910 REV HrpPiano | 920 REV Pipe     | 930 REV Phone    | 940 REV Mtlicous | 950 REV Distresd |

\*: These are stereo waveforms, offered in left-right pairs.

\*\*: These are menu waveforms. Include multiple waveforms assigned to keys individually.

\*\*\*: These are the phrase loop waveforms. The numbers included in the wave name represent the recommended tempo (B.P.M.). And these waveforms can be synchronized to a device such as a sequencer.

\* *Some of the waveform names shown in this list may appear differently on the display of the device being used, but the tones themselves remain unaffected.*

When you create a Patch using the waveforms stored in the Expansion Board, observe the following points:

- \* If you make a Patch with a single voice and then later play it in a chord, the sound may be distorted with certain settings for the Effects and TVA. If this happens, adjust the level of the Effects and TVA.
- \* This product uses waveforms of the SR-JV80 series. For this reason, the upper end of the keyboard may not sound because of key range restrictions.

\*: LとRでペアになるステレオ・ウェーブフォームです。

\*\*: メニュー・ウェーブフォームです。複数のウェーブフォームが、各キーに割り当てられています。

\*\*\*: フレーズ・ループのウェーブフォームです。ウェーブ・メニューに付いている数字は推奨テンポ(B.P.M.)です。また、これらのウェーブフォームはシーケンサー等との同期が可能です。

※ 一部のウェーブフォームの名前が、本リストと使用機器の画面表示とで異なる場合がありますが、音色自体に影響はありません。

このエクスパンション・ボードに収められているウェーブフォームを使ってパッチを作るときには、次の点に注意してください。

- ※ 単音でパッチを作ったとき、エフェクトやTVAの設定状態によって、その音を和音で演奏すると音が歪む場合があります。このようなときは、エフェクトやTVAのレベルを調整してください。
- ※ 本製品のウェーブフォームはSR-JV80シリーズのウェーブフォームを使用しているため、上鍵域で発音の制限があり発音しない部分があります。

# Menu Waveform (1)

## 1 Phrase MENU1

Key	Wave#	WaveName
C 4	4	61:Slow Grv
D 4	5	75:BoomRvBel
E 4	6	76:TrpHpKikn
F 4	7	78:NinjaBrek
G 4	8	80:Thump Grv
A 4	9	80:MetalHead
B 4	10	81:Ringn Kit #
C 5	11	83:Big & Bad #
D 5	12	83:HmBeatBx1
E 5	13	83:Poing Snr #
F 5	14	85:Homie #
G 5	15	85:Snr Wall
A 5	16	86:Street 16 #
B 5	17	86:Bubbles
C 6	18	88:TrenchTwn #

## 2 Phrase MENU2

Key	Wave#	WaveName
C 4	19	88:Cut Hats #
D 4	20	88:Yo!
E 4	21	88:Crackl'n #
F 4	22	88:HmBeatBx2
G 4	23	89:BuzyFunky #
A 4	24	89:Slamn'Grv
B 4	25	90:Swingn
C 5	26	90:NoizyBoys #
D 5	27	90:Swingdirt #
E 5	28	91:NotopHpHp #
F 5	29	91:Cruis'n #
G 5	30	91:Uptown #
A 5	31	91:BigBeauty #
B 5	32	92:Jazzman #
C 6	33	92:Overring #

## 3 Phrase MENU3

Key	Wave#	WaveName
C 4	34	92:Boom Town #
D 4	35	92:Too Big #
E 4	36	94:Ya Mon #
F 4	37	95:Head Bobn #
G 4	38	95:Pure Phat
A 4	39	96:PlainJane
B 4	40	96:Jane 2
C 5	41	98:Funkster1
D 5	42	98:Funkster2
E 5	43	104:BigBottom
F 5	44	104:Respect #
G 5	45	104:Riddim
A 5	46	108:Gargle

## 47 Phrase MENU4

Key	Wave#	WaveName
C 4	48	120:House 1
C#4	49	120:House 2
D 4	50	120:House 3
D#4	51	120:TeknoBNG
E 4	52	144:Tekno BD
F 4	53	144:TeknoHAT
F#4	54	160:Drum'nBs
G 4	55	184:Gabba
G#4	56	132:Detroit
A 4	57	132:Agogo
A#4	58	116:Elect'80
B 4	59	120:Electro1
C 5	60	138:Electro2

## 61 DrumLp MENU1

Key	Wave#	WaveName
C 4	63	125:Basic 1
D 4	64	125:Basic 2
E 4	65	125:ClpMania
F 4	66	125:LowToEnd
G 4	67	125:LivZone1
A 4	68	125:LivZone2
B 4	69	125:LivZone3
C 5	70	125:LivZone4
D 5	71	125:LivZone5

## 62 DrumLp MENU2

Key	Wave#	WaveName
C 4	72	125:LpFabric
D 4	73	125:PuristicL
E 4	74	125:PuristicR
F 4	75	125:FullHous
G 4	76	125:4thFloor
A 4	77	125:Front
B 4	78	125:Fatbrett
C 5	79	125:FatTrck1
D 5	80	125:FatTrck2
E 5	81	125:BsWorx 1
F 5	82	125:BsWorx 2
G 5	83	125:Mid Beat
A 5	84	125:Offbt HH

## 85 Perc.Lp MENU 1

Key	Wave#	WaveName
C 4	86	125:Tamb Man
D 4	87	125:AcntShk
E 4	88	125:DoubtShk
F 4	89	125:Ganza
G 4	90	125:Triangle
A 4	91	125:Conga L
B 4	92	125:Conga R
C 5	93	125:ToneCong
D 5	94	125:StpBongo
E 5	95	125:FullBrzl

## 96 Pf/Key MENU

Key	Wave#	WaveName
B 3	111	SubmarineSin
C 4	97	116:HousePf1
D 4	98	116:HousePf2
E 4	99	116:HousePf3
F 4	100	116:HousePf4
G 4	101	116:Pf&Str 1
A 4	102	116:Pf&Str 2
B 4	103	116:Pf&Str 3
C 5	104	125:E-Groove
D 5	105	125:SlowWah1
E 5	106	125:SlowWah2
F 5	107	Dry Chord D#
G 5	108	Dry Chord C#
A 5	109	Dry Chord F
B 5	110	House Organ
C 6	112	ShortStrings

## 113 Gtr/Bs MENU

Key	Wave#	WaveName
C 4	114	125:OpenStr1
D 4	115	125:OpenStr2
E 4	116	125:WahMute1
F 4	117	125:WahMute2
G 4	118	125:BendLick
A 4	119	125:Dry Funk
B 4	144	Hard Attack
C 5	145	Square Low
D 5	138	Bass Gliss
E 5	139	Bass Sustain
F 5	140	Bass Short
G 5	141	Bass Slide
A 5	142	Bass Down
B 5	143	Bass Slap

## 206 GTR FX MENU

Key	Wave#	WaveName
C 4	Wah Gtr 2a	*
D 4	Wah Gtr 2b	*
E 4	Wah Gtr 2c	*
F 4	Wah Gtr 2d	*
G 4	208	Wah Gtr Lp 1
A 4	209	Wah Gtr Lp 2
B 4		Wah GtrLp2 a *
C 5		Wah GtrLp2 b *
D 5		Wah GtrLp2 c *
E 5		Wah GtrLp2 d *
F 5	210	Wah Gtr A
G 5	211	Wah Gtr B
A 5	212	D.GtrUpwhine
B 5	213	Gtr Thumper

## 207 Gtr FX MENU

Key	Wave#	WaveName
C 4	GTR FX 1	*
C#4	GTR FX 2	*

## 214 Hit MENU 1

Key	Wave#	WaveName
-----	-------	----------

C 4	216	Brass Fall 2
-----	-----	--------------

D 4	217	Smear Hit 1
-----	-----	-------------

E 4	218	Smear Hit 2
-----	-----	-------------

F 4	219	LoFi MinorHt
-----	-----	--------------

G 4	220	BrassVox Hit
-----	-----	--------------

A 4	221	Brass Hit Lp
-----	-----	--------------

B 4	222	Mean Brs Hit
-----	-----	--------------

C 5	223	Sax Lick 1
-----	-----	------------

D 5	224	Sax Lick 2
-----	-----	------------

E 5	225	Sax Cry
-----	-----	---------

F 5	226	Sax Blast
-----	-----	-----------

G 5	228	HipHop Alarm
-----	-----	--------------

## 215 Hit MENU 2

Key	Wave#	WaveName
-----	-------	----------

C 4	229	Cuica Hit
-----	-----	-----------

D 4	230	Breath Hit
-----	-----	------------

E 4	231	Bauw Hit
-----	-----	----------

F 4	232	ClassicHseHt
-----	-----	--------------

G 4	233	JUNO Blip 1
-----	-----	-------------

A 4	234	JUNO Blip 2
-----	-----	-------------

B 4	235	Sci-Fi 2
-----	-----	----------

C 5	236	Slice of Trp
-----	-----	--------------

D 5	237	Rattle Hit
-----	-----	------------

E 5	238	P.Phatt Hit</

# Menu Waveform (2)

## 289 Voice MENU 5

Key	Wave#	WaveName
C 4	328	House Music
D 4	329	Come On
E 4	330	Oh No !
F 4	331	Oh Yes !
G 4	332	Alright
A 4	333	It's MyHouse
B 4	334	Higher
C 5	335	Everybody
D 5	336	Ouhouhooohou
E 5	337	Tic
F 5	338	Tac
G 5	339	Tigidi
A 5	340	Tac Tac
B 5	341	Auu

## 342 VOCODER MENU

Key	Wave#	WaveName
C 4	VP "ei"	*
C#4	VP "ii"	*
D 4	VP "ai"	*
D#4	VP "ou"	*
E 4	VP "ju"	*
F 4	VP "one"	*
F#4	VP "two"	*
G 4	VP "three"	*
G#4	VP "four"	*
A 4	VP "music"	*
A#4	VP "techno"	*
B 4	VP "groove"	*
C 5	VP "dance"	*
C#5	VP "funky"	*
D 5	VP "rhythm"	*
D#5	VP "machine"	*

## 472 Kick MENU 1

Key	Wave#	WaveName
C 4	485	Jungle Kick
D 4	486	Hip Kick
E 4	487	Ninja Kick
F 4	488	Break Kick
G 4	489	Funky Kick
A 4	490	Slamn'Kick 1
B 4	491	Too Big Kick
C 5	492	Boom Kick
D 5	493	FarNear Kick
E 5	494	Slamn'Kick 2
F 5	495	Hall Kick 1
G 5	496	Dance Kick 4
A 5	497	Thump Kick
B 5	498	PurePhatKick
C 6	499	Hall Kick 2

## 473 Kick MENU 2

Key	Wave#	WaveName
C 4	500	Plastic Kick
D 4	501	ElectricKick
E 4	513	TR808 Kick 3
F 4	502	TR808 KickLp
G 4	503	TR707 Kick 3
A 4	504	Lo-Fi Kick
B 4	505	Hybrid Kick
C 5	506	Rock Rim BD

## 505 Kick MENU 3

Key	Wave#	WaveName
C 4	507	TR909 Kick 1
C#4	508	TR909 Kick 2
D 4	509	TR909 Kick 3
D#4	509	Plastic BD 1
E 4	510	Plastic BD 2
F 4	511	TR909 Kick4
F#4	511	TR808 Kick 1
G 4	512	TR808 Kick 2
G#4	513	TR808 Kick 3
A 4	514	TR606 Kick 1
A#4	515	TR606 Kick 2
B 4	606	Dst Kick
C 5	516	TR707 Kick 1
C#5	517	TR707 Kick 2
D 5	518	Culture Kick

## 506 Kick MENU 4

Key	Wave#	WaveName
C 4	Hop Kick	*
C#4	Optic Kick	
D 4	Lo-Fi BD	
D#4	Wet Kick	
E 4	DR Cmp Kick	*
F 4	Video Kick	
F#4	JungleKick 1	
G 4	Street Kick	
G#4	Turbo Kick	
A 4	JungleKick 2	
A#4	Tekno Kick	
B 4	Sim Kick	
C 5	Dance Kick 2	*
C#5	TR909 Dst BD	
D 5	Roll Kick	#

## 532 Kick MENU 5

Key	Wave#	WaveName
C 4	534	Punchy K 1
D 4	535	Punchy K 2
E 4	536	Direct K
F 4	537	Tone K
G 4	538	Dynamic K
A 4	539	Clone K
B 4	540	Noizzy 909 K
C 5	541	Bottom 909 K

## 533 Kick MENU 6

Key	Wave#	WaveName
C 4	542	Sub & Noiz K
D 4	543	Open Cut K
E 4	544	Short Dry K
F 4	545	Medium K2
G 4	546	Hicut K
A 4	547	Full Range K
B 4	548	ToTheFloorK
C 5	549	DrctRehrsAlK
D 5	550	Fat Clap K
E 5	551	Bottom K
F 5	552	50Hz K
G 5	553	Full House K

## 554 Snare MENU 1

Key	Wave#	WaveName
C 4	557	HpHpJazzySnr
D 4	609	TR606 Snr 2
D 4	606	Snr Dst
D#4	610	TR606 Snr 3
E 4	611	TR707 Snr 1
F 4	612	TR707 Snr 2
G 4	613	CR78 Snare
G#4	614	Clap Snare 2
A 4	615	Jungle Snr 9
A#4	616	Rage Snare 2
B 4	617	Clap Snare 3
C 5	618	Clap Snare 4

## 556 Snare MENU 3

Key	Wave#	WaveName
C 4	585	TR808 Snr 5
D 4	586	TR808 Snr 6
E 4	587	TR808 Snr 7
F 4	588	TR606 Snr 4
G 4	589	Electro Snr
A 4	590	Echo Snare
B 4	591	TooBig Snr

## 592 Snare MENU 4

Key	Wave#	WaveName
C 4	597	TR909 Snr 1
C#4	598	TR909 Snr 2
D 4	599	TR909 Snr 3
D#4	600	TR909 Snr 4
E 4	601	TR909 Snr 5
F 4	602	TR909 Snr 6
G 4	603	TR909 Snr 7
G#4	909	Snr Dst
A 4	909	Snr Fuzz
A#4	TR808	Snr 5
B 4	604	TR808 Snr 1
C 5	605	TR808 Snr 2
C#5	606	TR808 Snr 3
D 5	607	TR808 Snr 4
D#5	TR808	Snr 6

## 596 Snare MENU 8

Key	Wave#	WaveName
C 4	Jungle Snr 10	*
C#4	632	Jungle Snr 5
D 4	Jungle Snr 8	*
D#4	633	Urban Snare
E 4	Lite Snare	*
F 4	634	Sim Snare
F#4	635	Electro Snr
G 4	635	Roll Snare

## 636 Snare MENU 9

Key	Wave#	WaveName
C 4	638	Dry Comp SN
D 4	639	ShrtDirectSN
E 4	640	Tone Comp SN
F 4	641	Wooden SN
G 4	642	High Rim SN
A 4	643	Mid Rim SN
B 4	644	Tone&SynthSN
C 5	645	Tiny SN
D 5	646	Little SN
E 5	647	Clap SN
F 5	648	Stick SN

## 637 Snare MENU 10

Key	Wave#	WaveName
C 4	649	Vintage SN
D 4	650	Cuttetd SN
E 4	651	Rim and SN
F 4	652	AllInOne SN
G 4	653	Syn-SN
A 4	654	Live SN
B 4	655	Back Rev SN
C 5	656	Heavy SN

## 657 Rim MENU

Key	Wave#	WaveName
C 4	658	Bright Rim
D 4	659	Ragga Rim 1
E 4	660	TR808 Rim 2
F 4	661	Ragga Rim 2
G 4	662	Lo-Fi Rim
A 4	663	Sizzle Rim
B 4	664	Real Rim

## 665 Tom MENU 1

Key	Wave#	WaveName
C 4	670	TR909 Tom
D 4	672	TR808 Tom
E 4	666	TR606 Tom 2
F 4	667	Electro Tom
G 4	668	Garbage Tom

## 669 Tom MENU 2

Key	Wave#	WaveName
C 4	670	TR909 Tom
C#4	671	TR909 DstTom
D 4	672	TR808 Tom
D#4	673	TR606 Tom
E 4	674	TR606 CmpTom
F 4	675	TR707 Tom
F#4	676	TR707 CmpTom
G 4	677	Deep Tom
G#4	678	Kick Tom
A 4	679	Natural Tom
A#4	680	Can Tom

# Menu Waveform (3)

## 681 HH/Cym MENU

Key	Wave#	WaveName
C 4	682	Overlord
D 4	683	Real Hat
E 4	684	Lil' Hat
F 4		Clear Hat *
G 4	685	Garbage Hat
A 4	686	Ninja Hat
B 4	687	Junk Hat #
C 5	688	Ragga ClHat #
D 5	689	Rock OpHat
E 5	690	HipHopMedHat #
F 5	691	CR78 Hat #
G 5	692	TR909 OpHat
A 5	693	TR909 Cymbal
B 5	694	TR808 Cymbal
C 6	695	Ragga Crash
D 6	696	Lo-Fi Ride

## 697 CHH MENU 1

Key	Wave#	WaveName
C 4	699	TR909 CHH 1
C#4	700	TR909 CHH 2
D 4	701	TR909 CHH 3
D#4	702	TR808 CHH 1
E 4		TR808 CHH 3 *
F 4	703	TR808 CHH 2
F#4		TR808 CHH 3 *
G 4	704	TR606 CHH
G#4		TR606 CHH 2 *
A 4		TR606 CHH 3 *
A#4	705	TR707 CHH
B 4	706	CR78 CHH
C 5		DM CHH *

## 698 CHH MENU 2

Key	Wave#	WaveName
C 4	707	Pop CHH
C#4		Pop CHH 2 *
D 4	708	Bristol CHH
D#4		Lithe CHH *
E 4		R8 CHH *

## 709 PHH MENU

Key	Wave#	WaveName
C 4	710	TR909 PHH 1
C#4	711	TR909 PHH 2
D 4	712	TR808 PHH
D#4		TR808 PHH 2 *
E 4	713	TR606 PHH
F 4		TR606 PHH 2 *
F#4	714	TR707 PHH
G 4		HH Pedal *

## 715 OHH MENU

Key	Wave#	WaveName
C 4	716	TR909 OHH 1
C#4	717	TR909 OHH 2
D 4		TR909 OHH 4 *
D#4	718	TR909 OHH 3
E 4	719	TR909 DstOHH
F 4		TR909 OHH 2 *
F#4	720	TR808 OHH
G 4		TR808 OHH 3 *
G#4	721	TR606 DstOHH
A 4		TR707 HH *
A#4	722	TR707 OHH
B 4	723	CR78 OHH
C 5		DM OHH *
C#5		Hop OHH *
D 5	724	R8 OHH
D#5	725	Cym OHH

## 726 HH MENU 1

Key	Wave#	WaveName
C 4	728	Old Style HH
D 4	729	ShortOpen HH
E 4	730	Closed8HiHH
F 4	731	ShortNzMidHH
G 4	732	Mid Hat
A 4	733	Hi Freq HH
B 4	734	808 HH

## 727 HH MENU 2

Key	Wave#	WaveName
C 4	735	OpenDitherHH
D 4	736	Open Soft HH
E 4	737	Noizzz HH
F 4	738	JazzClosedHH
G 4	739	Full Ambi HH
A 4	740	Open Hard HH
B 4	741	FastOpenSynHH
C 5	742	Hi Open HH
D 5	743	VinylOpen HH
E 5	744	Openopen HH
F 5	745	Vintage Hat
G 5	746	Let It Go HH
A 5	747	808 Open HH

## 748 Cymbal MENU1

Key	Wave#	WaveName
C 4	749	TR606 Cym 1
C#4	750	TR606 Cym 2
D 4	751	TR606 DstCym
D#4	752	TR909 Ride
E 4	753	TR909DstRide
F 4	754	TR707 Ride
F#4	755	TR909 Crash
G 4	756	TR909DsCrash

## 757 Cymbal MENU2

Key	Wave#	WaveName
C 4	758	Crash Zero
D 4	759	Crash 1 Long
E 4	760	Crash 1 Mute
F 4	761	Crash 2 Long
G 4	762	Crash 2 Mute
A 4	763	Hi Crash
B 4	764	Ride 3
C 5	765	Ride 3 Bell
D 5	766	Ride 4
E 5	767	Stick Cymbal
F 5	768	High Cymbal

## 769 Clap MENU 1

Key	Wave#	WaveName
C 4	770	Funk Clap
D 4	771	HipHop Clap
E 4	772	Crackhed
F 4	773	MC Clap
G 4	774	TR909 Clap 2

## 775 Clap MENU 2

Key	Wave#	WaveName
C 4	776	TR909 Clap
C#4	777	TS Clap
D 4	778	Clap Stop
E 4	808	Comp Clp *
F 4	779	TR707 Clap
F#4	780	HC2 Dry Clap
G 4		DM Clap *
G#4	781	Scratch Clap
A 4		Real Clap *
A#4		Groove Clap *
B 4	782	Comp Clap
C 5	783	Claptail
C#5		909 Clp Fuzz *

## 784 Clap MENU 3

Key	Wave#	WaveName
C 4	785	Shot Clap
D 4	786	Room Clap
E 4	787	Real Clap 1
F 4	788	Real Clap 2
G 4	789	Poly Clap

## 790 TMB&SKR MENU

Key	Wave#	WaveName
C 4	791	Tambourine 2
C#4	792	Rattle Tamb
D 4	793	TechnoShaker
D#4	794	Dance Shaker
E 4		TR808 Maracas *
F 4		CR78 Guiro *

## 795 COW&RIM MENU

Key	Wave#	WaveName
C 4	796	TR808Cowbell
C#4	797	TR707Cowbell
D 4	798	CR78 Cowbell
D#4	799	TR727 Agogo
E 4	800	TR909 Rim
F 4		TR909 Dst Rim *
F#4	801	TR808 Rim
G 4	802	TR808 RimLng
G#4		TR707 Rim *
A 4		Ragga Rim *
A#4	803	TR808 Claves

## 804 Perc. MENU 1

Key	Wave#	WaveName
C 4	805	TR808Claves2
D 4	806	TR808 Cowbel
E 4	807	Tamb.Short 2
F 4	808	Tamb. Long 2
G 4	809	CR78 Tamb 2
A 4	810	Jingle Bell
B 4	811	Belltree
C 5	812	Funky Tri #
D 5		Flextone *
E 5	813	TR727Quijada

## 814 PERCUSS MENU

Key	Wave#	WaveName
C 4	815	TR808 Conga1
C#4		TR808 Conga 3 *
D 4	816	TR808 Conga2
D#4		Hi Bongo L.F *
E 4		Lo Bongo L.F *
F 4		Mute CGA L.F *
F#4		Hi Conga L.F *
G 4		Lo Conga L.F *
G#4	817	Surdo mute
A 4	818	Surdo open
A#4		H Timbal L.F *
B 4		L Timbal L.F *
C 5		Tabla Comp *

## 819 Perc. MENU 2

Key	Wave#	WaveName
C 4	824	ShortGuira 1
D 4	825	ShortGuira 2
E 4	826	Guira 1
F 4	827	Guira 2
G 4	828	Schelle
A 4	829	Tin Cowbell
B 4	830	ReverbCowbel
C 5	831	Real Bell Hi
D 5	832	AnalogCwblLo
E 5	833	AnalogCwblHi
F 5	834	SynthCowbell
G 5	835	Block
A 5	836	High Claves

\* : Used only in the menu waveforms.  
# : This waveform was created by CHRONIC MUSIC (U.S.A.).

## 820 Perc. MENU 3

Key	Wave#	WaveName
C 4	837	Timbale 2 Hi
D 4	838	Timbale 2 Lo
E 4	839	LowRealConga
F 4	840	MidRealConga
G 4	841	Conga Slap 2
A 4	842	FstAtkCngMid
B 4	843	FstAtkCngHi
C 5	844	FstAtkCngLow
D 5	845	Da Conga Mid
E 5	846	Da Conga Hi
F 5	847	AnalgCongaHi
G 5	848	AnalgCongaLo
A 5	849	SynthCongaHi
B 5	850	SynthCongaLo
C 6	851	TalkingConga

## About the New Format

Expansion boards SRX-01~04 could only hold a maximum of 128 Patches. In order to make it possible to provide an even greater variety of sounds, a new format (implemented originally on the SRX-05) is now being employed. This new format is capable of handling more than 128 Patches.

If you are using one of the five models listed below, and are still using an older version of the system, you may need to upgrade its system to enable it to support the new SRX format. Check the system program version of your instrument; if your current version is the same as, or older than the corresponding one listed below, use the system update program on the included CD-ROM to upgrade to the latest version before using the SRX-08.

- Fantom: Update required for versions up to Ver. 1.12
- XV-5080: Update required for versions up to Ver. 1.24
- XV-3080: Update required for versions up to Ver. 1.08
- XV-88: Update required for versions up to Ver. 1.07
- RD-700: Update required for versions up to Ver. 1.04

For instructions on checking the system program version for each instrument, and upgrading the software, refer to the html files for the relevant instrument included on the CD-ROM.

## About the Included CD-ROM

The included CD-ROM features:

- System update programs compatible with new-format SRX expansion boards (for Fantom, XV-5080, XV-3080, XV-88, and RD-700)
- Data Reproducing the SR-JV's Original Patches and Rhythm Sets (Compatible models: Fantom, XV-5080, XV-5050, XV-3080, XV-88, XV-2020)
- SRX-01~09 demo songs
- BPM Conversion Table

For more detailed information on each file, refer to index\_e.html on the CD-ROM.

- \* Take proper care of the included CD-ROM; it will not be reissued.
- \* The system programs on the included CD-ROM are the latest versions, as of September, 2002. For information regarding newer versions than those on this disk, you should contact the nearest Roland Service Center.

## 新フォーマットについて

エクスパンション・ボード SRX-01 ~ 04 は、最大 128 パッチを収録していました。SRX-05 以降は、より多彩な音色をお客様に供給する為に、128 以上のパッチを扱えるよう、新フォーマットを採用しています。

これにより、以下の 5 機種において、現在お使いのバージョンによっては、新フォーマットに対応するためにバージョン・アップしていただく必要があります。システム・プログラム・バージョンをご確認の上、下記のバージョン、もしくはそれより古いバージョンの場合は、付属 CD-ROM に収録のシステム・アップデート・プログラムを使用して、製品をバージョン・アップしてから SRX-08 をお使いください。

- Fantom : Ver 1.12 まではアップデートが必要
- XV-5080 : Ver 1.24 まではアップデートが必要
- XV-3080 : Ver 1.08 まではアップデートが必要
- XV-88 : Ver 1.07 まではアップデートが必要
- RD-700 : Ver 1.04 まではアップデートが必要

各機種のシステム・プログラム・バージョンの確認方法、およびバージョン・アップ方法は、付属 CD-ROM に収録の、各機種別ファイルを参照してください。

## 付属 CD-ROM について

付属 CD-ROM には

- SRX エクスパンション・ボード新フォーマット対応用システム・アップデート・プログラム  
(Fantom, XV-5080, XV-3080, XV-88, RD-700)
- SR-JV オリジナル Patch / Rhythm Set 再現データ  
(対応機種 : Fantom, XV-5080, XV-5050, XV-3080, XV-88, XV-2020)
- SRX-01 ~ 09 デモ・ソング
- BPM 変換テーブル

が収録されています。各ファイルの詳しい内容は、CD-ROM 内の index\_j.html を参照してください。

- ※ 付属 CD-ROM は再発行しませんので、大切にお使いください。
- ※ 付属 CD-ROM に収録の各システム・プログラムは、2002 年 9 月時点での最新のものです。収録バージョンより新しいプログラムに関しては、もよりのローランド・サービスにお問い合わせください。



# ローランド製品保証書

[持込修理]

お客様	ご芳名	様
	ご住所	〒 _____

取扱販売店名・住所・

保証期間

お買い上げ日

年 月 日より

本体は一年間

ただし、ソフトウェア、付属品、消耗部品は除く

太枠内に記入または捺印の無い場合は、必ず販売店発行の領収書またはそのお買上げ年月日・販売店等を証明するものを保証書に添付願います。記入もしくは添付の無い場合は無効となりますので、ご注意ください。

型名 SRX-08 "Platinum Trax"

●本保証書は、本書記載内容で無料修理をさせていただくことを約束するものです。

●保証期間中に故障が発生した場合は、製品と本書をご持参ご提示の上、お買上げの販売店にご依頼ください。

●ご転居・ご贈答品などの場合で、お買上げ販売店に修理を依頼することができない場合は、ローランドサービスステーションにお問い合わせください。

●本書は再発行いたしません。所定事項の記入および内容をよくお読みの上、大切に保存してください。



ローランド株式会社

本社 〒530-0002 大阪市北区曾根崎新地1-4-20 桜橋IMビル11F  
電話 (06) 6345-9800

## 保証規定

1. 保証期間内において、取扱説明書・本体貼付ラベルなどの注意書に従った正常なご使用状態で発生した故障については、第3項に示す場合を除き、無料修理いたします。
2. 保証期間内に無料修理をお受けになる場合は、お買上げの販売店・又は最寄りのローランドサービスステーションにご依頼のうえ、修理の際に本書をご提示ください。お客様のご事情により出張修理を依頼された場合、保証期間中であっても出張料金を申し受けます。
3. 保証期間内でも、次の場合には有料修理となります。
  - (イ) 本書のご提示が無い場合。
  - (ロ) 本書にお買上げ年月日・販売店名の記入が無い場合、または字句を書き換えられた場合。
  - (ハ) ご使用上の誤り、又は当社の指定者以外の手により修理・改造された場合。
  - (二) 本製品に異常がなく、他の部分、他の機器に異常があり、点検及び改善した場合。
  - (ホ) お買上げ後の輸送、移動、落下等による故障や損傷および使用中に生じたキズ・汚れなどの外観上の変化。
  - (ヘ) 地震、落雷、風水害、その他の天災地変、火災、公害、ガス、異常電圧による故障や損傷。
  - (ト) 消耗部品（例：電池など）の取り替えを要する場合、および消耗部品の摩耗や劣化に起因する故障や損傷。
4. 本製品は日本国内でご使用いただくことを前提に製造・販売しております。従って本製品の保証は、日本国外ではお受けできませんので、ご了承ください。  
**This warranty is valid only in Japan.**

修理メモ

※ 本保証書は以上の保証規定により無料修理をお約束するものです。従ってこの保証書によってお客様の法律上の権利を制限するものではありません。

※ 本製品の補修用性能部品（製品の機能を維持するために必要な部品）の最低保有期間は製造打切後6年です。この部品保有期間を修理可能の期間とさせていただきます。保有期間経過後も、故障内容によっては修理可能の場合がありますので、ローランドサービスステーションまでお問い合わせください。

※ 修理の際、交換した部品を再生、再利用、製品の品質向上等の目的で回収させていただくことがありますので、ご協力願います。

Copyright © 2002 ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

© 2002 ローランド株式会社 本書の一部、もしくは全部を無断で複写・転載することを禁じます。

**Roland Corporation**

03122778

'05-6-5N