

Functionality Added to the TR-09 (Ver. 1.04)

This document explains the functionality that has been added to the TR-09. Read it together with the Owner's Manual.

Playing Sounds

Mute/Solo Settings

Here's how to make mute/solo settings for each sound.

1. Hold down the [SHIFT] button and press the [INSTRUMENT SELECT] (don't release them yet).
2. While continuing to hold down the [SHIFT] button and [INSTRUMENT SELECT] button, press the [ENTER] button to select either "MUTE" (MUTE) or "SOLO" (SOLO).
3. While continuing to hold down the [SHIFT] button and [INSTRUMENT SELECT] button, press a main key [1]–[16] to select the sound that you want to mute/solo.
The main key of the sound for which you specified mute/solo blinks.
4. By pressing the [CLEAR] button while continuing to hold down the [SHIFT] button and [INSTRUMENT SELECT] button, you can clear mute/solo for all sounds.

Pan Settings

Here's how to specify the pan (stereo position) of each sound.

1. Hold down the [SHIFT] button and press the [EDIT] button.
2. Use the [TEMPO] dial to select "PAN" (PAN).
3. Press a main key [1]–[16] to select a sound.
4. Use the [TEMPO] dial to specify the value.

MEMO

By holding down the [SHIFT] button and pressing the [ENTER] button you can return to the factory-set values.

5. Press the [EDIT] button or [ENTER] button to finish editing.

Errata

Please make the following corrections to the "TR-09 Owner's Manual."

Copying a Pattern

(Incorrect)

1. Select the paste-destination pattern.
Hold down the [SHIFT] button and press the following buttons in the order given.
BANK (I, II) → PATTERN GROUP (1-3) → MAIN KEY (1-16)

(Correct)

1. Select the paste-destination pattern.
 1. While continuing to hold down the [SHIFT] button, press the following buttons in the order shown.
Bank (I, II) → PATTERN GROUP (1-3)
 2. Press a main key [1]–[16].