

Functionality Added to the VP-03 (Ver. 1.04)

This document explains the functionality that has been added to the VP-03. Read it together with the Owner's Manual.

Step Sequencer

Sequencer Settings

Function	Controller		Explanation
Sampling threshold	[PLAY/STOP] + [13] →	[1]–[16] (default: [8])	This specifies the audio level that causes recording to start automatically. The higher the value, the higher the level at which recording starts.
Pre-sampling time	[PLAY/STOP] + [14] →	[1]–[16] (default: [9])	This specifies the time that is retrospectively recorded before the moment at which recording starts. The higher the value, the longer the time that is retrospectively recorded before the level specified by the sampling threshold setting is reached. Higher settings of this value make it easier to capture consonants.

* Sequencer settings return to the default values when the power is turned off.