

# VP-03 Chord Memory List / VP-03 コード・メモリー・リスト

When you play middle C (C4), the notes shown in the following table are heard.

中央のド (C4) を弾いたときに、下表の鍵盤が鳴ります。

1 "m (♭6)"	9 "m7 (5)"
2 "m7"	10 "m6"
3 "6 (9, #11, omit3)"	11 "m9"
4 "6"	12 "m6 (9)"
5 "Maj7"	13 "m9 (11)"
6 "(add 9)"	14 "Maj7 (add 13)"
7 "7 sus4 (9)"	15 "m9 (11)"
8 "7 (♭5)"	16 "6 (9, #11)"