RHYTHM PERFORMER

MIDI Implementation Chart

Date: Oct. 4, 2018

Model: TR-8S

Version 1.10

Function		Transmitted	Recognized	Remarks
Basic Channel	Default	10	10	Memorized
	Changed	1-16, OFF	1-16, OFF	
Mode	Default	Mode 4	Mode 4	
	Messages	x	x	
	Altered	**********	**********	
Note Number		*1	*1	
	: True Voice	**********		
Velocity	Note On	o 9nH v=80	o	
	Note Off	o 8nH v=00	o	
After Touch	Key's	x	x	
	Channel's	x	x	
Pitch Bend		x	x	
Control Change	9	o	o	SHUFFLE
	12	o	o	EXTERNAL IN LEVEL
	14	o *2	x	AUTO FILL IN [ON]
	15	o	o	MASTER FX [ON]
	16	o	o	DELAY LEVEL
	17	o	o	DELAY TIME
	18	o	o	DELAY FEEDBACK
	19	o	o	MASTER FX CTRL
	20	o	o	BD TUNE
	23	o	o	BD DECAY
	24	o	o	BD LEVEL
	25	o	o	SD TUNE
	28	o	o	SD DECAY
	29	o	o	SD LEVEL
	46	o	o	LT TUNE
	47	o	o	LT DECAY
	48	o	o	LT LEVEL
	49	o	o	MT TUNE
	50	o	o	MT DECAY
	51	o	o	MT LEVEL
	52	o	o	HT TUNE
	53	o	o	HT DECAY
	54	o	o	HT LEVEL
	55	o	o	RS TUNE
	56	o	o	RS DECAY
	57	o	o	RS LEVEL
	58	o	o	HC TUNE
	59	o	o	HC DECAY
	60	o	o	HC LEVEL
	61	o	o	CH TUNE
	62	o	o	CH DECAY
	63	o	o	CH LEVEL
	70	o *2	x	AUTO FILL IN [MANUAL TRIG]
	71	o	o	ACCENT
	80	o	o	OH TUNE
	81	o	o	OH DECAY
	82	o	o	OH LEVEL
	83	o	o	CC TUNE
	84	o	o	CC DECAY
	85	o	o	CC LEVEL
	86	o	o	RC TUNE
	87	o	o	RC DECAY
	88	o	o	RC LEVEL
	91	o	o	REVERB LEVEL
	96	o	o	BD CTRL
	97	o	o	SD CTRL
	102	o	o	LT CTRL
	103	o	o	MT CTRL
	104	o	o	HT CTRL
	105	o	o	RS CTRL
	106	o	o	HC CTRL
	107	o	o	CH CTRL
	108	o	o	OH CTRL
	109	o	o	CC CTRL
	110	o	o	RC CTRL
Program Change		o	o	
	: True Number	0-127	0-127	
System Exclusive		x	x	
System Commor	: Song Position	x	x	
	: Song Select	x	x	
	: Tune Request	x	x	
System Real Time	: Clock	o	o	
	: Start	o	o	
	: Continue	x	o	
	: Stop	o	o	
Aux Message	: All Sound Off	x	x	
	: Reset All Controllers	x	x	
	: Local On/Off	x	x	
	: All Notes Off	x	x	
	: Omni Mode Off	x	x	
	: Omni Mode On	x	x	
	: Mono Mode On	x	x	
	: Poly Mode On	x	x	
	: Active Sensing	o	o	
	: System Reset	x	x	

Notes

*1

INST	Note Number	Note Number (ALT)
BD	36	35
SD	38	40
LT	43	41
MT	47	45
HT	50	48
RS	37	56
HC	39	54
CH	42	44
OH	46	58
CC	49	61
RC	51	63
TRIGGER OUT	OFF	-----

These note numbers are configurable on UTILITY:MIDI:Inst Note.

*2 Transmitted when the UTILITY:SOUND:LocalSw is SURFACE.

Mode 1: Omni On, Poly　　Mode 2: Omni On, Mono　　o: Yes

Mode 3: Omni Off, Poly　　Mode 4: Omni Off, Mono　　x: No