



# Contents

|                                           |           |
|-------------------------------------------|-----------|
| <b>DRUM KIT</b> .....                     | <b>3</b>  |
| ◇ KIT screen .....                        | 3         |
| <b>KIT CUSTOMIZE</b> .....                | <b>4</b>  |
| ◇ INSTRUMENT .....                        | 4         |
| INSTRUMENT .....                          | 4         |
| V-EDIT .....                              | 6         |
| ◇ EQ/COMP .....                           | 10        |
| PAD EQ .....                              | 10        |
| PAD COMP .....                            | 10        |
| KIT COMP .....                            | 11        |
| KIT EQ .....                              | 13        |
| ◇ MIXER .....                             | 14        |
| ◇ AMBIENCE .....                          | 15        |
| OVERHEAD .....                            | 15        |
| ROOM .....                                | 18        |
| REVERB .....                              | 20        |
| KIT RESONANCE .....                       | 23        |
| ◇ BUS FX .....                            | 25        |
| ◇ KIT OTHERS .....                        | 28        |
| XSTICK .....                              | 28        |
| STRAINER .....                            | 29        |
| SNARE BUZZ .....                          | 30        |
| KIT VOLUME .....                          | 30        |
| KIT NAME .....                            | 31        |
| MUTE GROUP .....                          | 31        |
| KIT MIDI .....                            | 31        |
| KIT COLOR .....                           | 33        |
| POSITION/PEDAL .....                      | 33        |
| KIT OPTION .....                          | 34        |
| <b>SONG</b> .....                         | <b>36</b> |
| ◇ SONG .....                              | 36        |
| <b>CLICK</b> .....                        | <b>37</b> |
| ◇ Making the click play (metronome) ..... | 37        |
| ◇ COACH .....                             | 38        |
| PHRASE TRAINER .....                      | 38        |
| TIME CHECK .....                          | 39        |
| QUIET COUNT .....                         | 39        |
| AUTO UP/DOWN .....                        | 40        |
| STROKE MONITOR .....                      | 40        |
| BLAST BEAST .....                         | 40        |
| ✱ (Bluetooth) .....                       | 41        |
| <b>USER SAMPLE</b> .....                  | <b>42</b> |
| ◇ USER SAMPLE LIST .....                  | 42        |
| <b>BACKUP</b> .....                       | <b>43</b> |
| ◇ SAVE .....                              | 43        |
| ◇ LOAD .....                              | 43        |
| ◇ DELETE .....                            | 43        |
| ◇ SAVE 1 KIT .....                        | 43        |
| ◇ LOAD 1 KIT .....                        | 43        |
| ◇ DELETE 1 KIT .....                      | 43        |
| ◇ INFO .....                              | 43        |

|                                                             |            |
|-------------------------------------------------------------|------------|
| <b>SETUP</b> .....                                          | <b>44</b>  |
| ◇ Wi-Fi .....                                               | 44         |
| ◇ OUTPUT .....                                              | 45         |
| OUTPUT ROUTING .....                                        | 46         |
| ◇ USB AUDIO .....                                           | 47         |
| Configuring the routing for USB audio (Audio Routing) ..... | 47         |
| ◇ SYSTEM INFO .....                                         | 49         |
| ◇ SYSTEM MIDI .....                                         | 49         |
| ◇ CONTROL SETUP .....                                       | 52         |
| ◇ OPTION .....                                              | 54         |
| ◇ FACTORY RESET .....                                       | 55         |
| <b>TRIGGER</b> .....                                        | <b>56</b>  |
| <b>Effect parameters</b> .....                              | <b>66</b>  |
| ◇ FX list .....                                             | 66         |
| ◇ Thru .....                                                | 67         |
| ◇ Filter .....                                              | 67         |
| ◇ Phaser .....                                              | 72         |
| ◇ Flanger .....                                             | 74         |
| ◇ Chorus .....                                              | 75         |
| ◇ Modulation .....                                          | 77         |
| ◇ Drive/Amp .....                                           | 80         |
| ◇ Comp/Limiter .....                                        | 84         |
| ◇ Delay .....                                               | 87         |
| ◇ Looper .....                                              | 92         |
| ◇ Lo-fi .....                                               | 92         |
| ◇ Pitch .....                                               | 93         |
| ◇ Combination .....                                         | 94         |
| ◇ Note .....                                                | 106        |
| <b>Drum kit list</b> .....                                  | <b>107</b> |
| <b>Instrument list</b> .....                                | <b>109</b> |
| Preset .....                                                | 109        |
| Instrument Expansion .....                                  | 111        |
| <b>Song list</b> .....                                      | <b>118</b> |
| <b>Drum kit parameter structure</b> .....                   | <b>119</b> |
| <b>Block diagram</b> .....                                  | <b>120</b> |

ASIO is a trademark and software of Steinberg Media Technologies GmbH

Company names and product names appearing in this document are registered trademarks or trademarks of their respective owners.

# DRUM KIT

## KIT screen



| Parameter         | Value                                                                                                                                                                                                                                                              | Explanation                                                                                                   |
|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------|
| LIST window       |                                                                                                                                                                                                                                                                    |                                                                                                               |
| KIT LIST          | <p>Press the [F1] (LIST) button to display the KIT LIST window, where you can select a drum kit from the list.</p> <p><b>MEMO</b></p> <p>When you press the [F2] button in the kit list, you can register (ON) or deregister (OFF) the drum kit as a favorite.</p> |                                                                                                               |
| EFFECTS SW window |                                                                                                                                                                                                                                                                    |                                                                                                               |
| OVERHEAD          | OFF, ON                                                                                                                                                                                                                                                            | Shows the EFFECTS SWITCH window, where you can check and edit the ambience and on/off state of other effects. |
| ROOM              |                                                                                                                                                                                                                                                                    |                                                                                                               |
| REVERB            |                                                                                                                                                                                                                                                                    |                                                                                                               |
| KIT RESONANCE     |                                                                                                                                                                                                                                                                    |                                                                                                               |
| BUS FX A-D        |                                                                                                                                                                                                                                                                    |                                                                                                               |
| BUS REVERB        |                                                                                                                                                                                                                                                                    |                                                                                                               |
| KIT COMP/EQ       |                                                                                                                                                                                                                                                                    |                                                                                                               |
| PHRASE            |                                                                                                                                                                                                                                                                    |                                                                                                               |
| PHRASE            | <p>Plays the phrase of the currently selected drum kit, letting you check the sound.</p> <p>Press the button again to stop playback.</p>                                                                                                                           |                                                                                                               |
| WIRELESS window   |                                                                                                                                                                                                                                                                    |                                                                                                               |
| Bluetooth         | OFF, ON                                                                                                                                                                                                                                                            | Turns Bluetooth on/off.                                                                                       |
| Wi-Fi *1          | OFF, ON                                                                                                                                                                                                                                                            | Turns Wi-Fi on/off.                                                                                           |
| TOOLS window      |                                                                                                                                                                                                                                                                    |                                                                                                               |
| COPY KIT          | Copies the drum kit.                                                                                                                                                                                                                                               |                                                                                                               |
| COPY PAD INST     | Copies the pad instruments.                                                                                                                                                                                                                                        |                                                                                                               |
| KIT NAME          | Edits the name of the currently selected drum kit.                                                                                                                                                                                                                 |                                                                                                               |
| SAFETY MODE       | <p>You can disable the buttons to prevent them from being accidentally operated (safety mode).</p> <p>Refer to the “Reference Manual” (Roland website) for how to use safety mode.</p>                                                                             |                                                                                                               |
| SAVE 1KIT         | Backs up the individual drum kit settings (up to 999 files) that are saved on the V71 to an SD card.                                                                                                                                                               |                                                                                                               |
| LOAD 1KIT         | Loads the kit backup data that’s saved to an SD card back to the V71.                                                                                                                                                                                              |                                                                                                               |
| SNAPSHOT          | <p>You can temporarily save the currently edited drum kit, and compare it with the current settings or revert the settings (snapshot).</p> <p>For details on how to use the snapshots, refer to “Reference Manual” (Roland website).</p>                           |                                                                                                               |
| KIT VIEW          | Configures the background and text size for the KIT screen.                                                                                                                                                                                                        |                                                                                                               |


\*1 Please be aware that in some countries or regions, it might not be possible to use the Wi-Fi function.

## INSTRUMENT

1. Press the [INSTRUMENT] button.

2. Press the [F1] (INST) button.

The INSTRUMENT screen appears.



3. Select the pad that you want to edit.

4. Press the cursor buttons to move the cursor to the instrument.

\* The parameters that you can edit depend on the pad and instrument.

5. Use the [-] [+] buttons or the dial to select the instrument (p. 109).

### MEMO

You can also press the [ENTER] button to select an instrument from the list.

6. Press the [KIT] button to return to the KIT screen.

## INSTRUMENT

### Parameters that can be edited for each instrument

| Parameter           | Value                                                                                                                                                          | Explanation                                                                                                                                                                                                                                                                                                                                               |
|---------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>INST tab</b>     |                                                                                                                                                                |                                                                                                                                                                                                                                                                                                                                                           |
| Instrument          | 000 OFF,<br>001– (presets and Instrument Expansions),<br>SYNTH WAVE,<br>U001–U500 (user samples)                                                               | Use this to select an instrument by combining instrument banks and instrument numbers.<br>You can select a user sample or an instrument within an Instrument Expansion.                                                                                                                                                                                   |
| Layer switch        | OFF, ON                                                                                                                                                        | Turns each layer on/off.                                                                                                                                                                                                                                                                                                                                  |
| Layer volume        | -INF, -60.0–+6.0dB                                                                                                                                             | Volume for each layer                                                                                                                                                                                                                                                                                                                                     |
| <b>V-EDIT tab</b>   |                                                                                                                                                                |                                                                                                                                                                                                                                                                                                                                                           |
| V-EDIT parameters   | The V-EDIT parameters are shown according to the instrument that's selected.<br><b>MEMO</b><br>For details on the V-EDIT parameters, refer to "V-EDIT" (p. 6). |                                                                                                                                                                                                                                                                                                                                                           |
| Inst Pitch          | -4800–+4800                                                                                                                                                    | Instrument pitch (units of one cent)<br><b>MEMO</b><br>For instruments with V-EDIT parameters such as Tuning and Pitch, it may be more convenient to adjust the pitch with Tuning and Pitch, and then use Inst Pitch to fine-tune the pitch if necessary.                                                                                                 |
| Inst Pitch Sweep *1 | -100–+100                                                                                                                                                      | After the sound begins, the pitch gradually rises (falls).<br>Positive (+) values make the pitch start high and then fall; negative (-) values make the pitch start low and then rise.<br>Larger values produce greater change.<br>* In some cases, changing the Pitch setting by a large amount might limit the Inst Pitch Sweep effect.                 |
| Inst Decay *1       | 1–100                                                                                                                                                          | Length of decay                                                                                                                                                                                                                                                                                                                                           |
| Dynamic Enhancer    | OFF, NORMAL, WIDE                                                                                                                                              | Specifies whether the sense of strong strikes is enhanced (NORMAL, WIDE) or not enhanced (OFF).<br>Set this to "NORMAL" to apply the effect only when the pad is struck hard, and set this to "WIDE" to apply the effect when the pad is struck a little softer.<br>* If a user sample is assigned to the instrument, you can't specify Dynamic Enhancer. |

| Parameter             | Value                  | Explanation                                                                                                                                                                                                                                                                                       |
|-----------------------|------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>TRANSIENT tab</b>  |                        |                                                                                                                                                                                                                                                                                                   |
| Transient Switch      | OFF, ON                | Turns the transient effect on/off.                                                                                                                                                                                                                                                                |
| Type                  | Preset, Type 1–4       | Use this to set the effect that's used when a transient is applied, if a user sample (except for PLAY TYPE LOOP) is selected for the instrument. (When using the built-in tones, "(Preset)" is shown and this setting can't be edited.)                                                           |
| Attack Time           | 1–10                   | Time over which the attack changes                                                                                                                                                                                                                                                                |
| Attack Depth          | -100–+100              | Adjustment of the attack                                                                                                                                                                                                                                                                          |
| Attack Type           | NORMAL, WIDE 1, WIDE 2 | For the NORMAL setting, the transient attack effect is always applied.<br>For the WIDE 1 or 2 setting, the attack effect becomes weaker when you strike the pad more softly. This is effective when you want to soften the attack on the transients, such as when striking the snare drum softly. |
| Release Depth         | -100–+100              | Adjustment of the release                                                                                                                                                                                                                                                                         |
| Gain                  | -12.0–+6.0 dB          | Volume following transient adjustment                                                                                                                                                                                                                                                             |
| <b>EQ tab</b>         |                        |                                                                                                                                                                                                                                                                                                   |
| EQ Switch             | OFF, ON                | Turns the equalizer on/off.                                                                                                                                                                                                                                                                       |
| Low Freq              | 20–1kHz                | Frequency of the low range                                                                                                                                                                                                                                                                        |
| Low Gain              | -24–+24 dB             | Amount of boost/cut for the low-frequency range                                                                                                                                                                                                                                                   |
| Mid Freq              | 20–16kHz               | Center frequency of the mid range                                                                                                                                                                                                                                                                 |
| Mid Q                 | 0.5–16.0               | Width of the frequency range<br>Set a higher value for Q to narrow the range to be affected.                                                                                                                                                                                                      |
| Mid Gain              | -24–+24 dB             | Amount of boost/cut for the mid range                                                                                                                                                                                                                                                             |
| High Freq             | 1k–16kHz               | Frequency of the high range                                                                                                                                                                                                                                                                       |
| High Gain             | -24–+24 dB             | Amount of boost/cut for the high-frequency range                                                                                                                                                                                                                                                  |
| <b>LAYER MODE tab</b> |                        |                                                                                                                                                                                                                                                                                                   |
| Layer Mode            | MIX                    | Layers the instruments whose instrument switch is ON.                                                                                                                                                                                                                                             |
|                       | VELOCITY               | Specifies how the instrument plays in response to how hard the pad is struck.                                                                                                                                                                                                                     |
|                       | HI-HAT *2              | Instrument layer A plays when you trigger an open hi-hat, instrument B plays when you trigger a closed hi-hat, and instrument C plays when you trigger a closed pedal.                                                                                                                            |
| Fade In Sens *3       | 0–127                  | Sets the change in volume according to how hard you strike the pad, when the instrument begins to play.                                                                                                                                                                                           |
| Velocity Lower *3     | 1–127                  | Specifies the force of the strike at which the instrument begins to sound.                                                                                                                                                                                                                        |
| Velocity Upper *3     | 1–127                  | Specifies the force of the strike from which the instrument stops playing.                                                                                                                                                                                                                        |
| Fade Out Sens *3      | 0–127                  | When you play with a force equal or greater than the setting, the instrument gets quieter according to the Velocity Upper setting.                                                                                                                                                                |
| Dynamics *4           | FIXED                  | When you play with a force equal to or greater than the "Threshold" setting, the instrument plays at the same volume regardless of how hard you play.                                                                                                                                             |
|                       | FADE                   | Makes the instrument sound according to how hard you play.                                                                                                                                                                                                                                        |
| Threshold *5          | 1–127                  | Sets how hard you must strike the pads to make the sound start playing, when Dynamics is set to "FIXED".                                                                                                                                                                                          |

\*1 This is disabled if a user sample is assigned to the instrument and Play Type (p. 42) for the user sample is set to "LOOP ALT".

\*2 This is enabled when the pad to set is the hi-hat, and when the instrument is set to SYNTH WAVE or USER SAMPLE (Play Type = ONE SHOT).

\*3 This is enabled if Layer Mode is set to "VELOCITY" and Dynamics is set to "FADE".


\*4 This is enabled when Layer Mode = "VELOCITY".

\*5 This is enabled if Layer Mode is set to "VELOCITY" and Dynamics is set to "FIXED".

#### MEMO

If you press the [F6] (H&R) button to turn it "ON", you can simultaneously make settings for the head area and rim area, etc.

## V-EDIT




## KICK

| Parameter    | Value                               | Explanation                       |
|--------------|-------------------------------------|-----------------------------------|
| Tuning       | -100–100                            | Tuning of the head                |
| Muffling     | OFF, TAPE1–2, BLANKET1–3, WEIGHT1–2 | Muffling (muting) setting         |
| Head Type    | CLEAR, COATED, PINSTRIPE            | Type of head                      |
| Shell Depth  | 1.0–30.0 [inch]                     | Depth of the shell                |
| Beater Type  | FELT1–2, WOOD, PLASTIC1–2           | Type of beater                    |
| Mic Distance | -5–NORMAL–+5                        | Distance from the mic to the drum |
| Mic Size     | NORMAL, LARGE                       | Size of the mic                   |

\* PINSTRIPE is a registered trademark of Remo Inc., U.S.A.

## SNARE/CROSS STICK




| Parameter          | Value                             | Explanation                                                                                      |
|--------------------|-----------------------------------|--------------------------------------------------------------------------------------------------|
| Tuning             | -100–+100                         | Tuning of the head                                                                               |
| Muffling           | OFF, TAPE1–TAPE4, GEL1–3, RING1–2 | Muffling (muting) setting                                                                        |
| Head Type *1       | CLEAR, COATED, PINSTRIPE          | Type of head                                                                                     |
| Shell Depth *1     | 1.0–20.0 [inch]                   | Depth of the shell                                                                               |
| Overtone *2        | -5–+5                             | Amount of overtone components                                                                    |
| Mic Distance *1    | -5–NORMAL–+5                      | Distance from the mic to the snare drum                                                          |
| Strainer Adjust *3 | 0–32                              | Tension of the strainer (resonating cords)<br>When this is set to "0", the strainer is detached. |
| Wire Type          | DEFAULT, TYPE1–TYPE3              | Type of strainer                                                                                 |
| Wire Level         | -6–NORMAL–+6                      | Volume of strainer                                                                               |

\*1: Unavailable if the instrument group is CROSS STICK.

\*2 When the instrument group is "SNARE", this is disabled for some of the instruments. Unavailable if the instrument group is "CROSS STICK".


\*3 When a pad that supports strainer lever operations (such as the PD-14DSX) is assigned to SNARE, you can control this by operating the strainer lever or knob (p. 29).

## TOM



| Parameter    | Value                         | Explanation                      |
|--------------|-------------------------------|----------------------------------|
| Tuning       | -100—+100                     | Tuning of the head               |
| Muffling     | OFF, TAPE1–6, GEL1–4, FELT1–2 | Muffling (muting) setting        |
| Head Type    | CLEAR, COATED, PINSTRIPE      | Type of head                     |
| Shell Depth  | 1.0–30.0 [inch]               | Depth of the shell               |
| Mic Distance | -5–NORMAL—+5                  | Distance from the mic to the tom |

## HI-HAT/HI-HAT OTHERS/HI-HAT ELEC




| Parameter | Value                                    | Explanation                                                                                                                                                         |
|-----------|------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Size      | 1.0–40.0 [inch]                          | Hi-hat diameter                                                                                                                                                     |
| Thickness | -5–NORMAL—+5                             | Thickness of the hi-hat                                                                                                                                             |
| Fixed     | NORMAL, PRESS, CLOSE, HALF1, HALF2, OPEN | Extent of opening Hi-Hat<br>If something other than “NORMAL” is selected, the openness of the hi-hat does not change, regardless of how you press the hi-hat pedal. |

## MEMO

The closed hi-hat position (Fixed = CLOSE) can be enabled by pressing an optional footswitch or hitting a pad switch. For details, refer to “CONTROL SETUP” (p. 52).

## RIDE/CRASH/CHINA/SPLASH/STACKED CYMBAL



| Parameter     | Value                                   | Explanation                   |
|---------------|-----------------------------------------|-------------------------------|
| Size          | 1.0–40.0                                | Cymbal diameter               |
| Thickness     | -5–NORMAL—+5                            | Thickness of the cymbal       |
| Muffling      | OFF, TAPE1–12                           | Muffling (muting) setting     |
| Sizzle Type   | OFF, RIVET1, CHAIN, BEADS, COIN, RIVET2 | Type of sizzle                |
| Sizzle Amount | -3—+3                                   | Amount of sizzle              |
| Low Cut       | OFF, HALF, FULL                         | Volume of low-frequency sound |

## SYNTH WAVE

| Parameter      | Value                                                                                                                                                                                                                                                                                                                                        | Explanation                                                                                                                                                             |
|----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Template       | Template for the SYNTH instrument settings<br>* When you edit this parameter, all of the SYNTH parameters change to their optimal settings for your selection. You can then make further adjustments to these parameters as necessary. Depending on the settings of these parameters, the resulting effect might not match the Type setting. |                                                                                                                                                                         |
| Waveform       | Sets the waveform.                                                                                                                                                                                                                                                                                                                           |                                                                                                                                                                         |
|                | SINE                                                                                                                                                                                                                                                                                                                                         | Sine wave                                                                                                                                                               |
|                | WNOISE                                                                                                                                                                                                                                                                                                                                       | White noise                                                                                                                                                             |
|                | SAW                                                                                                                                                                                                                                                                                                                                          | Sawtooth wave                                                                                                                                                           |
|                | TRI                                                                                                                                                                                                                                                                                                                                          | Triangle wave                                                                                                                                                           |
|                | SQR                                                                                                                                                                                                                                                                                                                                          | Square wave                                                                                                                                                             |
|                | RAMP                                                                                                                                                                                                                                                                                                                                         | Ramp wave                                                                                                                                                               |
|                | JUNO                                                                                                                                                                                                                                                                                                                                         | Modulated sawtooth wave                                                                                                                                                 |
| Mono/Poly      | MONO, POLY                                                                                                                                                                                                                                                                                                                                   | Choose "MONO" if you want the tone assigned to the part to play monophonically, or "POLY" if you want to play it polyphonically.                                        |
| Start Phase    | OFF, 45, 90, 135, 180, 225, 270, 315°                                                                                                                                                                                                                                                                                                        | Phase of the waveform when triggered                                                                                                                                    |
| Shape          | 0–127                                                                                                                                                                                                                                                                                                                                        | Deforms the waveform.<br>Set this to "0" to use the original waveform (this has no effect for WNOISE).                                                                  |
| Fat            | 0–127                                                                                                                                                                                                                                                                                                                                        | Boosts the low-frequency region.<br>Set this to "0" to use the original waveform (this has no effect for WNOISE).                                                       |
| PITCH          |                                                                                                                                                                                                                                                                                                                                              |                                                                                                                                                                         |
| EnvSw          | OFF, ON                                                                                                                                                                                                                                                                                                                                      | Turns the pitch envelope on/off.                                                                                                                                        |
| T1–T3          | 5–10000mSec                                                                                                                                                                                                                                                                                                                                  | Specifies the pitch envelope times (T1–T4).<br>Larger values make the time to reach the next pitch longer (for example, T2 sets the time it takes to go from L1 to L2). |
| L0–L2, L3/FREQ | 20–10000Hz                                                                                                                                                                                                                                                                                                                                   | Sets the frequency of the pitch envelope.<br>L3: when EnvSw is "ON"<br>FREQ: when EnvSw is "OFF"                                                                        |
| VeloSens       | 0–127                                                                                                                                                                                                                                                                                                                                        | Adjusts the velocity sensitivity.<br>Larger settings raise the sensitivity.                                                                                             |
| EnvCurve       | 0–127                                                                                                                                                                                                                                                                                                                                        | Adjusts the changes to the pitch envelope.<br>For a straight line, set this to "0"; and for a curved line, set this to "127".                                           |

| Parameter      | Value                                          | Explanation                                                                                                                                                                                   |
|----------------|------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>FILTER</b>  |                                                |                                                                                                                                                                                               |
| EnvSw          | OFF, ON                                        | Turns the filter envelope on/off.                                                                                                                                                             |
| T1–T3          | 5–10000mSec                                    | Specifies the filter envelope times (T1–T3).<br>Larger values make the time to reach the next pitch longer (for example, T2 sets the time it takes to go from L1 to L2).                      |
| L0–L2, L3/FREQ | 20–10000Hz                                     | Specifies the frequency of the filter envelope.<br>L3: when EnvSw is “ON”<br>FREQ: when EnvSw is “OFF”                                                                                        |
| VeloSens       | 0–127                                          | Adjusts the velocity sensitivity.<br>Larger settings raise the sensitivity.                                                                                                                   |
| EnvCurve       | 0–127                                          | Adjusts the changes to the filter envelope.<br>For a straight line, set this to “0”; and for a curved line, set this to “127”.                                                                |
| Type           | THRU, LPF12, BPF12, HPF12, LPF24, BPF24, HPF24 | Selects the filter envelope type.                                                                                                                                                             |
| Reso           | 0–127                                          | Emphasizes the portion of the sound in the region of the cutoff frequency, adding character to the sound.<br>Excessively high settings can produce oscillation, causing the sound to distort. |
| <b>AMP</b>     |                                                |                                                                                                                                                                                               |
| T1–T3          | 5–10000mSec                                    | Specifies the amp envelope times (T1–T3).<br>Higher settings lengthen the time until the next volume level is reached. (For example, T2 is the time during which L1 changes to L2.)           |
| L0–L2          | -INF, -60–0dB                                  | Specifies the AMP envelope levels (L0–L2).                                                                                                                                                    |
| VeloCurve      | LIN, LOG1, LOG2, EXP1, EXP2, ARCT, TAN         | Sets the volume change curve in response to how hard you strike the pad.                                                                                                                      |
| EnvCurve       | 0–127                                          | Adjusts the changes to the amp envelope.<br>For a straight line, set this to “0”; and for a curved line, set this to “127”.                                                                   |
| Volume         | -INF, -60–+12dB                                | SYNTH WAVE volume                                                                                                                                                                             |

## USER SAMPLE


| Parameter | Value                             | Explanation                                                                                                                                                   |
|-----------|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pitch     | -100–100                          | Instrument pitch                                                                                                                                              |
| Decay     | 1–100                             | Length of decay                                                                                                                                               |
| Nuance    | OFF, SNR HEAD, TOM HEAD, CYM EDGE | Sets the nuance used when you strike the pads.<br>You can select from among the settings that are appropriate for the sound (snare or tom head, cymbal edge). |

## Instruments from other instrument groups

| Parameter | Value                        | Explanation                                                                             |
|-----------|------------------------------|-----------------------------------------------------------------------------------------|
| Pitch     | -100–+100                    | Instrument pitch                                                                        |
| Muffling  | OFF, MUFF+1–MUFF+8, MUFF MAX | Muffling (muting) setting<br>* The effect differs depending on the selected instrument. |

## EQ/COMP

You can adjust how the volume changes (kit compressor/pad compressor) or adjust the tonal character (kit equalizer/pad equalizer) for the individual pads and drum kits.



## PAD EQ

Configures the equalizer for each pad. You can configure the sounds for the head and rim separately.

| Parameter        | Value        | Explanation                                                                                  |
|------------------|--------------|----------------------------------------------------------------------------------------------|
| [F5] (EQ) button | OFF, ON      | Turns pad equalizer on/off.                                                                  |
| Low Cut          | OFF, 20–1kHz | Cuts the frequency region below the specified frequency (low cut).                           |
| Low Freq         | 20–1kHz      | Frequency of the low range                                                                   |
| Low Gain         | -24–+24 dB   | Amount of boost/cut for the low-frequency range                                              |
| Mid 1 Q          | 0.5–16.0     | Width of the frequency range<br>Set a higher value for Q to narrow the range to be affected. |
| Mid 1 Freq       | 20–16kHz     | Center frequency of the mid range                                                            |
| Mid 1 Gain       | -24–+24 dB   | Amount of boost/cut for the mid range                                                        |
| Mid 2 Q          | 0.5–16.0     | Width of the frequency range<br>Set a higher value for Q to narrow the range to be affected. |
| Mid 2 Freq       | 20–16kHz     | Center frequency of the mid range                                                            |
| Mid 2 Gain       | -24–+24 dB   | Amount of boost/cut for the mid range                                                        |
| High Freq        | 1k–16kHz     | Frequency of the high range                                                                  |
| High Gain        | -24–+24 dB   | Amount of boost/cut for the high-frequency range                                             |

### MEMO

If you press the [F6] (H&R) button to turn it “ON”, you can simultaneously make settings for the head area and rim area, etc.

## PAD COMP

Configures the compressor for each pad. The head and rim use these settings in common.

| Parameter                       | Value                                                                                             | Explanation                                                                                                                                                                                                                                                                                                                                                                                                            |
|---------------------------------|---------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| [F5] (Comp) button              | OFF, ON                                                                                           | Turns pad compressor on/off.                                                                                                                                                                                                                                                                                                                                                                                           |
| Volume                          | -INF, -60.0–+6.0dB                                                                                | Compressor volume                                                                                                                                                                                                                                                                                                                                                                                                      |
| Pad Comp Type                   | Selects the pad compressor type.                                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                        |
|                                 | STANDARD                                                                                          | A general compressor that's simple and easy to use.                                                                                                                                                                                                                                                                                                                                                                    |
|                                 | FETCOMP-76                                                                                        | This models a classic studio-use FET compressor.<br>* When you select FETCOMP-76, this effect may output a very loud sound, depending on how the parameters are set. Also, use caution when inputting very loud sounds into the FETCOMP-76 effect, as this may cause the output sound to distort or produce noise. If this happens, lower the Input Level or Output Level or take other measures to adjust the volume. |
| When Pad Comp Type = “STANDARD” |                                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Template                        | KICK 1, KICK 2, SNARE 1, SNARE 2, TOM 1, TOM 2, CYMBAL 1, CYMBAL 2, SOFT COMP, HARD COMP, LIMITER | Character of the compressor<br>* When you change this parameter, the pad compressor's parameters Ratio, Knee, Attack, and Release change to optimal settings for your selection. You can then make further adjustments to these parameters as necessary.                                                                                                                                                               |
| Threshold                       | -48–0 dB                                                                                          | Adjusts the volume at which compression begins                                                                                                                                                                                                                                                                                                                                                                         |
| Gain                            | -24.0–+24.0dB                                                                                     | Output level of the compressor                                                                                                                                                                                                                                                                                                                                                                                         |

| Parameter                                | Value                                                                                                                                                                                                                                                                                                          | Explanation                                                                                                                                                                                                                                                                                                                            |
|------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Attack                                   | 0.1–100ms                                                                                                                                                                                                                                                                                                      | Time from when the volume goes up the threshold level until the compressor effect applies                                                                                                                                                                                                                                              |
| Release                                  | 10–1000ms                                                                                                                                                                                                                                                                                                      | Time from when the volume falls below the threshold level until the compressor effect no longer applies                                                                                                                                                                                                                                |
| Ratio                                    | 1:1–INF:1                                                                                                                                                                                                                                                                                                      | Compression ratio                                                                                                                                                                                                                                                                                                                      |
| Knee                                     | HARD, SOFT1–3                                                                                                                                                                                                                                                                                                  | Attack of the sound at the moment compression is applied                                                                                                                                                                                                                                                                               |
| Balance                                  | D100:0W–D0:100W                                                                                                                                                                                                                                                                                                | The volume balance of the sound that passes through the compressor (W) and the unprocessed sound (D)                                                                                                                                                                                                                                   |
| <b>When Pad Comp Type = “FETCOMP-76”</b> |                                                                                                                                                                                                                                                                                                                |                                                                                                                                                                                                                                                                                                                                        |
| Template                                 | KICK PRESENCE, KICK SOFT, KICK MID, KICK HEAVY, SNARE PRESENCE, SNARE SOFT, SNARE MID, SNARE HEAVY, TOM PRESENCE, TOM SOFT, TOM MID, TOM HEAVY, FLOOR TOM SOFT, FLOOR TOM MID, FLOOR TOM HEAVY, HI-HAT PRESENCE, HI-HAT SOFT, HI-HAT MID, HI-HAT HEAVY, CYMBAL PRESENCE, CYMBAL SOFT, CYMBAL MID, CYMBAL HEAVY | Character of the compressor<br>* When you change this parameter, all parameters of the pad compressor change to optimal settings for your selection. You can then make further adjustments to these parameters as necessary. Depending on the settings of these parameters, the resulting effect might not match the Template setting. |
| Compression                              | OFF, ON                                                                                                                                                                                                                                                                                                        | If this is ON, the compression effect is applied.                                                                                                                                                                                                                                                                                      |
| Input Level                              | -INF, -30.0–+30.0dB                                                                                                                                                                                                                                                                                            | Adjusts the input volume.                                                                                                                                                                                                                                                                                                              |
| Output Level                             | -INF, -54.0–+6.0dB                                                                                                                                                                                                                                                                                             | Adjusts the output volume.                                                                                                                                                                                                                                                                                                             |
| Attack                                   | 0.0–7.0                                                                                                                                                                                                                                                                                                        | Sets the time it takes for compression to start, once the audio input crosses the threshold.<br>A value of 0.0 is the longest time it takes for compression to be applied.                                                                                                                                                             |
| Release                                  | 0.0–7.0                                                                                                                                                                                                                                                                                                        | Adjusts the time after the input signal volume falls below the threshold until compression stops.<br>A value of 0.0 is the longest time it takes for compression to be applied.                                                                                                                                                        |
| Ratio Mode                               | Adjusts the compression ratio.                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                        |
|                                          | ALL                                                                                                                                                                                                                                                                                                            | This works the same as if all buttons were pressed.                                                                                                                                                                                                                                                                                    |
|                                          | 20                                                                                                                                                                                                                                                                                                             | 20:1                                                                                                                                                                                                                                                                                                                                   |
|                                          | 12                                                                                                                                                                                                                                                                                                             | 12:1                                                                                                                                                                                                                                                                                                                                   |
|                                          | 8                                                                                                                                                                                                                                                                                                              | 8:1                                                                                                                                                                                                                                                                                                                                    |
| Balance                                  | 4                                                                                                                                                                                                                                                                                                              | 4:1                                                                                                                                                                                                                                                                                                                                    |
|                                          | D100:0W–D0:100W                                                                                                                                                                                                                                                                                                | The volume balance of the sound that passes through the compressor (W) and the unprocessed sound (D)                                                                                                                                                                                                                                   |

\* Pad compressor settings are made for individual pads. They cannot be made for individual strike locations (such as the head or rim).

## KIT COMP

Configures the compressor for the entire drum kit, on a kit-by-kit basis.

| Parameter                              | Value                                                                                                                                    | Explanation                                                                                                                                                                                                                                                                                                                                                                                                            |
|----------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| [F5] (Comp) button                     | OFF, ON                                                                                                                                  | Turns kit compressor on/off.                                                                                                                                                                                                                                                                                                                                                                                           |
| Kit Comp Type                          | This selects the kit compressor type.                                                                                                    |                                                                                                                                                                                                                                                                                                                                                                                                                        |
|                                        | STANDARD                                                                                                                                 | A dual-band compressor that's simple and easy to use.                                                                                                                                                                                                                                                                                                                                                                  |
|                                        | FETCOMP-76                                                                                                                               | This models a classic studio-use FET compressor.<br>* When you select FETCOMP-76, this effect may output a very loud sound, depending on how the parameters are set. Also, use caution when inputting very loud sounds into the FETCOMP-76 effect, as this may cause the output sound to distort or produce noise. If this happens, lower the Input Level or Output Level or take other measures to adjust the volume. |
| <b>When Kit Comp Type = “STANDARD”</b> |                                                                                                                                          |                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Template                               | SINGLE SOFT COMP, SINGLE HARD COMP, SINGLE LIMITER, SINGLE PARALLEL, 2 BAND SOFT COMP, 2 BAND HARD COMP, 2 BAND LIMITER, 2 BAND PARALLEL | Character of the compressor<br>* When you change this parameter, all parameters of the kit compressor change to optimal settings for your selection. You can then make further adjustments to these parameters as necessary. Depending on the settings of these parameters, the resulting effect might not match the Template setting.                                                                                 |
| Balance                                | D100:0W–D0:100W                                                                                                                          | The volume balance of the sound that passes through the compressor (W) and the unprocessed sound (D)                                                                                                                                                                                                                                                                                                                   |

| Parameter                                | Value                          | Explanation                                                                                                                                                                                                                                                                                                                            |
|------------------------------------------|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Split Freq                               | SINGLE, 10–16000 Hz            | Bandwidth of the compressor<br>If this is "SINGLE", the master compressor operates as a single-band compressor that is used only on the high band.                                                                                                                                                                                     |
| Hi Threshold *1                          | -60–0 dB                       | Adjusts the volume at which compression begins                                                                                                                                                                                                                                                                                         |
| Hi Gain *1                               | -60.0–+24.0dB                  | Output level of the compressor                                                                                                                                                                                                                                                                                                         |
| Hi Attack *1                             | 0.1–100ms                      | Time from when the volume goes up the threshold level until the compressor effect applies                                                                                                                                                                                                                                              |
| Hi Release *1                            | 10–1000ms                      | Time from when the volume falls below the threshold level until the compressor effect no longer applies                                                                                                                                                                                                                                |
| Hi Ratio *1                              | 1:1–INF:1                      | Compression ratio                                                                                                                                                                                                                                                                                                                      |
| Hi Knee *1                               | HARD, SOFT1–3                  | Attack of the sound at the moment compression is applied                                                                                                                                                                                                                                                                               |
| Lo Threshold *2                          | -60–0 dB                       | Adjusts the volume at which compression begins                                                                                                                                                                                                                                                                                         |
| Lo Gain *2                               | -60.0–+24.0dB                  | Output level of the compressor                                                                                                                                                                                                                                                                                                         |
| Lo Attack *2                             | 0.1–100ms                      | Time from when the volume goes up the threshold level until the compressor effect applies                                                                                                                                                                                                                                              |
| Lo Release *2                            | 10–1000ms                      | Time from when the volume falls below the threshold level until the compressor effect no longer applies                                                                                                                                                                                                                                |
| Lo Ratio *2                              | 1:1–INF:1                      | Compression ratio                                                                                                                                                                                                                                                                                                                      |
| Lo Knee *2                               | HARD, SOFT1–3                  | Attack of the sound at the moment compression is applied                                                                                                                                                                                                                                                                               |
| <b>When Kit Comp Type = "FETCOMP-76"</b> |                                |                                                                                                                                                                                                                                                                                                                                        |
| Template                                 | PRESENCE, SOFT, MID, HEAVY     | Character of the compressor<br>* When you change this parameter, all parameters of the kit compressor change to optimal settings for your selection. You can then make further adjustments to these parameters as necessary. Depending on the settings of these parameters, the resulting effect might not match the Template setting. |
| Compression                              | OFF, ON                        | If this is ON, the compression effect is applied.                                                                                                                                                                                                                                                                                      |
| Input Level                              | -INF, -30.0–+30.0dB            | Adjusts the input volume.                                                                                                                                                                                                                                                                                                              |
| Output Level                             | -INF, -54.0–+6.0dB             | Adjusts the output volume.                                                                                                                                                                                                                                                                                                             |
| Attack                                   | 0.0–7.0                        | Sets the time it takes for compression to start, once the audio input crosses the threshold.<br>A value of 0.0 is the longest time it takes for compression to be applied.                                                                                                                                                             |
| Release                                  | 0.0–7.0                        | Adjusts the time after the input signal volume falls below the threshold until compression stops.<br>A value of 0.0 is the longest time it takes for compression to be applied.                                                                                                                                                        |
| Ratio Mode                               | Adjusts the compression ratio. |                                                                                                                                                                                                                                                                                                                                        |
|                                          | ALL                            | This works the same as if all buttons were pressed.                                                                                                                                                                                                                                                                                    |
|                                          | 20                             | 20:1                                                                                                                                                                                                                                                                                                                                   |
|                                          | 12                             | 12:1                                                                                                                                                                                                                                                                                                                                   |
|                                          | 8                              | 8:1                                                                                                                                                                                                                                                                                                                                    |
|                                          | 4                              | 4:1                                                                                                                                                                                                                                                                                                                                    |
| Balance                                  | D100:0W–D0:100W                | The volume balance of the sound that passes through the compressor (W) and the unprocessed sound (D)                                                                                                                                                                                                                                   |

\*1: If Split Freq is set to something other than "SINGLE", the low band and high band can be set independently.

\*2 Only if Split Freq is set to 10 Hz or greater.

\* If the routing setting (p. 47) Master Out is "DIRECT", the kit compressor does not apply to the sound that is output from the MASTER OUT jacks.

## Meters shown in the KIT COMP screen

In the KIT COMP screen, the “input meter”, the “gain reduction meter”, and the “output meter” are displayed.

When Split Freq is “SINGLE” (single compressor)

### Input meter

The “input meter” shows the level (dB) being input to the master comp.

### Gain reduction meter

The “gain reduction meter” shows the change in level (dB) produced by the master comp.



### Output meter

The “output meter” shows the output level (dB) following the master comp.


When Split Freq is “10–16000 Hz” (2-band compressor)

### Input meter

The “input meter” shows the level (dB) being input to the master comp. This is shown individually for the low and high bands.

### Output meter

The “output meter” shows the output level (dB) following the master comp.



### Gain reduction meter

The “gain reduction meter” shows the change in level (dB) produced by the master comp. This is shown individually for the low and high bands.

Adjust the kit compressor’s “Gain” so that the output meter does not exceed 0 dB (i.e., so that it does not clip).

## KIT EQ

Configures the equalizer for the entire drum kit, on a kit-by-kit basis.

| Parameter              | Value                                                        | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|------------------------|--------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| [F5] (EQ) button       | OFF, ON                                                      | Turns the EQ that’s applied to the entire drum kit on/off.<br><br>Switches the EQ mode.                                                                                                                                                                                                                                                                                                                                                                   |
| [F6] (Mid/Side) button | OFF, ON                                                      | <b>OFF (NORMAL):</b> Adjusts the input sound so that the tonal character is the same on the left and right sides.<br><b>ON (MID/SIDE):</b> Adjusts the input sounds at the center of the stereo field (MID) and the sounds at the left-right sides of the stereo field (SIDE) separately. The respective Q, Freq and Gain setting values are common for the MID side of the NORMAL and MID/SIDE EQ modes.<br><br><b>NORMAL</b><br><br><b>MID/SIDE</b><br> |
| Type                   | SHELV (Shelving),<br>PEAK (MID1 and MID2: fixed to “PEAK”)   | Type of equalizer                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Q                      | 0.5–16.0 (only when Type is set to “PEAK”)                   | Width of the frequency range<br>Set a higher value for Q to narrow the range to be affected.                                                                                                                                                                                                                                                                                                                                                              |
| Freq                   | 20Hz–1kHz (LOW)<br>20Hz–16kHz (MID1, MID2)<br>1–16kHz (HIGH) | Center frequency                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Gain                   | -12–+12dB                                                    | Amount of boost/cut                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Input Gain             | -12–+12dB                                                    | The volume of the input sound.<br><br>When the [F6] (Mid/Side) button is “OFF” (NORMAL), this is “Input Gain”; and when the button is “ON” (MID/SIDE), this is “Mid Input Gain” or “Side Input Gain”, depending on which side is selected.                                                                                                                                                                                                                |


## MIXER

Here's how to set the volume, pan and other effects for each pad or drum kit.

You can also adjust how the volume responds to the striking force.

### 1. Press the [MIXER] button.

The MIXER screen appears.



### 2. Press the function buttons to access the respective settings screens.

### 3. Select the pad that you want to edit.

### 4. Use cursor buttons to select a parameter, and use the [-] [+] buttons or the dial to edit the value.

### 5. Press the [KIT] button to return to the KIT screen.

| Parameter             | Value               | Explanation                                                                                                                                                                                                                                                                               |
|-----------------------|---------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>VOLUME/PAN tab</b> |                     |                                                                                                                                                                                                                                                                                           |
| Pad Volume            | -INF, -60.0--+6.0dB | Volume of each pad                                                                                                                                                                                                                                                                        |
| Pan                   | L30-R30             | Stereo position of each pad                                                                                                                                                                                                                                                               |
| <b>MIN VOLUME tab</b> |                     |                                                                                                                                                                                                                                                                                           |
| Minimum Volume        | 0-15                | Minimum volume of each pad<br>This lets you increase the volume of the softest hits while preserving the volume of the strongest hits. This can make it easier to hear ghost notes on the snare or legato notes on the ride cymbal.                                                       |
| <b>KIT VOLUME tab</b> |                     |                                                                                                                                                                                                                                                                                           |
| Kit Volume *1         |                     | Drum kit volume                                                                                                                                                                                                                                                                           |
| Closed-Pedal Volume   |                     | Pedal hi-hat volume                                                                                                                                                                                                                                                                       |
| XStick Volume         | -INF, -60.0--+6.0dB | Cross-stick volume                                                                                                                                                                                                                                                                        |
| Snare Buzz Volume     |                     | Snare resonance volume                                                                                                                                                                                                                                                                    |
| Strainer Throw Volume |                     | Volume of the sound that's heard when the strainer lever is raised or lowered                                                                                                                                                                                                             |
| HH Open/Close Balance | -5--+5              | Balance between open and close volume<br>Lower values decrease the volume of the hi-hat when played while open, relative to the volume when played while closed. Higher values increase the volume of the hi-hat when played while open, relative to the volume when played while closed. |

\*1 You can also change the Kit Volume from KIT OTHERS (p. 28).


#### MEMO

If you press the [F6] (H&R) button to turn it "ON", you can simultaneously make settings for the head area and rim area, etc.

## AMBIENCE

### 1. Press the [AMBIENCE] button.

The AMBIENCE screen appears.



#### MEMO

On the AMBIENCE screen, you can easily configure how much of the ambience effect is applied from each pad, turn the ambience on/off for each and adjust the volume. You can edit these settings in detail by pressing a function button to access the respective settings screen.

### 2. Press the function buttons to access the respective settings screens.

### 3. Edit the ambience settings.

### 4. On the respective screens, switch the ambience on/off.

### 5. Press the [KIT] button to return to the KIT screen.

#### MEMO

- If you press the [F5] (H&R) button to turn it "ON", you can simultaneously make settings for the head area and rim area, etc.
- When you press the [F6] (AmbOnly) button to turn it "ON", you can temporarily hear just the ambience sound from the master outputs and headphones (only when MASTER DIRECT is "NORMAL" for the master outputs).

## OVERHEAD

- \* Use caution when inputting very loud sounds into the OVERHEAD effect, as this may cause the output sound to distort or produce noise. If this happens, lower the volume of signal sent from the pads to OVERHEAD, or use FILTER, PRE TRANSIENT, PRE COMP and so forth to adjust the volume.

| Parameter           | Value                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  | Explanation                                                                                                                                                     |
|---------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>SEND tab</b>     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                                                                                                                                                 |
| Overhead Send Level | -INF, -60.0—+6.0dB                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | Depth of overhead for each pad                                                                                                                                  |
| [F5] (OH) button    | OFF, ON                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Turns the overhead effect on/off.                                                                                                                               |
| [F6] (H&R) button   | OFF, ON                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Specifies whether head and rim of instruments are selected as a set (ON) or independently (OFF).                                                                |
| <b>FILTER tab</b>   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |                                                                                                                                                                 |
| Pre Filter Type     | Overhead input filter type<br>The sound sent to the overheads can be passed through a filter. There are two filters connected in series, one in the previous stage and one in the following stage in the signal chain. The selectable settings are different for each.<br>You can choose from one through six. By using a filter, you can input the kick, snare, toms, and cymbals into the overhead mics with the low-frequency and high-frequency regions adjusted individually for each instrument. |                                                                                                                                                                 |
|                     | Settings for the filter in the previous stage                                                                                                                                                                                                                                                                                                                                                                                                                                                          | THRU<br>Sends the unaltered input sound through the filter in the following stage, or to the overhead.                                                          |
|                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | HICUT<br>Cuts the frequency region above the base frequency and sends the sound to the filter in the following stage. The Q can be adjusted.                    |
|                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | LOCUT<br>Cuts the frequency region below the base frequency and sends the sound to the filter in the following stage. The Q can be adjusted.                    |
|                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        | PKG<br>Boosts or cuts the frequency region around the base frequency, and sends the sound to the filter in the following stage. The Q and gain can be adjusted. |
| Pre Filter Freq     | 20–16kHz                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Center frequency                                                                                                                                                |
| Pre Filter Q        | 0.5–16.0                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               | Width of the frequency range<br>Set a higher value for Q to narrow the range to be affected.                                                                    |
| Pre Filter Gain *1  | -40.0—+15.0dB                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          | Amount of boost/cut                                                                                                                                             |

| Parameter               | Value                                                                          | Explanation                                                                                                                                                                                                                                                                                                                                 |
|-------------------------|--------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Post Filter Type        | Settings for the filter in the following stage                                 | THRU<br>Sends the unaltered input sound through the filter in the following stage, or to the overhead.                                                                                                                                                                                                                                      |
|                         |                                                                                | LPF<br>Cuts the frequency region above the base frequency, and sends the sound to the overheads.                                                                                                                                                                                                                                            |
|                         |                                                                                | HPF<br>Cuts the frequency region below the base frequency and sends the sound to the overheads.                                                                                                                                                                                                                                             |
|                         |                                                                                | LSF<br>Boosts or attenuates the frequency region below the cutoff frequency and sends the sound to the overheads.                                                                                                                                                                                                                           |
|                         |                                                                                | HSF<br>Boosts or attenuates the frequency region above the cutoff frequency and sends the sound to the overheads.                                                                                                                                                                                                                           |
| Post Filter Freq        | 20–16kHz                                                                       | Center frequency                                                                                                                                                                                                                                                                                                                            |
| Post Filter Gain *2     | -40.0–+15.0dB                                                                  | Amount of boost/cut                                                                                                                                                                                                                                                                                                                         |
| [F5] (OH) button        | OFF, ON                                                                        | Turns the overhead effect on/off.                                                                                                                                                                                                                                                                                                           |
| [F6] (OHOnly) button    | OFF, ON                                                                        | You can temporarily listen to the overhead sound only.                                                                                                                                                                                                                                                                                      |
| ASSIGN tab              |                                                                                |                                                                                                                                                                                                                                                                                                                                             |
| Overhead Filter Assign  | BYPASS, FILTER 1–6                                                             | Overhead input filter selection for each pad                                                                                                                                                                                                                                                                                                |
|                         |                                                                                | BYPASS<br>The input filter is not used; the sound is sent directly to the overheads.                                                                                                                                                                                                                                                        |
|                         |                                                                                | 1–6<br>The sound is sent to the specified input filter.                                                                                                                                                                                                                                                                                     |
| [F5] (OH) button        | OFF, ON                                                                        | Turns the overhead effect on/off.                                                                                                                                                                                                                                                                                                           |
| [F6] (H&R) button       | OFF, ON                                                                        | Specifies whether head and rim of instruments are selected as a set (ON) or independently (OFF).                                                                                                                                                                                                                                            |
| OVERHEAD tab            |                                                                                |                                                                                                                                                                                                                                                                                                                                             |
| PRE TRANSIENT           |                                                                                |                                                                                                                                                                                                                                                                                                                                             |
| Transient Switch        | OFF, ON                                                                        | Turns the transient effect on/off.                                                                                                                                                                                                                                                                                                          |
| Attack                  | -50–0                                                                          | Adjusts the attack of the overhead input sound.                                                                                                                                                                                                                                                                                             |
| Gain                    | -INF, -60.0–+12.0dB                                                            | Volume following transient adjustment                                                                                                                                                                                                                                                                                                       |
| [F5] (Transient) button | OFF, ON                                                                        | Turns the transient effect on/off.                                                                                                                                                                                                                                                                                                          |
| PRE COMP                |                                                                                |                                                                                                                                                                                                                                                                                                                                             |
| Comp Switch             | OFF, ON                                                                        | Turns the pre limiter on/off.                                                                                                                                                                                                                                                                                                               |
| Threshold               | -60–0 dB                                                                       | Adjusts the volume at which compression begins                                                                                                                                                                                                                                                                                              |
| Gain                    | -24.0–+24.0dB                                                                  | Output volume of the pre limiter                                                                                                                                                                                                                                                                                                            |
| Ratio                   | 1:1–INF:1                                                                      | Compression ratio                                                                                                                                                                                                                                                                                                                           |
| Knee                    | HARD, SOFT1–3                                                                  | Attack of the sound at the moment compression is applied                                                                                                                                                                                                                                                                                    |
| Attack                  | 0.1–100ms                                                                      | Time from when the volume goes up the threshold level until the compressor effect applies                                                                                                                                                                                                                                                   |
| Release                 | 10–1000ms                                                                      | Time from when the volume falls below the threshold level until the compressor effect no longer applies                                                                                                                                                                                                                                     |
| [F6] (Comp) button      | OFF, ON                                                                        | Turns the pre limiter on/off.                                                                                                                                                                                                                                                                                                               |
| MIC                     |                                                                                |                                                                                                                                                                                                                                                                                                                                             |
| Template                | 1:NATURAL, 2:SOLID, 3:CHIC, 4:CLEAR, 5:WARM, 6:DRY, 7:DEEP, 8:NARROW, 9:PUNCHY | Overhead settings templates<br>* When you edit this parameter, all settings for overhead (other than Overhead Level) are changed to their optimal values. You can then make further adjustments to these parameters as necessary. Depending on the settings of these parameters, the resulting effect might not match the Mic Type setting. |
| Mic Type                | NATURAL, SOLID, CHIC, WARM, CLEAR, DRY, NARROW, PUNCHY                         | Type of mic                                                                                                                                                                                                                                                                                                                                 |
| Time                    | -64–0                                                                          | Overhead reverberation time                                                                                                                                                                                                                                                                                                                 |
| Distance                | 0–6                                                                            | Distance between the mics and the performer                                                                                                                                                                                                                                                                                                 |
| Output Width            | DEFAULT, WIDE+1–WIDE+6                                                         | Sense of space for the overhead sound                                                                                                                                                                                                                                                                                                       |
| Overhead Level          | -INF, -60.0–+12.0dB                                                            | Volume of overhead                                                                                                                                                                                                                                                                                                                          |
| [F5] (OH) button        | OFF, ON                                                                        | Turns the overhead effect on/off.                                                                                                                                                                                                                                                                                                           |
| [F6] (OHOnly) button    | OFF, ON                                                                        | You can temporarily listen to the overhead sound only.                                                                                                                                                                                                                                                                                      |
| POST EQ                 |                                                                                |                                                                                                                                                                                                                                                                                                                                             |
| [F5] (EQ) button        | OFF, ON                                                                        | Switches the EQ on/off.                                                                                                                                                                                                                                                                                                                     |

| Parameter              | Value                                                 | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                        |
|------------------------|-------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| [F6] (Mid/Side) button | OFF, ON                                               | Switches the EQ mode.<br><b>OFF (NORMAL):</b> Adjusts the input sound so that the tonal character is the same on the left and right sides.<br><b>ON (MID/SIDE):</b> Adjusts the input sounds at the center of the stereo field (MID) and the sounds at the left-right sides of the stereo field (SIDE) separately. The respective Q, Freq and Gain setting values are common for the MID side of the NORMAL and MID/SIDE EQ modes. |
| Q                      | 0.5–16.0 (only when Type is set to MID)               | Width of the frequency range<br>Set a higher value for Q to narrow the range to be affected.                                                                                                                                                                                                                                                                                                                                       |
| Freq                   | 20Hz–1kHz (LOW)<br>20Hz–16kHz (MID)<br>1–16kHz (HIGH) | Center frequency                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Gain                   | -40–+15dB                                             | Amount of boost/cut                                                                                                                                                                                                                                                                                                                                                                                                                |
| POST COMP              |                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Comp Switch            | OFF, ON                                               | Turns post comp on/off.                                                                                                                                                                                                                                                                                                                                                                                                            |
| Threshold              | -60–0 dB                                              | Adjusts the volume at which compression begins                                                                                                                                                                                                                                                                                                                                                                                     |
| Gain                   | -24.0–+24.0dB                                         | Output volume of the post comp                                                                                                                                                                                                                                                                                                                                                                                                     |
| Ratio                  | 1:1–INF:1                                             | Compression ratio                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Knee                   | HARD, SOFT1–3                                         | Attack of the sound at the moment compression is applied                                                                                                                                                                                                                                                                                                                                                                           |
| Attack                 | 0.1–100ms                                             | Time from when the volume goes up the threshold level until the compressor effect applies                                                                                                                                                                                                                                                                                                                                          |
| Release                | 10–1000ms                                             | Time from when the volume falls below the threshold level until the compressor effect no longer applies                                                                                                                                                                                                                                                                                                                            |
| [F5] (OH) button       | OFF, ON                                               | Turns the overhead effect on/off.                                                                                                                                                                                                                                                                                                                                                                                                  |
| [F6] (Comp) button     | OFF, ON                                               | Turns post comp on/off.                                                                                                                                                                                                                                                                                                                                                                                                            |
| BUS SEND               |                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| OH Send Bus Select     | OFF, BUS A–D                                          | Configures the bus to which the overhead sound is sent.                                                                                                                                                                                                                                                                                                                                                                            |
| OH Send Level          | -INF, -60.0–+6.0dB                                    | Amount of overhead sound signal to send to the bus                                                                                                                                                                                                                                                                                                                                                                                 |
| [F5] (OH) button       | OFF, ON                                               | Turns the overhead effect on/off.                                                                                                                                                                                                                                                                                                                                                                                                  |
| [F6] (OHOnly) button   | OFF, ON                                               | You can temporarily listen to the overhead sound only.                                                                                                                                                                                                                                                                                                                                                                             |

\*1 Enabled when Pre Filter Type is "PKG".

\*2 Enabled when Post Filter Type is "LSF" or "HSF".

## ROOM

\* Use caution when inputting very loud sounds into the ROOM effect, as this may cause the output sound to distort or produce noise. If this happens, lower the volume of signal sent from the pads to ROOM, or use FILTER, PRE TRANSIENT, PRE COMP and so forth to adjust the volume.

| Parameter               | Value                                                                                                                                                        | Explanation                                                                                             |
|-------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|
| <b>SEND tab</b>         |                                                                                                                                                              |                                                                                                         |
| Room Send Level         | -INF, -60.0–+6.0dB                                                                                                                                           | Amount of room applied to each pad                                                                      |
| [F4] (H&R) button       | OFF, ON                                                                                                                                                      | Specifies whether head and rim of instruments are selected as a set (ON) or independently (OFF).        |
| [F5] (Room) button      | OFF, ON                                                                                                                                                      | Turns the room effect on/off.                                                                           |
| [F6] (RoomOnly) button  | OFF, ON                                                                                                                                                      | You can temporarily listen to the room sound only.                                                      |
| <b>ROOM tab</b>         |                                                                                                                                                              |                                                                                                         |
| <b>PRE EQ</b>           |                                                                                                                                                              |                                                                                                         |
| Low Cut                 | OFF, 20–1kHz                                                                                                                                                 | Cuts the frequency region below the specified frequency (low cut).                                      |
| Type                    | SHELV (Shelving),<br>PEAK (MID1 and MID2: fixed to "PEAK")                                                                                                   | Type of equalizer                                                                                       |
| Q                       | 0.5–16.0 (only when Type is set to "PEAK")                                                                                                                   | Width of the frequency range<br>Set a higher value for Q to narrow the range to be affected.            |
| Freq                    | 20Hz–1kHz (LOW)<br>20Hz–16kHz (MID1, MID2)<br>1–16kHz (HIGH)                                                                                                 | Center frequency                                                                                        |
| Gain                    | -40–+15dB                                                                                                                                                    | Amount of boost/cut                                                                                     |
| [F4] (EQ) button        | OFF, ON                                                                                                                                                      | Switches the EQ on/off.                                                                                 |
| [F5] (Room) button      | OFF, ON                                                                                                                                                      | Turns the room effect on/off.                                                                           |
| [F6] (RoomOnly) button  | OFF, ON                                                                                                                                                      | You can temporarily listen to the room sound only.                                                      |
| <b>PRE TRANSIENT</b>    |                                                                                                                                                              |                                                                                                         |
| Transient Switch        | OFF, ON                                                                                                                                                      | Turns the transient effect on/off.                                                                      |
| Attack                  | -50–0                                                                                                                                                        | Adjusts the attack of the room input sound.                                                             |
| Gain                    | -INF, -60.0–+12.0dB                                                                                                                                          | Volume following transient adjustment                                                                   |
| [F3] (Transient) button | OFF, ON                                                                                                                                                      | Turns the transient effect on/off.                                                                      |
| <b>PRE COMP</b>         |                                                                                                                                                              |                                                                                                         |
| Comp Sw Switch          | OFF, ON                                                                                                                                                      | Turns the pre limiter on/off.                                                                           |
| Threshold               | -60–0 dB                                                                                                                                                     | Adjusts the volume at which compression begins                                                          |
| Gain                    | -24.0–+24.0dB                                                                                                                                                | Output volume of the pre limiter                                                                        |
| Ratio                   | 1:1–INF:1                                                                                                                                                    | Compression ratio                                                                                       |
| Knee                    | HARD, SOFT1–3                                                                                                                                                | Attack of the sound at the moment compression is applied                                                |
| Attack                  | 0.1–100ms                                                                                                                                                    | Time from when the volume goes up the threshold level until the compressor effect applies               |
| Release                 | 10–1000ms                                                                                                                                                    | Time from when the volume falls below the threshold level until the compressor effect no longer applies |
| [F4] (Comp) button      | OFF, ON                                                                                                                                                      | Turns the pre limiter on/off.                                                                           |
| [F5] (Room) button      | OFF, ON                                                                                                                                                      | Turns the room effect on/off.                                                                           |
| [F6] (RoomOnly) button  | OFF, ON                                                                                                                                                      | You can temporarily listen to the room sound only.                                                      |
| <b>ROOM</b>             |                                                                                                                                                              |                                                                                                         |
| Type                    | REALISTIC, SYNTHETIC                                                                                                                                         | Type of room                                                                                            |
| Output Width            | DEFAULT–WIDE +6                                                                                                                                              | Spaciousness of room sound                                                                              |
| Place *1                | ISOLATION ROOM, WOOD STUDIO, MODERN STUDIO, LIVE HOUSE, SMALL STAGE, SMALL HALL, HALL STAGE, HALL AUDIENCE, CATHEDRAL, STADIUM STAGE, STADIUM AUDIENCE, CAVE | Type of room reverberation                                                                              |
| Distance *1             | 0–6                                                                                                                                                          | Sense of distance for the room's reverberation                                                          |
| Time *1                 | -64–0                                                                                                                                                        | Reverberation time of the room                                                                          |
| Input Gain *2           | -48–+16dB                                                                                                                                                    | Adjusts the volume of signal input to reverb.                                                           |
| Character *2            | Air, Dimensional, Fog, Roomy, Chamber, Solid, Light, Session, Metal                                                                                          | Type of room reverberation                                                                              |

| Parameter              | Value                                                 | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                        |
|------------------------|-------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Time *2                | 0.1–1.5sec                                            | Reverberation time of the room                                                                                                                                                                                                                                                                                                                                                                                                     |
| Attack Time *2         | 1–10                                                  | Adjusts the attack time (the time it takes for the sound to rise in volume) for the reverb sound.                                                                                                                                                                                                                                                                                                                                  |
| HF Damp Freq *2        | 1000–8000Hz                                           | Adjusts the frequency above which the high-frequency portion of the reverb sound is cut.                                                                                                                                                                                                                                                                                                                                           |
| HF Damp *2             | 0.01–1.00                                             | Adjusts the high-frequency portion of the reverb.                                                                                                                                                                                                                                                                                                                                                                                  |
| Pre Delay *2           | 0m–50msec                                             | Adjusts the delay time from the direct sound until the reverb sound is heard.                                                                                                                                                                                                                                                                                                                                                      |
| Spread *2              | 0.00–1.50                                             | Spread of the reverb sound                                                                                                                                                                                                                                                                                                                                                                                                         |
| Gate Switch *2         | OFF, ON                                               | Turns the gate reverb effect on/off.                                                                                                                                                                                                                                                                                                                                                                                               |
| Gate Threshold *2      | -60–+6dB                                              | Volume at which the gate reverb is triggered                                                                                                                                                                                                                                                                                                                                                                                       |
| Gate Hold Time *2      | 0–500msec                                             | Adjusts the time from when the gate reverb starts being heard until the reverb sound is cut off.                                                                                                                                                                                                                                                                                                                                   |
| Gate Release Time *2   | 10–500msec                                            | Adjusts the decay length of the gate reverb sound.                                                                                                                                                                                                                                                                                                                                                                                 |
| [F5] (Room) button     | OFF, ON                                               | Turns the room effect on/off.                                                                                                                                                                                                                                                                                                                                                                                                      |
| [F6] (RoomOnly) button | OFF, ON                                               | You can temporarily listen to the room sound only.                                                                                                                                                                                                                                                                                                                                                                                 |
| POST EQ                |                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Q                      | 0.5–16.0 (only when Type is set to MID)               | Width of the frequency range<br>Set a higher value for Q to narrow the range to be affected.                                                                                                                                                                                                                                                                                                                                       |
| Freq                   | 20Hz–1kHz (LOW)<br>20Hz–16kHz (MID)<br>1–16kHz (HIGH) | Center frequency                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Gain                   | -40–+15dB                                             | Amount of boost/cut                                                                                                                                                                                                                                                                                                                                                                                                                |
| [F3] (Room) button     | OFF, ON                                               | Turns the room effect on/off.                                                                                                                                                                                                                                                                                                                                                                                                      |
| [F4] (EQ) button       | OFF, ON                                               | Switches the EQ on/off.                                                                                                                                                                                                                                                                                                                                                                                                            |
| [F5] (Mid/Side) button | OFF, ON                                               | Switches the EQ mode.<br><b>OFF (NORMAL):</b> Adjusts the input sound so that the tonal character is the same on the left and right sides.<br><b>ON (MID/SIDE):</b> Adjusts the input sounds at the center of the stereo field (MID) and the sounds at the left-right sides of the stereo field (SIDE) separately. The respective Q, Freq and Gain setting values are common for the NORMAL and MID side of the MID/SIDE EQ modes. |
| [F6] (RoomOnly) button | OFF, ON                                               | You can temporarily listen to the room sound only.                                                                                                                                                                                                                                                                                                                                                                                 |
| POST COMP              |                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Comp Switch            | OFF, ON                                               | Turns post comp on/off.                                                                                                                                                                                                                                                                                                                                                                                                            |
| Threshold              | -60–0 dB                                              | Adjusts the volume at which compression begins                                                                                                                                                                                                                                                                                                                                                                                     |
| Gain                   | -24.0–+24.0dB                                         | Output volume of the post comp                                                                                                                                                                                                                                                                                                                                                                                                     |
| Ratio                  | 1:1–INF:1                                             | Compression ratio                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Knee                   | HARD, SOFT1–3                                         | Attack of the sound at the moment compression is applied                                                                                                                                                                                                                                                                                                                                                                           |
| Attack                 | 0.1–100ms                                             | Time from when the volume goes up the threshold level until the compressor effect applies                                                                                                                                                                                                                                                                                                                                          |
| Release                | 10–1000ms                                             | Time from when the volume falls below the threshold level until the compressor effect no longer applies                                                                                                                                                                                                                                                                                                                            |
| [F5] (Room) button     | OFF, ON                                               | Turns the room effect on/off.                                                                                                                                                                                                                                                                                                                                                                                                      |
| [F6] (Comp) button     | OFF, ON                                               | Turns post comp on/off.                                                                                                                                                                                                                                                                                                                                                                                                            |
| [F6] (RoomOnly) button | OFF, ON                                               | You can temporarily listen to the room sound only.                                                                                                                                                                                                                                                                                                                                                                                 |
| BUS SEND               |                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Room Send Bus Select   | OFF, BUS A–D                                          | Selects the bus to which the room sound is sent.                                                                                                                                                                                                                                                                                                                                                                                   |
| Room Send Level        | -INF, -60.0–+6.0dB                                    | Amount of room sound sent to bus                                                                                                                                                                                                                                                                                                                                                                                                   |
| [F5] (Room) button     | OFF, ON                                               | Turns the room effect on/off.                                                                                                                                                                                                                                                                                                                                                                                                      |
| [F6] (RoomOnly) button | OFF, ON                                               | You can temporarily listen to the room sound only.                                                                                                                                                                                                                                                                                                                                                                                 |

\*1 Enabled when Type is "REALISTIC".

\*2 Enabled when Type is "SYNTHETIC".

## REVERB

### Common parameters

| Parameter               | Value                                                                                    | Explanation                                                                                             |
|-------------------------|------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------|
| <b>SEND tab</b>         |                                                                                          |                                                                                                         |
| Reverb Send Level       | -INF, -60.0--+6.0dB                                                                      | Amount of reverb applied to each pad                                                                    |
| [F4] (H&R) button       | OFF, ON                                                                                  | Specifies whether head and rim of instruments are selected as a set (ON) or independently (OFF).        |
| [F5] (Reverb) button    | OFF, ON                                                                                  | Turns reverb on/off.                                                                                    |
| [F6] (RevOnly) button   | OFF, ON                                                                                  | You can temporarily listen to the reverb sound only.                                                    |
| <b>REVERB tab</b>       |                                                                                          |                                                                                                         |
| <b>PRE TRANSIENT</b>    |                                                                                          |                                                                                                         |
| Transient Switch        | OFF, ON                                                                                  | Turns the transient effect on/off.                                                                      |
| Attack                  | -50-0                                                                                    | Adjusts the attack of the reverb input sound.                                                           |
| Gain                    | -INF, -60.0--+12.0dB                                                                     | Volume following transient adjustment                                                                   |
| [F4] (Transient) button | OFF, ON                                                                                  | Turns the transient effect on/off.                                                                      |
| [F5] (Reverb) button    | OFF, ON                                                                                  | Turns reverb on/off.                                                                                    |
| [F6] (RevOnly) button   | OFF, ON                                                                                  | You can temporarily listen to the reverb sound only.                                                    |
| <b>REVERB</b>           |                                                                                          |                                                                                                         |
| Reverb Type             | TD-50 REVERB, TD-50 ROOM, WARM HALL, SRV-2000, SRV-2000(NLR), SIMPLE REVERB, LONG REVERB | Type of room reverberation                                                                              |
| Reverb Level            | -INF, -60.0--+12.0dB                                                                     | Reverb volume                                                                                           |
| [F5] (Reverb) button    | OFF, ON                                                                                  | Turns reverb on/off.                                                                                    |
| [F6] (RevOnly) button   | OFF, ON                                                                                  | You can temporarily listen to the reverb sound only.                                                    |
| <b>POST COMP</b>        |                                                                                          |                                                                                                         |
| Comp Switch             | OFF, ON                                                                                  | Turns post comp on/off.                                                                                 |
| Threshold               | -60-0 dB                                                                                 | Adjusts the volume at which compression begins                                                          |
| Gain                    | -24.0--+24.0dB                                                                           | Output volume of the post comp                                                                          |
| Ratio                   | 1:1-INF:1                                                                                | Compression ratio                                                                                       |
| Knee                    | HARD, SOFT1-3                                                                            | Attack of the sound at the moment compression is applied                                                |
| Attack                  | 0.1-100ms                                                                                | Time from when the volume goes up the threshold level until the compressor effect applies               |
| Release                 | 10-1000ms                                                                                | Time from when the volume falls below the threshold level until the compressor effect no longer applies |
| [F4] (Reverb) button    | OFF, ON                                                                                  | Turns reverb on/off.                                                                                    |
| [F5] (Comp) button      | OFF, ON                                                                                  | Turns post comp on/off.                                                                                 |
| [F6] (RevOnly) button   | OFF, ON                                                                                  | You can temporarily listen to the reverb sound only.                                                    |
| <b>BUS SEND</b>         |                                                                                          |                                                                                                         |
| Reverb Send Bus Select  | OFF, BUS A-D                                                                             | Selects the bus to which the reverb sound is sent.                                                      |
| Reverb Send Level       | -INF, -60.0--+6.0dB                                                                      | Amount of reverb sound sent to bus                                                                      |
| [F5] (Reverb) button    | OFF, ON                                                                                  | Turns reverb on/off.                                                                                    |
| [F6] (RevOnly) button   | OFF, ON                                                                                  | You can temporarily listen to the reverb sound only.                                                    |

## Specific parameters

### TD-50 REVERB

| Parameter   | Value                             | Explanation                                                                                                                                                                     |
|-------------|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Reverb Type | ROOM1, ROOM2, HALL1, HALL2, PLATE | Type of reverb                                                                                                                                                                  |
| Pre Delay   | 0–100msec                         | Adjusts the delay time from the direct sound until the reverb sound is heard.                                                                                                   |
| Time        | 0.1–10.0sec                       | Time length of reverberation                                                                                                                                                    |
| Density     | 0–127                             | Density of reverb sound                                                                                                                                                         |
| Diffusion   | 0–127                             | Change in the density of the reverb sound over time<br>The higher the value, the denser the sound becomes as time elapses (The effect is more obvious for longer reverb times). |
| LF Damp     | 0–100                             | Adjusts the low-frequency portion of the reverb.                                                                                                                                |
| HF Damp     | 0–100                             | Adjusts the high-frequency portion of the reverb.                                                                                                                               |
| Spread      | 0–127                             | Spread of the reverb sound                                                                                                                                                      |
| Tone        | 0–127                             | Tonal character of reverb sound                                                                                                                                                 |

### TD-50 ROOM

| Parameter    | Value                                                                                                                                                                                                                                                 | Explanation                         |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------|
| Type         | BEACH, LIVING ROOM, BATH ROOM, STUDIO, GARAGE, LOCKER ROOM, THEATER, CAVE, GYMNASIUM, DOME STADIUM, BOOTH A, BOOTH B, STUDIO A, STUDIO B, BASEMENT, JAZZ CLUB, ROCK CLUB, BALLROOM, GATE, CONCERT HALL, SPORTS ARENA, EXPO HALL, BOTTLE, CITY, SPIRAL | Type of the room                    |
| Room Size    | TINY, SMALL, MEDIUM, LARGE, HUGE                                                                                                                                                                                                                      | Size of the room                    |
| Room Shape   | 0–100                                                                                                                                                                                                                                                 | Room shape and reverberation length |
| Wall Type    | CURTAIN, CLOTH, WOOD, PLASTER, CONCRETE, GLASS                                                                                                                                                                                                        | Wall material                       |
| Mic Position | NEXT DOOR, LOW FLOOR, LOW, MID LOW, MID, MID HIGH, HIGH, CEILING A, CEILING B                                                                                                                                                                         | Tonal change caused by mic position |

### WARM HALL

| Parameter     | Value              | Explanation                                                                              |
|---------------|--------------------|------------------------------------------------------------------------------------------|
| Pre Delay     | 0.0–100.0msec      | Adjusts the delay time from when the direct sound plays until the reverb sound is heard. |
| Time          | 0.3–30.0sec        | Adjusts the decay length of the reverb sound.                                            |
| Pre LPF       | 16–15000Hz, BYPASS | Frequency below which to cut the high-frequency portion of the sound entering the reverb |
| Pre HPF       | BYPASS, 16–15000Hz | Frequency below which to cut the low-frequency portion of the sound entering the reverb  |
| PreLoop LPF   | 16–15000Hz, BYPASS | Frequency above which to cut the high-frequency portion of the extended reverberation    |
| Diffusion     | 0–127              | Adjusts the change in the density of the reverb over time.                               |
| HF Damp Freq  | 1000–8000Hz        | Adjusts the frequency above which the high-frequency portion of the reverb sound is cut. |
| HF Damp Ratio | 0.1–1.0            | Adjusts the amount by which to attenuate the high-frequency portion of the reverb.       |

## SRV-2000

| Parameter   | Value                                                                        | Explanation                                                                                                      |
|-------------|------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|
| Selection   | R0.3, R1.0, R7.0, R15, R22, R26, R32, R37, H15, H22, H26, H32, H37, P-B, P-A | Selects the type of reverb offered by the Roland SRV-2000 digital reverb.                                        |
|             |                                                                              | <b>R37–R0.3</b> Room reverb.<br>Higher values increase the size of the room.                                     |
|             |                                                                              | <b>H37–H15</b> Hall reverb.<br>Higher values increase the size of the concert hall.                              |
|             |                                                                              | <b>P-B</b> Plate reverb.<br>A more flamboyant reverb sound than P-A.                                             |
|             |                                                                              | <b>P-A</b> Plate reverb.                                                                                         |
| Pre Delay   | 0–160msec                                                                    | Adjusts the delay time from when the direct sound plays until the reverb sound is heard.                         |
| Time        | 0.1–99.0sec                                                                  | Adjusts the decay length of the reverb sound.                                                                    |
| HF Damp     | 0.05–1.00                                                                    | Adjusts the high-frequency portion of the reverb.                                                                |
| Density     | 0–9                                                                          | Adjusts the density of the late reverberation.                                                                   |
| Attack Gain | 0–9                                                                          | Adjusts the gain of the early reflections.                                                                       |
| Attack Time | 0–9                                                                          | Adjusts the time of the early reflections.                                                                       |
| ER Density  | 0–9                                                                          | Adjusts the density of the early reflections.                                                                    |
| ER Level    | 0–99                                                                         | Adjusts the volume of the early reflections.                                                                     |
| EQ Low Freq | 0.04k–1.00kHz                                                                | Frequency of the low range.                                                                                      |
| EQ Low Gain | –24–+12dB                                                                    | Gain of the low range.                                                                                           |
| EQ Mid Freq | 0.25–9.99kHz                                                                 | Frequency of the middle range.                                                                                   |
| EQ Mid Gain | –24–+12dB                                                                    | Gain of the middle range.                                                                                        |
| EQ Mid Q    | 0.2–9.0                                                                      | Width of the middle range.<br>Set a higher value for Q to narrow the range to be affected.                       |
| EQ Hi Freq  | 0.80–9.99kHz                                                                 | Frequency of the high range.                                                                                     |
| EQ Hi Gain  | –24–+12dB                                                                    | Gain of the high range                                                                                           |
| EQ Hi Q     | 0.2–9.0                                                                      | Specifies the width of the high-frequency range.<br>Set a higher value for Q to narrow the range to be affected. |

## SRV-2000(NLR)

| Parameter   | Value         | Explanation                                                                                                      |
|-------------|---------------|------------------------------------------------------------------------------------------------------------------|
| Pre Delay   | 0–120msec     | Adjusts the delay time from when the direct sound plays until the reverb sound is heard.                         |
| Reverb Time | –0.9–+99.0sec | Adjusts the decay length of the reverb sound.                                                                    |
| Gate Time   | 10–450msec    | Adjusts the time from when the reverb starts being heard until the reverb sound is cut off.                      |
| EQ Low Freq | 0.04–1.00kHz  | Frequency of the low range.                                                                                      |
| EQ Low Gain | –24–+12dB     | Gain of the low range.                                                                                           |
| EQ Mid Freq | 0.25–9.99kHz  | Frequency of the middle range.                                                                                   |
| EQ Mid Gain | –24–+12dB     | Gain of the middle range.                                                                                        |
| EQ Mid Q    | 0.2–9.0       | Width of the middle range.<br>Set a higher value for Q to narrow the range to be affected.                       |
| EQ Hi Freq  | 0.80–9.99kHz  | Frequency of the high range.                                                                                     |
| EQ Hi Gain  | –24–+12dB     | Gain of the high range                                                                                           |
| EQ Hi Q     | 0.2–9.0       | Specifies the width of the high-frequency range.<br>Set a higher value for Q to narrow the range to be affected. |

## SIMPLE REVERB

| Parameter      | Value                                                        | Explanation                                                           |
|----------------|--------------------------------------------------------------|-----------------------------------------------------------------------|
| Type           | ROOM1, ROOM2, STAGE1, STAGE2, HALL1, HALL2, DELAY, PAN-DELAY | Type of reverb                                                        |
| Time           | 0–127                                                        | Time length of reverberation                                          |
| HF Damp        | 200Hz–BYPASS                                                 | Adjusts the high-frequency portion of the reverb.                     |
| Delay Feedback | 0–127                                                        | Adjusts the level at which the reverb sound is returned to the input. |

## LONG REVERB

| Parameter    | Value              | Explanation                                                                                                                                   |
|--------------|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| Depth        | 0–127              | Effect depth                                                                                                                                  |
| Time         | 0–127              | Time length of reverberation                                                                                                                  |
| Pre LPF      | 16–15000Hz, BYPASS | Center frequency at which the high frequencies of the input sound are filtered (set this to BYPASS if you do not want to cut the frequencies) |
| Pre HPF      | BYPASS, 16–15000Hz | Center frequency at which the low frequencies of the input sound are filtered (set this to BYPASS if you do not want to cut the frequencies)  |
| Peaking Freq | 200–8000Hz         | Frequency of the filter that boosts/cuts a specific frequency region of the input sound                                                       |
| Peaking Gain | -15–+15 dB         | Amount of boost/cut produced by the filter at the specified frequency region of the input sound                                               |
| Peaking Q    | 0.5–8.0            | Bandwidth of the filter that boosts or cuts the specified frequency region of the input sound                                                 |
| HF Damp      | 16–15000Hz, BYPASS | Frequency at which the high-frequency content of the resonant sound will be cut (BYPASS: no cut)                                              |
| LF Damp      | BYPASS, 16–15000Hz | Frequency at which the low-frequency content of the resonant sound is cut (BYPASS: no cut)                                                    |


## KIT RESONANCE

- \* Use caution when inputting very loud sounds into the KIT RESONANCE effect, as this may cause the output sound to distort or produce noise. If this happens, lower the volume of signal sent from the pads to KIT RESONANCE, or use PRE TRANSIENT and so forth to adjust the volume.

| Parameter                | Value               | Explanation                                                                                          |
|--------------------------|---------------------|------------------------------------------------------------------------------------------------------|
| <b>SEND tab</b>          |                     |                                                                                                      |
| Kit Resonance Send Level | -INF, -60.0–+6.0dB  | Amount of kit resonance applied to each pad                                                          |
| [F4] (H&R) button        | OFF, ON             | Specifies whether head and rim of instruments are selected as a set (ON) or independently (OFF).     |
| [F5] (Reso) button       | OFF, ON             | Turns the kit resonance effect on/off.                                                               |
| [F6] (ResoOnly) button   | OFF, ON             | Lets you temporarily hear just the kit resonance sound.                                              |
| <b>KIT RESO tab</b>      |                     |                                                                                                      |
| <b>PRE EQ</b>            |                     |                                                                                                      |
| Low Cut                  | OFF, 20–1kHz        | Cuts the frequency region below the specified frequency (low cut).                                   |
| Mid 1 Q                  | 0.5–16.0            | Width of the midrange frequency band<br>Set a higher value for Q to narrow the range to be affected. |
| Mid 1 Freq               | 20–16kHz            | Center frequency of the mid range                                                                    |
| Mid 1 Gain               | -40.0–+15.0dB       | Amount of boost/cut for the mid range                                                                |
| Mid 2 Q                  | 0.5–16.0            | Width of the midrange frequency band<br>Set a higher value for Q to narrow the range to be affected. |
| Mid 2 Freq               | 20–16kHz            | Center frequency of the mid range                                                                    |
| Mid 2 Gain               | -40.0–+15.0dB       | Amount of boost/cut for the mid range                                                                |
| [F3] (EQ) button         | OFF, ON             | Switches the EQ on/off.                                                                              |
| [F5] (Reso) button       | OFF, ON             | Turns the kit resonance effect on/off.                                                               |
| [F6] (ResoOnly) button   | OFF, ON             | Lets you temporarily hear just the kit resonance sound.                                              |
| <b>PRE TRANSIENT</b>     |                     |                                                                                                      |
| Transient Switch         | OFF, ON             | Turns the transient effect on/off.                                                                   |
| Attack                   | -50–0               | Adjusts the attack of the kit resonance input sound.                                                 |
| Gain                     | -INF, -60.0–+12.0dB | Volume following transient adjustment                                                                |

| Parameter                | Value                                                 | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                        |
|--------------------------|-------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| [F4] (Transient) button  | OFF, ON                                               | Turns the transient effect on/off.                                                                                                                                                                                                                                                                                                                                                                                                 |
| KIT RESO                 |                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Drums Type               | STANDARD SET, SMALL SET                               | Kit resonance reverberation type                                                                                                                                                                                                                                                                                                                                                                                                   |
| Time                     | -64–0                                                 | Kit resonance reverberation time                                                                                                                                                                                                                                                                                                                                                                                                   |
| Character                | 0–6                                                   | Tonal character of the kit resonance                                                                                                                                                                                                                                                                                                                                                                                               |
| Kit Resonance Level      | -INF, -60.0–+12.0dB                                   | Amount of kit resonance applied                                                                                                                                                                                                                                                                                                                                                                                                    |
| [F5] (Reso) button       | OFF, ON                                               | Turns the kit resonance effect on/off.                                                                                                                                                                                                                                                                                                                                                                                             |
| [F6] (ResoOnly) button   | OFF, ON                                               | Lets you temporarily hear just the kit resonance sound.                                                                                                                                                                                                                                                                                                                                                                            |
| POST EQ                  |                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Q                        | 0.5–16.0 (only when Type is set to MID)               | Width of the frequency range<br>Set a higher value for Q to narrow the range to be affected.                                                                                                                                                                                                                                                                                                                                       |
| Freq                     | 20Hz–1kHz (LOW)<br>20Hz–16kHz (MID)<br>1–16kHz (HIGH) | Center frequency                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Gain                     | -40–+15dB                                             | Amount of boost/cut                                                                                                                                                                                                                                                                                                                                                                                                                |
| [F3] (Room) button       | OFF, ON                                               | Turns the room effect on/off.                                                                                                                                                                                                                                                                                                                                                                                                      |
| [F4] (EQ) button         | OFF, ON                                               | Switches the EQ on/off.                                                                                                                                                                                                                                                                                                                                                                                                            |
| [F5] (Mid/Side) button   | OFF, ON                                               | Switches the EQ mode.<br><b>OFF (NORMAL):</b> Adjusts the input sound so that the tonal character is the same on the left and right sides.<br><b>ON (MID/SIDE):</b> Adjusts the input sounds at the center of the stereo field (MID) and the sounds at the left-right sides of the stereo field (SIDE) separately. The respective Q, Freq and Gain setting values are common for the NORMAL and MID side of the MID/SIDE EQ modes. |
| [F6] (ResoOnly) button   | OFF, ON                                               | Lets you temporarily hear just the kit resonance sound.                                                                                                                                                                                                                                                                                                                                                                            |
| POST COMP                |                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Comp Switch              | OFF, ON                                               | Turns post comp on/off.                                                                                                                                                                                                                                                                                                                                                                                                            |
| Threshold                | -60–0 dB                                              | Adjusts the volume at which compression begins                                                                                                                                                                                                                                                                                                                                                                                     |
| Gain                     | -24.0–+24.0dB                                         | Output volume of the post comp                                                                                                                                                                                                                                                                                                                                                                                                     |
| Ratio                    | 1:1–INF:1                                             | Compression ratio                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Knee                     | HARD, SOFT1–3                                         | Attack of the sound at the moment compression is applied                                                                                                                                                                                                                                                                                                                                                                           |
| Attack                   | 0.1–100ms                                             | Time from when the volume goes up the threshold level until the compressor effect applies                                                                                                                                                                                                                                                                                                                                          |
| Release                  | 10–1000ms                                             | Time from when the volume falls below the threshold level until the compressor effect no longer applies                                                                                                                                                                                                                                                                                                                            |
| [F4] (Reso) button       | OFF, ON                                               | Turns the kit resonance effect on/off.                                                                                                                                                                                                                                                                                                                                                                                             |
| [F5] (Comp) button       | OFF, ON                                               | Turns post comp on/off.                                                                                                                                                                                                                                                                                                                                                                                                            |
| [F6] (ResoOnly) button   | OFF, ON                                               | Lets you temporarily hear just the kit resonance sound.                                                                                                                                                                                                                                                                                                                                                                            |
| BUS SEND                 |                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Kit Reso Send Bus Select | OFF, BUS A–D                                          | Selects the bus to which the kit resonance sound is sent.                                                                                                                                                                                                                                                                                                                                                                          |
| Kit Reso Send Level      | -INF, -60.0–+6.0dB                                    | Amount of kit resonance sound sent to bus                                                                                                                                                                                                                                                                                                                                                                                          |
| [F5] (Reso) button       | OFF, ON                                               | Turns the kit resonance effect on/off.                                                                                                                                                                                                                                                                                                                                                                                             |
| [F6] (ResoOnly) button   | OFF, ON                                               | Lets you temporarily hear just the kit resonance sound.                                                                                                                                                                                                                                                                                                                                                                            |

# BUS FX



| Parameter              | Value                                                                                                                                        | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|------------------------|----------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>ROUTING tab</b>     |                                                                                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Pad Send Head/Rim      | PAD, HEAD/RIM                                                                                                                                | Sets whether to apply the BUS FX effect to each pad as a whole, or individually (to the head/rim and other parts of each pad), for the currently selected pads.                                                                                                                                                                                                                                                                                                                                                                    |
| Output Routing         | DRUM, DRUM+SEND BUS A, INSERT TO BUS A, DRUM+SEND BUS B, INSERT TO BUS B, DRUM+SEND BUS C, INSERT TO BUS C, DRUM+SEND BUS D, INSERT TO BUS D | <p>Sets which BUS FX effect to apply to the currently selected pad.</p> <p>For "DRUM+SEND BUS A–D", the BUS FX effect sound is added to the drum sound.</p> <p>For "INSERT TO BUS A–D", the drum sound is not output, and only the BUS FX effect sound is output.</p> <p>When Pad Send Head/Rim is set to "PAD", you can set the effects to be applied to the entire pad; and when Pad Send Head/Rim is set to "HEAD/RIM", you can set the effects to be applied only to individual parts of the pad, such as the head or rim.</p> |
| Pad Send Level *1      | -INF, -60.0–+6.0dB                                                                                                                           | <p>Specifies the amount of effect applied to each pad.</p> <p>When Pad Send Head/Rim is set to "PAD", you can set the effects to be applied to the entire pad; and when Pad Send Head/Rim is set to "HEAD/RIM", you can set the effects to be applied only to individual parts of the pad, such as the head or rim.</p>                                                                                                                                                                                                            |
| BUS-A Output           | BUS A, A+SEND B, INSERT B, A+SEND C, INSERT C, A+SEND D, INSERT D                                                                            | <p>Specifies the output destination of BUS-A.</p> <p>The effect sound can be sent to other buses as well.</p> <p>For instance, with the "A+SEND B" setting, you can input the BUS-A effect to BUS-B while the BUS-A effect is heard.</p> <p>With the "INSERT B" setting, all BUS-A effect sounds are input to BUS-B.</p>                                                                                                                                                                                                           |
| BUS-B Output           | BUS B, B+SEND C, INSERT C, B+SEND D, INSERT D                                                                                                | Sets the output destination for BUS-B.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| BUS-C Output           | BUS C, C+SEND D, INSERT D                                                                                                                    | Sets the output destination for BUS-C.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| BUS-A–C Send Level     | -INF, -60.0–+6.0dB                                                                                                                           | Sets how much signal is sent to the send destination when BUS-A–C Output is "BUS+SEND".                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| BUS-A–D Reverb Send    | -INF, -60.0–+6.0dB                                                                                                                           | Sets how much signal is sent to reverb for buses A–D.                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Pad Side Chain Control | OFF, BUS-A FX1, BUS-A FX2, BUS-B FX1, BUS-B FX2, BUS-C FX1, BUS-C FX2, BUS-D FX1, BUS-D FX2                                                  | <p>Use this setting when controlling the effect side chain from the pads.</p> <p>* The effects that are set as control destinations must be able to accept side chain input.</p>                                                                                                                                                                                                                                                                                                                                                   |
| <b>PAD ASSIGN tab</b>  |                                                                                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Pad Send Head/Rim      | PAD, HEAD/RIM                                                                                                                                | Sets whether to apply the BUS FX effect to each pad as a whole, or individually (to the head/rim and other parts of each pad), for the currently selected pads.                                                                                                                                                                                                                                                                                                                                                                    |
| Output Routing         | DRUM, DRUM+SEND BUS A, INSERT TO BUS A, DRUM+SEND BUS B, INSERT TO BUS B, DRUM+SEND BUS C, INSERT TO BUS C, DRUM+SEND BUS D, INSERT TO BUS D | <p>Sets which BUS FX effect to apply to the currently selected pad.</p> <p>For "DRUM+SEND BUS A–D", the BUS FX effect sound is added to the drum sound.</p> <p>For "INSERT TO BUS A–D", the drum sound is not output, and only the BUS FX effect sound is output.</p> <p>When Pad Send Head/Rim is set to "PAD", you can set the effects to be applied to the entire pad; and when Pad Send Head/Rim is set to "HEAD/RIM", you can set the effects to be applied only to individual parts of the pad, such as the head or rim.</p> |
| <b>PAD SEND tab</b>    |                                                                                                                                              |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Pad Send Head/Rim      | PAD, HEAD/RIM                                                                                                                                | Sets whether to apply the BUS FX effect to each pad as a whole, or individually (to the head/rim and other parts of each pad), for the currently selected pads.                                                                                                                                                                                                                                                                                                                                                                    |
| Pad Send Level *1      | -INF, -60.0–+6.0dB                                                                                                                           | Specifies the amount of effect applied to each pad.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |

\*1 This is enabled when Output Routing is "DRUM+SEND BUS A–D".

## FX EDIT

| Parameter          | Value                                                                                             | Explanation                  |
|--------------------|---------------------------------------------------------------------------------------------------|------------------------------|
| <b>BUS-A-D tab</b> |                                                                                                   |                              |
| Type               | Effect type<br><b>MEMO</b><br>For more about multi-effects, refer to "Effect parameters" (p. 66). |                              |
| [F5] (Fx1) button  | OFF, ON                                                                                           | Turns on/off the FX1 effect. |
| [F6] (Fx2) button  | OFF, ON                                                                                           | Turns on/off the FX2 effect. |

## SIDE CHAIN

| Parameter                           | Value                                                                                       | Explanation                                                                                                                                                                      |
|-------------------------------------|---------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>PRE-GATE tab</b>                 |                                                                                             |                                                                                                                                                                                  |
| FX1, 2 Sidechain Pre-Gate Sw        | OFF, ON                                                                                     | Side chain control signal gate on/off                                                                                                                                            |
| FX1, 2 Sidechain Pre-Gate Threshold | -60-0 dB                                                                                    | Volume level at which the gate begins to close                                                                                                                                   |
| FX1, 2 Sidechain Pre-Gate Mode      | Type of gate                                                                                |                                                                                                                                                                                  |
|                                     | GATE                                                                                        | Closes the gate when the control signal volume is low, which cuts off the control signal.                                                                                        |
|                                     | DUCK                                                                                        | Closes the gate when the control signal volume is high, which cuts off the control signal.                                                                                       |
| FX1, 2 Sidechain Pre-Gate Attack    | 0-100ms                                                                                     | Adjusts the time it takes for the gate to fully open after being triggered.                                                                                                      |
| FX1, 2 Sidechain Pre-Gate Hold      | 10-1000ms                                                                                   | Adjusts the time it takes for the gate to start closing after the control signal falls beneath the Threshold level.                                                              |
| FX1, 2 Sidechain Pre-Gate Release   | 10-1000ms                                                                                   | Adjusts the time it takes the gate to fully close after the hold time.                                                                                                           |
| FX1, 2 Sidechain Pre-Gate Balance   | D100:0W-D0:100W                                                                             | Sets the volume balance between the control signal (D) and the effect sound (W).                                                                                                 |
| FX1, 2 Sidechain Pre-Gate Level     | 0-127                                                                                       | Output Level                                                                                                                                                                     |
| FX1, 2 Sidechain Pre-Gate Gain      | -24.0-+24.0dB                                                                               | PRE-GATE gain                                                                                                                                                                    |
| <b>PAD ASSIGN tab</b>               |                                                                                             |                                                                                                                                                                                  |
| Pad Side Chain Control              | OFF, BUS-A FX1, BUS-A FX2, BUS-B FX1, BUS-B FX2, BUS-C FX1, BUS-C FX2, BUS-D FX1, BUS-D FX2 | Use this setting when controlling the effect side chain from the pads.<br>* Effects that are configured as control destinations must be able to accept side chain input (p. 66). |
| <b>PAD SEND tab</b>                 |                                                                                             |                                                                                                                                                                                  |
| Side Chain Control Send Level       | -INF, -60.0-+12.0dB                                                                         | Amount of side chain control                                                                                                                                                     |


## BUS REVERB

| Parameter               | Value                                                                                    | Explanation                                                                                                                            |
|-------------------------|------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| <b>PRE TRANSIENT</b>    |                                                                                          |                                                                                                                                        |
| Transient Switch        | OFF, ON                                                                                  | Turns the transient effect on/off.                                                                                                     |
| Attack                  | -50-0                                                                                    | Adjusts the attack of the bus reverb input sound.                                                                                      |
| Gain                    | -INF, -60.0-+12.0dB                                                                      | Volume following transient adjustment                                                                                                  |
| [F4] (Transient) button | OFF, ON                                                                                  | Turns the transient effect on/off.                                                                                                     |
| [F5] (Reverb) button    | OFF, ON                                                                                  | Turns reverb on/off.                                                                                                                   |
| [F6] (Comp) button      | OFF, ON                                                                                  | Turns post comp on/off.                                                                                                                |
| <b>REVERB</b>           |                                                                                          |                                                                                                                                        |
| Reverb Type             | TD-50 REVERB, TD-50 ROOM, WARM HALL, SRV-2000, SRV-2000(NLR), SIMPLE REVERB, LONG REVERB | Type of room reverberation<br><b>MEMO</b><br>For details on the parameters that can be edited, refer to "Specific parameters" (p. 21). |
| Reverb Level            | -INF, -60.0-+12.0dB                                                                      | Reverb volume                                                                                                                          |
| [F4] (Transient) button | OFF, ON                                                                                  | Turns the transient effect on/off.                                                                                                     |
| [F5] (Reverb) button    | OFF, ON                                                                                  | Turns reverb on/off.                                                                                                                   |
| [F6] (Comp) button      | OFF, ON                                                                                  | Turns post comp on/off.                                                                                                                |
| <b>POST COMP</b>        |                                                                                          |                                                                                                                                        |
| Comp Switch             | OFF, ON                                                                                  | Turns post comp on/off.                                                                                                                |
| Threshold               | -60-0 dB                                                                                 | Adjusts the volume at which compression begins                                                                                         |
| Gain                    | -24.0-+24.0dB                                                                            | Output volume of the post comp                                                                                                         |
| Ratio                   | 1:1-INF:1                                                                                | Compression ratio                                                                                                                      |
| Knee                    | HARD, SOFT1-3                                                                            | Attack of the sound at the moment compression is applied                                                                               |
| Attack                  | 0.1-100ms                                                                                | Time from when the volume goes up the threshold level until the compressor effect applies                                              |
| Release                 | 10-1000ms                                                                                | Time from when the volume falls below the threshold level until the compressor effect no longer applies                                |
| [F4] (Transient) button | OFF, ON                                                                                  | Turns the transient effect on/off.                                                                                                     |
| [F5] (Reverb) button    | OFF, ON                                                                                  | Turns reverb on/off.                                                                                                                   |
| [F6] (Comp) button      | OFF, ON                                                                                  | Turns post comp on/off.                                                                                                                |

## KIT OTHERS

### 1. Press the [OTHERS] button.

The KIT OTHERS screen appears.




### 2. Use the cursor buttons or the dial to select the menu that you want to edit, and press the [ENTER] button.

### 3. Edit the drum kit settings.


### 4. Press the [KIT] button to return to the KIT screen.

## XSTICK



| Parameter                   | Value                                                                                                                                                                                            | Explanation                                                                                                                                                                                                                                                                                                                                         |
|-----------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| INST tab                    |                                                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                     |
| XSTICK INST                 |                                                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                     |
| Cross stick switch          | OFF, ON                                                                                                                                                                                          | Specifies whether sounding (ON) and not sounding (OFF) the instrument assigned to the cross-stick for the snare pad.                                                                                                                                                                                                                                |
| Instrument                  | Selects the instrument to assign to the cross stick.<br>* When you assign the snare or cross stick instrument to layer A of the snare rim, the cross stick instrument is automatically assigned. |                                                                                                                                                                                                                                                                                                                                                     |
| XStick Volume               | -INF, -60.0—+6.0dB                                                                                                                                                                               | Cross-stick sound volume                                                                                                                                                                                                                                                                                                                            |
| XSTICK TRANSIENT            |                                                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                     |
| Type                        | Preset, Type 1–4                                                                                                                                                                                 | Use this to set the effect that's used when a transient is applied, if a user sample (except for PLAY TYPE LOOP) is selected for the instrument. (When using the built-in tones, "(Preset)" is shown and this setting can't be edited.)                                                                                                             |
| Attack Time                 | 1–10                                                                                                                                                                                             | Time over which the attack changes                                                                                                                                                                                                                                                                                                                  |
| Attack Depth                | -100—+100                                                                                                                                                                                        | Adjustment of the attack                                                                                                                                                                                                                                                                                                                            |
| Attack Type                 | NORMAL, WIDE 1, WIDE 2                                                                                                                                                                           | For the NORMAL setting, the transient attack effect is always applied.<br>For the WIDE 1 or 2 setting, the attack effect becomes weaker when you strike the pad more softly. This is effective when you want to soften the attack on the transients, such as when striking the snare drum softly.                                                   |
| Release Depth               | -100—+100                                                                                                                                                                                        | Adjustment of the release                                                                                                                                                                                                                                                                                                                           |
| Gain                        | -12.0—+6.0 dB                                                                                                                                                                                    | Volume following transient adjustment                                                                                                                                                                                                                                                                                                               |
| [F4] (Transient) button     | Transient OFF, ON                                                                                                                                                                                | Turns the transient effect on/off for the cross stick.                                                                                                                                                                                                                                                                                              |
| [F5] (Analog XStick) button | OFF, ON                                                                                                                                                                                          | Sets whether to play the cross stick sound (ON) or not (OFF) from an analog pad, when a digitally-connected pad (snare) is not connected.<br>* If the trigger input of a pad that supports both cross-stick technique and digital connection (such as the PD-14DSX or the PD-140DS) is assigned to a snare, cross stick playing is always possible. |
| [F6] (COPY) button          | Copies the cross stick settings.                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                     |
| V-EDIT tab                  |                                                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                     |
| –                           | Edits the instrument cross stick sound using V-EDIT.<br><div>MEMO</div> <div>You can select any instrument aside from SYNTH WAVE for the cross stick sound.</div>                                |                                                                                                                                                                                                                                                                                                                                                     |

## STRAINER



| Parameter               | Value                                                                    | Explanation                                                                                                                                                                                        |
|-------------------------|--------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>LEVER tab</b>        |                                                                          |                                                                                                                                                                                                    |
| Strainer Lever Function | STRAINER ON/OFF, FX CONTROL, FUNCTION OFF                                | This sets the function that's used when you operate the strainer lever. When this is set to "FX CONTROL", you can control the effects that are set in the FX CTRL tab.                             |
| Strainer Mode           | BEHAVIOR                                                                 | Sets whether to change the snare sound according to the strainer lever position. When the PD-14DSX is connected, this changes the snare sound according to the strainer lever position.            |
|                         | ALWAYS ON, ALWAYS OFF                                                    | Sets whether to trigger the strainer sound for the snare ("ALWAYS ON") or not ("ALWAYS OFF"), regardless of the connection with the PD-14DSX or the strainer lever position.                       |
| Strainer Throw Sound    | OFF, TYPE1–TYPE7                                                         | The sound that's heard when the strainer lever is raised or lowered.                                                                                                                               |
| Strainer Throw Volume   | -INF, -60.0–+6.0dB                                                       | The volume of the sound that's heard when the strainer lever is raised or lowered.                                                                                                                 |
| <b>SW/KNOB tab</b>      |                                                                          |                                                                                                                                                                                                    |
| Strainer Sw Func        | This sets the function that's used when you operate the strainer switch. |                                                                                                                                                                                                    |
|                         | OFF                                                                      | Disables the function.                                                                                                                                                                             |
|                         | DISPLAY STRAINER KNOB FUNC                                               | Shows the name of the function that's assigned to the strainer knob.                                                                                                                               |
|                         | SONG TOP                                                                 | Return to the beginning of the song.                                                                                                                                                               |
|                         | SONG PLAY/STOP                                                           | Play/stop the song.                                                                                                                                                                                |
|                         | Bluetooth PLAY/STOP *1                                                   | Plays/stops the song on the connected smartphone.                                                                                                                                                  |
|                         | CLICK PLAY/STOP                                                          | Plays/stops the click.                                                                                                                                                                             |
|                         | TAP TEMPO                                                                | Lets you set the tempo by pressing the strainer switch at the desired interval (tap tempo).                                                                                                        |
|                         | SNARE BUZZ ON/OFF                                                        | Turns the snare resonance (buzz) on/off.                                                                                                                                                           |
|                         | SNAPSHOT SAVE                                                            | Temporarily saves the drum kit being edited for comparison (as a snapshot). For details on the snapshots, refer to the "Reference Manual" (Roland website).                                        |
|                         | ALL SOUND OFF                                                            | Stops the currently-sounding drum performance sound or user sample playback.                                                                                                                       |
| Strainer Knob Func      | This sets the function that's used when you operate the strainer knob.   |                                                                                                                                                                                                    |
|                         | OFF                                                                      | Disables the function.                                                                                                                                                                             |
|                         | SONG#                                                                    | Calls up the previous or next song.                                                                                                                                                                |
|                         | Bluetooth SONG# *1                                                       | Recalls the previous or next song on a smartphone connected via Bluetooth.                                                                                                                         |
|                         | CLICK TEMPO                                                              | Adjusts the click tempo.                                                                                                                                                                           |
|                         | SNARE BUZZ VOLUME                                                        | Adjusts the snare resonance volume.                                                                                                                                                                |
|                         | STRAINER ADJUST *2                                                       | Adjusts how much the strainer is applied.                                                                                                                                                          |
|                         | SNARE TUNING *2                                                          | Adjusts the tuning of the snare sound.                                                                                                                                                             |
|                         | SNARE MUFFLING *2                                                        | Adjusts the muffling of the snare sound.                                                                                                                                                           |
|                         | LED BRIGHTNESS                                                           | You can change the brightness of the buttons on a kit-by-kit basis ([KIT] button, [-] [+]) button, [HEAD PREVIEW] button, [RIM] (PREVIEW) button), as well as for the dial and strainer indicator. |
|                         | LCD BRIGHTNESS                                                           | Adjusts the brightness of the display.                                                                                                                                                             |

| Parameter                                                      | Value                     | Explanation                                                             |
|----------------------------------------------------------------|---------------------------|-------------------------------------------------------------------------|
| <b>FX CTRL tab (when Strainer Lever Function = FX CONTROL)</b> |                           |                                                                         |
| Effect control switch                                          | DISABLE                   | No effect is controlled.                                                |
|                                                                | LEVER ON                  | The effect turns ON when the strainer lever is set to the ON position.  |
|                                                                | LEVER OFF                 | The effect turns ON when the strainer lever is set to the OFF position. |
| <b>AMBIENCE CONTROL</b>                                        |                           |                                                                         |
| OVERHEAD                                                       | Overhead mic              |                                                                         |
| ROOM                                                           | Room ambience             |                                                                         |
| REVERB                                                         | Reverb                    |                                                                         |
| KIT RESO                                                       | Kit resonance             |                                                                         |
| <b>BUS FX CONTROL</b>                                          |                           |                                                                         |
| BUS-A FX1                                                      | BUS-A FX1 effect          |                                                                         |
| BUS-A FX2                                                      | BUS-A FX2 effect          |                                                                         |
| BUS-B FX1                                                      | BUS-B FX1 effect          |                                                                         |
| BUS-B FX2                                                      | BUS-B FX2 effect          |                                                                         |
| BUS-C FX1                                                      | BUS-C FX1 effect          |                                                                         |
| BUS-C FX2                                                      | BUS-C FX2 effect          |                                                                         |
| BUS-D FX1                                                      | BUS-D FX1 effect          |                                                                         |
| BUS-D FX2                                                      | BUS-D FX2 effect          |                                                                         |
| BUS REVERB                                                     | Reverb applied to the bus |                                                                         |

\*1 Some smartphones and music playback apps may not let you control the song from the V71.


\*2 You can adjust the effect of the snare/cross stick sound that's applied to each of the SNARE layers all at once, while keeping a balance between the layers.

## SNARE BUZZ



| Parameter           | Value              | Explanation                                                                                  |
|---------------------|--------------------|----------------------------------------------------------------------------------------------|
| Snare Buzz Switch   | OFF, ON            | Turns the snare resonance (buzz) on/off.                                                     |
| Snare Buzz Volume   | -INF, -60.0—+6.0dB | Snare resonance volume                                                                       |
| Snare Buzz Sens     | OFF, 1–12          | Snare resonance for each pad                                                                 |
| Snare Buzz Muffling | OFF, 1–8, MAX      | Sets the muffling (mute) of the snare resonance sound for each pad.                          |
| [F5] (Buzz) button  | OFF, ON            | Turns the snare resonance (buzz) on/off.                                                     |
| [F6] (H&R) button   | H&R OFF, H&R ON    | Sets whether to configure both the head and rim at the same time (ON) or individually (OFF). |

## KIT VOLUME




| Parameter  | Value              | Explanation               |
|------------|--------------------|---------------------------|
| Kit Volume | -INF, -60.0—+6.0dB | Sets the drum kit volume. |

### MEMO


You can press the [F5] (KIT -) and [F6] (KIT +) buttons to switch between drum kits. This is useful when you want to level out the volume for each drum kit.

## KIT NAME



| Parameter    | Value       | Explanation                                                                                                                                                          |
|--------------|-------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Kit Name     |             | Edits the name of the currently selected drum kit. You can enter a kit name (upper line) of up to 16 characters, and a sub-name (lower line) of up to 64 characters. |
| Kit Sub Name | <b>MEMO</b> | For details on how to edit the name, refer to the “Reference Manual” (Roland website).                                                                               |


## MUTE GROUP



| Parameter               | Value        | Explanation                                                                                                                                                   |
|-------------------------|--------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SEND                    |              | Specify the mute group number. When you strike the pad of the number specified in SEND, the sound of the pad assigned to the same number in RECEIVE is muted. |
| RECEIVE                 | – (OFF), 1–8 | * Even if you specify the same number in SEND and RECEIVE for the same location (e.g., head or rim) of the same pad, muting does not occur.                   |
| [F6] (CLEAR ALL) button |              | Clears all mute groups.                                                                                                                                       |

- \* When you specify a mute group, an arrow indicates the pads that are muted when you strike the currently selected pad, and the pads that when struck will mute the currently selected pad.

## KIT MIDI



| Parameter            | Value          | Explanation                                                                                             |
|----------------------|----------------|---------------------------------------------------------------------------------------------------------|
| <b>NOTE No. tab</b>  |                |                                                                                                         |
| MIDI Note No.        | 0 (C)–127 (G9) | Sets the MIDI note number transmitted and received by each pad.                                         |
|                      | OFF            | Note messages are not transmitted or received                                                           |
| <b>GATE TIME tab</b> |                |                                                                                                         |
| MIDI Gate Time       | 0.1–8.0s       | Sets the duration of the notes transmitted by each pad.                                                 |
| <b>CHANNEL tab</b>   |                |                                                                                                         |
| MIDI Channel         | Channel 1–16   | Sets the MIDI channel on which each pad transmits or receives note messages or control change messages. |
|                      | GLOBAL         | Transmits and receives on the transmit/receive channel (p. 49) specified in SETUP.                      |

- \* To play a pad from an external MIDI device, the incoming message must match the MIDI note number and MIDI channel setting of the desired pad.

### MEMO

To return to the default values, press the [F6] (DEFAULT) button.

## MIDI note numbers transmitted and received by the hi-hat

| Item                                  | Explanation                                                            |
|---------------------------------------|------------------------------------------------------------------------|
| HI-HAT OPEN HEAD<br>HI-HAT OPEN RIM   | MIDI note number transmitted and received by open hi-hat (head, rim)   |
| HI-HAT CLOSE HEAD<br>HI-HAT CLOSE RIM | MIDI note number transmitted and received by closed hi-hat (head, rim) |
| HI-HAT CLOSED-PEDAL                   | MIDI note number transmitted and received by pedal hi-hat              |

## MIDI note numbers transmitted and received by the snare

| Parameter               | Explanation                                                                                                             |
|-------------------------|-------------------------------------------------------------------------------------------------------------------------|
| SNARE HEAD<br>SNARE RIM | MIDI note number transmitted and received by head shot and rim shot                                                     |
| SNARE BRUSH             | MIDI note number transmitted and received by brush sweep                                                                |
| SNARE XSTICK            | MIDI note number transmitted and received by cross stick                                                                |
| SNARE THROW ON          | MIDI note number transmitted or received when you raise the strainer lever                                              |
| SNARE THROW OFF         | MIDI note number transmitted or received when you lower the strainer lever                                              |
| SNARE THROW OFF HEAD    | MIDI note number transmitted or received when a head shot is played while the strainer lever is off the head (detached) |
| SNARE THROW OFF RIM     | MIDI note number transmitted or received when a rim shot is played while the strainer lever is off the head             |
| SNARE THROW OFF BRUSH   | MIDI note number transmitted or received when playing with a brush while the strainer lever is off the head             |
| SNARE THROW OFF XSTICK  | MIDI note number transmitted or received when a cross stick is played while the strainer lever is off the head          |

## When setting multiple pads to the same note number

When playing the internal sound generator of the V71, if an incoming note number is assigned to more than one pad, that note plays the instrument of the pad with the lowest trigger input number. If the same note number is assigned to both the head and the rim, the head instrument is sounded.

### MEMO

An asterisk (\*) appears at the right of the note number for trigger inputs that are not sounded.

Example:

Note number "38 (D 2)" is set for the head and rim of trigger input 2 SNARE and the head of trigger input 3 TOM 1. In this case, when note number 38 (D2) is received, the instrument assigned to the head of trigger input 2 SNARE is played.


### About the gate time

Percussion sound modules normally produce sound only in response to "Note on" messages, and ignore "Note off" messages. However general-purpose sound modules or samplers do receive the note-off messages that are transmitted and respond by turning off the sound.

Since gate time is normally not necessary for a percussion sound module, this is set to the minimum value when the unit is shipped from the factory. If a note-off message is received while the sound module has this setting, it is received as an extremely brief note that has almost no time to be heard, and is nearly inaudible. (Alternatively, it is possible that this could be heard as an unwanted noise.) To avoid this, specify the note duration of the MIDI performance data that is produced when you strike each pad.


\* If the same note number is sounded again in an overlapping manner, a note-off is transmitted before transmitting note-on, even if it is within the gate time.

## KIT COLOR



| Parameter | Value         | Explanation                                                                                                                                                                                                                                                                                                                           |
|-----------|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Kit Color | 1: WHITE      | <p>You can change the colors of the buttons on a kit-by-kit basis ([KIT] button, [-] [+] button, [HEAD PREVIEW] button, [RIM] (PREVIEW) button), as well as for the dial and strainer indicator.</p> <p><b>MEMO</b></p> <p>When "11:CUSTOM" is selected, you can set the red, green and blue values each within a range of 0–255.</p> |
|           | 2: RED        |                                                                                                                                                                                                                                                                                                                                       |
|           | 3: GREEN      |                                                                                                                                                                                                                                                                                                                                       |
|           | 4: BLUE       |                                                                                                                                                                                                                                                                                                                                       |
|           | 5: LIGHT BLUE |                                                                                                                                                                                                                                                                                                                                       |
|           | 6: PINK       |                                                                                                                                                                                                                                                                                                                                       |
|           | 7: PURPLE     |                                                                                                                                                                                                                                                                                                                                       |
|           | 8: ORANGE     |                                                                                                                                                                                                                                                                                                                                       |
|           | 9: YELLOW     |                                                                                                                                                                                                                                                                                                                                       |
|           | 10: EMERALD   |                                                                                                                                                                                                                                                                                                                                       |
|           | 11: CUSTOM    |                                                                                                                                                                                                                                                                                                                                       |

## POSITION/PEDAL



| Parameter           | Value                        | Explanation                                                                                                                                                                         |
|---------------------|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| POSITION tab        |                              |                                                                                                                                                                                     |
| Position Control *1 | OFF, ON, ON (Rim Click Off)  | Turns on/off tonal changes that occur depending on your strike location or the nuances of your rim shots.                                                                           |
|                     |                              | <b>Head</b>                                                                                                                                                                         |
|                     |                              | Snare: strike position, left-right detection (only for PD-140DS and PD-14DSX)                                                                                                       |
|                     |                              | Tom: Strike position                                                                                                                                                                |
|                     |                              | <b>Rim</b>                                                                                                                                                                          |
|                     |                              | Snare: rim shot nuance, left-right detection for rimshot (only for PD-140DS and PD-14DSX)                                                                                           |
|                     |                              | Tom: Rim shot nuance                                                                                                                                                                |
|                     |                              | <b>Bow</b>                                                                                                                                                                          |
|                     |                              | Hi-hat: Strike position, left-right detection (VH-14D only)                                                                                                                         |
|                     |                              | Ride: Strike position, left-right detection (CY-18DR only)                                                                                                                          |
|                     |                              | <b>Edge</b>                                                                                                                                                                         |
|                     |                              | Hi-hat: left-right detection (VH-14D only)                                                                                                                                          |
|                     |                              | Ride: left-right detection (CY-18DR only)                                                                                                                                           |
| POS AREA tab        |                              |                                                                                                                                                                                     |
| Position Area *1    | INSIDE -5–DEFAULT–OUTSIDE +5 | Specifies the striking area for the head or rim.<br>“INSIDE” settings make it easier to play notes toward the inside; “OUTSIDE” settings make it easier to play toward the outside. |

## PEDAL BEND tab

## Pedal Bend Range

-24-0-24

Specifies the amount of pitch change that occurs according to the depth to which you press the hi-hat pedal.


You can set this for each pad (head and rim separately) in semitone units.

\*1: This supports the following trigger inputs.

- SNARE
- TOM1-4
- HI-HAT (only when a VH-14D is assigned to the hi-hat trigger input)
- Ride box (head), edge (rim); only when CY-18DR is assigned to RIDE trigger input
- AUX1-4

\* Depending on the pad that is connected or the instrument that is selected, there might be cases in which this has no effect.

## KIT OPTION



## Parameter

## Value

## Explanation

## BRUSH tab

## Brush Switch

OFF, ON

Specifies whether you're performing with sticks (OFF) or brushes (ON).

If this is "ON", you can perform by scraping (sweeping) the brushes.

\* This is enabled when an instrument that supports brush playing is assigned to snare head layer A.

## KIT TEMPO tab

## Kit Tempo

OFF

Use a common tempo (V71) for the entire p. 37.

The tempo does not change when you switch drum kits.

ON

Individually specify a tempo for each drum kit.

The click tempo and the tempo of tempo-synchronized effects can be individually specified for each drum kit.

## Tempo


20.0-260.0

Tempo specified for each drum kit

Hold down the [SHIFT] button and turn the dial if you want to fine-tune the value in decimal points.

| Parameter                | Value                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|--------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>KIT PHRASE tab</b>    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Kit Phrase               | 01: 8beat - Med<br>02: 8beat - Fast<br>03: 8beat - Slow<br>04: 16beat 1<br>05: 16beat 2<br>06: 16beat Slow 1<br>07: 16beat Slow 2<br>08: Ballad<br>09: Rock - Fast 1<br>10: Rock - Fast 2<br>11: Rock - Med 1<br>12: Rock - Med 2<br>13: Rock - Fast<br>14: Rock - Slow<br>15: Tom Beat 1<br>16: Tom Beat 2<br>17: Metal 1<br>18: Metal 2<br>19: Metal 3<br>20: Jazz Funk 1<br>21: Jazz Funk 2<br>22: Funk<br>23: Funk Shuffle1<br>24: Funk Shuffle2<br>25: Funk Shuffle3<br>26: R&B - Shuffle<br>27: R&B - Slow<br>28: Modern Gospel<br>29: Samba Kick<br>30: Samba Bateria<br>31: Songo<br>32: Latin Jazz<br>33: Jazz - Slow<br>34: Jazz - Med 1<br>35: Jazz - Med 2<br>36: Jazz - Med 3<br>37: Jazz - Fast 1<br>38: Jazz - Fast 2<br>39: Jazz Tom Beat<br>40: Second Line<br>41: Elec Beat 1<br>42: Elec Beat 2<br>43: Elec Beat 3<br>44: Drum'n'Bass<br>45: Trap 1<br>46: Trap 2<br>47: Dub Step<br>48: Break Beats<br>49: Sound Check 1<br>50: Sound Check 2<br>51: Sound Check 3<br>52: Sound Check 4 | Selects the kit phrase to play back.                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Kit Phrase Play (GLOBAL) | OFF, ON                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     | When this is "OFF", kit phrase playback is disabled for all drum kits. This is useful when you don't want to accidentally trigger the kit phrases, such as when you're playing live.<br><br>This parameter setting applies to the V71 overall.                                                                                                                                                                                                             |
| <b>KIT VIEW tab</b>      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Kit Image                | OFF, ON, GLOBAL                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | Sets the background image that's shown on the kit screen.<br><br>You can import your own image file from an SD card or from the V71 Editor into the V71, and use it as the background image for the KIT screen. This is useful when you want to make your own drum kit easier to select.<br><br>When this is "OFF", no background image is shown for the KIT screen. To set the view for all KIT screen backgrounds on the V71 in common, select "GLOBAL". |
| Kit Name Size            | SMALL, MEDIUM, LARGE, GLOBAL                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                | Configures the text size for the KIT screen.<br><br>To set the text size for all KIT screens as a common setting that applies to the V71 overall, set this to "GLOBAL".                                                                                                                                                                                                                                                                                    |

## SONG



| Parameter                             | Value                                                                                   | Explanation                                                                                                                                                                                                                                                                 |
|---------------------------------------|-----------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>SONG SOURCE window</b>             |                                                                                         |                                                                                                                                                                                                                                                                             |
| INTERNAL                              | Built-in songs                                                                          |                                                                                                                                                                                                                                                                             |
| SD CARD <Top>                         | Song in top directory of SD card                                                        |                                                                                                                                                                                                                                                                             |
| DRUM REC DATA                         | Songs for drum performance data recorded on this unit                                   |                                                                                                                                                                                                                                                                             |
| AUDIO REC DATA                        | Songs recorded on this unit as audio data                                               |                                                                                                                                                                                                                                                                             |
| <b>SETUP/INFO window</b>              |                                                                                         |                                                                                                                                                                                                                                                                             |
| <b>SETUP</b>                          |                                                                                         |                                                                                                                                                                                                                                                                             |
| Loop                                  | OFF, ON                                                                                 | Sets whether to repeatedly play back (ON) or not received (OFF).                                                                                                                                                                                                            |
| Song Level                            | -INF, -60.0—+6.0dB                                                                      | Song (audio data) volume                                                                                                                                                                                                                                                    |
| Click Track Level                     | -INF, -60.0—+6.0dB                                                                      | Click track volume<br>* Only if there is a click track corresponding to the song                                                                                                                                                                                            |
| <b>INFO</b>                           |                                                                                         |                                                                                                                                                                                                                                                                             |
| Song Bank                             | Song save location (temporary area in internal storage, or SD card)                     |                                                                                                                                                                                                                                                                             |
| Song Name                             | Song name                                                                               |                                                                                                                                                                                                                                                                             |
| Folder                                | Song save location on SD card                                                           |                                                                                                                                                                                                                                                                             |
| Total Time                            | Song playback time<br>* This is not shown for songs containing only a drum performance. |                                                                                                                                                                                                                                                                             |
| <b>REC screen</b>                     |                                                                                         |                                                                                                                                                                                                                                                                             |
| Rec Mode                              | DRUM REC<br>AUDIO REC                                                                   | Records as SMF data (MIDI).<br>Records as audio data (WAV).                                                                                                                                                                                                                 |
| Rec Number                            | TEMPORARY                                                                               | Records to temporary memory on this unit (one song).                                                                                                                                                                                                                        |
|                                       | SD#01–99 (DRUM REC)<br>SD#001–200 (AUDIO REC)                                           | Records to an SD card.<br>* This cannot be selected if you have not inserted an SD card into the V71.<br>* For AUDIO REC, the Rec Number is set automatically.                                                                                                              |
| Rec Target *1                         | ALL                                                                                     | The input audio from the MIX IN (STEREO) jack and the playback audio from a smartphone connected via Bluetooth is recorded, in addition to your drum playing.                                                                                                               |
|                                       | DRUMS ONLY                                                                              | Only your drum playing is recorded.                                                                                                                                                                                                                                         |
| Rec Gain *1                           | -24—+24dB                                                                               | Sets the volume used when recording.                                                                                                                                                                                                                                        |
| Play a song while recording *2        | OFF, ON                                                                                 | To play back a song while recording, set this to “ON”.                                                                                                                                                                                                                      |
| Play and record a song *1             | OFF, ON                                                                                 | To record a song in addition to playing the drums, set this to “ON”.                                                                                                                                                                                                        |
| <b>DRUM REC DATA EXPORT screen *2</b> |                                                                                         |                                                                                                                                                                                                                                                                             |
| Export Type                           | SMF                                                                                     | Exports the drum performance to SMF format.                                                                                                                                                                                                                                 |
|                                       | WAV (Drums)                                                                             | Exports the drum performance to an audio file.                                                                                                                                                                                                                              |
|                                       | WAV (Drums with song)                                                                   | Exports the drum performance including the song to an audio file.<br>You can only set this when your drum playing is recorded along with a song.                                                                                                                            |
|                                       | SMF+WAV                                                                                 | Exports the drum performance to both an audio file and an SMF.                                                                                                                                                                                                              |
| Kit                                   | 001–200                                                                                 | Selects the drum kit that’s used when exporting your drum performance to an audio file.                                                                                                                                                                                     |
| Export Gain                           | 0—+24dB                                                                                 | Sets the output level used when exporting the audio file.<br>Press the [F6] (▶/■) button to play back a preview of the recorded data (the export results). Adjust the audio file volume while checking the output level meters. Positive (+) values make the volume louder. |
| Post Export Time                      | 0–10sec                                                                                 | The tail end of the sound may get chopped off when you export an audio file. If this happens, increase this value to prevent this problem.                                                                                                                                  |

\*1 Only when SONG SOURCE is “AUDIO REC DATA”.


\*2 Only when SONG SOURCE is “DRUM REC DATA”.

## Making the click play (metronome)

You can sound a click and practice drumming at a steady tempo.

### 1. Press the [CLICK] button.

The CLICK screen appears.



| Parameter           | Value                                                                                                                                 | Explanation                                                                                                                                         |
|---------------------|---------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>TEMPO tab</b>    |                                                                                                                                       |                                                                                                                                                     |
| [F6] (CLICK) button | OFF, ON                                                                                                                               | Plays/stops the click.                                                                                                                              |
| Tempo *1            | 20.0–260.0                                                                                                                            | Tempo                                                                                                                                               |
| Beat *1             | 1–9                                                                                                                                   | Number of beats per measure                                                                                                                         |
| Template            | QTR NOTES, 8TH NOTES, UPBEATS, 16TH NOTES, 3 OVER 2, 8TH NOTE TRIPLETS                                                                | You can select the volume for each click timing from the templates.                                                                                 |
| Accent              |                                                                                                                                       |                                                                                                                                                     |
| ♩ (Quarter)         | OFF, 1–9, MAX                                                                                                                         | Volume for each click timing                                                                                                                        |
| ♪ (Eighth)          |                                                                                                                                       |                                                                                                                                                     |
| ♫ (Sixteenth)       |                                                                                                                                       |                                                                                                                                                     |
| ♫♫ (Triplet)        |                                                                                                                                       |                                                                                                                                                     |
| <b>SETUP tab</b>    |                                                                                                                                       |                                                                                                                                                     |
| Sound               | METRONOME, CLICK, VOICE, BEEP 1, BEEP 2, TEK CLICK, STICKS, CLAVES, WOOD BLOCK, COWBELL, AGOGO, TRIANGLE, TAMBOURINE, MARACAS, CABASA | Selects the click sound.                                                                                                                            |
| Level               | -INF, -60.0–+6.0dB                                                                                                                    | Adjusts the click volume.                                                                                                                           |
| Pan                 | L30–CENTER–R30                                                                                                                        | Adjusts the stereo location of the click.                                                                                                           |
| LED Reference       | OFF, ON                                                                                                                               | Specifies whether the [CLICK] button blinks in time with the click (ON) or does not blink (OFF).<br>This is enabled even when the click is stopped. |
| Tap Switch          | OFF, ON                                                                                                                               | You can specify the tempo by striking the pad specified by Tap Pad or by pressing a button (Tap Tempo).                                             |
| Tap Pad             | KICK, SNARE HEAD–AUX4 RIM, PREVIEW                                                                                                    | Selects the pad (or the [PREVIEW] button) to use to set the tap tempo.                                                                              |

\*1 This can't be changed while playing back a DRUM REC song (p. 118) or recorded data.

COACH

1. On the CLICK screen, press the [F5] (COACH) button.

The COACH screen appears.




2. Use the cursor buttons or the dial to select the mode that you want to set, and press the [ENTER] button.

| Mode           | Explanation                                                                                                                          |
|----------------|--------------------------------------------------------------------------------------------------------------------------------------|
| PHRASE TRAINER | This is a mode where you practice playing exactly along with the phrase.                                                             |
| TIME CHECK     | This mode is for checking how accurate your timing is when you're playing along with the click.                                      |
| QUIET COUNT    | This mode lets you practice maintaining the tempo.                                                                                   |
| AUTO UP/DOWN   | This mode lets you practice playing along with a changing tempo.                                                                     |
| STROKE MONITOR | This mode lets you practice playing the pads at a constant velocity, by checking how hard you strike the pads.                       |
| BLAST BEAST    | This mode lets you strike the pads as hard as possible and as fast as you can within 10 seconds, and then check how much you played. |


3. Practice in the mode that you selected.

PHRASE TRAINER




| Parameter  | Value           | Explanation                                                                                        |
|------------|-----------------|----------------------------------------------------------------------------------------------------|
| SELECT     |                 |                                                                                                    |
| CATEGORY   | Exercises       | Phrases suitable for practicing the basics.                                                        |
|            | Grooves & Fills | Phrases suitable for practicing grooves and fills.                                                 |
| SETUP      |                 |                                                                                                    |
| Score LED  | OFF, ON         | When this is "ON", the [KIT] button lights up according to the timing at which you strike the pad. |
| Score Mark | Type1-4         | Select a score mark design for displaying the practice results.                                    |

## TIME CHECK




| Parameter       | Value                                                                       | Explanation                                                                                                                            |
|-----------------|-----------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| <b>CLICK</b>    |                                                                             |                                                                                                                                        |
| Tempo           | 20.0–260.0                                                                  | Click tempo                                                                                                                            |
| <b>SETUP</b>    |                                                                             |                                                                                                                                        |
| Length          | 4, 8, 16, 32 meas, INF                                                      | Specifies the number of measures to practice.<br>When set to “INF”, the practice does not stop until you press the [F6] (STOP) button. |
| Difficulty      | EASY                                                                        | The standard level                                                                                                                     |
|                 | HARD                                                                        | The timing is checked more strictly.                                                                                                   |
| Pad 1–4         | Selects the type of pad used for practice.<br>You can set up to four types. |                                                                                                                                        |
| Graph Direction | BEHIND-AHEAD                                                                | The left side of the timing graph is shown as BEHIND (late).                                                                           |
|                 | AHEAD-BEHIND                                                                | The left side of the timing graph is shown as AHEAD (early).                                                                           |

## QUIET COUNT




| Parameter    | Value                                                                                                            | Explanation                                                                                                                              |
|--------------|------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
| <b>CLICK</b> |                                                                                                                  |                                                                                                                                          |
| Tempo        | 20.0–260.0                                                                                                       | Click tempo                                                                                                                              |
| <b>SETUP</b> |                                                                                                                  |                                                                                                                                          |
| Measures     | 2, 4, 8, 16                                                                                                      | Specify the length (measures) of the interval for which the click will alternate between “Sounding” and “Quiet”.                         |
| Quiet        | Of the measures specified by “Measures”, this setting specifies the length of the measures that will be “Quiet”. |                                                                                                                                          |
|              | RANDOM                                                                                                           | The length of the “Quiet” interval randomly changes each time.                                                                           |
|              | 1, 2, 4                                                                                                          | Specifies the length (number of measures) of the “Quiet” interval.<br>* This setting cannot be longer than half of the “Measures” value. |

## AUTO UP/DOWN




| Parameter             | Value                        | Explanation                                                                                                                                     |
|-----------------------|------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>CLICK</b>          |                              |                                                                                                                                                 |
| Tempo                 | 20.0–260.0                   | Click tempo                                                                                                                                     |
| <b>SETUP</b>          |                              |                                                                                                                                                 |
| Max Tempo             | 20.0–260.0                   | The maximum tempo<br>* You cannot set a value lower than the start tempo.                                                                       |
| Length                | Sets how the tempo changes.  |                                                                                                                                                 |
|                       | 1UP                          | The tempo changes from start tempo to maximum tempo.                                                                                            |
|                       | 1UP-DOWN                     | The tempo changes from start tempo to maximum tempo, and then back to the start tempo.                                                          |
|                       | 3UP-DOWN                     | The tempo changes from start tempo to maximum tempo and then back to the start tempo, and repeats this three times.                             |
|                       | INF                          | The tempo changes from start tempo to maximum tempo and then back to the start tempo, and repeats this until the [F6] (STOP) button is pressed. |
| Tempo Change Amount   | 1, 4, 5, 8, 10, 20           | Sets the amount by which the tempo changes.                                                                                                     |
| Tempo Change Interval | 2 beats, 1, 2, 4, 8, 16 meas | Sets the interval at which the tempo changes.                                                                                                   |

## STROKE MONITOR




| Parameter    | Value                              | Explanation |
|--------------|------------------------------------|-------------|
| <b>CLICK</b> |                                    |             |
| Tempo        | 20.0–260.0                         | Click tempo |
| <b>SETUP</b> |                                    |             |
| Pad          | Selects the pad used for practice. |             |

## BLAST BEAST




| Parameter    | Value                              | Explanation                                                             |
|--------------|------------------------------------|-------------------------------------------------------------------------|
| <b>SETUP</b> |                                    |                                                                         |
| Mode         | This selects the practice mode.    |                                                                         |
|              | POWER x SPEED                      | Practices the velocity (power) and speed with which you strike the pad. |
|              | SPEED                              | Practices the speed with which you strike the pad.                      |
| Pad          | Selects the pad used for practice. |                                                                         |

# ⌘ (Bluetooth)



| Parameter                      | Value         | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|--------------------------------|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>[F6] (Bluetooth) button</b> | OFF, ON       | Turns this unit's Bluetooth functionality on/off.                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>Bluetooth MIDI</b>          | OFF, ON       | Turns this unit's Bluetooth MIDI functionality on/off.<br>If this is ON, you can connect this unit with a Bluetooth MIDI-compatible app on your smartphone or other device.                                                                                                                                                                                                                                                                    |
| <b>Device ID</b>               | OFF, 1–99     | Sets the MIDI Device ID.<br>Set this to the number that's appended to the device name of this unit, as shown on your Bluetooth-connected smartphone. (Example; "V71 AUDIO 1", "V71 MIDI 1", etc.)<br>If you're using more than one of this unit in the same place, this is useful for identifying them.<br><br>* If you've changed the Device ID, the new setting takes effect when you press [F5] (SET DEVICE ID) button to save the setting. |
| <b>Bluetooth Audio Gain</b>    | 0, +6, +12 dB | Sets the Bluetooth audio input level.                                                                                                                                                                                                                                                                                                                                                                                                          |

## USER SAMPLE LIST



| Parameter                                                                                                                | Value                                                                                                                                                                            | Explanation                                                                                                         |
|--------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------|
| Play Type                                                                                                                | ONESHOT MONO                                                                                                                                                                     | When you strike the pad, the currently-heard sound is silenced before the new sound is heard. Notes do not overlap. |
|                                                                                                                          | ONESHOT POLY                                                                                                                                                                     | When you strike the pad repeatedly, the sounds of the notes are heard overlapping.                                  |
|                                                                                                                          | LOOP ALT                                                                                                                                                                         | The user sample plays repeatedly (loop). Each time you strike the pad, the sound alternately plays or stops.        |
| Sample Gain                                                                                                              | -12+12dB                                                                                                                                                                         | Adjusts the user sample volume.                                                                                     |
| EDIT tab                                                                                                                 |                                                                                                                                                                                  |                                                                                                                     |
| ZOOM                                                                                                                     | Zooms the waveform display in or out.                                                                                                                                            |                                                                                                                     |
| Start Point *1                                                                                                           | 0-07937742                                                                                                                                                                       | Adjusts the start point (the location at which the user sample starts playing).                                     |
| End Point *1                                                                                                             | 257-07937999                                                                                                                                                                     | Adjusts the end point (the location at which the user sample stops playing).                                        |
| RENAME                                                                                                                   | Press the [F6] (RENAME) button to edit the name of the user sample.<br><div>MEMO</div><br>For details on how to edit the name, refer to the “Reference Manual” (Roland website). |                                                                                                                     |
| RENUMBER-IMPORT                                                                                                          |                                                                                                                                                                                  |                                                                                                                     |
| <div>MEMO</div><br>For details on the respective parameter operations, refer to the “Reference Manual” (Roland website). |                                                                                                                                                                                  |                                                                                                                     |

- \*1 You can't set the end point earlier than the start point.  
 You can't set the start point and end point to the same value.  
 For both the start point and end point, you can't specify a value that exceeds the length of the user sample.

# BACKUP

## SAVE

| Parameter         | Value                                                                                                                                    | Explanation                                      |
|-------------------|------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------|
| Backup Number     | 1–99                                                                                                                                     | Selects the backup number.                       |
| With User Samples | OFF, ON                                                                                                                                  | Selects whether user samples are also backed up. |
| Backup Name       | Adds a name to the backup data.<br><b>MEMO</b><br>For details on how to edit the name, refer to the “Reference Manual” (Roland website). |                                                  |

## LOAD

| Parameter                       | Value   | Explanation                                                                                                                                    |
|---------------------------------|---------|------------------------------------------------------------------------------------------------------------------------------------------------|
| Backup Number                   | 1–99    | Selects the backup number.                                                                                                                     |
| With User Samples               | OFF, ON | Selects whether user samples are also loaded.                                                                                                  |
| With Instrument Expansion Slots | OFF, ON | Selects whether to load the Instrument Expansions.<br>* You can't load Instrument Expansions into a slot if they aren't installed in the rack. |

## DELETE

| Parameter     | Value | Explanation              |
|---------------|-------|--------------------------|
| Backup Number | 1–99  | Deletes the backup data. |

## SAVE 1 KIT

| Parameter         | Value   | Explanation                                      |
|-------------------|---------|--------------------------------------------------|
| Backup Kit        | 1–200   | Select the drum kit that you want to back up.    |
| With User Samples | OFF, ON | Selects whether user samples are also backed up. |
| Backup Number     | 1–999   | Selects the backup number.                       |

## LOAD 1 KIT

| Parameter         | Value   | Explanation                                      |
|-------------------|---------|--------------------------------------------------|
| Backup Number     | 1–999   | Selects the backup number.                       |
| With User Samples | OFF, ON | Selects whether user samples are also backed up. |
| Destination Kit   | 1–200   | Selects the load-destination drum kit.           |

## DELETE 1 KIT

| Parameter     | Value | Explanation                                            |
|---------------|-------|--------------------------------------------------------|
| Backup Number | 1–999 | Selects the kit backup number that you want to delete. |


## INFO

| Parameter | Explanation                     |
|-----------|---------------------------------|
| ALL       | Number of saved backup data     |
| 1 KIT     | Number of saved kit backup data |

# SETUP

## 1. Press the [SETUP] button.

The SETUP MENU screen appears.



## 2. Use the cursor buttons or the dial to select the menu that you want to edit, and press the [ENTER] button.

| Setup menu    | Explanation                                                                             | Page  |
|---------------|-----------------------------------------------------------------------------------------|-------|
| Wi-Fi         | Lets you connect the V71 to the Roland Cloud Connect app via Wi-Fi.                     | p. 44 |
| OUTPUT        | Specifies the output destination of the sounds.                                         | p. 45 |
| USB AUDIO     | Configures the USB audio.                                                               | p. 47 |
| SYSTEM INFO   | Used for checking how much memory is free on this unit, as well as the program version. | p. 49 |
| SYSTEM MIDI   | Configures the overall MIDI-related settings for the V71.                               | p. 49 |
| CONTROL SETUP | Assigns functions to the footswitch and pads.                                           | p. 52 |
| OPTION        | Configures the preview button, audio input, display, Auto Off and so on.                | p. 54 |
| FACTORY RESET | Restores the factory settings.                                                          | p. 55 |


## 3. Edit the settings of the menu that you selected.

### MEMO

For details on operations in the setup menu, refer to "Reference Manual" (Roland website).


## Wi-Fi

\* Please be aware that in some countries or regions, it might not be possible to use the Wi-Fi function.




| Parameter            | Value                                                                                                                                                                                                                                                                                    | Explanation                                                                |
|----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------|
| Time Zone            | UTC-12:00--+14:00                                                                                                                                                                                                                                                                        | Time zone setting<br>Set this according to the region in which you reside. |
| [F1] (RESET) button  | Resets the Wi-Fi settings.<br>Reset the settings when you want to reconfigure or set a different Wi-Fi access point.<br><b>MEMO</b><br>You can configure the Wi-Fi settings from the Roland Cloud Connect app by pressing the [F1] (SETUP) button while holding down the [SHIFT] button. |                                                                            |
| [F2] (MANUAL) button | Shows a screen with a 2D code that gives you easy access to the V71 Web page and support page.                                                                                                                                                                                           |                                                                            |
| [F6] (Wi-Fi) button  | OFF, ON                                                                                                                                                                                                                                                                                  | Lets you connect the V71 to the Roland Cloud Connect app via Wi-Fi.        |

# OUTPUT



| Parameter                     | Value                                                                                                         | Explanation                                                                                                                                                                                       |
|-------------------------------|---------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>PAD MASTER tab</b>         |                                                                                                               |                                                                                                                                                                                                   |
| Pad Master Assign             | PHONES (MASTER OFF),<br>PHONES+MASTER LR                                                                      | Specifies each pad's output assignments for the PHONES jacks and MASTER OUT jacks (when OUTPUT ROUTING Master Output Mode is set to "NORMAL").                                                    |
| <b>PAD DIRECT tab</b>         |                                                                                                               |                                                                                                                                                                                                   |
| Pad Direct Assign             | OFF, 1, 2, 1-2, 3, 4, 3-4, 5, 6,<br>5-6, 7, 8, 7-8, MASTER DIRECT<br>L, MASTER DIRECT R, MASTER<br>DIRECT L+R | Specifies each pad's output assignments for the DIRECT OUT 1-8 jacks and MASTER OUT jacks (when OUTPUT ROUTING Master Output Mode is set to "DIRECT").                                            |
| <b>OTHER MST tab</b>          |                                                                                                               |                                                                                                                                                                                                   |
| OTHER OUTPUT ASSIGN<br>MASTER | PHONES (MASTER OFF),<br>PHONES+MASTER LR                                                                      | Specifies the output assignments for the PHONES and MASTER OUT jacks (when OUTPUT ROUTING Master Output Mode is set to "NORMAL") for the ambience, BUS FX, USB audio, songs and so forth.         |
| <b>OTHER DIR tab</b>          |                                                                                                               |                                                                                                                                                                                                   |
| OTHER OUTPUT ASSIGN<br>DIRECT | OFF, 1, 2, 1+2, 3, 4, 3+4, 5, 6,<br>5+6, 7, 8, 7+8, MASTER DIRECT<br>L, MASTER DIRECT R, MASTER<br>DIRECT L+R | Specifies the output assignments for the DIRECT OUT 1-8 and MASTER OUT jacks (when OUTPUT ROUTING Master Output Mode is set to "DIRECT") for the ambience, BUS FX, USB audio, songs and so forth. |
| <b>MONITOR tab</b>            |                                                                                                               |                                                                                                                                                                                                   |
| -                             | -                                                                                                             | Monitor the output volume of each jack.                                                                                                                                                           |


## OUTPUT ROUTING



| Parameter             | Value                                                                  | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-----------------------|------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>ROUTING tab</b>    |                                                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Master Output Mode *1 | MASTER, DIRECT                                                         | <p>Selects whether the output of the MASTER OUT jacks is the same signal as the DIRECT OUT jacks (DIRECT) or not (MASTER).</p> <ul style="list-style-type: none"> <li>If this is "DIRECT", the output of the MASTER OUT jacks is not affected by the master compressor and master EQ, allowing you to use the MASTER OUT jacks as DIRECT OUT jacks (the setting of the [MASTER] knob does apply). This setting also applies to the USB audio output to your computer.</li> <li>The PHONES jacks output the sound processed by the master compressor and master EQ.</li> <li>If you want the output of the MASTER OUT jacks to be output as direct output, assign the output to MASTER DIRECT in the PAD OUTPUT screen (DIRECT tab) and the OTHER OUTPUT screen (DIRECT tab).</li> </ul> |
| Faders to Direct      | OFF, ON                                                                | <p>Specifies whether the fader values are applied to the output from the DIRECT OUT jacks (ON) or are not applied (OFF).</p> <ul style="list-style-type: none"> <li>If this is "OFF", the output from the DIRECT OUT jacks is not affected by the panel faders. If the OUTPUT ROUTING Master Out is "DIRECT", and Faders to Direct is "OFF", the output from the MASTER OUT jacks is also unaffected by the panel faders. Regardless of the Faders to Direct setting, the output from the PHONES jacks is always affected by the panel faders.</li> <li>This means that the faders at hand can be used to adjust the balance of the sound monitored by the performer, independently of the balance adjusted by the PA.</li> </ul>                                                       |
| Group Faders Sw       | OFF, ON                                                                | <p>Sets whether to enable (ON) or disable (OFF) the panel faders.</p> <p>When set to "OFF", this sets the adjustable volumes of the faders to a fixed value of 0 dB, regardless of the current fader settings on the panel. This is useful when you want to keep all the volumes at a fixed level, such as for preserving the volume balance using a mixer and so forth.</p>                                                                                                                                                                                                                                                                                                                                                                                                            |
| <b>LOW CUT tab</b>    |                                                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Low Cut Freq          | 20Hz, 25Hz, 31.5Hz, 40Hz, 50Hz, 63Hz, 80Hz, 100Hz, 125Hz, 160Hz, 200Hz | <p>Cuts the frequency region below the specified frequency (low cut). This setting is common to all output jacks.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Master Low Cut        | OFF, ON                                                                | Specifies whether low cut is applied (ON) or is not applied (OFF) to the sound that is output from the MASTER OUT jacks.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| Phones Low Cut        | OFF, ON                                                                | Specifies whether low cut is applied (ON) or is not applied (OFF) to the sound that is output from the PHONES jacks.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Direct Low Cut        | OFF, ON                                                                | Specifies whether low cut is applied (ON) or is not applied (OFF) to the sound that is output from the DIRECT OUT jacks.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| <b>DIRECT ATT tab</b> |                                                                        |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Direct Out Att        | -12, -6, 0dB                                                           | <p>Lowers the volume of the DIRECT OUT jacks (attenuator).</p> <p>This lets you decrease the volume if the output of the V71 is too high, causing distortion on the device that receives these signals. This applies to all DIRECT OUT jacks.</p> <p>If Master Out is set to "DIRECT", this also applies to the output from the MASTER OUT jacks.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                   |

\*1 This also applies to the V71's sound that is output via USB audio.

# USB AUDIO



| Parameter                                           | Value                                                                                             | Explanation                                                                                                                                                                                                                                         |
|-----------------------------------------------------|---------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>ROUTING tab</b>                                  |                                                                                                   |                                                                                                                                                                                                                                                     |
| Driver Mode                                         | Switches between the V71's dedicated USB driver and the driver provided by your operating system. |                                                                                                                                                                                                                                                     |
|                                                     | <b>MEMO</b>                                                                                       | After you change this setting, it is enabled once you restart the V71.                                                                                                                                                                              |
|                                                     | GENERIC                                                                                           | Use the driver provided by the operating system. USB MIDI and USB audio (2 ch. recording and playback) can be used.                                                                                                                                 |
|                                                     | VENDOR                                                                                            | Use the V71's dedicated driver provided by Roland. USB MIDI and USB audio (32 ch. recording and playback) can be used.                                                                                                                              |
| USB Audio Input Gain                                | -36--+12dB                                                                                        | Adjusts the input level<br>This setting is common to Input MAIN and SUB.                                                                                                                                                                            |
| USB Audio Output Gain                               | -24--+24 dB                                                                                       | Adjusts the output level<br>This setting is common to all outputs.                                                                                                                                                                                  |
| Volume Select Input MAIN<br>Volume Select Input SUB | Specifies the knob that adjusts the input volume of USB audio (Input MAIN, SUB).                  |                                                                                                                                                                                                                                                     |
|                                                     | OFF                                                                                               | The volume is not adjusted by a knob.                                                                                                                                                                                                               |
|                                                     | SONG                                                                                              | The [SONG] knob adjusts the volume.                                                                                                                                                                                                                 |
|                                                     | CLICK                                                                                             | The [CLICK] knob adjusts the volume.                                                                                                                                                                                                                |
| Audio Routing                                       | NORMAL                                                                                            | This routing is used for typical purposes. Normally, you should use this setting (the PAD DIRECT IN audio is muted).                                                                                                                                |
|                                                     | PAD DIRECT IN                                                                                     | Lets you directly input the USB AUDIO output from your computer to the mixer for each pad. To avoid accidents due to loopback with this setting, the USB AUDIO output from the V71 to your computer is muted (all output to the computer is muted). |
|                                                     | LOOPBACK                                                                                          | Enables all USB AUDIO input/output.<br><b>* Be careful, as the USB audio input and output may be directly connected and inadvertently result in a very loud sound, depending on the settings of your computer and the V71.</b>                      |
| <b>MONITOR tab</b>                                  |                                                                                                   |                                                                                                                                                                                                                                                     |
| —                                                   | Monitor the output volume of each jack.                                                           |                                                                                                                                                                                                                                                     |

## Configuring the routing for USB audio (Audio Routing)

This shows you how to configure the routing for the USB audio input/output.


Use this to directly input the sound from your computer to the pads of the V71, or to limit the sounds sent from the V71 to your computer.

The standard setting is "NORMAL".

### MEMO

This is enabled when the Driver Mode is "VENDOR".


## NORMAL



V71 → PC: MASTER OUT, DIRECT OUT 1–8, direct output of each pad


PC → V71: MAIN, SUB

PAD DIRECT IN



V71 → PC: All USB audio output from the V71 is muted.  
PC → V71: MAIN, SUB, direct input to each pad

LOOPBACK



V71 → PC: MASTER OUT, DIRECT OUT 1–8, direct output of each pad  
PC → V71: MAIN, SUB, direct input to each pad

\* A dialog box appears when you use the “LOOPBACK” setting.

NOTE

When using the loopback setting, the USB audio input and output may connect directly and inadvertently produce a very loud sound, depending on the settings of your computer and the . For this reason, use caution with this setting.

Audio routing I/O chart

|                           | Audio Routing |               |          |
|---------------------------|---------------|---------------|----------|
|                           | NORMAL        | PAD DIRECT IN | LOOPBACK |
| V71 Ó PC                  |               |               |          |
| MASTER OUT                | ✓             | mute          | ✓        |
| DIRECT OUT                | ✓             | mute          | ✓        |
| Direct output of each pad | ✓             | mute          | ✓        |
| PC V71ÓV71                |               |               |          |
| INPUT MAIN/SUB            | ✓             | ✓             | ✓        |
| PAD DIRECT IN             | mute          | ✓             | ✓        |


USB audio input destination settings

|         |       |         |        |         |      |
|---------|-------|---------|--------|---------|------|
| Ch1-2   | MAIN  | Ch13-14 | TOM3   | Ch25-26 | AUX1 |
| Ch3-4   | SUB   | Ch15-16 | TOM4   | Ch27-28 | AUX2 |
| Ch5-6   | KICK  | Ch17-18 | HI-HAT | Ch29-30 | AUX3 |
| Ch7-8   | SNARE | Ch19-20 | CRASH1 | Ch31-32 | AUX4 |
| Ch9-10  | TOM1  | Ch21-22 | CRASH2 |         |      |
| Ch11-12 | TOM2  | Ch23-24 | RIDE   |         |      |

USB audio output destination settings


|       |          |         |          |         |         |
|-------|----------|---------|----------|---------|---------|
| Ch1-2 | MASTER   | Ch9     | DIRECT 7 | Ch21-22 | TOM4    |
| Ch3   | DIRECT 1 | Ch10    | DIRECT 8 | Ch23-24 | HI-HAT  |
| Ch4   | DIRECT 2 | Ch11-12 | KICK     | Ch25-26 | CRASH1  |
| Ch5   | DIRECT 3 | Ch13-14 | SNARE    | Ch27-28 | CRASH2  |
| Ch6   | DIRECT 4 | Ch15-16 | TOM1     | Ch29-30 | RIDE    |
| Ch7   | DIRECT 5 | Ch17-18 | TOM2     | Ch31-32 | AUX     |
| Ch8   | DIRECT 6 | Ch19-20 | TOM3     |         | 1/2/3/4 |

## SYSTEM INFO



| Parameter           | Value                                                                                                                                                                                                                                                                                                                                                            | Explanation |
|---------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|
| <b>VERSION tab</b>  |                                                                                                                                                                                                                                                                                                                                                                  |             |
| Program Version     | <p>Program version</p> <p>If you select the “Pop-up Notification for Updates” check box, a pop-up notification appears when the program is updated (only when connected to Wi-Fi).</p> <p><b>MEMO</b></p> <p>Press the [F6] (MANUAL) button to display a 2D code that you can scan with your smartphone for easy access to the V71 website and support page.</p> |             |
| <b>SAMPLE tab</b>   |                                                                                                                                                                                                                                                                                                                                                                  |             |
| Remaining Memory    | Remaining amount for user samples in user memory                                                                                                                                                                                                                                                                                                                 |             |
| Imported Samples    | Number of imported user samples                                                                                                                                                                                                                                                                                                                                  |             |
| <b>SD CARD tab</b>  |                                                                                                                                                                                                                                                                                                                                                                  |             |
| All                 | Backup data saved on the SD card (all settings)                                                                                                                                                                                                                                                                                                                  |             |
| 1 KIT               | Kit backup data saved on the SD card                                                                                                                                                                                                                                                                                                                             |             |
| <b>DIGITAL tab</b>  |                                                                                                                                                                                                                                                                                                                                                                  |             |
| Pad                 | Indicates the digitally-connected pads that are connected to the V71.                                                                                                                                                                                                                                                                                            |             |
| Program Version     | Indicates the program version of digitally-connected pads that are connected to the V71.                                                                                                                                                                                                                                                                         |             |
| Status              | <p>Shows whether the pads that are digitally connected to the V71 need to be updated or not.</p> <p>If you’ve digitally connected a pad that uses an earlier firmware version, you should update that pad.</p> <p><b>MEMO</b></p> <p>For details on how to update the pad, refer to “Reference Manual” (Roland website).</p>                                     |             |
| <b>LICENSES tab</b> |                                                                                                                                                                                                                                                                                                                                                                  |             |
| –                   | Shows the license information for the technologies used on the V71.                                                                                                                                                                                                                                                                                              |             |

## SYSTEM MIDI



| Parameter           | Value         | Explanation                                                                                                                                                                                                                |
|---------------------|---------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>BASIC tab</b>    |               |                                                                                                                                                                                                                            |
| MIDI Tx/Rx Sw       | OFF, ON       | Turns the transmitting and receiving MIDI messages on/off.                                                                                                                                                                 |
| Global MIDI Channel | 1–16Ch        | Transmit and receive channel.                                                                                                                                                                                              |
| Program Change Tx   | OFF, ON       | Turns program change transmission on/off.                                                                                                                                                                                  |
| Program Change Rx   | OFF, ON       | Turns program change reception on/off.                                                                                                                                                                                     |
| Soft Thru MIDI In   |               | This allows performance data from a MIDI device connected to the V71’s MIDI IN connector to be transmitted to another MIDI device connected to the MIDI OUT connector or to a computer connected to the USB COMPUTER port. |
|                     | OFF           | Performance data received from the V71’s MIDI IN connector will not be sent to the MIDI OUT connector or the USB COMPUTER port.                                                                                            |
|                     | ON (MIDI OUT) | Performance data received from the V71’s MIDI IN connector will be sent to the MIDI OUT connector.                                                                                                                         |
|                     | ON (USB MIDI) | Performance data received from the device connected to the V71’s MIDI IN connector will be sent to the USB COMPUTER port.                                                                                                  |
|                     | ON (MIDI+USB) | Performance data received from the device connected to the V71’s MIDI IN connector will be sent to the MIDI OUT connector and the USB COMPUTER port.                                                                       |


| Parameter              | Value                                                                                                                                                                              | Explanation                                                                                                                                                                                                                                                                                                                         |
|------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Soft Thru USB MIDI In  |                                                                                                                                                                                    | Performance data from a computer connected to the V71's USB COMPUTER port can be transmitted to a MIDI device connected to the MIDI OUT connector.                                                                                                                                                                                  |
|                        | OFF                                                                                                                                                                                | Performance data received via the V71's USB COMPUTER port is not transmitted to the MIDI OUT connector.                                                                                                                                                                                                                             |
|                        | ON                                                                                                                                                                                 | Performance data received via the V71's USB COMPUTER port is transmitted to the MIDI OUT connector.                                                                                                                                                                                                                                 |
| Local Control          | OFF, ON                                                                                                                                                                            | Turns on/off the connection between the performance data from the pads and the V71's sound generator section<br>Normally you'll leave this "ON". If this is "OFF", the performance data from the pads is not connected to the V71's sound generator section.                                                                        |
| Device ID              | 17–32                                                                                                                                                                              | Device ID setting<br>The setting described here is necessary only when you wish to transmit separate data to two or more V71 units at the same time. Do not change this setting in any other case.                                                                                                                                  |
| Transmit Edit Data     | OFF, ON                                                                                                                                                                            | Specifies whether changes in the 's settings are transmitted as system exclusive messages (ON) or not transmitted (OFF).                                                                                                                                                                                                            |
| Receive Exclusive      | OFF, ON                                                                                                                                                                            | Specifies whether system exclusive messages are received (ON) or not received (OFF).                                                                                                                                                                                                                                                |
| <b>CONTROL tab</b>     |                                                                                                                                                                                    |                                                                                                                                                                                                                                                                                                                                     |
| Hi-Hat Pedal CC        | OFF, MODULATION (1), BREATH (2), FOOT (4), EXPRESSION (11), GENERAL1 (16), GENERAL2 (17), GENERAL3 (18), GENERAL4 (19), GENERAL5 (80), GENERAL6 (81), GENERAL7 (82), GENERAL8 (83) | Control change used for transmitting/receiving the depth to which the hi-hat pedal pressed                                                                                                                                                                                                                                          |
| Snare CC               |                                                                                                                                                                                    | Control change message that's transmitted/received for the strike position (from the center to the outer rim) of the snare                                                                                                                                                                                                          |
| Snare Angle CC         |                                                                                                                                                                                    | Control change message that's transmitted/received for the strike position (angle) of the snare, when connected to the PD-140DS or PD-14DSX                                                                                                                                                                                         |
| Snare Strainer CC      |                                                                                                                                                                                    | Control change message that's transmitted/received when the PD-14DSX is connected and the strainer lever is raised or lowered                                                                                                                                                                                                       |
| Ride CC                |                                                                                                                                                                                    | Control change message that's transmitted/received for the strike position of the ride (from center to front)                                                                                                                                                                                                                       |
| Ride LR CC             |                                                                                                                                                                                    | Control change used for transmitting/receiving the ride strike position (left-right) when connected to the CY-18DR                                                                                                                                                                                                                  |
| Toms/AUXs CC           |                                                                                                                                                                                    | Control change used for transmitting/receiving the strike position of the tom 1–4 and AUX 1–4                                                                                                                                                                                                                                       |
| Hi-Hat CC              |                                                                                                                                                                                    | Control change used for transmitting/receiving the hi-hat strike position (from center to front) when connected to the VH-14D                                                                                                                                                                                                       |
| Hi-Hat LR CC           | 0–127                                                                                                                                                                              | Control change used for transmitting/receiving the hi-hat strike position (left-right) when connected to the VH-14D                                                                                                                                                                                                                 |
| HH Note# Border        |                                                                                                                                                                                    | This number specifies the pedal position at which to switch from open hi-hat to closed hi-hat.<br><br>* There's no need to change this setting if you're performed and recording only with the V71 and the pads.                                                                                                                    |
| Hi-Resolution Velocity |                                                                                                                                                                                    | The setting for CC#88 (high-resolution velocity prefix).<br>If this is enabled, the velocity is output at high resolution (1.00–127.00) when you strike a pad that's connected digitally.<br>If this is disabled, digitally-connected pads use the same resolution (1–127) as the pads that are connected via the TRIGGER IN jacks. |
| Cymbal Choke Shot      | OFF, ON                                                                                                                                                                            | Switches support for the performance technique of striking a pad while choking it.<br>If this is "ON", striking a pad while choking it immediately mutes the sound after it begins. If this is "OFF", the sound is not muted immediately even if you strike a pad while choking it.                                                 |
| [F6] (DEFAULT) button  | You can press the [F6] (DEFAULT) button to revert the CC settings to their default values.                                                                                         |                                                                                                                                                                                                                                                                                                                                     |

| Parameter           | Value                  | Explanation                                                                                                                                                                                               |
|---------------------|------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>SYNC tab</b>     |                        |                                                                                                                                                                                                           |
| Sync Mode           | INTERNAL               | Choose this setting if you're using the V71 by itself without synchronizing it to another device, or if you want another device to operate in synchronization with the V71.                               |
|                     | EXTERNAL               | Choose this setting if you want the V71 to operate according to synchronization messages that it receives from another device.                                                                            |
| Clock Source        | MIDI, USB MIDI         | When Sync Mode is "EXTERNAL", this specifies whether the synchronizes to synchronization messages from the MIDI IN connector (MIDI) or to synchronization messages from the USB COMPUTER port (USB MIDI). |
| Sync Out            | OFF, ON                | Specifies whether MIDI synchronization messages are transmitted to another device (ON) or not transmitted (OFF).                                                                                          |
| <b>PROG CHG tab</b> |                        |                                                                                                                                                                                                           |
| MIDI Program Change | Bank0–PC0, Bank1–PC127 | You can freely specify the correspondence between drum kits and the program change numbers that are transmitted and received.                                                                             |

## Using the Local Control setting

If you're using a DAW with the performance data from the pads and V71's sound generator section, you should turn the Local Control "OFF".

This is because we need to connect these sections in the following order: the performance data from the pads → your DAW → the V71's sound generator. Since the performance data from the pads and V71's sound generator are connected internally, such a connection order is normally impossible. However, if the Local Control is "OFF", the performance data from the pads and V71's sound generator section will be independent, allowing you to use a DAW as shown here in the illustration.



## Specifying the HH Note# Border


The note number transmitted when you strike the hi-hat will change depending on the amount of pressure on the hi-hat pedal.



At the factory default value (127), the closed hi-hat note number will be transmitted only if the hi-hat pad is played with the pedal completely depressed.

If you want this note number to be transmitted when the pedal is slightly raised, set this to a value such as "90".

\* In some cases, changing the hi-hat note number border setting might cause a song to play back differently than when it was recorded.

CONTROL SETUP



| Parameter                                           | Value                                                            | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-----------------------------------------------------|------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FOOT SW tab                                         |                                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Foot Switch 1 Func(SW1),<br>Foot Switch 2 Func(SW2) | → "Functions that you can assign to a footswitch or pad" (p. 53) | <p>Assigns a function to a footswitch (separately sold: BOSS FS-5U, FS-6) connected to the V71.</p> <p><b>Connecting an FS-5U</b></p>  <p>* If you use a mono cable to connect a single FS-5U, it will operate as SW 2.</p> <p>* The FS-5L cannot be used.</p> <p><b>Connecting an FS-6</b></p>  |
| PAD CTRL tab                                        |                                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Aux3 Head Func,<br>Aux3 Rim Func                    | → "Functions that you can assign to a footswitch or pad" (p. 53) | Assigns functions to a pad connected to TRIGGER IN jack 13/AUX3. You can assign separate functions to the head and to the rim.                                                                                                                                                                                                                                                                                                                                          |
| Aux4 Head Func,<br>Aux4 Rim Func                    |                                                                  | Assigns functions to a pad connected to TRIGGER IN jack 14/AUX4. You can assign separate functions to the head and to the rim.                                                                                                                                                                                                                                                                                                                                          |


## Functions that you can assign to a footswitch or pad







| Value                     | Explanation                                                                                                |
|---------------------------|------------------------------------------------------------------------------------------------------------|
| OFF                       | No function is assigned.                                                                                   |
| KIT# INC                  | Calls up the previous kit.                                                                                 |
| KIT# DEC                  | Calls up the next kit.                                                                                     |
| SET LIST# INC             | Calls up the previous set list.                                                                            |
| SET LIST# DEC             | Calls up the previous set list.                                                                            |
| SONG# INC                 | Calls up the previous song.                                                                                |
| SONG# DEC                 | Calls up the next song.                                                                                    |
| SONG PLAY                 | Play the song.                                                                                             |
| SONG STOP                 | Stop the song.                                                                                             |
| SONG TOP                  | Return to the beginning of the song.                                                                       |
| SONG PLAY/STOP            | Play/stop the song.                                                                                        |
| SONG AB REPEAT            | Specifies A-B repeat.                                                                                      |
| Bluetooth# INC *1         | Recalls the next song on a smartphone connected via Bluetooth.                                             |
| Bluetooth# DEC *1         | Recalls the previous song on a smartphone connected via Bluetooth.                                         |
| Bluetooth PLAY *1         | Plays the current song on your smartphone connected via Bluetooth.                                         |
| Bluetooth STOP *1         | Stops the current song on your smartphone connected via Bluetooth.                                         |
| Bluetooth PLAY/STOP *1    | Plays/stops the current song on your smartphone connected via Bluetooth.                                   |
| CLICK PLAY                | Plays the click.                                                                                           |
| CLICK STOP                | Stops the click.                                                                                           |
| CLICK PLAY/STOP           | Plays/stops the click.                                                                                     |
| BUS-A FX1 ON/OFF          | Switches BUS A FX 1 on/off.                                                                                |
| BUS-A FX2 ON/OFF          | Switches BUS A FX 2 on/off.                                                                                |
| BUS-B FX1 ON/OFF          | Switches BUS B FX 1 on/off.                                                                                |
| BUS-B FX2 ON/OFF          | Switches BUS B FX 2 on/off.                                                                                |
| BUS-C FX1 ON/OFF          | Switches BUS C FX 1 on/off.                                                                                |
| BUS-C FX2 ON/OFF          | Switches BUS C FX 2 on/off.                                                                                |
| BUS-D FX1 ON/OFF          | Switches BUS D FX 1 on/off.                                                                                |
| BUS-D FX2 ON/OFF          | Switches BUS D FX 2 on/off.                                                                                |
| OVERHEAD ON/OFF           | Turns the overhead sound on/off.                                                                           |
| ROOM ON/OFF               | Turns the room sound on/off.                                                                               |
| KIT REVERB ON/OFF         | Turns reverb on/off.                                                                                       |
| KIT RESONANCE ON/OFF      | Turns the kit resonance on/off.                                                                            |
| BUS REVERB ON/OFF         | Turns bus reverb on/off.                                                                                   |
| ANALOG XSTICK ON/OFF      | Turns the cross stick playing on/off for the snare pad that's connected to the respective TRIGGER IN jack. |
| FIXED HI-HAT CLOSE/NORMAL | Switches the "Fixed" (p. 7) setting of the hi-hat to "CLOSE" or not.                                       |
| SNARE WIRE SOUND ON/OFF   | Sets whether the Strainer Adjust (p. 6) parameter for the snare is turned off or not.                      |
| ALL SOUND OFF             | Stops the currently-sounding drum performance sound or user sample playback.                               |
| KIT SOUND MUTE *2         | Mutes all drum kits sounds while the footswitch is pressed.                                                |

\*1 Some smartphones and music playback apps may not let you control the song from the V71.

\*2 This can only be selected for FOOT SWITCH 1/2 FUNC.

## OPTION




| Parameter                  | Value                                                                                                                           | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|----------------------------|---------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>PREVIEW tab</b>         |                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| <b>Preview Mode</b>        | This shows the steps for configuring how the preview sounds when you press the [HEAD PREVIEW] button or [RIM] (PREVIEW) button. |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|                            | NORMAL                                                                                                                          | The volume changes in response to how hard you press the buttons. You can adjust the sensitivity and curve.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|                            | FIXED                                                                                                                           | The volume remains the same regardless of how hard you press the buttons.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|                            | PREVIEW OFF                                                                                                                     | Turns the preview off (no sound is heard even when you press the buttons). This is useful when you want to prevent the unit from accidentally operating when onstage, or when you don't want the V71 to accidentally operate when exposed to strong impact.                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| <b>Velocity</b>            | 1–127                                                                                                                           | Velocity when Preview Mode is set to “FIXED”                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| <b>Head Sensitivity *1</b> | 1.0–32.0                                                                                                                        | Specifies the sensitivity when the [HEAD PREVIEW] button is pressed.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| <b>Rim Sensitivity *1</b>  | 1.0–32.0                                                                                                                        | Specifies the sensitivity when the [RIM] (PREVIEW) button is pressed.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| <b>Curve *1</b>            | Volume change in response to pad strike strength                                                                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|                            | LINEAR1, LINEAR2                                                                                                                |  <p>The standard setting. This produces the most natural correspondence between playing dynamics and volume change. The “LINEAR2” setting is useful when you want to generate greater velocities.</p>                                                                                                                                                                                                                                                                                                                                                                                                                             |
|                            | EXP1, EXP2                                                                                                                      |  <p>Compared to “LINEAR”, strong dynamics produce a greater change.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|                            | LOG1, LOG2                                                                                                                      |  <p>Compared to “LINEAR”, a soft playing produces a greater change.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|                            | SPLINE                                                                                                                          |  <p>Extreme changes are made in response to playing dynamics.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|                            | LOUD1, LOUD2                                                                                                                    |  <p>Very little dynamic response, making it easy to maintain strong volume levels. If you're using a drum trigger as an external pad, these settings will produce reliable triggering.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| <b>Threshold *1</b>        | 0–31                                                                                                                            | <p>Minimum sensitivity of preview button</p> <p>This setting allows a trigger signal to be received only when the pad is above a determined force level (velocity). This can be used to prevent the preview button from being activated due to vibrations from other pads. In the following example, B will sound but A and C will not sound.</p>  <p>Check this by gradually increasing the threshold value while pressing the preview button. If the sound cuts out when you press the preview button more softly, lower the value a little. Repeat this process until you get the perfect setting for your playing style.</p> |

| Parameter            | Value                                                                                                                                                               | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
|----------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| AUDIO IN tab         |                                                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Mix In Gain          | 0, +6, +12 dB                                                                                                                                                       | Set the volume for the MIX IN jack.                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Bluetooth Audio Gain |                                                                                                                                                                     | Sets the Bluetooth audio volume.                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| LCD/LED tab          |                                                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| LCD Brightness       | 1–16                                                                                                                                                                | Display brightness                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| LED Brightness       | 0–15                                                                                                                                                                | Brightness of the buttons ([KIT] button, [–] [+] button, [HEAD PREVIEW] button, [RIM] (PREVIEW) button), dial and strainer indicator                                                                                                                                                                                                                                                                                                                                                       |
| KIT VIEW tab         |                                                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Kit Image            | OFF, ON, GLOBAL                                                                                                                                                     | <p>Configures the background for the KIT screen.</p> <p>You can import your own image file from an SD card or from the V71 Editor into the V71, and use it as the background image for the KIT screen. This is useful when you want to make your own drum kits easier to select.</p> <p>When this is “OFF”, no background image is shown for the KIT screen. To set the view for all KIT screen backgrounds as a common setting that applies to the V71 overall, set this to “GLOBAL”.</p> |
| Kit Name Size        | SMALL, MEDIUM, LARGE, GLOBAL                                                                                                                                        | <p>Configures the text size for the KIT screen.</p> <p>To set the text size for all KIT screens as a common setting that applies to the V71 overall, set this to “GLOBAL”.</p>                                                                                                                                                                                                                                                                                                             |
| AUTO OFF tab         |                                                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Auto Off             | Specifies whether the unit will turn off automatically after a certain time has elapsed. If you don't want the unit to turn off automatically, choose “OFF” setting |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|                      | OFF                                                                                                                                                                 | The power does not turn off automatically.                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|                      | 20 minutes                                                                                                                                                          | When 20 minutes have elapsed without any pad being struck or any operation being performed, the unit turns off automatically.                                                                                                                                                                                                                                                                                                                                                              |
|                      | 4 hours                                                                                                                                                             | When four hours have elapsed without any pad being struck or any operation being performed, the unit will turn off automatically.                                                                                                                                                                                                                                                                                                                                                          |
| KIT PHRASE tab       |                                                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Kit Phrase Play      | OFF, ON                                                                                                                                                             | Configures the kit phrase function. You can stop playback of the kit phrases in the KIT screen. If you don't want to trigger the kit phrases accidentally, such as when you're playing live, set this to “OFF”.                                                                                                                                                                                                                                                                            |

\*1 This is enabled if Preview Mode is “NORMAL”.

## FACTORY RESET



| Parameter     | Value                                                                                                                                                               | Explanation |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|
| Factory Reset | <p>Returns the V71 to its factory settings.</p> <p><b>MEMO</b></p> <p>For details on the factory reset operation, refer to “Reference Manual” (Roland website).</p> |             |

# TRIGGER


1. Press the [TRIGGER] button.
2. Press the [F1] (BANK) button.






The TRIGGER - BANK screen appears.



3. Use the [-] [+] buttons or the dial to specify the trigger bank.
4. Select the pad that you want to edit.
5. Use the [-] [+] buttons or the dial to specify the trigger type.
- \* You can't change the trigger type of a trigger input that's assigned to a pad that supports a digital connection.
6. Press the [KIT] button to return to the KIT screen.

| Parameter          | Value                                           | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|--------------------|-------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>BANK tab</b>    |                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Bank No.           | 1–16                                            | Trigger bank number                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Bank Name          | 16 characters                                   | Trigger bank name                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Global Sens        | LOW, NORMAL, HIGH                               | Adjusts the overall sensitivity for all pads. For a broader range of dynamic control, select "LOW". To play with a light touch, select "HIGH".<br>This setting is enabled for all trigger banks.                                                                                                                                                                                                                                                                                                                                                                                                             |
| <b>DIGITAL tab</b> |                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Pad Assign         | N/A, KICK–AUX4                                  | Specifies the trigger input to which a digitally-connected pad is assigned.<br>A digitally connected pad for which you select "N/A" is not used; the settings of the pad connected to the TRIGGER IN jack are applied.<br>* Only the VH-14D supports closed/open hi-hats assigned to [HI-HAT], out of all pads that support digital connectivity.                                                                                                                                                                                                                                                            |
| <b>BASIC tab</b>   |                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Trig Type          | For details, refer to "Trig Type list" (p. 60). | Specifies the model of pad (trigger type) that is connected to each trigger input.<br>Set this to "OFF" if no pads are connected to the TRIGGER IN jacks.<br>* You can't change the trigger type of a trigger input that's assigned to a pad that supports a digital connection.<br><b>MEMO</b><br>When you specify the trigger type, the trigger parameters (with the exception of certain parameters such as cross-stick cancel) are set to optimal values. These values are only general guidelines; you can make fine adjustments as appropriate according to how you attach the pad and how you use it. |
| Sensitivity        | 1.0–32.0                                        | You can adjust the sensitivity of the pads to accommodate your personal playing style.<br>Increasing this value increases the sensitivity, so that even soft strikes on the pad are sounded at high volume. Decreasing this value decreases the sensitivity, so that even strong strikes on the pad are sounded at low volume.                                                                                                                                                                                                                                                                               |
| Threshold          | 0–31                                            | Minimum sensitivity of the pad<br>This setting allows a trigger signal to be received only when the pad is above a determined force level (velocity). This can be used to prevent a pad from sounding because of vibrations from other pads. In the following example, B will sound but A and C will not sound.<br>Check this by gradually increasing the value while playing the pad. Check this and adjust accordingly. Repeat this process until you get the perfect setting for your playing style.                                                                                                      |



| Parameter            | Value                                                             | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|----------------------|-------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Curve                | Volume change in response to pad strike strength                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|                      | LINEAR                                                            |  <p>The standard setting. This produces the most natural correspondence between playing dynamics and volume change.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|                      | EXP1, EXP2                                                        |  <p>Compared to "LINEAR", strong dynamics produce a greater change.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|                      | LOG1, LOG2                                                        |  <p>Compared to "LINEAR", a soft playing produces a greater change.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|                      | SPLINE                                                            |  <p>Extreme changes are made in response to playing dynamics.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|                      | LOUD1, LOUD2                                                      |  <p>Very little dynamic response, making it easy to maintain strong volume levels. If you're using a drum trigger as an external pad, these settings will produce reliable triggering.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| Rim Gain             | 0–3.2                                                             | <p>Adjusts the balance between the force of striking the rim or edge and the loudness of the sound.</p> <p>If you increase this value, even soft strikes on the rim are sounded at high volume. If you decrease this value, even strong strikes on the rim are sounded at low volume. This is available for pads that support rim shots.</p>                                                                                                                                                                                                                                                                                                                                                                                                                |
| Head/Rim Adjust      | 0–80                                                              | <p>This setting specifies how easy it is to play a head shot or rim shot.</p> <p>If the rim sound is heard when you strike the head strongly, increase this value. If the head sound is heard when you play an open rim shot, decrease this value.</p> <p>If the head sound is heard when you softly play a rim shot, decrease this value.</p> <p><b>MEMO</b></p> <p>If the rim shot sound is heard when you play a head shot, or if a head shot sound is heard when you play a rim shot, make small changes to the Head/Rim Adjust values while you continue trying out the results. Extreme changes to the values will cause the wrong sound to be heard when you strike the pad, for example producing the rim shot sound when you play a head shot.</p> |
| HI-HAT tab           |                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Trig Type            | This is the same parameter as Trig Type (p. 56) in the BASIC tab. |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Offset *1, *2        | -100–+100                                                         | <p>Extent of opening Hi-Hat</p> <p>The bigger the value is, the wider the opening extent is.</p> <p><b>MEMO</b></p> <p>For details on how to adjust the offset, refer to "Configuring the hi-hat" in the Reference Manual. You can make fine adjustments to the hi-hat parameters as necessary.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Foot Splash Sens *1  | -10–+10                                                           | Amount of how easy to make the foot splash                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Noise Cancel *1, *2  | 1–3                                                               | <p>Amount of strength to cancel the bow and edge noise when you play foot close.</p> <p>The bigger the value is, the more difficult to have a noise excluding the foot close.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
| CC Max *1, *3        | 90, 127                                                           | <p>Amount of control change that is transmitted in stepping the hi-hat pedal down completely.</p> <p>* There's no need to change this setting if you're performed only with the V71 and the pads.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| Pressure Sens *1, *4 | 1–5                                                               | <p>Adjusts how the sound of the closed hi-hat changes according to how hard you press down on the pedal (the pressure used) while the pedal is closed.</p> <p>Larger values make the sound change more easily when you press down softly.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |

\*1 Digitally-connected pads aside from the VH-14D do not support hi-hat pedal playing.

\*2 Only if Trig Type is set to "VH-12", "VH-13", or "VH-14D".

\*3 Only if Trig Type is set to something other than "VH-12", "VH-13", or "VH-14D".


\*4 Only if Trig Type is set to "VH-14D".

## Making detailed settings for digitally-connected pads

### 1. Press the [TRIGGER] button.

### 2. Press the [F2] (DIGITAL) button.

The TRIGGER - DIGITAL PAD screen appears.



### 3. Use cursor buttons to select a parameter, and use the [-] [+] buttons or the dial to edit the value.


### 4. Press the [KIT] button to return to the KIT screen.



\* The parameters that can be set differ depending on the type of pad.

| Parameter           | Value    | Explanation                                                                                                                                                                                                                         |
|---------------------|----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Position Adjust     | 1–10     | Adjusts how the tonal character is affected by strike position. Lower values adjust toward the center, and higher values adjust toward the circumference.                                                                           |
| Position Adjust LR  | 1–10     | Adjusts how the tonal character is affected by the left-right strike position. Lower values adjust toward the center, and higher values adjust toward the circumference.                                                            |
| XStick Detect Sens  | OFF, 1–5 | Adjusts how easy it is to use cross-stick playing technique. If this is “OFF”, cross-stick technique is unavailable.                                                                                                                |
| Strainer Lever Sens | 1–5      | Configures the sensitivity for the operating sound of the strainer lever. Lower values produce a softer sound even if you operate the lever quickly, and higher values produce a louder sound even if you operate the lever slowly. |
| LED Brightness      | OFF, 1–5 | Adjusts the brightness of the strainer indicator. Decreasing this value makes the sound darker, and increasing this value makes the sound brighter.                                                                                 |
| Choke Sens          | OFF, 1–5 | Adjusts the sensitivity of choking technique. If this is “OFF”, choking technique is unavailable.                                                                                                                                   |
| Bell Gain           | 0–3.2    | Adjusts the balance between the force of a strike on the bell (bell shot technique) and the loudness of the sound. With higher values of this setting, a high volume can be produced even by a soft strike on the bell.             |

## ADVANCED

| Parameter    | Value     | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|--------------|-----------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ADVANCED tab |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Scan Time    | 0ms–4.0ms | <p>Trigger signal detection time</p> <p>Since the rise time of the trigger signal waveform may differ slightly depending on the characteristics of each pad or acoustic drum trigger (drum pickup), you may notice that identical hits (velocity) may produce sound at different volumes. If this occurs, you can adjust the “Scan Time” so that your way of playing can be detected more precisely.</p> <p>While repeatedly hitting the pad at a constant force, gradually raise the Scan Time value from 0 msec, until the resulting volume stabilizes at the loudest level. At this setting, try both soft and loud strikes, and make sure that the volume changes appropriately.</p> <p>* As the value is set higher, the time it takes for the sound to be played increases. Set this to the lowest value possible.</p> |



| Parameter            | Value    | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|----------------------|----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Mask Time            | 0ms–64ms | <p><b>Double triggering prevention</b></p> <p>When playing a kick trigger the beater can bounce back and hit the head a second time immediately after the intended note—with acoustic drums sometimes the beater stays against the head—this causes a single hit to “double trigger” (two sounds instead of one). The Mask Time setting helps to prevent this. Once a pad has been hit, any additional trigger signals occurring within the specified “Mask Time” will be ignored.</p> <p>Adjust the “Mask Time” value while playing the pad.</p> <p>When using a kick trigger, try to let the beater bounce back and hit the head very quickly, then raise the “Mask Time” value until there are no more sounds made by the beater rebound.</p> <p>Increasing this value makes it more likely that a note played in rapid succession will drop out. Set this to the lowest value possible.</p> <p><b>MEMO</b></p> <p>If two or more sounds are being produced when you strike the head just once, then adjust Retrigger Cancel.</p>                                                                                                                                                                                                                                                                                             |
| Retrigger Cancel     | 1–16     | <p><b>Detecting trigger signal attenuation</b></p> <p>Important if you are using acoustic drum triggers. Such triggers can produce altered waveforms, which may also cause inadvertent sounding at Point A in the following figure (Retrigger).</p> <p>This occurs in particular at the decaying edge of the waveform. Retrigger Cancel detects such distortion in and prevents retriggering from occurring.</p> <p>While repeatedly striking the pad, raise the “Retrigger Cancel” value until retriggering no longer occurs.</p> <p>Although setting this to a high value prevents retriggering, it then becomes easy for sounds to be omitted when the drums played fast (roll etc.). Set this to the lowest value possible while still ensuring that there is no retriggering.</p> <p><b>MEMO</b></p> <p>You can also eliminate this problem of retriggering with the Mask Time setting. Mask Time does not detect trigger signals if they occur within the specified amount of time after the previous trigger signal was received. Retrigger Cancel detects the attenuation of the trigger signal level, and triggers the sound after internally determining which trigger signals were actually generated when the head was struck, while weeding out the other false trigger signals that need not trigger a sound.</p>  |
| Position Detect Head | OFF, ON  | Turns head strike position detection on/off                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Position Detect Rim  | OFF, ON  | Turns rim strike position detection on/off                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
| ExtNoiseCancel       | OFF, 1–5 | <p>This setting lets you prevent a drum from being triggered unwantedly by a strike on a drum to which no drum trigger is attached, or by sound or vibration from the surroundings (noise cancellation).</p> <p>This noise cancel function can be used if you use a stereo cable to connect an “RT-30K” or “RT-30HR” drum trigger to the following TRIGGER IN jacks and specify the Trig Type.</p> <p>Supported TRIGGER IN jacks</p> <ul style="list-style-type: none"> <li>• KICK</li> <li>• SNARE</li> <li>• TOM1–4</li> <li>• AUX1–4</li> </ul> <p>* The “RT-30H” does not support the noise cancel function.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| XStick Threshold     | 0–127    | <p>For a pad that is connected to a TRIGGER IN jack, this specifies the force at which to switch between the cross stick sound and open rim shot sound.</p> <p>Setting this to a higher value makes it easier to get cross stick sounds. When set to “0”, playing a cross stick produces the open rim shot sound.</p> <p>For a digitally connected pad that allows cross stick technique, playing a cross stick with a strike that is stronger than the value of this setting produces the open rim shot sound.</p> <p>* For a pad that is connected to a TRIGGER IN jack, be aware that if this value is raised excessively, the cross stick sound will also be heard when you play an open rim shot.</p>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |

| Parameter         | Value                                                                                                                                                                          | Explanation                                                                                                                                    |
|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| TRIG MON tab      |                                                                                                                                                                                |                                                                                                                                                |
| –                 | This shows real-time information that shows the force (velocity) with which each pad is struck, as well as the strike points for the hi-hat, snare, ride cymbal, toms and AUX. |                                                                                                                                                |
| DrumLink tab      |                                                                                                                                                                                |                                                                                                                                                |
| –                 | This tab is for configuring the settings for V-Drums pads connected wirelessly or for DWe pads connected via a DrumLink™ hub (p. 61).                                          |                                                                                                                                                |
| XTALK tab         |                                                                                                                                                                                |                                                                                                                                                |
| XTalk Cancel Rate | 0–80                                                                                                                                                                           | Strength of crosstalk cancellation<br><div>MEMO</div> For details on how to make these settings, refer to “Reference Manual” (Roland website). |

## Trig Type list

| Used Pad | Trig Type | Rim Shot | Bell shot | Positional sensing |     | Choke play |
|----------|-----------|----------|-----------|--------------------|-----|------------|
|          |           |          |           | Head               | Rim |            |
| KD-A22   | KD-A22    | -        | -         | -                  | -   | -          |
| KD-22    | KD-22     | -        | -         | -                  | -   | -          |
| KD-222   | KD-222    | -        | -         | -                  | -   | -          |
| KD-220   | KD-220    | -        | -         | -                  | -   | -          |
| KD-200   | KD-200    | -        | -         | -                  | -   | -          |
| KD-20    | KD-20     | -        | -         | -                  | -   | -          |
| KD-18    | KD-18     | -        | -         | -                  | -   | -          |
| KD-180   | KD-180    | -        | -         | -                  | -   | -          |
| KD-180L  | KD-180L   | -        | -         | -                  | -   | -          |
| KD-140   | KD-140    | -        | -         | -                  | -   | -          |
| KD-12    | KD-12     | -        | -         | -                  | -   | -          |
| KD-120   | KD-120    | -        | -         | -                  | -   | -          |
| KD-85    | KD-85     | -        | -         | -                  | -   | -          |
| KD-10    | KD-10     | -        | -         | -                  | -   | -          |
| KD-9     | KD-9      | -        | -         | -                  | -   | -          |
| KD-8     | KD-8      | -        | -         | -                  | -   | -          |
| KD-7     | KD-7      | -        | -         | -                  | -   | -          |
| KDQ-8    | KDQ-8     | -        | -         | -                  | -   | -          |
| KT-10    | KT-10     | -        | -         | -                  | -   | -          |
| KT-9     | KT-9      | -        | -         | -                  | -   | -          |
| PDA120   | PDA120    | ✓        | -         | -                  | ✓   | -          |
| PDA120L  | PDA120L   | ✓        | -         | -                  | -   | -          |
| PDA100   | PDA100    | ✓        | -         | -                  | ✓   | -          |
| PDA100L  | PDA100L   | ✓        | -         | -                  | -   | -          |
| PDA140F  | PDA140F   | ✓        | -         | -                  | ✓   | -          |
| PD-12X   | PD-12X    | ✓        | -         | ✓                  | ✓   | -          |
| PD-12P   | PD-12P    | ✓        | -         | ✓                  | ✓   | -          |
| PD-128   | PD-128    | ✓        | -         | ✓                  | ✓   | -          |
| PD-125X  | PD-125X   | ✓        | -         | ✓                  | ✓   | -          |
| PD-125   | PD-125    | ✓        | -         | ✓                  | ✓   | -          |
| PD-10X   | PD-10X    | ✓        | -         | ✓                  | ✓   | -          |
| PD-10P   | PD-10P    | ✓        | -         | ✓                  | ✓   | -          |
| PD-108   | PD-108    | ✓        | -         | ✓                  | ✓   | -          |
| PD-105X  | PD-105X   | ✓        | -         | ✓                  | ✓   | -          |
| PD-105   | PD-105    | ✓        | -         | ✓                  | ✓   | -          |
| PD-85    | PD-85     | ✓        | -         | ✓                  | ✓   | -          |
| PDX-100  | PDX-100   | ✓        | -         | ✓                  | ✓   | -          |
| PDX-12   | PDX-12    | ✓        | -         | -                  | -   | -          |
| PD-10H   | PD-10H    | ✓        | -         | -                  | -   | -          |
| PD-8H    | PD-8H     | ✓        | -         | -                  | -   | -          |

| Used Pad     | Trig Type    | Rim Shot | Bell shot | Positional sensing |     | Choke play |
|--------------|--------------|----------|-----------|--------------------|-----|------------|
|              |              |          |           | Head               | Rim |            |
| PDX-8        | PDX-8        | ✓        | -         | -                  | -   | -          |
| PDX-6        | PDX-6        | ✓        | -         | -                  | -   | -          |
| PDQ-8S       | PDQ-8S       | ✓        | -         | -                  | -   | -          |
| PDQ-8        | PDQ-8        | -        | -         | -                  | -   | -          |
| PD-8         | PD-8         | ✓        | -         | -                  | -   | ✓          |
| VH-13        | VH-13        | ✓        | -         | -                  | -   | ✓          |
| VH-12        | VH-12        | ✓        | -         | -                  | -   | ✓          |
| VH-11        | VH-11        | ✓        | -         | -                  | -   | ✓          |
| VH-10        | VH-10        | ✓        | -         | -                  | -   | ✓          |
| CY-16R-T     | CY-16R-T     | ✓        | ✓         | ✓                  | -   | ✓          |
| CY-15R       | CY-15R       | ✓        | ✓         | ✓                  | -   | ✓          |
| CY-14R-T     | CY-14R-T     | ✓        | ✓         | ✓                  | -   | ✓          |
| CY-14C-T     | CY-14C-T     | ✓        | -         | ✓                  | -   | ✓          |
| CY-14C       | CY-14C       | ✓        | -         | ✓                  | -   | ✓          |
| CY-13R       | CY-13R       | ✓        | ✓         | ✓                  | -   | ✓          |
| CY-12C       | CY-12C       | ✓        | -         | ✓                  | -   | ✓          |
| CY-12R/C     | CY-12R/C     | ✓        | ✓         | ✓                  | -   | ✓          |
| CY-12C-T     | CY-12C-T     | ✓        | -         | ✓                  | -   | ✓          |
| CY-8         | CY-8         | ✓        | -         | -                  | -   | ✓          |
| CY-5         | CY-5         | ✓        | -         | -                  | -   | ✓          |
| CYQ-12       | CYQ-12       | ✓        | -         | -                  | -   | ✓          |
| BT-1         | BT-1         | -        | -         | -                  | -   | -          |
|              | BT-1 SENS *1 | -        | -         | -                  | -   | -          |
| Generic pads | PAD1         | ✓        | -         | -                  | -   | ✓          |
|              | PAD2         | ✓        | -         | -                  | -   | -          |
|              | PAD3         | ✓        | -         | -                  | -   | ✓          |
| RT-30K       | RT-30K       | -        | -         | -                  | -   | -          |
| RT-30HR      | RT-30HR      | ✓        | -         | -                  | -   | -          |
| RT-30H       | RT-30H SN *2 | -        | -         | -                  | -   | -          |
|              | RT-30H TM *3 | -        | -         | -                  | -   | -          |
| RT-10K       | RT-10K       | -        | -         | -                  | -   | -          |
| RT-10S       | RT-10S       | ✓        | -         | -                  | -   | -          |
| RT-10T       | RT-10T       | -        | -         | -                  | -   | -          |

\*1 When using the BT-1, it is possible to further increase the sensitivity for soft strikes, but this increases the possibility of unwanted triggering by vibration from the surroundings.

\*2 Select this if you attach an RT-30H to the snare.

\*3 Select this if you attach an RT-30H to a tom.

## Trigger inputs and playing methods corresponding chart

### Rim shot/cross stick

\* Use a dual-trigger type pad.

| Trigger Input | Rim Shot   |          | Cross Stick |
|---------------|------------|----------|-------------|
|               | Rubber Pad | Mesh Pad |             |
| KICK          | -          | -        | -           |
| SNARE         | ✓          | ✓        | ✓           |
| TOM 1-4       | ✓          | ✓        | -           |
| HI-HAT        | ✓          | -        | -           |
| CRASH 1, 2    | ✓          | -        | -           |
| RIDE          | ✓          | -        | -           |
| AUX 1-4       | ✓          | ✓        | -           |

### Positional sensing/rim shot nuance

| Trigger Input | Positional Sensing (Head) | Rim Shot Nuance |
|---------------|---------------------------|-----------------|
| KICK          | -                         | -               |
| SNARE         | ✓                         | ✓               |
| TOM 1-4       | ✓                         | ✓               |
| HI-HAT        | - *1                      | - *1            |
| CRASH 1, 2    | -                         | -               |
| RIDE          | ✓                         | - *2            |
| AUX 1-4       | ✓                         | ✓               |

\*1 This is enabled when "HI-HAT" is assigned to the VH-14D.

\*2 This is enabled when "RIDE" is assigned to the CY-18DR.



#### MEMO

- Brush sweep can be used only SNARE.
- Each playing method can be used with the instruments corresponding to it.
- Bell shots are possible only for "RIDE".
- Cross-stick is possible only for "SNARE".

## Configuring V-Drums/DWe pads connected wirelessly (DrumLink)



\* The values aside from those of the Assign parameter are stored in the WT-10/DrumLink hub, not in the V71. These parameters are not saved when you perform the BACKUP ALL operation on the V71.

| Parameter             | Value                                                                                                                               | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|-----------------------|-------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>HUB tab</b>        |                                                                                                                                     |                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| RF Channels Selection | Automatic, Manual                                                                                                                   | Selects whether the channel used for wireless communication between the DH-10/DrumLink™ hub and the pads should be set automatically (Automatic) or manually (Manual).                                                                                                                                                                                                                                                                                              |
| Main Ch.<br>Ack Ch.   | 1 (2402 MHz),<br>2 (2423 MHz),<br>3 (2426 MHz),<br>4 (2448 MHz),<br>5 (2451 MHz),<br>6 (2474 MHz),<br>7 (2477 MHz),<br>8 (2480 MHz) | Sets the channel used when RF Channels Selection is set to "Manual".<br>The Main Ch. is the channel used for the DH-10/DrumLink™ hub → pad direction, and the Ack. Ch. is the channel used for the pad → DH-10/DrumLink™ hub direction.<br>In situations such as when you're using another DH-10/DrumLink™ hub nearby, you can avoid interference by setting each unit to a different channel.<br>* You can't set the Main Ch. and the Ack Ch. to the same channel. |
| Scan on Start-up      | OFF, ON                                                                                                                             | If RF Channels Selection is set to "Automatic", this selects whether to automatically scan the channels (ON) or not (OFF), when the DH-10/DrumLink™ hub is launched.                                                                                                                                                                                                                                                                                                |
| Disable RF Alerts     | OFF, ON                                                                                                                             | In the event of radio wave interference, this selects whether to display alert messages on the screen (OFF) or not (ON).                                                                                                                                                                                                                                                                                                                                            |
| MIDI Output           | Soft Only, Hub Only, Soft+Hub                                                                                                       | Sets the connector that's used for the DH-10/DrumLink™ hub.<br>Soft Only: Uses only USB.<br>Hub Only: Uses only MIDI OUT.<br>Soft+Hub: Uses both USB and MIDI OUT.<br>* When connecting the V71 to the DH-10/DrumLink™ hub, use either the "Soft Only" or the "Soft+Hub" setting.                                                                                                                                                                                   |
| Send Note Off         | OFF, ON                                                                                                                             | When using MIDI OUT on the DH-10/DrumLink™ hub, this determines whether to output note-off data or not.                                                                                                                                                                                                                                                                                                                                                             |

| Parameter        | Value                                                                                          | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|------------------|------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>BASIC tab</b> |                                                                                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Assign           | N/A, KICK, SNARE, TOM1, TOM2, TOM3, TOM4, HI-HAT, CRASH1, CRASH2, RIDE, AUX1, AUX2, AUX3, AUX4 | Specifies the trigger input to which a connected pad should be assigned.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Sensitivity      | 1–16                                                                                           | <p>Adjusts the sensitivity of the pads, which lets you control the balance between how hard you strike the pads and the volume.</p> <ul style="list-style-type: none"> <li>* Increasing this value increases the sensitivity, so that even soft strikes on the pad play the sound at higher volumes.</li> <li>* Decreasing this value decreases the sensitivity, so that even hard strikes on the pad play the sound at lower volumes.</li> </ul>                                                                                                                                                                                                                                                                   |
| Threshold        | 1–15                                                                                           | <p>Adjusts the minimum sensitivity of the pads.</p> <ul style="list-style-type: none"> <li>* Higher values make the pads respond only when you strike them harder.</li> <li>* Lower values make the pads respond even when you strike them softer. Note that the pads may respond incorrectly when you set this to a lower value.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                        |
| Retrigger        | 0–15                                                                                           | <p>Adjusts the detection of attenuation for the trigger signal.</p> <p>The pad may accidentally retrigger multiple times even though you've only struck the pad once. This is caused by fluctuations in the trigger signal that's transmitted when you strike a pad. Use this parameter to prevent this kind of retriggering due to fluctuations in the trigger signal. While repeatedly striking the pad, raise the value until retriggering no longer occurs. Although higher values prevent retriggering, this has the side effect of omitting some sounds when you repeatedly strike the pad in quick succession. Set this to the lowest value possible while still ensuring that there is no retriggering.</p> |
| Scan Time (ms)   | 2.0–5.0                                                                                        | <p>Fine-tunes the trigger signal detection time.</p> <p>Since the rise time of the trigger signal waveform differs slightly depending on the characteristics of each pad, the sounds produced may vary in volume even when you're striking the pad at the same velocity. If this occurs, you can adjust the trigger signal detection time (Scan Time) so that your playing strength can be detected more precisely.</p> <ul style="list-style-type: none"> <li>* As the value is set higher, the time it takes for the sound to play increases. Set this to as low a value as possible.</li> </ul>                               |
| Mask Time (ms)   | 0–70                                                                                           | <p>Adjust this to prevent double triggering.</p> <p>For instance, when you play the kick drum, the beater can bounce back and hit the head a second time immediately after the intended note, which causes a single hit to "double trigger" (two sounds instead of one).</p> <p>The Mask Time setting helps to prevent this. Once a pad is struck, any additional trigger signals occurring within the specified time are ignored.</p> <p>Increasing this value makes it more likely that notes played in rapid succession are to drop out. Set this to as low a value as possible.</p>                                         |
| <b>CURVE tab</b> |                                                                                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| Curve            | USER, LINEAR, LOG1, LOG2, LOG3, POW1, POW2, POW3, EXP1, EXP2, EXP3                             | <p>Adjusts how the volume changes in response to how hard you strike the pad.</p> <p>On the V71, you can select settings that are adjusted via DWe Control (USER) and from multiple presets (LINEAR–EXP3).</p> <ul style="list-style-type: none"> <li>* You can set Curve and Dynamic Range for each playing style.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                      |
| Dynamic Range    | 0–100                                                                                          | <p>Adjusts the range of dynamics you use to strike the pads.</p> <p>Increasing this value narrows the range, so that even soft strikes on the pad play the sound at a high volume.</p> <p>This is useful for making detailed adjustments according to your playing technique, after you have adjusted the pad sensitivity using the Sensitivity parameter.</p>                                                                                                                                                                                                                                                                                                                                                      |

| Parameter                          | Value     | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|------------------------------------|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>OPT/ADV tab</b>                 |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| <b>Settings common to all pads</b> |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| LED On Hit                         | OFF, ON   | Sets whether the LED built into the pad lights up when you strike the pad.                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| <b>KD series</b>                   |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| XTalk Cancel                       | OFF, 1–80 | <p>Adjusts the crosstalk sensitivity.</p> <p>Crosstalk is a feature that prevents accidentally triggering a pad due to the vibrations of other pads.</p> <p>For example, if two pads are mounted on the same drum stand, the vibrations when you strike one pad may cause the other pad to sound unintentionally.</p> <p>Increasing this value prevents the pad from being triggered by the vibrations of other pads.</p> <p>However, if you set the value too high, some sounds may drop out when you strike one pad and another at the same time.</p> |
| <b>PD series</b>                   |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Rim Gain                           | 0.0–3.2   | <p>Adjusts the balance between how hard you strike the rim and the resulting velocity value.</p> <p>If you increase this value, softer strikes on the rim play the sound at a higher velocity. If you decrease this value, stronger strikes on the rim play the sound at a lower velocity.</p>                                                                                                                                                                                                                                                          |
| Rimshot / Head                     | 0.0–15.5  | <p>Adjusts the crossover point between the snare drum head zone and the rim shot zone.</p> <p>Increase this value if the rim shot plays even when you strike the head.</p> <p>Decrease this value if the head sound is heard even when you play a rim shot.</p> <p>* Set this by gradually changing the value while checking how this affects the sound.</p>                                                                                                                                                                                            |
| XTalk Cancel                       | OFF, 1–80 | <p>Adjusts the crosstalk sensitivity.</p> <p>Crosstalk is a feature that prevents accidentally triggering a pad due to the vibrations of other pads.</p> <p>For example, if two pads are mounted on the same drum stand, the vibrations when you strike one pad may cause the other pad to sound unintentionally.</p> <p>Increasing this value prevents the pad from being triggered by the vibrations of other pads.</p> <p>However, if you set the value too high, some sounds may drop out when you strike one pad and another at the same time.</p> |
| <b>VH series</b>                   |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
| Edge Gain                          | 0.0–3.2   | <p>Adjusts the balance between how hard you strike the edge and the resulting velocity value.</p> <p>If you increase this value, softer strikes on the edge play the sound at a higher velocity. If you decrease this value, stronger strikes on the edge play the sound at a lower velocity.</p>                                                                                                                                                                                                                                                       |
| CC Max                             | 90, 127   | <p>Sets the control change (CC) value that's transmitted when you press the hi-hat pedal completely.</p> <p>* Select whether the maximum CC value when you press the HH CTRL pedal (connected to PAD2) should be 90 or 127.</p> <p>* When you turn on the "Hi-Hat" parameter that is configurable on the INPUT CONFIGURATION screen, you can configure other pads besides the VH series.</p>                                                                                                                                                            |
| Open Pedal Tune                    | -7–0–+7   | <p>Sets the CC value used when the hi-hat is opened.</p> <p>If the CC value does not fall to zero when the pedal is released, you can make it do so by changing this to a negative value.</p> <p>* When you turn on the "Hi-Hat" parameter that is configurable on the INPUT CONFIGURATION screen, you can configure other pads besides the VH series.</p>                                                                                                                                                                                              |
| Closed Pedal Tune                  | -7–0–+7   | <p>Sets the range between the open and closed hi-hat position.</p> <p>Smaller values result in a higher closed position, which lets you close the hi-hat with less force.</p> <p>Larger values make the hi-hat close only when you press the pedal with greater force.</p> <p>* When you turn on the "Hi-Hat" parameter that is configurable on the INPUT CONFIGURATION screen, you can configure other pads besides the VH series.</p>                                                                                                                 |
| XTalk Cancel                       | OFF, 1–80 | <p>Adjusts the crosstalk sensitivity.</p> <p>Crosstalk is a feature that prevents accidentally triggering a pad due to the vibrations of other pads.</p> <p>For example, if two pads are mounted on the same drum stand, the vibrations when you strike one pad may cause the other pad to sound unintentionally.</p> <p>Increasing this value prevents the pad from being triggered by the vibrations of other pads.</p> <p>However, if you set the value too high, some sounds may drop out when you strike one pad and another at the same time.</p> |

| Parameter             | Value     | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|-----------------------|-----------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>CY series</b>      |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Positional Sensing    | OFF, ON   | Turns positional sensing (which detects where the pad was struck) on/off.<br>* This parameter is only for pads that support positional sensing (CY-16R-T/CY-15R/CY-14R-T/CY-13R/CY-12R/C).                                                                                                                                                                                                                                                                                                                                       |
| Edge Gain             | 0.0–3.2   | Adjusts the balance between how hard you strike the edge and the resulting velocity value.<br>If you increase this value, softer strikes on the edge play the sound at a higher velocity. If you decrease this value, stronger strikes on the edge play the sound at a lower velocity.                                                                                                                                                                                                                                           |
| XTalk Cancel          | OFF, 1–80 | Adjusts the crosstalk sensitivity.<br>Crosstalk is a feature that prevents accidentally triggering a pad due to the vibrations of other pads.<br>For example, if two pads are mounted on the same drum stand, the vibrations when you strike one pad may cause the other pad to sound unintentionally.<br>Increasing this value prevents the pad from being triggered by the vibrations of other pads.<br>However, if you set the value too high, some sounds may drop out when you strike one pad and another at the same time. |
| <b>RT series</b>      |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Rim Gain              | 0.0–3.2   | Adjusts the balance between how hard you strike the rim and the resulting velocity value.<br>If you increase this value, softer strikes on the rim play the sound at a higher velocity. If you decrease this value, stronger strikes on the rim play the sound at a lower velocity.                                                                                                                                                                                                                                              |
| Rimshot / Head        | 0.0–15.5  | Adjusts the crossover point between the snare drum head zone and the rim shot zone.<br>Increase this value if the rim shot plays even when you strike the head.<br>Decrease this value if the head sound is heard even when you play a rim shot.<br>* Set this by gradually changing the value while checking how this affects the sound.                                                                                                                                                                                        |
| Ext Noise Cancel      | 0–5       | This prevents a drum from being triggered unintentionally due to the sound of striking another drum that doesn't have a drum trigger attached, or due to external sound or vibration (noise cancel).                                                                                                                                                                                                                                                                                                                             |
| XTalk Cancel          | OFF, 1–80 | Adjusts the crosstalk sensitivity.<br>Crosstalk is a feature that prevents accidentally triggering a pad due to the vibrations of other pads.<br>For example, if two pads are mounted on the same drum stand, the vibrations when you strike one pad may cause the other pad to sound unintentionally.<br>Increasing this value prevents the pad from being triggered by the vibrations of other pads.<br>However, if you set the value too high, some sounds may drop out when you strike one pad and another at the same time. |
| <b>DWe snare, tom</b> |           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Rim Zone              | OFF, ON   | Lets you switch rim detection on/off.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
| Rimshot Zone          | OFF, ON   | Lets you switch rim shot detection on/off.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| XStick Zone           | OFF, ON   | Lets you switch cross stick detection on/off.<br>* This parameter is only for the snare drum.                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Positional Sensing    | OFF, ON   | Lets you turn strike position detection on/off.<br>* This parameter is only for the snare drum.<br>* When Pos Sensing is set to on, the Pitch Bend parameter which can be set in the DWe Control application is automatically switched off.                                                                                                                                                                                                                                                                                      |
| Rimshot / Head        | 0.0–15.5  | Lets you adjust how easily the rim shot and head sounds play.<br>Decrease this value if the rim shot plays even when you strike the head.<br>Increase this value if the head sound is heard when you play a rim shot.<br>* Set this by gradually changing the value while checking how this affects the sound.                                                                                                                                                                                                                   |
| Rim / Rimshot         | 0.0–1.0   | Lets you adjust how easily the rim and rim shot sounds play.<br>If the rim sound is heard when you play a rim shot, decrease this value.<br>Increase this value if the rim shot plays even when you strike just the rim.<br>* Set this by gradually changing the value while checking how this affects the sound.                                                                                                                                                                                                                |

| Parameter                     | Value                                                                                                                                    | Explanation                                                                                                                                                                                                                                                                                                                                                                 |
|-------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Positional Sensing Smoothness | 0–15                                                                                                                                     | Adjusts how the sound changes according to the strike position detected on the snare.<br>* This parameter is only for the snare drum.                                                                                                                                                                                                                                       |
| Positional Sensing Range      | 1–8                                                                                                                                      | Adjusts the range over which the strike position is detected on the pad face of the snare.<br>Larger values make the sounds play more readily when you strike closer to the center of the pad face; smaller values make the sounds play more readily when you strike towards the edges of the pad face.<br>* This parameter is only for the snare drum.                     |
| DWe crash, ride, hi-hat       |                                                                                                                                          |                                                                                                                                                                                                                                                                                                                                                                             |
| FSR Auto Calibration          | OFF, ON                                                                                                                                  | Lets you turn auto-calibration on/off for the sensors that are built into the edges of the cymbals.<br>Turn this function on if the surrounding environment (such as temperature) changes significantly when you're using the DWe crash or ride. This function automatically calibrates the trigger detection accuracy.<br>* This parameter is only for the crash and ride. |
| Bell / Bow                    | 0.0–1.0                                                                                                                                  | Lets you adjust how easily the bell and bow sounds play.<br>Decrease this value if the bell sound plays even when you strike the bow.<br>Increase this value if the bow sound is heard when you play the bell.<br>* Set this by gradually changing the value while checking how this affects the sound.                                                                     |
| CC Smoothness                 | 0–15                                                                                                                                     | Adjusts the resolution used when detecting the motion of the hi-hat pedal.<br>Use a smaller value when you want to minimize the changes in sound between the open and closed state.<br>* This parameter is only for the hi-hat.                                                                                                                                             |
| Closed Pedal Tune             | -7–7                                                                                                                                     | Adjusts the position at which the hi-hat closes.<br>Smaller values result in a higher closed position, which lets you close the hi-hat with less force.<br>Larger values make the hi-hat close only when you press the pedal with greater force.<br>* This parameter is only for the hi-hat.                                                                                |
| INPUT CONFIG window           |                                                                                                                                          |                                                                                                                                                                                                                                                                                                                                                                             |
| Hi-Hat                        | Set this to "ON" when using a pad connected to the PAD1 jack on the WT-10 as a hi-hat.                                                   |                                                                                                                                                                                                                                                                                                                                                                             |
|                               |                                                       |                                                                                                                                                                                                                                                                                                                                                                             |
|                               | OFF                                                                                                                                      | The input from the PAD2 jack is not recognized as the HH CTRL signal from the PAD1 jack.                                                                                                                                                                                                                                                                                    |
|                               | ON                                                                                                                                       | When the trigger input assignment is set to "HI-HAT", the input from PAD2 on the WT-10 is recognized as the HH CTRL signal from the PAD1 jack.                                                                                                                                                                                                                              |
| 2 Zone                        | This parameter can be operated when setting a pad for the PAD1 jack of the WT-10 that supports playing bell shots, such as the CY-16R-T. |                                                                                                                                                                                                                                                                                                                                                                             |
|                               |                                                       |                                                                                                                                                                                                                                                                                                                                                                             |
|                               | OFF                                                                                                                                      | If the trigger input assignment is set to "RIDE", the input from the PAD2 jack is recognized as a bell signal for the PAD1 jack.                                                                                                                                                                                                                                            |
|                               | ON                                                                                                                                       | You can set the pad you like for the PAD2 jack, even when setting a ride pad like the CY-16R-T for the PAD1 jack (the input from the PAD2 jack is not recognized as a bell signal for the PAD1 jack).                                                                                                                                                                       |

# Effect parameters

## FX list

### Thru

|      |         |
|------|---------|
| THRU | page 67 |
|------|---------|

### Filter

|                   |         |
|-------------------|---------|
| EQUALIZER         | page 67 |
| MID SIDE EQ       | page 68 |
| SPECTRUM          | page 69 |
| ISOLATOR          | page 69 |
| LOW BOOST         | page 69 |
| SUPER FILTER      | page 69 |
| MULTI MODE FILTER | page 70 |
| STEP FILTER       | page 70 |
| ENHANCER          | page 70 |
| EXCITER           | page 71 |
| AUTO WAH *1       | page 71 |
| HUMANIZER *1      | page 71 |

### Phaser

|                  |         |
|------------------|---------|
| PHASER           | page 72 |
| SMALL PHASER     | page 72 |
| SCRIPT 90        | page 72 |
| SCRIPT 100       | page 72 |
| STEP PHASER      | page 73 |
| MLT STAGE PHASER | page 73 |
| INFINITE PHASER  | page 73 |

### Flanger

|                   |         |
|-------------------|---------|
| FLANGER           | page 74 |
| SBF-325 (Flanger) | page 74 |
| STEP FLANGER      | page 75 |

### Chorus

|                               |         |
|-------------------------------|---------|
| CHORUS                        | page 75 |
| HEXA-CHORUS                   | page 76 |
| TREM CHORUS                   | page 76 |
| SPACE-D                       | page 76 |
| CE-1 (Chorus)                 | page 77 |
| SDD-320 (DIMENSION D)         | page 77 |
| JUNO CHORUS (JUNO-106 Chorus) | page 77 |

### Modulation

|                   |         |
|-------------------|---------|
| RING MODULATOR *1 | page 77 |
| TREMOLO           | page 77 |
| AUTO PAN          | page 78 |
| SLICER *1         | page 78 |
| ROTARY            | page 79 |
| VK ROTARY         | page 79 |

### Drive/Amp

|                                        |         |
|----------------------------------------|---------|
| OVERDRIVE                              | page 80 |
| DISTORTION                             | page 80 |
| T-SCREAM                               | page 80 |
| FUZZ                                   | page 80 |
| TONE FATTENER                          | page 80 |
| HMS DISTORTION                         | page 81 |
| SATURATOR                              | page 81 |
| DRUM SATURATOR                         | page 81 |
| WARM SATURATOR                         | page 82 |
| GUITAR AMP SIMULATOR                   | page 82 |
| EP AMP SIMULATOR (RD EP Amp Simulator) | page 83 |
| SPEAKER SIMULATOR                      | page 84 |

### Comp/Limiter

|                                |         |
|--------------------------------|---------|
| COMPRESSOR *1                  | page 84 |
| FETCOMP-78 (FET compressor 78) | page 84 |
| MID SIDE COMPRESSOR            | page 85 |
| LIMITER                        | page 85 |
| SUSTAINER                      | page 86 |
| TRANSIENT *1                   | page 86 |
| GATE *1                        | page 86 |

### Delay

|                                      |         |
|--------------------------------------|---------|
| DELAY                                | page 87 |
| MOD DELAY                            | page 87 |
| 2TAP PAN DELAY                       | page 88 |
| 3TAP PAN DELAY                       | page 88 |
| 4TAP PAN DELAY                       | page 89 |
| MULTI TAP DELAY (Multi Tap Delay)    | page 89 |
| REVERSE DELAY *1                     | page 90 |
| TIME CTRL DELAY (Time Control Delay) | page 90 |
| TAPE ECHO                            | page 91 |
| MID SIDE DELAY                       | page 91 |

### Looper

|            |         |
|------------|---------|
| BPM LOOPER | page 92 |
|------------|---------|

### Lo-fi

|                              |         |
|------------------------------|---------|
| LOFI COMP (Lo-Fi Compressor) | page 92 |
| BIT CRUSHER                  | page 92 |
| PHONOGRAPH                   | page 93 |

### Pitch

|                  |         |
|------------------|---------|
| PITCH SHIFTER    | page 93 |
| 2V PITCH SHIFTER | page 94 |

\*1 Indicates effects that support side chain input

## Combination

|                                                   |          |
|---------------------------------------------------|----------|
| OD → CHORUS (Overdrive → Chorus)                  | page 94  |
| OD → FLANGER (Overdrive → Flanger)                | page 94  |
| OD → DELAY (Overdrive → Delay)                    | page 95  |
| DS → CHORUS (Distortion → Chorus)                 | page 95  |
| DS → FLANGER (Distortion → Flanger)               | page 95  |
| DS → DELAY (Distortion → Delay)                   | page 96  |
| OD/DS → TWAH (Overdrive/Distortion → Touch Wah)   | page 96  |
| OD/DS → AWAH (Overdrive/Distortion → Auto Wah)    | page 97  |
| GT AMP → CHORUS (Guitar Amp Simulator → Chorus)   | page 97  |
| GT AMP → FLANGER (Guitar Amp Simulator → Flanger) | page 98  |
| GT AMP → PHASER (Guitar Amp Simulator → Phaser)   | page 99  |
| GT AMP → DELAY (Guitar Amp Simulator → Delay)     | page 100 |
| EP AMP → TREMOLO (EP Amp Simulator → Tremolo)     | page 101 |
| EP AMP → CHORUS (EP Amp Simulator → Chorus)       | page 101 |
| EP AMP → FLANGER (EP Amp Simulator → Flanger)     | page 102 |
| EP AMP → PHASER (EP Amp Simulator → Phaser)       | page 102 |
| EP AMP → DELAY (EP Amp Simulator → Delay)         | page 102 |
| EH → CHORUS (Enhancer → Chorus)                   | page 103 |
| EH → FLANGER (Enhancer → Flanger)                 | page 103 |
| EH → DELAY (Enhancer → Delay)                     | page 103 |
| CHO → DELAY                                       | page 104 |
| FLG → DELAY (Flanger → Delay)                     | page 104 |
| THRU                                              | page 67  |
| JD-MULTI                                          | page 105 |

## Thru

## THRU

## Filter

## EQUALIZER

This is a four-band stereo equalizer (low, mid x 2, high).



| Parameter | Value                                                                                              | Explanation                                                                                 |
|-----------|----------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
| Low Freq  | 20, 25, 31, 40, 50, 63, 80, 100, 125, 160, 200, 250, 315, 400 [Hz]                                 | Frequency of the low range                                                                  |
| Low Gain  | -15–+15 [dB]                                                                                       | Amount of boost/cut for the low-frequency range                                             |
| Mid1 Freq | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000 [Hz] | Frequency of the middle range 1                                                             |
| Mid1 Gain | -15–+15 [dB]                                                                                       | Gain of the middle range 1                                                                  |
| Mid1 Q    | 0.5, 1.0, 2.0, 4.0, 8.0                                                                            | Width of the middle range 1<br>Set a higher value for Q to narrow the range to be affected. |
| Mid2 Freq | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000 [Hz] | Frequency of the middle range 2                                                             |
| Mid2 Gain | -15–+15 [dB]                                                                                       | Gain of the middle range 2                                                                  |
| Mid2 Q    | 0.5, 1.0, 2.0, 4.0, 8.0                                                                            | Width of the middle range 2<br>Set a higher value for Q to narrow the range to be affected. |
| HighFreq  | 2000, 2500, 3150, 4000, 5000, 6300, 8000, 10000, 12500, 16000 [Hz]                                 | Frequency of the high range                                                                 |
| High Gain | -15–+15 [dB]                                                                                       | Amount of boost/cut for the high-frequency range                                            |
| Level     | 0–127                                                                                              | Output Level                                                                                |

## MID SIDE EQ

This effect allows the left/right signals that have similar phase to be tonally adjusted in a different way than the left/right signals that have different phase.




| Parameter   | Value                                                                                              | Explanation                                                                                                     |
|-------------|----------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------|
| M EQ Switch | OFF, ON                                                                                            | Switches whether to apply tonal adjustment to left/right input signals whose phase is similar (in phase).       |
| M In G      | -12.00~+12.00 [dB]                                                                                 | Volume of left/right input signals whose phase is similar (in phase)                                            |
| M Low F     | 20, 25, 31, 40, 50, 63, 80, 100, 125, 160, 200, 250, 315, 400 [Hz]                                 | Frequency of the low range                                                                                      |
| M Low G     | -12.00~+12.00 [dB]                                                                                 | Amount of boost/cut for the low-frequency range                                                                 |
| M Mid1 F    | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000 [Hz] | Frequency of the middle range 1                                                                                 |
| M Mid1 G    | -12.00~+12.00 [dB]                                                                                 | Gain of the middle range 1                                                                                      |
| M Mid1 Q    | 0.5, 1.0, 2.0, 4.0, 8.0                                                                            | Width of the middle range 1<br>Set a higher value for Q to narrow the range to be affected.                     |
| M Mid2 F    | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000 [Hz] | Frequency of the middle range 2                                                                                 |
| M Mid2 G    | -12.00~+12.00 [dB]                                                                                 | Gain of the middle range 2                                                                                      |
| M Mid2 Q    | 0.5, 1.0, 2.0, 4.0, 8.0                                                                            | Width of the middle range 2<br>Set a higher value for Q to narrow the range to be affected.                     |
| M Mid3 F    | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000 [Hz] | Frequency of the middle range 3                                                                                 |
| M Mid3 G    | -12.00~+12.00 [dB]                                                                                 | Gain of the middle range 3                                                                                      |
| M Mid3 Q    | 0.5, 1.0, 2.0, 4.0, 8.0                                                                            | Width of the middle range 3<br>Set a higher value for Q to narrow the range to be affected.                     |
| M High F    | 2000, 2500, 3150, 4000, 5000, 6300, 8000, 10000, 12500, 16000 [Hz]                                 | Frequency of the high range                                                                                     |
| M High G    | -12.00~+12.00 [dB]                                                                                 | Amount of boost/cut for the high-frequency range                                                                |
| S EQ Switch | OFF, ON                                                                                            | Switches whether to apply tonal adjustment to left/right input signals whose phase is distant (opposite phase). |
| S In G      | -12.00~+12.00 [dB]                                                                                 | Volume of left/right signals whose phase is distant (opposite phase)                                            |

| Parameter | Value                                                                                              | Explanation                                                                                 |
|-----------|----------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
| S Low F   | 20, 25, 31, 40, 50, 63, 80, 100, 125, 160, 200, 250, 315, 400 [Hz]                                 | Frequency of the low range                                                                  |
| S Low G   | -12.00~+12.00 [dB]                                                                                 | Amount of boost/cut for the low-frequency range                                             |
| S Mid1 F  | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000 [Hz] | Frequency of the middle range 1                                                             |
| S Mid1 G  | -12.00~+12.00 [dB]                                                                                 | Gain of the middle range 1                                                                  |
| S Mid1 Q  | 0.5, 1.0, 2.0, 4.0, 8.0                                                                            | Width of the middle range 1<br>Set a higher value for Q to narrow the range to be affected. |
| S Mid2 F  | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000 [Hz] | Frequency of the middle range 2                                                             |
| S Mid2 G  | -12.00~+12.00 [dB]                                                                                 | Gain of the middle range 2                                                                  |
| S Mid2 Q  | 0.5, 1.0, 2.0, 4.0, 8.0                                                                            | Width of the middle range 2<br>Set a higher value for Q to narrow the range to be affected. |
| S Mid3 F  | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000 [Hz] | Frequency of the middle range 3                                                             |
| S Mid3 G  | -12.00~+12.00 [dB]                                                                                 | Gain of the middle range 3                                                                  |
| S Mid3 Q  | 0.5, 1.0, 2.0, 4.0, 8.0                                                                            | Width of the middle range 3<br>Set a higher value for Q to narrow the range to be affected. |
| S High F  | 2000, 2500, 3150, 4000, 5000, 6300, 8000, 10000, 12500, 16000 [Hz]                                 | Frequency of the high range                                                                 |
| S HighG   | -12.00~+12.00 [dB]                                                                                 | Amount of boost/cut for the high-frequency range                                            |
| Level     | 0~127                                                                                              | Output Level                                                                                |

## SPECTRUM


This is a stereo spectrum. Spectrum is a type of filter which modifies the timbre by boosting or cutting the level at specific frequencies.



| Parameter | Value                   | Explanation                                                                          |
|-----------|-------------------------|--------------------------------------------------------------------------------------|
| Band1     | -15–+15 [dB]            | Gain of each frequency band                                                          |
| Band2     |                         |                                                                                      |
| Band3     |                         |                                                                                      |
| Band4     |                         |                                                                                      |
| Band5     |                         |                                                                                      |
| Band6     |                         |                                                                                      |
| Band7     |                         |                                                                                      |
| Band8     |                         |                                                                                      |
| Q         | 0.5, 1.0, 2.0, 4.0, 8.0 | Simultaneously adjusts the width of the adjusted ranges for all the frequency bands. |
| Level     | 0–127                   | Output Level                                                                         |

## ISOLATOR

This is an equalizer which cuts the volume greatly, allowing you to add a special effect to the sound by cutting the volume in varying ranges.



| Parameter  | Value       | Explanation                                                                                                                                                                                      |
|------------|-------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Low Level  | -60–+4 [dB] | These boost and cut each of the High, Middle, and Low frequency ranges. At -60 dB, the sound becomes inaudible. 0 dB is equivalent to the input level of the sound.                              |
| Mid Level  | -60–+4 [dB] |                                                                                                                                                                                                  |
| High Level | -60–+4 [dB] |                                                                                                                                                                                                  |
| Low AP Sw  | OFF, ON     | Turns the Anti-Phase function on and off for the Low frequency ranges. When turned on, the counter-channel of stereo sound is inverted and added to the signal.                                  |
| Low AP Lv  | 0–127       | Adjusts the level settings for the Low frequency ranges. Adjusting this level for certain frequencies allows you to lend emphasis to specific parts (This is effective only for stereo source.). |
| Mid AP Sw  | OFF, ON     | Settings of the Anti-Phase function for the Middle frequency ranges.                                                                                                                             |
| Mid AP Lv  | 0–127       | The parameters are the same as for the Low frequency ranges.                                                                                                                                     |
| Boost Sw   | OFF, ON     | Turns Low Booster on/off. This emphasizes the bottom to create a heavy bass sound.                                                                                                               |

| Parameter | Value | Explanation                                                                                                                              |
|-----------|-------|------------------------------------------------------------------------------------------------------------------------------------------|
| Boost Lv  | 0–127 | Increasing this value gives you a heavier low end. Depending on the Isolator and filter settings this effect may be hard to distinguish. |
| Level     | 0–127 | Output Level                                                                                                                             |

## LOW BOOST

Boosts the volume of the lower range, creating powerful lows.



| Parameter  | Value                                      | Explanation                                               |
|------------|--------------------------------------------|-----------------------------------------------------------|
| Boost Freq | 50, 56, 63, 71, 80, 90, 100, 112, 125 [Hz] | Center frequency at which the lower range will be boosted |
| Boost Gain | 0–+12 [dB]                                 | Center frequency at which the lower range will be boosted |
| Boost Wid  | WIDE, MID, NARROW                          | Width of the lower range that will be boosted             |
| Low Gain   | -15–+15 [dB]                               | Amount of boost/cut for the low-frequency range           |
| High Gain  | -15–+15 [dB]                               | Amount of boost/cut for the high-frequency range          |
| Level      | 0–127                                      | Output Level                                              |

## SUPER FILTER

This is a filter with an extremely sharp slope. The cutoff frequency can be varied cyclically.




| Parameter | Value                | Explanation                                                                                                                                                                                                                                                                       |
|-----------|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Type      | LPF, BPF, HPF, NOTCH | Filter type<br>Frequency range that will pass through each filter<br><b>LPF:</b> Frequencies below the cutoff<br><b>BPF:</b> Frequencies in the region of the cutoff<br><b>HPF:</b> Frequencies above the cutoff<br><b>NOTCH:</b> Frequencies other than the region of the cutoff |
| Slope     | -12, -24, -36 [dB]   | Amount of attenuation per octave<br><b>-12 dB:</b> Gentle<br><b>-24 dB:</b> Steep<br><b>-36 dB:</b> Extremely steep                                                                                                                                                               |
| Cutoff    | 0–127                | Cutoff frequency of the filter<br>Increasing this value will raise the cutoff frequency.                                                                                                                                                                                          |

| Parameter | Value                     | Explanation                                                                                                                                                                                                 |
|-----------|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Resonance | 0–100                     | Filter resonance level<br>Increasing this value will emphasize the region near the cutoff frequency.                                                                                                        |
| Gain      | 0–+12 [dB]                | Amount of boost for the filter output                                                                                                                                                                       |
| Mod Sw    | OFF, ON                   | On/off switch for cyclic change                                                                                                                                                                             |
| Mod Wave  | TRI, SQR, SIN, SAW1, SAW2 | How the cutoff frequency will be modulated<br><b>TRI:</b> Triangle wave<br><b>SQR:</b> Square wave<br><b>SIN:</b> Sine wave<br><b>SAW1:</b> Sawtooth wave (upward)<br><b>SAW2:</b> Sawtooth wave (downward) |
|           | SAW1 SAW2                 |                                                                                                                            |
| Rate Sync | OFF, ON                   | When this is "ON", the rate is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                                                                                                              |
| Rate      | 0.05–10.00 [Hz]           |                                                                                                                                                                                                             |
| Rate Note | Note<br>⇒ "Note" (p. 106) | Frequency of modulation                                                                                                                                                                                     |
| Depth     | 0–127                     | Depth of modulation                                                                                                                                                                                         |
| Attack    | 0–127                     | Speed at which the cutoff frequency will change This is effective if Mod Wave is SQR, SAW1, or SAW2.                                                                                                        |
| Level     | 0–127                     | Output Level                                                                                                                                                                                                |

## MULTI MODE FILTER

This is a filter that is adjusted for effective use in a DJ performance.



| Parameter | Value                  | Explanation                                                                                                            |
|-----------|------------------------|------------------------------------------------------------------------------------------------------------------------|
| Type      | LPF/HPF, LPF, HPF, BPF | Filter type<br><b>LPF/HPF:</b> The filter type is automatically switched according to the Filter Tone parameter value. |
| Tone      | 0–255                  | Frequency at which the filter operates                                                                                 |
| Color     | 0–255                  | Filter resonance level<br>Higher values more strongly emphasize the region of the operating frequency.                 |
| Slope     | -12, -24, -36 [dB]     | Amount of attenuation per octave                                                                                       |
|           |                        | <b>-12 dB:</b> Gentle                                                                                                  |
|           |                        | <b>-24 dB:</b> Steep<br><b>-36 dB:</b> Extremely steep                                                                 |
| Gain      | 0–+12 [dB]             | Amount of boost for the filter output                                                                                  |
| Level     | 0–127                  | Output Level                                                                                                           |

## STEP FILTER


This is a filter whose cutoff frequency can be modulated in steps. You can specify the pattern by which the cutoff frequency will change.



| Parameter | Value                     | Explanation                                                                                                                                                                                                                                                        |
|-----------|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1–16 | 0–127                     | Cutoff frequency at each step                                                                                                                                                                                                                                      |
| Rate Sync | OFF, ON                   | When this is "ON", the rate is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                                                                                                                                                                     |
| Rate      | 0.05–10.00 [Hz]           |                                                                                                                                                                                                                                                                    |
| Rate Note | Note<br>⇒ "Note" (p. 106) | Frequency of modulation                                                                                                                                                                                                                                            |
| Attack    | 0–127                     | Speed at which the cutoff frequency changes between steps                                                                                                                                                                                                          |
| Type      | LPF, BPF, HPF, NOTCH      | Frequency range that will pass through each filter<br><b>LPF:</b> Frequencies below the cutoff<br><b>BPF:</b> Frequencies in the region of the cutoff<br><b>HPF:</b> Frequencies above the cutoff<br><b>NOTCH:</b> Frequencies other than the region of the cutoff |
|           |                           |                                                                                                                                                                                                                                                                    |
|           |                           |                                                                                                                                                                                                                                                                    |
|           |                           |                                                                                                                                                                                                                                                                    |
| Slope     | -12, -24, -36 [dB]        | Amount of attenuation per octave<br><b>-12 dB:</b> Gentle<br><b>-24 dB:</b> Steep<br><b>-36 dB:</b> Extremely steep                                                                                                                                                |
|           |                           |                                                                                                                                                                                                                                                                    |
|           |                           |                                                                                                                                                                                                                                                                    |
| Reso      | 0–127                     | Filter resonance level<br>Increasing this value will emphasize the region near the cutoff frequency.                                                                                                                                                               |
| Gain      | 0–+12 [dB]                | Amount of boost for the filter output                                                                                                                                                                                                                              |
| Level     | 0–127                     | Output Level                                                                                                                                                                                                                                                       |

## ENHANCER


Controls the overtone structure of the high frequencies, adding sparkle and tightness to the sound.



| Parameter | Value        | Explanation                                      |
|-----------|--------------|--------------------------------------------------|
| Sens      | 0–127        | Sensitivity of the enhancer                      |
| Mix       | 0–127        | Level of the overtones generated by the enhancer |
| Low Gain  | -15–+15 [dB] | Amount of boost/cut for the low-frequency range  |
| High Gain | -15–+15 [dB] | Amount of boost/cut for the high-frequency range |
| Level     | 0–127        | Output Level                                     |

## EXCITER

This adds dynamics to the sound, by dynamically bringing up the high end using a split-band compressor.



| Parameter   | Value           | Explanation                                                                     |
|-------------|-----------------|---------------------------------------------------------------------------------|
| Band2 Thrs  | -80.0–0.0 (dB)  | Raises the midrange frequency levels when they fall below the specified amount. |
| Band2 Gain  | 0–+24 (dB)      | Sets how much to raise the levels when the midrange volume is low.              |
| Band3 Thrs  | -80.0–0.0 (dB)  | Raises the high-end frequency levels when they fall below the specified amount. |
| Band3 Gain  | 0–+24 (dB)      | Sets how much to raise the levels when the high-end frequency volume is low.    |
| Split1 Freq | 2000–5000 (Hz)  | Frequency at which the low and midrange frequencies are split                   |
| Split2 Freq | 3000–10000 (Hz) | Frequency at which the midrange and high-end frequencies are split              |
| Level       | 0–127           | Output Level                                                                    |

## AUTO WAH

Cyclically controls a filter to create cyclic change in timbre.




| Parameter | Value    | Explanation                                                                                                                                                              |
|-----------|----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Mode      | LPF, BPF | Filter type<br><b>LPF:</b> The wah effect will be applied over a wide frequency range.<br><b>BPF:</b> The wah effect will be applied over a narrow frequency range.      |
| Manual    | 0–127    | Center frequency at which the wah effect is applied                                                                                                                      |
| Peak      | 0–127    | Width of the frequency region at which the wah effect is applied.<br>Increasing this value will make the frequency region narrower.                                      |
| Sens      | 0–127    | Sensitivity with which the filter is modified                                                                                                                            |
| Polarity  | UP, DOWN | Direction in which the filter will move<br><b>UP:</b> The filter will change toward a higher frequency.<br><b>DOWN:</b> The filter will change toward a lower frequency. |

| Parameter | Value                     | Explanation                                                                                    |
|-----------|---------------------------|------------------------------------------------------------------------------------------------|
| Rate Sync | OFF, ON                   | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37) |
| Rate      | 0.05–10.00 [Hz]           |                                                                                                |
| Rate Note | Note<br>→ "Note" (p. 106) | Frequency of modulation                                                                        |
| Depth     | 0–127                     | Depth at which the wah effect is modulated                                                     |
| Phase     | 0–180 [deg]               | Adjusts the degree of phase shift of the left and right sounds when the wah effect is applied. |
| Low Gain  | -15–+15 [dB]              | Amount of boost/cut for the low-frequency range                                                |
| High Gain | -15–+15 [dB]              | Amount of boost/cut for the high-frequency range                                               |
| Level     | 0–127                     | Output Level                                                                                   |

## HUMANIZER

Adds a vowel character to the sound, making it similar to a human voice.




| Parameter     | Value                     | Explanation                                                                                                                                                                                        |
|---------------|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Drive Sw      | OFF, ON                   | Overdrive on/off                                                                                                                                                                                   |
| Drive         | 0–127                     | Degree of distortion<br>Also changes the volume.                                                                                                                                                   |
| Vowel1        | a, e, i, o, u             | Vowel 1                                                                                                                                                                                            |
| Vowel2        | a, e, i, o, u             | Vowel 2                                                                                                                                                                                            |
| Rate Sync     | OFF, ON                   | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                                                     |
| Rate          | 0.05–10.00 [Hz]           |                                                                                                                                                                                                    |
| Rate Note     | Note<br>→ "Note" (p. 106) | Frequency at which the two vowels switch                                                                                                                                                           |
| Depth         | 0–127                     | Effect depth                                                                                                                                                                                       |
| In Sync Sw    | OFF, ON                   | LFO reset on/off<br>Determines whether the LFO for switching the vowels is reset by the input signal (ON) or not (OFF).                                                                            |
| In Sync Thres | 0–127                     | Volume level at which reset is applied                                                                                                                                                             |
| Manual        | 0–100                     | Point at which Vowel 1/2 switch<br><b>0–49:</b> Vowel 1 will have a longer duration.<br><b>50:</b> Vowel 1 and 2 will be of equal duration.<br><b>51–100:</b> Vowel 2 will have a longer duration. |
| Low Gain      | -15–+15 [dB]              | Amount of boost/cut for the low-frequency range                                                                                                                                                    |
| High Gain     | -15–+15 [dB]              | Amount of boost/cut for the high-frequency range                                                                                                                                                   |
| Pan           | L64–63R                   | Stereo location of the output sound                                                                                                                                                                |
| Level         | 0–127                     | Output Level                                                                                                                                                                                       |

## Phaser

## PHASER

This is a stereo phaser. A phase-shifted sound is added to the original sound and modulated.



| Parameter | Value                      | Explanation                                                                                                                                                                                                                                                                                                                  |
|-----------|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Mode      | 4-STAGE, 8-STAGE, 12-STAGE | Number of stages in the phaser                                                                                                                                                                                                                                                                                               |
| Manual    | 0–127                      | Adjusts the basic frequency from which the sound will be modulated.                                                                                                                                                                                                                                                          |
| Rate Sync | OFF, ON                    | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                                                                                                                                                                               |
| Rate      | 0.05–10.00 [Hz]            |                                                                                                                                                                                                                                                                                                                              |
| Rate Note | Note<br>→ "Note" (p. 106)  | Frequency of modulation                                                                                                                                                                                                                                                                                                      |
| Depth     | 0–127                      | Depth of modulation                                                                                                                                                                                                                                                                                                          |
| Polarity  | INVERSE, SYNCHRO           | Selects whether the left and right phase of the modulation will be the same or the opposite.<br><b>INVERSE:</b> The left and right phase will be opposite.<br>When using a mono source, this spreads the sound.<br><b>SYNCHRO:</b> The left and right phase will be the same.<br>Select this when inputting a stereo source. |
| Resonance | 0–127                      | Amount of feedback                                                                                                                                                                                                                                                                                                           |
| Feedback  | -98–+98 [%]                | Adjusts the proportion of the phaser sound that is fed back into the effect. Negative (-) settings will invert the phase.                                                                                                                                                                                                    |
| Mix       | 0–127                      | Level of the phase-shifted sound                                                                                                                                                                                                                                                                                             |
| Low Gain  | -15–+15 [dB]               | Amount of boost/cut for the low-frequency range                                                                                                                                                                                                                                                                              |
| High Gain | -15–+15 [dB]               | Amount of boost/cut for the high-frequency range                                                                                                                                                                                                                                                                             |
| Level     | 0–127                      | Output Level                                                                                                                                                                                                                                                                                                                 |

## SMALL PHASER

This simulates an analog phaser of the past.

It is particularly suitable for electric piano.



| Parameter | Value        | Explanation                                      |
|-----------|--------------|--------------------------------------------------|
| Rate      | 0–100        | Frequency of modulation                          |
| Color     | 1, 2         | Modulation character                             |
| Low Gain  | -15–+15 [dB] | Amount of boost/cut for the low-frequency range  |
| High Gain | -15–+15 [dB] | Amount of boost/cut for the high-frequency range |
| Level     | 0–127        | Output Level                                     |

## SCRIPT 90

This simulates a different analog phaser than Small Phaser.

It is particularly suitable for electric piano.



| Parameter | Value        | Explanation                                      |
|-----------|--------------|--------------------------------------------------|
| Speed     | 0–100        | Speed of modulation                              |
| Depth     | 0–127        | Depth of modulation                              |
| Low Gain  | -15–+15 [dB] | Amount of boost/cut for the low-frequency range  |
| High Gain | -15–+15 [dB] | Amount of boost/cut for the high-frequency range |
| Level     | 0–127        | Output Level                                     |

## SCRIPT 100

This simulates an analog phaser of the past.




| Parameter | Value                     | Explanation                                                                                              |
|-----------|---------------------------|----------------------------------------------------------------------------------------------------------|
| Rate Sync | OFF, ON                   | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)           |
| Rate      | 0.05–10.00 [Hz]           |                                                                                                          |
| Rate Note | Note<br>→ "Note" (p. 106) | Frequency of modulation                                                                                  |
| Duty      | -50–50                    | Adjusts the ratio of speeds at which the modulation rises or falls.                                      |
| Min       | 0–100                     | Lower limit reached by modulation                                                                        |
| Max       | 0–100                     | Upper limit reached by modulation                                                                        |
| Manual Sw | OFF, ON                   | Applies modulation according to the value of the Manual parameter, rather than modulating automatically. |

| Parameter | Value | Explanation                                                         |
|-----------|-------|---------------------------------------------------------------------|
| Manual    | 0–100 | Adjusts the basic frequency from which the sound will be modulated. |
| Resonance | 0–66  | Amount of feedback                                                  |
| Mix       | 0–127 | Level of the phase-shifted sound                                    |
| Level     | 0–127 | Output Level                                                        |

## STEP PHASER


This is a stereo phaser. The phaser effect will be varied gradually.



| Parameter   | Value                      | Explanation                                                                                                                                                                                                                                                                                                                  |
|-------------|----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Mode        | 4-STAGE, 8-STAGE, 12-STAGE | Number of stages in the phaser                                                                                                                                                                                                                                                                                               |
| Manual      | 0–127                      | Adjusts the basic frequency from which the sound will be modulated.                                                                                                                                                                                                                                                          |
| Rate Sync   | OFF, ON                    | When this is "ON", the rate is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                                                                                                                                                                                                                               |
| Rate        | 0.05–10.00 [Hz]            |                                                                                                                                                                                                                                                                                                                              |
| Rate Note   | Note<br>⇒ "Note" (p. 106)  | Frequency of modulation                                                                                                                                                                                                                                                                                                      |
| Depth       | 0–127                      | Depth of modulation                                                                                                                                                                                                                                                                                                          |
| Polarity    | INVERSE, SYNCHRO           | Selects whether the left and right phase of the modulation will be the same or the opposite.<br><b>INVERSE:</b> The left and right phase will be opposite.<br>When using a mono source, this spreads the sound.<br><b>SYNCHRO:</b> The left and right phase will be the same.<br>Select this when inputting a stereo source. |
| Resonance   | 0–127                      | Amount of feedback                                                                                                                                                                                                                                                                                                           |
| Feedback    | -98–+98 [%]                | Adjusts the proportion of the phaser sound that is fed back into the effect. Negative (-) settings will invert the phase.                                                                                                                                                                                                    |
| S Rate Sync | OFF, ON                    | When this is "ON", the rate is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                                                                                                                                                                                                                               |
| S.Rate      | 0.10–20.00 [Hz]            |                                                                                                                                                                                                                                                                                                                              |
| S.Rate Nt   | Note<br>⇒ "Note" (p. 106)  | Rate of the step-wise change in the phaser effect                                                                                                                                                                                                                                                                            |
| Mix         | 0–127                      | Level of the phase-shifted sound                                                                                                                                                                                                                                                                                             |
| Low Gain    | -15–+15 [dB]               | Amount of boost/cut for the low-frequency range                                                                                                                                                                                                                                                                              |
| High Gain   | -15–+15 [dB]               | Amount of boost/cut for the high-frequency range                                                                                                                                                                                                                                                                             |
| Level       | 0–127                      | Output Level                                                                                                                                                                                                                                                                                                                 |

## MLT STAGE PHASER


Extremely high settings of the phase difference produce a deep phaser effect.



| Parameter | Value                                                    | Explanation                                                                                    |
|-----------|----------------------------------------------------------|------------------------------------------------------------------------------------------------|
| Mode      | 4-STAGE, 8-STAGE, 12-STAGE, 16-STAGE, 20-STAGE, 24-STAGE | Number of stages in the phaser                                                                 |
| Manual    | 0–127                                                    | Adjusts the basic frequency from which the sound will be modulated.                            |
| Rate Sync | OFF, ON                                                  | When this is "ON", the rate is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37) |
| Rate      | 0.05–10.00 [Hz]                                          |                                                                                                |
| Rate Note | Note<br>⇒ "Note" (p. 106)                                | Frequency of modulation                                                                        |
| Depth     | 0–127                                                    | Depth of modulation                                                                            |
| Resonance | 0–127                                                    | Amount of feedback                                                                             |
| Mix       | 0–127                                                    | Level of the phase-shifted sound                                                               |
| Pan       | L64–63R                                                  | Stereo location of the output sound                                                            |
| Low Gain  | -15–+15 [dB]                                             | Amount of boost/cut for the low-frequency range                                                |
| High Gain | -15–+15 [dB]                                             | Amount of boost/cut for the high-frequency range                                               |
| Level     | 0–127                                                    | Output Level                                                                                   |

## INFINITE PHASER

A phaser that continues raising/lowering the frequency at which the sound is modulated.



| Parameter | Value        | Explanation                                                                                                 |
|-----------|--------------|-------------------------------------------------------------------------------------------------------------|
| Mode      | 1–4          | Higher values will produce a deeper phaser effect.                                                          |
| Speed     | -100–+100    | Speed at which to raise or lower the frequency at which the sound is modulated<br>(+: upward / -: downward) |
| Resonance | 0–127        | Amount of feedback                                                                                          |
| Mix       | 0–127        | Level of the phase-shifted sound                                                                            |
| Pan       | L64–63R      | Stereo location of the output sound                                                                         |
| Low Gain  | -15–+15 [dB] | Amount of boost/cut for the low-frequency range                                                             |
| High Gain | -15–+15 [dB] | Amount of boost/cut for the high-frequency range                                                            |
| Level     | 0–127        | Output Level                                                                                                |


## Flanger

### FLANGER

This is a stereo flanger (The LFO has the same phase for left and right.).

It produces a metallic resonance that rises and falls like a jet airplane taking off or landing.

A filter is provided so that you can adjust the timbre of the flanged sound.



| Parameter | Value                                                                                              | Explanation                                                                                                                                                              |
|-----------|----------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Type      | OFF, LPF, HPF                                                                                      | Filter type<br><b>OFF:</b> No filter is used<br><b>LPF:</b> Cuts the frequency range above the Cutoff Freq<br><b>HPF:</b> Cuts the frequency range below the Cutoff Freq |
| Cutoff    | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000 [Hz] | Basic frequency of the filter                                                                                                                                            |
| Pre Delay | 0.0–100 [msec]                                                                                     | Adjusts the delay time from the direct sound until the flanger sound is heard.                                                                                           |
| Rate Sync | OFF, ON                                                                                            | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                           |
| Rate      | 0.05–10.00 [Hz]                                                                                    |                                                                                                                                                                          |
| Rate Note | Note<br>→ "Note" (p. 106)                                                                          | Frequency of modulation                                                                                                                                                  |
| Depth     | 0–127                                                                                              | Depth of modulation                                                                                                                                                      |
| Phase     | 0–180 [deg]                                                                                        | Spatial spread of the sound                                                                                                                                              |
| Feedback  | -98→+98 [%]                                                                                        | Adjusts the proportion of the flanger sound that is fed back into the effect. Negative (-) settings will invert the phase.                                               |
| Low Gain  | -15→+15 [dB]                                                                                       | Amount of boost/cut for the low-frequency range                                                                                                                          |
| High Gain | -15→+15 [dB]                                                                                       | Amount of boost/cut for the high-frequency range                                                                                                                         |
| Balance   | D100:0W–D0:100W                                                                                    | Volume balance between the direct sound (D) and the flanger sound (W)                                                                                                    |
| Level     | 0–127                                                                                              | Output Level                                                                                                                                                             |

### SBF-325 (Flanger)

This effect reproduces Roland's SBF-325 analog flanger.


It provides three types of flanging effect (which adds a metallic resonance to the original sound) and a chorus-type effect.



| Parameter  | Value                     | Explanation                                                                                                                                                                                             |
|------------|---------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Mode       |                           | Types of flanging effect                                                                                                                                                                                |
|            | FL1                       | A typical mono flanger                                                                                                                                                                                  |
|            | FL2                       | A stereo flanger that preserves the stereo positioning of the original sound                                                                                                                            |
|            | FL3                       | A cross-mix flanger that produces a more intense effect                                                                                                                                                 |
| Rate Sync  | CHO                       | A chorus effect                                                                                                                                                                                         |
|            | OFF, ON                   | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                                                          |
| Rate       | 0.02–5.00 [Hz]            |                                                                                                                                                                                                         |
| Rate Note  | Note<br>→ "Note" (p. 106) | Modulation frequency of the flanger effect                                                                                                                                                              |
| Depth      | 0–127                     | Modulation depth of the flanger effect                                                                                                                                                                  |
| Manual     | 0–127                     | Center frequency at which the flanger effect is applied                                                                                                                                                 |
| Feedback   | 0–127                     | Amount by which the flanging effect is boosted<br>If Mode is CHO, this setting is ignored.                                                                                                              |
| RMod Phase | NORM, INV                 | Phase of the right channel modulation:<br>Normally, you will leave this at Normal (NORM).<br>If you specify Inverted (INV), the modulation (upward/downward movement) of the right channel is inverted. |
| L Phase    | NORM, INV                 | Phase when mixing the flanging sound with the original sound                                                                                                                                            |
| R Phase    | NORM, INV                 | <b>NORM:</b> normal phase<br><b>INV:</b> inverse phase                                                                                                                                                  |
| Level      | 0–127                     | Output Level                                                                                                                                                                                            |

## STEP FLANGER

This is a flanger in which the flanger pitch changes in steps. The speed at which the pitch changes can also be specified in terms of a note-value of a specified tempo.




| Parameter   | Value                                                                                              | Explanation                                                                                                                                                              |
|-------------|----------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Type        | OFF, LPF, HPF                                                                                      | Filter type<br><b>OFF:</b> No filter is used<br><b>LPF:</b> Cuts the frequency range above the Cutoff Freq<br><b>HPF:</b> Cuts the frequency range below the Cutoff Freq |
| Cutoff      | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000 [Hz] | Basic frequency of the filter                                                                                                                                            |
| Pre Delay   | 0.0–100 [msec]                                                                                     | Adjusts the delay time from the direct sound until the flanger sound is heard.                                                                                           |
| Rate Sync   | OFF, ON                                                                                            | When this is "ON", the rate is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                                                                           |
| Rate        | 0.05–10.00 [Hz]                                                                                    |                                                                                                                                                                          |
| Rate Note   | Note<br>⇒ "Note" (p. 106)                                                                          | Frequency of modulation                                                                                                                                                  |
| Depth       | 0–127                                                                                              | Depth of modulation                                                                                                                                                      |
| Phase       | 0–180 [deg]                                                                                        | Spatial spread of the sound                                                                                                                                              |
| Feedback    | -98–+98 [%]                                                                                        | Adjusts the proportion of the flanger sound that is fed back into the effect. Negative (-) settings will invert the phase.                                               |
| S.Rate Sync | OFF, ON                                                                                            | When this is "ON", the rate is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                                                                           |
| S.Rate      | 0.10–20.00 [Hz]                                                                                    |                                                                                                                                                                          |
| S.Rate Nt   | Note<br>⇒ "Note" (p. 106)                                                                          | Rate (period) of pitch change                                                                                                                                            |
| Low Gain    | -15–+15 [dB]                                                                                       | Amount of boost/cut for the low-frequency range                                                                                                                          |
| High Gain   | -15–+15 [dB]                                                                                       | Amount of boost/cut for the high-frequency range                                                                                                                         |
| Balance     | D100:0W–D0:100W                                                                                    | Volume balance between the direct sound (D) and the flanger sound (W)                                                                                                    |
| Level       | 0–127                                                                                              | Output Level                                                                                                                                                             |

## Chorus

### CHORUS


This is a stereo chorus. A filter is provided so that you can adjust the timbre of the chorus sound.



| Parameter | Value                                                                                              | Explanation                                                                                                                                                              |
|-----------|----------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Type      | OFF, LPF, HPF                                                                                      | Filter type<br><b>OFF:</b> No filter is used<br><b>LPF:</b> Cuts the frequency range above the Cutoff Freq<br><b>HPF:</b> Cuts the frequency range below the Cutoff Freq |
| Cutoff    | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000 [Hz] | Basic frequency of the filter                                                                                                                                            |
| Pre Delay | 0.0–100 [msec]                                                                                     | Adjusts the delay time from the direct sound until the chorus sound is heard.                                                                                            |
| Rate Sync | OFF, ON                                                                                            | When this is "ON", the rate is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                                                                           |
| Rate      | 0.05–10.00 [Hz]                                                                                    |                                                                                                                                                                          |
| Rate Note | Note<br>⇒ "Note" (p. 106)                                                                          | Frequency of modulation                                                                                                                                                  |
| Depth     | 0–127                                                                                              | Depth of modulation                                                                                                                                                      |
| Phase     | 0–180 [deg]                                                                                        | Spatial spread of the sound                                                                                                                                              |
| Low Gain  | -15–+15 [dB]                                                                                       | Amount of boost/cut for the low-frequency range                                                                                                                          |
| High Gain | -15–+15 [dB]                                                                                       | Amount of boost/cut for the high-frequency range                                                                                                                         |
| Balance   | D100:0W–D0:100W                                                                                    | Volume balance between the direct sound (D) and the chorus sound (W)                                                                                                     |
| Level     | 0–127                                                                                              | Output Level                                                                                                                                                             |

## HEXA-CHORUS


Uses a six-phase chorus (six layers of chorused sound) to give richness and spatial spread to the sound.



| Parameter  | Value                     | Explanation                                                                                                                                                                                                              |
|------------|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pre Delay  | 0.0–100 [msec]            | Adjusts the delay time from the direct sound until the chorus sound is heard.                                                                                                                                            |
| Rate Sync  | OFF, ON                   | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                                                                           |
| Rate       | 0.05–10.00 [Hz]           |                                                                                                                                                                                                                          |
| Rate Note  | Note<br>→ "Note" (p. 106) | Frequency of modulation                                                                                                                                                                                                  |
| Depth      | 0–127                     | Depth of modulation                                                                                                                                                                                                      |
| PreDly Dev | 0–20                      | Adjusts the differences in Pre Delay between each chorus sound.                                                                                                                                                          |
| Depth Dev  | -20–+20                   | Adjusts the difference in modulation depth between each chorus sound.                                                                                                                                                    |
| Pan Dev    | 0–20                      | Adjusts the difference in stereo location between each chorus sound.<br><b>0:</b> All chorus sounds will be in the center.<br><b>20:</b> Each chorus sound will be spaced at 60 degree intervals relative to the center. |
| Balance    | D100:0W–D0:100W           | Volume balance between the direct sound (D) and the chorus sound (W)                                                                                                                                                     |
| Level      | 0–127                     | Output Level                                                                                                                                                                                                             |

## TREM CHORUS

This is a chorus effect with added Tremolo (cyclic modulation of volume).




| Parameter | Value          | Explanation                                                                                      |
|-----------|----------------|--------------------------------------------------------------------------------------------------|
| Pre Delay | 0.0–100 [msec] | Adjusts the delay time from the direct sound until the chorus sound is heard.                    |
| Cho Sync  | OFF, ON        | When this is "ON", the effect is synchronized with the current click tempo.<br>→ "Tempo" (p. 37) |

| Parameter    | Value                     | Explanation                                                                                      |
|--------------|---------------------------|--------------------------------------------------------------------------------------------------|
| C.Rate       | 0.05–10.00 [Hz]           |                                                                                                  |
| C.Rate Nt    | Note<br>→ "Note" (p. 106) | Modulation frequency of the chorus effect                                                        |
| Cho Depth    | 0–127                     | Modulation depth of the chorus effect                                                            |
| Trm Sync     | OFF, ON                   | When this is "ON", the effect is synchronized with the current click tempo.<br>→ "Tempo" (p. 37) |
| T.Rate       | 0.05–10.00 [Hz]           |                                                                                                  |
| T.Rate Nt    | Note<br>→ "Note" (p. 106) | Modulation frequency of the tremolo effect                                                       |
| Trm Separate | 0–127                     | Depth of the tremolo effect                                                                      |
| Trm Phase    | 0–180 [deg]               | Spread of the tremolo effect                                                                     |
| Balance      | D100:0W–D0:100W           | Volume balance between the direct sound (D) and the tremolo chorus sound (W)                     |
| Level        | 0–127                     | Output Level                                                                                     |

## SPACE-D

This is a multiple chorus that applies two-phase modulation in stereo. It gives no impression of modulation, but produces a transparent chorus effect.




| Parameter | Value                     | Explanation                                                                                    |
|-----------|---------------------------|------------------------------------------------------------------------------------------------|
| Pre Delay | 0.0–100 [msec]            | Adjusts the delay time from the direct sound until the chorus sound is heard.                  |
| Rate Sync | OFF, ON                   | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37) |
| Rate      | 0.05–10.00 [Hz]           |                                                                                                |
| Rate Note | Note<br>→ "Note" (p. 106) | Frequency of modulation                                                                        |
| Depth     | 0–127                     | Depth of modulation                                                                            |
| Phase     | 0–180 [deg]               | Spatial spread of the sound                                                                    |
| Low Gain  | -15–+15 [dB]              | Amount of boost/cut for the low-frequency range                                                |
| High Gain | -15–+15 [dB]              | Amount of boost/cut for the high-frequency range                                               |
| Balance   | D100:0W–D0:100W           | Volume balance between the direct sound (D) and the chorus sound (W)                           |
| Level     | 0–127                     | Output Level                                                                                   |

## CE-1 (Chorus)

This models the classic BOSS CE-1 chorus effect unit.

It provides a chorus sound with a distinctively analog warmth.



| Parameter | Value        | Explanation                                      |
|-----------|--------------|--------------------------------------------------|
| Intensity | 0–127        | Chorus depth                                     |
| Low Gain  | -15–+15 [dB] | Amount of boost/cut for the low-frequency range  |
| High Gain | -15–+15 [dB] | Amount of boost/cut for the high-frequency range |
| Level     | 0–127        | Output Level                                     |

## SDD-320 (DIMENSION D)


This models Roland's DIMENSION D (SDD-320). It provides a clear chorus sound.



| Parameter | Value                     | Explanation                                      |
|-----------|---------------------------|--------------------------------------------------|
| Mode      | 1, 2, 3, 4, 1+4, 2+4, 3+4 | Switches the mode.                               |
| Low Gain  | -15–+15 [dB]              | Amount of boost/cut for the low-frequency range  |
| High Gain | -15–+15 [dB]              | Amount of boost/cut for the high-frequency range |
| Level     | 0–127                     | Output Level                                     |

## JUNO CHORUS (JUNO-106 Chorus)

This models the chorus effects of the Roland JUNO-106.




| Parameter | Value                    | Explanation                                                                               |
|-----------|--------------------------|-------------------------------------------------------------------------------------------|
| Mode      | I, II, I+II, JX I, JX II | Type of Chorus<br><b>I+II:</b> The state in which two buttons are pressed simultaneously. |
| Noise Lv  | 0–127                    | Volume of the noise produced by chorus                                                    |
| Balance   | D100:0W–D0:100W          | Volume balance between the dry sound (D) and effect sound (W)                             |
| Level     | 0–127                    | Output Level                                                                              |

## Modulation

### RING MODULATOR

This is an effect that applies amplitude modulation (AM) to the input signal, producing bell-like sounds. You can also change the modulation frequency in response to changes in the volume of the sound sent into the effect.



| Parameter | Value           | Explanation                                                                                                                                                                                                                         |
|-----------|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Frequency | 0–127           | Adjusts the frequency at which modulation is applied.                                                                                                                                                                               |
| Sens      | 0–127           | Adjusts the amount of frequency modulation applied.                                                                                                                                                                                 |
| Polarity  | UP, DOWN        | Determines whether the frequency modulation moves towards higher frequencies or lower frequencies.<br><b>UP:</b> The filter will change toward a higher frequency.<br><b>DOWN:</b> The filter will change toward a lower frequency. |
| Low Gain  | -15–+15 [dB]    | Amount of boost/cut for the low-frequency range                                                                                                                                                                                     |
| High Gain | -15–+15 [dB]    | Amount of boost/cut for the high-frequency range                                                                                                                                                                                    |
| Balance   | D100:0W–D0:100W | Volume balance between the direct sound (D) and the effect sound (W)                                                                                                                                                                |
| Level     | 0–127           | Output Level                                                                                                                                                                                                                        |

### TREMOLO

Cyclically changes the volume.




| Parameter | Value                          | Explanation                                                                                                                                                      |
|-----------|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Mod Wave  | TRI, SQR, SIN, SAW1, SAW2, TRP | Modulation Wave<br><b>TRI:</b> Triangle wave<br><b>SQR:</b> Square wave<br><b>SIN:</b> Sine wave<br><b>SAW1/2:</b> Sawtooth wave<br><b>TRP:</b> Trapezoidal wave |
| Rate Sync | OFF, ON                        | When this is "ON", the rate is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                                                                   |
| Rate      | 0.05–10.00 [Hz]                |                                                                                                                                                                  |
| Rate Note | Note<br>⇒ "Note" (p. 106)      | Frequency of the change                                                                                                                                          |

| Parameter | Value        | Explanation                                      |
|-----------|--------------|--------------------------------------------------|
| Depth     | 0–127        | Depth to which the effect is applied             |
| Low Gain  | -15–+15 [dB] | Amount of boost/cut for the low-frequency range  |
| High Gain | -15–+15 [dB] | Amount of boost/cut for the high-frequency range |
| Level     | 0–127        | Output Level                                     |

## AUTO PAN

Cyclically modulates the stereo location of the sound.



| Parameter | Value                          | Explanation                                                                                                                                                      |
|-----------|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Mod Wave  | TRI, SQR, SIN, SAW1, SAW2, TRP | Modulation Wave<br><b>TRI:</b> Triangle wave<br><b>SQR:</b> Square wave<br><b>SIN:</b> Sine wave<br><b>SAW1/2:</b> Sawtooth wave<br><b>TRP:</b> Trapezoidal wave |
|           | SAW1 R, SAW2 L                 |                                                                                                                                                                  |
| Rate Sync | OFF, ON                        | When this is "ON", the rate is synchronized with the current click tempo.<br>➔ "Tempo" (p. 37)                                                                   |
| Rate      | 0.05–10.00 [Hz]                |                                                                                                                                                                  |
| Rate Note | Note<br>➔ "Note" (p. 106)      | Frequency of the change                                                                                                                                          |
| Depth     | 0–127                          | Depth to which the effect is applied                                                                                                                             |
| Low Gain  | -15–+15 [dB]                   | Amount of boost/cut for the low-frequency range                                                                                                                  |
| High Gain | -15–+15 [dB]                   | Amount of boost/cut for the high-frequency range                                                                                                                 |
| Level     | 0–127                          | Output Level                                                                                                                                                     |

## SLICER

By applying successive cuts to the sound, this effect turns a conventional sound into a sound that appears to be played as a backing phrase. This is especially effective when applied to sustain-type sounds.




| Parameter     | Value                     | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|---------------|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Step 1–16     | 0–127                     | Level at each step                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |
| Rate Sync     | OFF, ON                   | When this is "ON", the rate is synchronized with the current click tempo.<br>➔ "Tempo" (p. 37)                                                                                                                                                                                                                                                                                                                                                                                                  |
| Rate          | 0.05–10.00 [Hz]           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| Rate Note     | Note<br>➔ "Note" (p. 106) | Rate at which the 16-step sequence will cycle                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
| Attack        | 0–127                     | Speed at which the level changes between steps                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| In Sync Sw    | OFF, ON                   | Specifies whether an input note will cause the sequence to resume from the first step of the sequence (ON) or not (OFF)                                                                                                                                                                                                                                                                                                                                                                         |
| In Sync Thres | 0–127                     | Volume at which an input note will be detected                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| Mode          | LEGATO, SLASH             | Sets the manner in which the volume changes as one step progresses to the next.<br><b>LEGATO:</b> The change in volume from one step's level to the next remains unaltered. If the level of a following step is the same as the one preceding it, there is no change in volume.<br><b>SLASH:</b> The level is momentarily set to 0 before progressing to the level of the next step.<br>This change in volume occurs even if the level of the following step is the same as the preceding step. |
| Shuffle       | 0–127                     | Timing of volume changes in levels for even-numbered steps (step 2, step 4, step 6...)<br>The higher the value, the later the beat progresses.                                                                                                                                                                                                                                                                                                                                                  |
| Level         | 0–127                     | Output Level                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |

## ROTARY

This simulates a classic rotary speaker of the past.

Since the operation of the high-frequency and low-frequency rotors can be specified independently, the distinctive modulation can be reproduced realistically. This is most effective on organ patches.




| Parameter  | Value           | Explanation                                                                                                                                                                                                        |
|------------|-----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Speed      | SLOW, FAST      | Simultaneously switch the rotational speed of the low frequency rotor and high frequency rotor.<br><b>SLOW:</b> Slows down the rotation to the Slow Rate.<br><b>FAST:</b> Speeds up the rotation to the Fast Rate. |
| Wf Slow    | 0.05–10.00 [Hz] | Slow speed (SLOW) of the low frequency rotor                                                                                                                                                                       |
| Wf Fast    | 0.05–10.00 [Hz] | Fast speed (FAST) of the low frequency rotor                                                                                                                                                                       |
| Wf Accel   | 0–15            | Adjusts the time it takes the low frequency rotor to reach the newly selected speed when switching from fast to slow (or slow to fast) speed. Lower values will require longer times.                              |
| Wf Level   | 0–127           | Volume of the low frequency rotor                                                                                                                                                                                  |
| Tw Slow    | 0.05–10.00 [Hz] | Settings of the high frequency rotor<br>The parameters are the same as for the low frequency rotor                                                                                                                 |
| Tw Fast    | 0.05–10.00 [Hz] |                                                                                                                                                                                                                    |
| Tw Accel   | 0–15            |                                                                                                                                                                                                                    |
| Tw Level   | 0–127           |                                                                                                                                                                                                                    |
| Separation | 0–127           | Spatial dispersion of the sound                                                                                                                                                                                    |
| Level      | 0–127           | Output Level                                                                                                                                                                                                       |

## VK ROTARY

This type provides modified response for the rotary speaker, with the low end boosted further.

This effect features the same specifications as the VK-7's built-in rotary speaker.



| Parameter | Value           | Explanation                                                                                                                                                          |
|-----------|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Speed     | SLOW, FAST      | Rotational speed of the rotating speaker<br><b>SLOW:</b> Slow<br><b>FAST:</b> Fast                                                                                   |
| Brake     | OFF, ON         | Switches the rotation of the rotary speaker.<br>When this is turned on, the rotation will gradually stop. When it is turned off, the rotation will gradually resume. |
| Wf Slow   | 0.05–10.00 [Hz] | Low-speed rotation speed of the woofer                                                                                                                               |
| Wf Fast   | 0.05–10.00 [Hz] | High-speed rotation speed of the woofer                                                                                                                              |
| Wf Trs Up | 0–127           | Adjusts the rate at which the woofer rotation speeds up when the rotation is switched from Slow to Fast.                                                             |
| Wf Trs Dw | 0–127           | Adjusts the rate at which the woofer rotation speeds up when the rotation is switched from Fast to Slow.                                                             |
| Wf Level  | 0–127           | Volume of the woofer                                                                                                                                                 |
| Tw Slow   | 0.05–10.00 [Hz] | Settings of the tweeter<br>The parameters are the same as for the woofer.                                                                                            |
| Tw Fast   | 0.05–10.00 [Hz] |                                                                                                                                                                      |
| Tw Trs Up | 0–127           |                                                                                                                                                                      |
| Tw Trs Dw | 0–127           |                                                                                                                                                                      |
| Tw Level  | 0–127           |                                                                                                                                                                      |
| Spread    | 0–10            | Sets the rotary speaker stereo image. The higher the value set, the wider the sound is spread out.                                                                   |
| Low Gain  | -15–+15 [dB]    | Amount of boost/cut for the low-frequency range                                                                                                                      |
| High Gain | -15–+15 [dB]    | Amount of boost/cut for the high-frequency range                                                                                                                     |
| Level     | 0–127           | Output Level                                                                                                                                                         |
| OD Switch | OFF, ON         | Overdrive on/off                                                                                                                                                     |
| OD Gain   | 0–127           | Overdrive input level<br>Higher values will increase the distortion.                                                                                                 |
| OD Drive  | 0–127           | Degree of distortion                                                                                                                                                 |
| OD Level  | 0–127           | Volume of the overdrive                                                                                                                                              |

## Drive/Amp

### OVERDRIVE

This is an overdrive that provides heavy distortion.



| Parameter  | Value                             | Explanation                                                                                                                                                                |
|------------|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Drive      | 0–127                             | Degree of distortion<br>Also changes the volume.                                                                                                                           |
| Tone       | 0–127                             | Sound quality of the Overdrive effect                                                                                                                                      |
| Amp Switch | OFF, ON                           | Turns the Amp Simulator on/off.                                                                                                                                            |
| Amp Type   | SMALL, BUILT-IN, 2-STACK, 3-STACK | Type of guitar amp<br><b>SMALL:</b> Small amp<br><b>BUILT-IN:</b> Single-unit type amp<br><b>2-STACK:</b> Large double stack amp<br><b>3-STACK:</b> Large triple stack amp |
| Low Gain   | -15–+15 [dB]                      | Amount of boost/cut for the low-frequency range                                                                                                                            |
| High Gain  | -15–+15 [dB]                      | Amount of boost/cut for the high-frequency range                                                                                                                           |
| Pan        | L64–63R                           | Stereo location of the output sound                                                                                                                                        |
| Level      | 0–127                             | Output Level                                                                                                                                                               |

### DISTORTION

Produces a more intense distortion than Overdrive.



| Parameter  | Value                             | Explanation                                                                                                                                                                |
|------------|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Drive      | 0–127                             | Degree of distortion<br>Also changes the volume.                                                                                                                           |
| Tone       | 0–127                             | Sound quality of the Overdrive effect                                                                                                                                      |
| Amp Switch | OFF, ON                           | Turns the Amp Simulator on/off.                                                                                                                                            |
| Amp Type   | SMALL, BUILT-IN, 2-STACK, 3-STACK | Type of guitar amp<br><b>SMALL:</b> Small amp<br><b>BUILT-IN:</b> Single-unit type amp<br><b>2-STACK:</b> Large double stack amp<br><b>3-STACK:</b> Large triple stack amp |
| Low Gain   | -15–+15 [dB]                      | Amount of boost/cut for the low-frequency range                                                                                                                            |
| High Gain  | -15–+15 [dB]                      | Amount of boost/cut for the high-frequency range                                                                                                                           |
| Pan        | L64–63R                           | Stereo location of the output sound                                                                                                                                        |
| Level      | 0–127                             | Output Level                                                                                                                                                               |

### T-SCREAM


This models a classic analog overdrive. It is distinctive in adding an appropriate amount of overtones without muddying the sound.



| Parameter  | Value | Explanation                                      |
|------------|-------|--------------------------------------------------|
| Distortion | 0–127 | Degree of distortion<br>Also changes the volume. |
| Tone       | 0–127 | Tonal character of the overdrive                 |
| Level      | 0–127 | Output Level                                     |

### FUZZ


Adds overtones and intensely distorts the sound.



| Parameter | Value | Explanation                                                       |
|-----------|-------|-------------------------------------------------------------------|
| Drive     | 0–127 | Adjusts the depth of distortion.<br>This also changes the volume. |
| Tone      | 0–100 | Sound quality of the Overdrive effect                             |
| Level     | 0–127 | Output Level                                                      |

### TONE FATTENER


This effect applies distinctive distortion, adding overtones to give more depth to the sound.



| Parameter  | Value     | Explanation                                  |
|------------|-----------|----------------------------------------------|
| Odd Level  | 0–400 [%] | Raising the value adds odd-order overtones.  |
| Even Level | 0–400 [%] | Raising the value adds even-order overtones. |
| Level      | 0–127     | Output Level                                 |

## HMS DISTORTION


This is a distortion-type effect that models the vacuum tube amp section of a rotary speaker of the past.



| Parameter | Value | Explanation            |
|-----------|-------|------------------------|
| Dist      | 0–127 | Strength of distortion |
| Level     | 0–127 | Output Level           |

## SATURATOR

This effect combines overdrive and filter.



| Parameter  | Value                    | Explanation                                                                                                                                                                                                                                                                                                                                                                                                                 |
|------------|--------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pre Type   | THRU, LPF, HPF, LSV, HSV | Types of filter that precedes the distortion processing<br><b>THRU</b> : No filter is applied<br><b>LPF</b> : A filter that passes the sound below the specified frequency<br><b>HPF</b> : A filter that passes the sound above the specified frequency<br><b>LSV</b> : A filter that boosts/cuts the sound below the specified frequency<br><b>HSV</b> : A filter that boosts/cuts the sound above the specified frequency |
| Pre Freq   | 20–16000 [Hz]            | Frequency at which the pre-distortion filter operates                                                                                                                                                                                                                                                                                                                                                                       |
| Pre Gain   | -24.0–+24.0 [dB]         | For the LSV/HSV types, the amount of boost/cut                                                                                                                                                                                                                                                                                                                                                                              |
| Drive      | 0.0–48.0 [dB]            | Strength of distortion                                                                                                                                                                                                                                                                                                                                                                                                      |
| Post1 Type | THRU, LPF, HPF, LSV, HSV | Type of filter 1 which follows the distortion processing                                                                                                                                                                                                                                                                                                                                                                    |
| Post1 Frq  | 20–16000 [Hz]            | Frequency at which post-distortion filter 1 operates                                                                                                                                                                                                                                                                                                                                                                        |
| Post1 Gain | -24.0–+24.0 [dB]         | For the LSV/HSV types, the amount of boost/cut                                                                                                                                                                                                                                                                                                                                                                              |
| Post2 Type | THRU, LPF, HPF, LSV, HSV | Type of filter 2 which follows the distortion processing                                                                                                                                                                                                                                                                                                                                                                    |
| Post2 Frq  | 20–16000 [Hz]            | Frequency at which post-distortion filter 2 operates                                                                                                                                                                                                                                                                                                                                                                        |
| Post2 Gain | -24.0–+24.0 [dB]         | For the LSV/HSV types, the amount of boost/cut                                                                                                                                                                                                                                                                                                                                                                              |

| Parameter  | Value                    | Explanation                                                                                                                                                                                                                                                                                                                                                                                  |
|------------|--------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Post3 Type | THRU, LPF, HPF, BPF, PKG | Type of filter 3 which follows the distortion processing<br><b>THRU</b> : No filter is applied<br><b>LPF</b> : A filter that passes the sound below the specified frequency<br><b>HPF</b> : A filter that passes the sound above the specified frequency<br><b>BPF</b> : A filter that passes only the specified frequency<br><b>PKG</b> : A filter that boosts/cuts the specified frequency |
| Post3 Freq | 20–16000 [Hz]            | Frequency at which post-distortion filter 3 operates                                                                                                                                                                                                                                                                                                                                         |
| Post3 Gain | -24.0–+24.0 [dB]         | For the PKG type, the amount of boost/cut                                                                                                                                                                                                                                                                                                                                                    |
| Post3 Q    | 0.5–16.0                 | Width of the frequency range affected by the filter                                                                                                                                                                                                                                                                                                                                          |
| Sense      | -60.0–0.0 [dB]           | Adjust this value so that the sound is not made louder when distortion is applied.                                                                                                                                                                                                                                                                                                           |
| Post Gain  | -48.0–+12.0 [dB]         | Gain following distortion processing                                                                                                                                                                                                                                                                                                                                                         |
| Balance    | D100:0W–D0:100W          | Volume balance between the dry sound (D) and effect sound (W)                                                                                                                                                                                                                                                                                                                                |
| Level      | 0–127                    | Output Level                                                                                                                                                                                                                                                                                                                                                                                 |

## DRUM SATURATOR


A saturator which distorts the sound is connected in parallel with a compressor, producing a rougher tonal character and boosting the loudness. This also cuts the low-frequency region of the input audio.



| Parameter       | Value       | Explanation                                      |
|-----------------|-------------|--------------------------------------------------|
| Saturator Gain  | 0–127       | Input volume to the saturator                    |
| Saturator Drive | 0–127       | Degree of distortion                             |
| Saturator Level | 0–127       | Output volume of the saturator                   |
| Comp Depth      | 0–127       | Amount of compression                            |
| Comp Level      | 0–127       | Output level of the compressor                   |
| Hi Gain         | -12–+6 [dB] | Amount of boost/cut for the high-frequency range |
| Level           | 0–127       | Output Level                                     |

## WARM SATURATOR

This is a variety of saturator, and is distinctive for its warmer sound.




| Parameter  | Value                    | Explanation                                                                                                                                                                                                                                                                                                                                                                                                            |
|------------|--------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Low Freq   | 20–16000 [Hz]            | Input filter (low range)<br>Boosts/cuts the sound below the specified frequency.                                                                                                                                                                                                                                                                                                                                       |
| Low Gain   | -24.0–+24.0 [dB]         | Input filter (low range)<br>Amount of boost/cut                                                                                                                                                                                                                                                                                                                                                                        |
| Hi Slope   | THRU, -12dB, -24dB       | Input filter (high frequency) slope (attenuation characteristics or amount of attenuation per octave)<br><b>THRU:</b> No attenuation<br><b>-12 dB:</b> Gentle<br><b>-24 dB:</b> Steep                                                                                                                                                                                                                                  |
| Hi Freq    | 20–16000 [Hz]            | Input filter (high range)<br>Boosts/cuts the sound above the specified frequency.                                                                                                                                                                                                                                                                                                                                      |
| Pre Type   | THRU, LPF, HPF, LSV, HSV | Types of filter that precedes the distortion processing<br><b>THRU:</b> No filter is applied<br><b>LPF:</b> A filter that passes the sound below the specified frequency<br><b>HPF:</b> A filter that passes the sound above the specified frequency<br><b>LSV:</b> A filter that boosts/cuts the sound below the specified frequency<br><b>HSV:</b> A filter that boosts/cuts the sound above the specified frequency |
| Pre Freq   | 20–16000 [Hz]            | Frequency at which the pre-distortion filter operates                                                                                                                                                                                                                                                                                                                                                                  |
| Pre Gain   | -24.0–+24.0 [dB]         | For the LSV/HSV types, the amount of boost/cut                                                                                                                                                                                                                                                                                                                                                                         |
| Drive      | 0.0–48.0 [dB]            | Strength of distortion                                                                                                                                                                                                                                                                                                                                                                                                 |
| Post1 Type | THRU, LPF, HPF, LSV, HSV | Type of filter 1 which follows the distortion processing                                                                                                                                                                                                                                                                                                                                                               |
| Post1 Freq | 20–16000 [Hz]            | Frequency at which post-distortion filter 1 operates                                                                                                                                                                                                                                                                                                                                                                   |
| Post1 Gain | -24.0–+24.0 [dB]         | For the LSV/HSV types, the amount of boost/cut                                                                                                                                                                                                                                                                                                                                                                         |
| Post2 Type | THRU, LPF, HPF, LSV, HSV | Type of filter 2 which follows the distortion processing                                                                                                                                                                                                                                                                                                                                                               |
| Post2 Freq | 20–16000 [Hz]            | Frequency at which post-distortion filter 2 operates                                                                                                                                                                                                                                                                                                                                                                   |
| Post2 Gain | -24.0–+24.0 [dB]         | For the LSV/HSV types, the amount of boost/cut                                                                                                                                                                                                                                                                                                                                                                         |

| Parameter  | Value                    | Explanation                                                                                                                                                                                                                                                                                                                                                                             |
|------------|--------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Post3 Type | THRU, LPF, HPF, BPF, PKG | Type of filter 3 which follows the distortion processing<br><b>THRU:</b> No filter is applied<br><b>LPF:</b> A filter that passes the sound below the specified frequency<br><b>HPF:</b> A filter that passes the sound above the specified frequency<br><b>BPF:</b> A filter that passes only the specified frequency<br><b>PKG:</b> A filter that boosts/cuts the specified frequency |
| Post3 Freq | 20–16000 [Hz]            | Frequency at which post-distortion filter 3 operates                                                                                                                                                                                                                                                                                                                                    |
| Post3 Gain | -24.0–+24.0 [dB]         | For the PKG type, the amount of boost/cut                                                                                                                                                                                                                                                                                                                                               |
| Post3 Q    | 0.5–16.0                 | Width of the frequency range affected by the filter                                                                                                                                                                                                                                                                                                                                     |
| Sense      | -60.0–0.0 [dB]           | Adjust this value so that the sound is not made louder when distortion is applied.                                                                                                                                                                                                                                                                                                      |
| Post Gain  | -48.0–+12.0 [dB]         | Gain following distortion processing                                                                                                                                                                                                                                                                                                                                                    |
| Balance    | D100:0W–D0:100W          | Volume balance between the dry sound (D) and effect sound (W)                                                                                                                                                                                                                                                                                                                           |
| Level      | 0–127                    | Output Level                                                                                                                                                                                                                                                                                                                                                                            |

## GUITAR AMP SIMULATOR

This is an effect that simulates the sound of a guitar amplifier.




| Parameter  | Value       | Explanation                                                                                                                                               |
|------------|-------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pre Amp Sw | OFF, ON     | Turns the amp switch on/off.                                                                                                                              |
| ATyp       | JC-120      | This models the sound of the Roland JC-120.                                                                                                               |
|            | CLEAN TWIN  | This models a Fender Twin Reverb.                                                                                                                         |
|            | MATCH DRIVE | This models the sound input to left input on a Matchless D/C-30.<br>A simulation of the latest tube amp widely used in styles from blues rock and fusion. |
|            | BG LEAD     | This models the lead sound of the MESA/ Boogie combo amp.<br>The sound of a tube amp typical of the late '70s to '80s.                                    |
|            | MS1959I     | This models the sound input to Input I on a Marshall 1959. This is a trebly sound suited to hard rock.                                                    |
|            | MS1959II    | This models the sound input to Input II on a Marshall 1959.                                                                                               |

| Parameter  | Value             | Explanation                                                                                                                                                         |                                                |            |
|------------|-------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------|------------|
| ATyp       | MS1959I+II        | A model of the Marshall 1959 sound, with inputs I and II connected in parallel. Offers a sound with a more emphasized low-end than MS1959I.                         |                                                |            |
|            | SLDN LEAD         | This models a Soldano SLO-100. This is the typical sound of the eighties.                                                                                           |                                                |            |
|            | METAL 5150        | This models the lead channel of a Peavey EVH 5150.                                                                                                                  |                                                |            |
|            | METAL LEAD        | This is distortion sound that is ideal for performances of heavy riffs.                                                                                             |                                                |            |
|            | OD-1              | This models the sound of the BOSS OD-1. This produces sweet, mild distortion.                                                                                       |                                                |            |
|            | OD-2 TURBO        | This is the high-gain overdrive sound of the BOSS OD-2.                                                                                                             |                                                |            |
|            | DISTORTION        | This gives a basic, traditional distortion sound.                                                                                                                   |                                                |            |
|            | FUZZ              | A fuzz sound with rich harmonic content.                                                                                                                            |                                                |            |
| Drive      | 0–127             | Volume and amount of distortion of the amp                                                                                                                          |                                                |            |
| Master     | 0–127             | Volume of the entire pre-amp                                                                                                                                        |                                                |            |
| Gain       | LOW, MIDDLE, HIGH | Amount of pre-amp distortion                                                                                                                                        |                                                |            |
| Bass       | 0–127             | Tone of the bass/mid/treble frequency range                                                                                                                         |                                                |            |
| Middle     | 0–127             |                                                                                                                                                                     |                                                |            |
| Treble     | 0–127             |                                                                                                                                                                     |                                                |            |
| Presence   | 0–127             | Tone for the ultra-high frequency range                                                                                                                             |                                                |            |
| Bright     | OFF, ON           | Turning this “On” produces a sharper and brighter sound.<br><br>* This parameter applies to the “JC-120”, “CLEAN TWIN”, “MATCH DRIVE”, and “BG LEAD” Pre Amp Types. |                                                |            |
| Speaker Sw | OFF, ON           | Selects whether the sound will be sent through the speaker simulation (ON) or not (OFF)                                                                             |                                                |            |
| STyp       |                   | Cabinet                                                                                                                                                             | Diameter (in inches) and number of the speaker | Microphone |
|            | SMALL 1           | small open-back enclosure                                                                                                                                           | 10                                             | dynamic    |
|            | SMALL 2           | small open-back enclosure                                                                                                                                           | 10                                             | dynamic    |
|            | MIDDLE            | open back enclosure                                                                                                                                                 | 12 x 1                                         | dynamic    |
|            | JC-120            | open back enclosure                                                                                                                                                 | 12 x 2                                         | dynamic    |
|            | BUILT-IN 1        | open back enclosure                                                                                                                                                 | 12 x 2                                         | dynamic    |
|            | BUILT-IN 2        | open back enclosure                                                                                                                                                 | 12 x 2                                         | condenser  |
|            | BUILT-IN 3        | open back enclosure                                                                                                                                                 | 12 x 2                                         | condenser  |
|            | BUILT-IN 4        | open back enclosure                                                                                                                                                 | 12 x 2                                         | condenser  |
|            | BUILT-IN 5        | open back enclosure                                                                                                                                                 | 12 x 2                                         | condenser  |
|            | BG STACK 1        | sealed enclosure                                                                                                                                                    | 12 x 2                                         | condenser  |
|            | BG STACK 2        | large sealed enclosure                                                                                                                                              | 12 x 2                                         | condenser  |
|            | MS STACK 1        | large sealed enclosure                                                                                                                                              | 12 x 4                                         | condenser  |
|            | MS STACK 2        | large sealed enclosure                                                                                                                                              | 12 x 4                                         | condenser  |
|            | METAL STACK       | large double stack                                                                                                                                                  | 12 x 4                                         | condenser  |
|            | 2-STACK           | large double stack                                                                                                                                                  | 12 x 4                                         | condenser  |
|            | 3-STACK           | large triple stack                                                                                                                                                  | 12 x 4                                         | condenser  |

| Parameter    | Value   | Explanation                                                                                                                                                                                       |
|--------------|---------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Mic Setting  | 1–3     | Adjusts the location of the microphone that is recording the sound of the speaker.<br>This can be adjusted in three steps, with the microphone becoming more distant in the order of 1, 2, and 3. |
| Mic Level    | 0–127   | Volume of the microphone                                                                                                                                                                          |
| Direct Level | 0–127   | Volume of the direct sound                                                                                                                                                                        |
| Pan          | L64–63R | Stereo location of the output sound                                                                                                                                                               |
| Level        | 0–127   | Output Level                                                                                                                                                                                      |

## EP AMP SIMULATOR (RD EP Amp Simulator)

This is an effect that was developed for the RD series SuperNatural E.Piano.



| Parameter  | Value                       | Explanation                                                                                      |
|------------|-----------------------------|--------------------------------------------------------------------------------------------------|
| Bass       | -50–+50                     | Amount of low-frequency boost/cut                                                                |
| Treble     | -50–+50                     | Amount of high-frequency boost/cut                                                               |
| Tremolo Sw | OFF, ON                     | Tremolo on/off                                                                                   |
| Type       | OLDCASE MONO                | A standard electric piano sound of the early 70s (mono)                                          |
|            | OLDCASE STEREO              | A standard electric piano sound of the early 70s (stereo)                                        |
|            | NEWCASE                     | A standard electric piano sound of the late 70s and early 80s                                    |
|            | DYNO                        | A classic modified electric piano                                                                |
|            | WURLY                       | A classic electric piano of the '60s                                                             |
| Speed Sync | OFF, ON                     | When this is “ON”, the speed is synchronized with the current click tempo.<br>→ “Tempo” (p. 37)  |
| Speed      | 0.05–10.00 [Hz]             |                                                                                                  |
| Speed Nt   | Note<br>→ “Note” (p. 106)   | Rate of the tremolo effect                                                                       |
| Depth      | 0–127                       | Depth of the tremolo effect                                                                      |
| Shape      | 0–20                        | Adjusts the waveform of the tremolo.                                                             |
| AMP        | OFF, ON                     | Turns the speaker and distortion on/off                                                          |
| Speaker    | LINE, OLD, NEW, WURLY, TWIN | Type of speaker. If LINE is selected, the sound will not be sent through the speaker simulation. |
| Drive      | 0–127                       | Degree of distortion<br>Also changes the volume.                                                 |
| Level      | 0–127                       | Output Level                                                                                     |

## SPEAKER SIMULATOR

Simulates the speaker type and mic settings used to record the speaker sound.



| Parameter   | Value       | Explanation                                                                                                                                                                                       |
|-------------|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Type        |             | <div>Cabinet</div> <div>Diameter (in inches) and number of the speaker</div> <div>Microphone</div>                                                                                                |
|             | SMALL 1     | small open-back enclosure 10 dynamic                                                                                                                                                              |
|             | SMALL 2     | small open-back enclosure 10 dynamic                                                                                                                                                              |
|             | MIDDLE      | open back enclosure 12 x 1 dynamic                                                                                                                                                                |
|             | JC-120      | open back enclosure 12 x 2 dynamic                                                                                                                                                                |
|             | BUILT-IN 1  | open back enclosure 12 x 2 dynamic                                                                                                                                                                |
|             | BUILT-IN 2  | open back enclosure 12 x 2 condenser                                                                                                                                                              |
|             | BUILT-IN 3  | open back enclosure 12 x 2 condenser                                                                                                                                                              |
|             | BUILT-IN 4  | open back enclosure 12 x 2 condenser                                                                                                                                                              |
|             | BUILT-IN 5  | open back enclosure 12 x 2 condenser                                                                                                                                                              |
|             | BG STACK 1  | sealed enclosure 12 x 2 condenser                                                                                                                                                                 |
|             | BG STACK 2  | large sealed enclosure 12 x 2 condenser                                                                                                                                                           |
|             | MS STACK 1  | large sealed enclosure 12 x 4 condenser                                                                                                                                                           |
|             | MS STACK 2  | large sealed enclosure 12 x 4 condenser                                                                                                                                                           |
|             | METAL STACK | large double stack 12 x 4 condenser                                                                                                                                                               |
| Mic Setting | 1-3         | Adjusts the location of the microphone that is recording the sound of the speaker.<br>This can be adjusted in three steps, with the microphone becoming more distant in the order of 1, 2, and 3. |
|             |             |                                                                                                                                                                                                   |
| Mic Level   | 0-127       | Volume of the microphone                                                                                                                                                                          |
| Direct Lv   | 0-127       | Volume of the direct sound                                                                                                                                                                        |
| Level       | 0-127       | Output Level                                                                                                                                                                                      |

## Comp/Limiter

### COMPRESSOR

Flattens out high levels and boosts low levels, smoothing out fluctuations in volume.



| Parameter | Value                             | Explanation                                                                                                                                                                                                                                 |
|-----------|-----------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Attack    | 0-124                             | Sets the speed at which compression starts                                                                                                                                                                                                  |
| Release   | 0-124                             | Adjusts the time after the signal volume falls below the Threshold Level until compression is no longer applied.                                                                                                                            |
| Threshold | -60-0 [dB]                        | Adjusts the volume at which compression begins                                                                                                                                                                                              |
| Knee      | 0-30 [dB]                         | This smooths out the sonic transition, from when the compression is not engaged until when the compression begins.<br>This gradually applies compression from just before the Threshold point. Higher values produce a smoother transition. |
| Ratio     | 1:1, 1.5:1, 2:1, 4:1, 16:1, INF:1 | Compression ratio                                                                                                                                                                                                                           |
| Post Gain | 0-+18 [dB]                        | Level of the output sound                                                                                                                                                                                                                   |
| Level     | 0-127                             | Output Level                                                                                                                                                                                                                                |

### FETCOMP-78 (FET compressor 78)

This models a classic studio-use FET compressor.



- \* When the INPUT and OUTPUT values are both at 0.0 dB, this indicates a gain of about 40.0 dB.
- \* When you select FETCOMP-78, this effect may output a very loud sound, depending on how the parameters are set. Also, use caution when inputting very loud sounds into the FETCOMP-78 effect, as this may cause the output sound to distort or produce noise. If this happens, lower the In Level L/R or the Out Level L/R, or take other measures to adjust the volume.

| Parameter   | Value                | Explanation                                                   |
|-------------|----------------------|---------------------------------------------------------------|
| Comp Sw     | OFF, ON              | If this is ON, the compression effect is applied.             |
| In Level L  | -INF, -60.0-0.0 [dB] | Adjusts the volume of signal input through the left channel.  |
| In Level R  | -INF, -60.0-0.0 [dB] | Adjusts the volume of signal input through the right channel. |
| Out Level L | -INF, -60.0-0.0 [dB] | Adjusts the volume of signal output from the left channel.    |

| Parameter      | Value                                           | Explanation                                                                                                                                                                                         |
|----------------|-------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Out Level R    | -INF, -60.0–0.0 [dB]                            | Adjusts the volume of signal output from the right channel.                                                                                                                                         |
| Stereo Link Sw | OFF, ON                                         | When this is "ON", the left-right channels are compressed equally to match the louder signal of the two channels (left or right).                                                                   |
| Attack         | 0.0–7.0                                         | Sets the time it takes for compression to start, once the audio input crosses the threshold.<br>A value of 0.0 is the longest time it takes for compression to be applied.                          |
| Release        | 0.0–7.0                                         | Adjusts the time after the input signal volume falls below the threshold until compression stops.<br>A value of 0.0 is the longest time it takes for compression to be applied.                     |
| Ratio Mode     | RATIO 4, RATIO 8, RATIO 12, RATIO 20, RATIO ALL | Adjusts the compression ratio.<br><b>RATIO 4:4:1</b><br><b>RATIO 8:8:1</b><br><b>RATIO 12:12:1</b><br><b>RATIO 20:20:1</b><br><b>RATIO ALL: This works the same as if all buttons were pressed.</b> |

## MID SIDE COMPRESSOR

This effect allows the left/right signals that have similar phase to be adjusted to a different sense of volume than the left/right signals that have different phase.




| Parameter | Value                             | Explanation                                                                                                                                                                                                                               |
|-----------|-----------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| M Comp Sw | OFF, ON                           | Switches whether to adjust the sense of volume for left/right input signals whose phase is similar (in phase).                                                                                                                            |
| M Attack  | 0–124                             | Sets the speed at which compression starts                                                                                                                                                                                                |
| M Release | 0–124                             | Adjusts the time after the signal volume falls below the M Thres Level until compression is no longer applied.                                                                                                                            |
| M Thres   | -60–0 [dB]                        | Adjusts the volume at which compression begins                                                                                                                                                                                            |
| M Knee    | 0–30 [dB]                         | This smooths out the sonic transition, from when the compression is not engaged until when the compression begins.<br>This gradually applies compression from just before the M Thres point. Higher values produce a smoother transition. |
| M Ratio   | 1:1, 1.5:1, 2:1, 4:1, 16:1, INF:1 | Compression ratio                                                                                                                                                                                                                         |
| M Gain    | 0–+18 [dB]                        | Level of the output sound                                                                                                                                                                                                                 |
| S Comp Sw | OFF, ON                           | Switches whether to adjust the sense of volume for left/right input signals whose phase is distant (opposite phase).                                                                                                                      |

| Parameter | Value                             | Explanation                                                                                                                                                                                                                               |
|-----------|-----------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| S Attack  | 0–124                             | Sets the speed at which compression starts                                                                                                                                                                                                |
| S Release | 0–124                             | Adjusts the time after the signal volume falls below the S Thres Level until compression is no longer applied.                                                                                                                            |
| S Thres   | -60–0 [dB]                        | Adjusts the volume at which compression begins                                                                                                                                                                                            |
| S Knee    | 0–30 [dB]                         | This smooths out the sonic transition, from when the compression is not engaged until when the compression begins.<br>This gradually applies compression from just before the S Thres point. Higher values produce a smoother transition. |
| S Ratio   | 1:1, 1.5:1, 2:1, 4:1, 16:1, INF:1 | Compression ratio                                                                                                                                                                                                                         |
| S Gain    | 0–+18 [dB]                        | Level of the output sound                                                                                                                                                                                                                 |
| Level     | 0–127                             | Output Level                                                                                                                                                                                                                              |

## LIMITER

Compresses signals that exceed a specified volume level, preventing distortion from occurring.



| Parameter | Value                  | Explanation                                                                                                      |
|-----------|------------------------|------------------------------------------------------------------------------------------------------------------|
| Release   | 0–127                  | Adjusts the time after the signal volume falls below the Threshold Level until compression is no longer applied. |
| Threshold | 0–127                  | Adjusts the volume at which compression begins                                                                   |
| Ratio     | 1.5:1, 2:1, 4:1, 100:1 | Compression ratio                                                                                                |
| Post Gain | 0–+18 [dB]             | Level of the output sound                                                                                        |
| Low Gain  | -15–+15 [dB]           | Amount of boost/cut for the low-frequency range                                                                  |
| High Gain | -15–+15 [dB]           | Amount of boost/cut for the high-frequency range                                                                 |
| Level     | 0–127                  | Output Level                                                                                                     |

## SUSTAINER


By compressing loud input and boosting low input, this effect keeps the volume consistent to produce a sustain effect without distortion.



| Parameter | Value        | Explanation                                                                                                               |
|-----------|--------------|---------------------------------------------------------------------------------------------------------------------------|
| Sustain   | 0–127        | Adjusts the range in which a low input signal is boosted to a consistent volume.<br>Higher values produce longer sustain. |
| Attack    | 0–127        | Time until the volume is compressed                                                                                       |
| Release   | 0–127        | Time until compression is removed                                                                                         |
| Post Gain | -15–+15 [dB] | Level of the output sound                                                                                                 |
| Low Gain  | -15–+15 [dB] | Amount of boost/cut for the low-frequency range                                                                           |
| High Gain | -15–+15 [dB] | Amount of boost/cut for the high-frequency range                                                                          |
| Level     | 0–127        | Output Level                                                                                                              |

## TRANSIENT


This effect lets you control the way in which the sound attacks and decays.



| Parameter | Value          | Explanation                                                                                                     |
|-----------|----------------|-----------------------------------------------------------------------------------------------------------------|
| Attack    | -50–+50        | Character of the attack.<br>Higher values make the attack more aggressive; lower values make the attack milder. |
| Release   | -50–+50        | Character of the decay.<br>Higher values make the sound linger; lower values make the sound cutoff quickly.     |
| Out Gain  | -24–+12 [dB]   | Output gain                                                                                                     |
| Sens      | LOW, MID, HIGH | Quickness with which the attack is detected                                                                     |
| Level     | 0–127          | Output Level                                                                                                    |

## GATE

Cuts the reverb's delay according to the volume of the sound sent into the effect. Use this when you want to create an artificial-sounding decrease in the reverb's decay.




| Parameter | Value           | Explanation                                                                                                                                                                                                                                             |
|-----------|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Threshold | 0–127           | Volume level at which the gate begins to close                                                                                                                                                                                                          |
| Mode      | GATE, DUCK      | Type of gate<br><b>GATE:</b> The gate will close when the volume of the original sound decreases, cutting the original sound.<br><b>DUCK (Duking):</b> The gate will close when the volume of the original sound increases, cutting the original sound. |
| Attack    | 0–127           | Adjusts the time it takes for the gate to fully open after being triggered.                                                                                                                                                                             |
| Hold      | 0–127           | Adjusts the time it takes for the gate to start closing after the source sound falls beneath the Threshold.                                                                                                                                             |
| Release   | 0–127           | Adjusts the time it takes the gate to fully close after the hold time.                                                                                                                                                                                  |
| Balance   | D100:0W–D0:100W | Volume balance between the direct sound (D) and the effect sound (W)                                                                                                                                                                                    |
| Level     | 0–127           | Output Level                                                                                                                                                                                                                                            |

## Delay


### DELAY

This is a stereo delay.

When Feedback Mode is NORMAL:



When Feedback Mode is CROSS:




| Parameter  | Value                                                                                                      | Explanation                                                                                                                                                         |
|------------|------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Dly L Sync | OFF, ON                                                                                                    | When this is "ON", the rate is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                                                                      |
| DL.Time    | 1–1300 [msec]                                                                                              |                                                                                                                                                                     |
| DLTime Nt  | Note<br>⇒ "Note" (p. 106)                                                                                  | Adjusts the time until the left delay sound is heard.                                                                                                               |
| Dly R Sync | OFF, ON                                                                                                    | When this is "ON", the rate is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                                                                      |
| DR.Time    | 1–1300 [msec]                                                                                              |                                                                                                                                                                     |
| DRTIME Nt  | Note<br>⇒ "Note" (p. 106)                                                                                  | Adjusts the time until the right delay sound is heard.                                                                                                              |
| Phase L    | NORMAL, INVERSE                                                                                            | Phase of left and right delay sound                                                                                                                                 |
| Phase R    | NORMAL, INVERSE                                                                                            | <b>NORMAL:</b> Non-inverted<br><b>INVERT:</b> Inverted                                                                                                              |
| Fbk Mode   | NORMAL, CROSS                                                                                              | Selects the way in which delay sound is fed back into the effect. (See the figures above.)                                                                          |
| Feedback   | -98–+98 [%]                                                                                                | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase.                                            |
| HF Damp    | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Adjusts the frequency above which sound fed back to the effect is filtered out. If you don't want to filter out any high frequencies, set this parameter to BYPASS. |

| Parameter | Value           | Explanation                                                         |
|-----------|-----------------|---------------------------------------------------------------------|
| Low Gain  | -15–+15 [dB]    | Amount of boost/cut for the low-frequency range                     |
| High Gain | -15–+15 [dB]    | Amount of boost/cut for the high-frequency range                    |
| Balance   | D100:0W–D0:100W | Volume balance between the direct sound (D) and the delay sound (W) |
| Level     | 0–127           | Output Level                                                        |


## MOD DELAY

Adds modulation to the delayed sound.

When Feedback Mode is NORMAL:




When Feedback Mode is CROSS:



| Parameter  | Value                     | Explanation                                                                                                              |
|------------|---------------------------|--------------------------------------------------------------------------------------------------------------------------|
| Dly L Sync | OFF, ON                   | When this is "ON", the rate is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                           |
| DL.Time    | 1–1300 [msec]             |                                                                                                                          |
| DLTime Nt  | Note<br>⇒ "Note" (p. 106) | Adjusts the time until the left delay sound is heard.                                                                    |
| Dly R Sync | OFF, ON                   | When this is "ON", the rate is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                           |
| DR.Time    | 1–1300 [msec]             |                                                                                                                          |
| DRTIME Nt  | Note<br>⇒ "Note" (p. 106) | Adjusts the time until the right delay sound is heard.                                                                   |
| Fbk Mode   | NORMAL, CROSS             | Selects the way in which delay sound is fed back into the effect. (See the figures above.)                               |
| Feedback   | -98–+98 [%]               | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase. |

| Parameter | Value                                                                                                      | Explanation                                                                                                                                                                 |
|-----------|------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| HF Damp   | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Adjusts the frequency above which sound fed back to the effect is filtered out. If you don't want to filter out any high frequencies, set this parameter to <b>BYPASS</b> . |
| Rate Sync | OFF, ON                                                                                                    | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                              |
| Rate      | 0.05–10.00 [Hz]                                                                                            |                                                                                                                                                                             |
| Rate Note | Note<br>→ "Note" (p. 106)                                                                                  | Frequency of modulation                                                                                                                                                     |
| Depth     | 0–127                                                                                                      | Depth of modulation                                                                                                                                                         |
| Phase     | 0–180 [deg]                                                                                                | Spatial spread of the sound                                                                                                                                                 |
| Low Gain  | -15–+15 [dB]                                                                                               | Amount of boost/cut for the low-frequency range                                                                                                                             |
| High Gain | -15–+15 [dB]                                                                                               | Amount of boost/cut for the high-frequency range                                                                                                                            |
| Balance   | D100:0W–D0:100W                                                                                            | Volume balance between the direct sound (D) and the delay sound (W)                                                                                                         |
| Level     | 0–127                                                                                                      | Output Level                                                                                                                                                                |

## 2TAP PAN DELAY




| Parameter  | Value                                                                                                      | Explanation                                                                                                                                                                 |
|------------|------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Delay Sync | OFF, ON                                                                                                    | If this is ON, the delay synchronizes with the tempo.                                                                                                                       |
| D.Time(ms) | 1–2600 [msec]                                                                                              |                                                                                                                                                                             |
| D.Time(Nt) | Note<br>→ "Note" (p. 106)                                                                                  | Adjusts the time until the second delay sound is heard.                                                                                                                     |
| Delay Fbk  | -98–+98 [%]                                                                                                | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase.                                                    |
| Dly HF     | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Adjusts the frequency above which sound fed back to the effect is filtered out. If you don't want to filter out any high frequencies, set this parameter to <b>BYPASS</b> . |
| Dly1 Pan   | L64–63R                                                                                                    | Adjusts the stereo location of delay 1.                                                                                                                                     |
| Dly2 Pan   | L64–63R                                                                                                    | Adjusts the stereo location of delay 2.                                                                                                                                     |
| Dly1 Lv    | 0–127                                                                                                      | Adjusts the volume of delay 1.                                                                                                                                              |
| Dly2 Lv    | 0–127                                                                                                      | Adjusts the volume of delay 2.                                                                                                                                              |
| Low Gain   | -15–+15 [dB]                                                                                               | Amount of boost/cut for the low-frequency range                                                                                                                             |
| High Gain  | -15–+15 [dB]                                                                                               | Amount of boost/cut for the high-frequency range                                                                                                                            |

| Parameter | Value           | Explanation                                                                                                                           |
|-----------|-----------------|---------------------------------------------------------------------------------------------------------------------------------------|
| Balance   | D100:0W–D0:100W | Adjusts the volume balance between the sound that is sent through the delay (W) and the sound that is not sent through the delay (D). |
| Level     | 0–127           | Output Level                                                                                                                          |

## 3TAP PAN DELAY



Produces three delay sounds; center, left and right.



| Parameter  | Value                                                                                                      | Explanation                                                                                                                                                                 |
|------------|------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Dly L Sync | OFF, ON                                                                                                    | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                              |
| DL.Time    | 1–2600 [msec]                                                                                              |                                                                                                                                                                             |
| DLTime Nt  | Note<br>→ "Note" (p. 106)                                                                                  | Adjusts the time until the left delay sound is heard.                                                                                                                       |
| Dly R Sync | OFF, ON                                                                                                    | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                              |
| DR.Time    | 1–2600 [msec]                                                                                              |                                                                                                                                                                             |
| DRTime Nt  | Note<br>→ "Note" (p. 106)                                                                                  | Adjusts the time until the right delay sound is heard.                                                                                                                      |
| Dly C Sync | OFF, ON                                                                                                    | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                              |
| DC.Time    | 1–2600 [msec]                                                                                              |                                                                                                                                                                             |
| DCTime Nt  | Note<br>→ "Note" (p. 106)                                                                                  | Adjusts the time until the center delay sound is heard.                                                                                                                     |
| C Feedback | -98–+98 [%]                                                                                                | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase.                                                    |
| HF Damp    | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Adjusts the frequency above which sound fed back to the effect is filtered out. If you don't want to filter out any high frequencies, set this parameter to <b>BYPASS</b> . |
| Left Lv    | 0–127                                                                                                      |                                                                                                                                                                             |
| Right Lv   | 0–127                                                                                                      | Volume of each delay sound                                                                                                                                                  |
| Center Lv  | 0–127                                                                                                      |                                                                                                                                                                             |
| Low Gain   | -15–+15 [dB]                                                                                               | Amount of boost/cut for the low-frequency range                                                                                                                             |
| High Gain  | -15–+15 [dB]                                                                                               | Amount of boost/cut for the high-frequency range                                                                                                                            |
| Balance    | D100:0W–D0:100W                                                                                            | Volume balance between the direct sound (D) and the delay sound (W)                                                                                                         |
| Level      | 0–127                                                                                                      | Output Level                                                                                                                                                                |

## 4TAP PAN DELAY

This effect has four delays.




| Parameter | Value                                                                                                      | Explanation                                                                                                                                                                 |
|-----------|------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Dly1 Sync | OFF, ON                                                                                                    | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                              |
| D1.Time   | 1–2600 [msec]                                                                                              | Adjusts the time from the original sound until delay 1 sounds is heard.                                                                                                     |
| D1Time Nt | Note<br>→ "Note" (p. 106)                                                                                  |                                                                                                                                                                             |
| Dly2 Sync | OFF, ON                                                                                                    | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                              |
| D2.Time   | 1–2600 [msec]                                                                                              | Adjusts the time from the original sound until delay 2 sounds is heard.                                                                                                     |
| D2Time Nt | Note<br>→ "Note" (p. 106)                                                                                  |                                                                                                                                                                             |
| Dly3 Sync | OFF, ON                                                                                                    | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                              |
| D3.Time   | 1–2600 [msec]                                                                                              | Adjusts the time from the original sound until delay 3 sounds is heard.                                                                                                     |
| D3Time Nt | Note<br>→ "Note" (p. 106)                                                                                  |                                                                                                                                                                             |
| Dly4 Sync | OFF, ON                                                                                                    | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                              |
| D4.Time   | 1–2600 [msec]                                                                                              | Adjusts the time from the original sound until delay 4 sounds is heard.                                                                                                     |
| D4Time Nt | Note<br>→ "Note" (p. 106)                                                                                  |                                                                                                                                                                             |
| Dly1 Fbk  | -98–+98 [%]                                                                                                | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase.                                                    |
| HF Damp   | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Adjusts the frequency above which sound fed back to the effect is filtered out. If you don't want to filter out any high frequencies, set this parameter to <b>BYPASS</b> . |
| Dly1 Lv   | 0–127                                                                                                      | Volume of each delay                                                                                                                                                        |
| Dly2 Lv   | 0–127                                                                                                      |                                                                                                                                                                             |
| Dly3 Lv   | 0–127                                                                                                      |                                                                                                                                                                             |
| Dly4 Lv   | 0–127                                                                                                      |                                                                                                                                                                             |
| Low Gain  | -15–+15 [dB]                                                                                               | Amount of boost/cut for the low-frequency range                                                                                                                             |

| Parameter | Value               | Explanation                                                         |
|-----------|---------------------|---------------------------------------------------------------------|
| High Gain | -15–+15 [dB]        | Amount of boost/cut for the high-frequency range                    |
| Balance   | D100:0W–<br>D0:100W | Volume balance between the direct sound (D) and the delay sound (W) |
| Level     | 0–127               | Output Level                                                        |

## MULTI TAP DELAY (Multi Tap Delay)

This effect has four delays. Each of the Delay Time parameters can be set to a note length based on the selected tempo. You can also set the panning and level of each delay sound.




| Parameter | Value                                                                                                      | Explanation                                                                                                                                                                 |
|-----------|------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Dly1 Sync | OFF, ON                                                                                                    | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                              |
| D1.Time   | 1–2600 [msec]                                                                                              | Adjusts the time from the original sound until delay 1 sounds is heard.                                                                                                     |
| D1Time Nt | Note<br>→ "Note" (p. 106)                                                                                  |                                                                                                                                                                             |
| Dly2 Sync | OFF, ON                                                                                                    | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                              |
| D2.Time   | 1–2600 [msec]                                                                                              | Adjusts the time from the original sound until delay 2 sounds is heard.                                                                                                     |
| D2Time Nt | Note<br>→ "Note" (p. 106)                                                                                  |                                                                                                                                                                             |
| Dly3 Sync | OFF, ON                                                                                                    | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                              |
| D3.Time   | 1–2600 [msec]                                                                                              | Adjusts the time from the original sound until delay 3 sounds is heard.                                                                                                     |
| D3Time Nt | Note<br>→ "Note" (p. 106)                                                                                  |                                                                                                                                                                             |
| Dly4 Sync | OFF, ON                                                                                                    | When this is "ON", the rate is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                              |
| D4.Time   | 1–2600 [msec]                                                                                              | Adjusts the time from the original sound until delay 4 sounds is heard.                                                                                                     |
| D4Time Nt | Note<br>→ "Note" (p. 106)                                                                                  |                                                                                                                                                                             |
| Dly1 Fbk  | -98–+98 [%]                                                                                                | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase.                                                    |
| HF Damp   | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Adjusts the frequency above which sound fed back to the effect is filtered out. If you don't want to filter out any high frequencies, set this parameter to <b>BYPASS</b> . |

| Parameter | Value           | Explanation                                                          |
|-----------|-----------------|----------------------------------------------------------------------|
| Dly1 Pan  | L64–63R         | Stereo location of Delays 1–4                                        |
| Dly2 Pan  | L64–63R         |                                                                      |
| Dly3 Pan  | L64–63R         |                                                                      |
| Dly4 Pan  | L64–63R         |                                                                      |
| Dly1 Lv   | 0–127           | Volume of each delay                                                 |
| Dly2 Lv   | 0–127           |                                                                      |
| Dly3 Lv   | 0–127           |                                                                      |
| Dly4 Lv   | 0–127           |                                                                      |
| Low Gain  | -15–+15 [dB]    | Amount of boost/cut for the low-frequency range                      |
| High Gain | -15–+15 [dB]    | Amount of boost/cut for the high-frequency range                     |
| Balance   | D100:0W–D0:100W | Volume balance between the direct sound (D) and the effect sound (W) |
| Level     | 0–127           | Output Level                                                         |

## REVERSE DELAY

This is a reverse delay that adds a reversed and delayed sound to the input sound. A tap delay is connected immediately after the reverse delay.




| Parameter  | Value                                                                                                      | Explanation                                                                                                                  |
|------------|------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------|
| Threshold  | 0–127                                                                                                      | Volume at which the reverse delay will begin to be applied                                                                   |
| RDly Sync  | OFF, ON                                                                                                    | When this is "ON", the effect is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                             |
| RD.Time    | 1–1300 [msec]                                                                                              | Delay time from when sound is input into the reverse delay until the delay sound is heard                                    |
| RD.Time Nt | Note<br>→ "Note" (p. 106)                                                                                  |                                                                                                                              |
| RDly Fbk   | -98–+98 [%]                                                                                                | Proportion of the delay sound that is to be returned to the input of the reverse delay negative (-) values invert the phase) |
| RDly HF    | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Frequency at which the high-frequency content of the reverse-delayed sound will be cut ( <b>BYPASS:</b> no cut)              |
| RDly Pan   | L64–63R                                                                                                    | Panning of the reverse delay sound                                                                                           |
| RDly Level | 0–127                                                                                                      | Volume of the reverse delay sound                                                                                            |
| Dly1 Sync  | OFF, ON                                                                                                    | When this is "ON", the effect is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                             |
| D1.Time    | 1–1300 [msec]                                                                                              | Delay time from when sound is input into the tap delay until the delay sound is heard                                        |
| D1Time Nt  | Note<br>→ "Note" (p. 106)                                                                                  |                                                                                                                              |

| Parameter | Value                                                                                                      | Explanation                                                                                                               |
|-----------|------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------|
| Dly2 Sync | OFF, ON                                                                                                    | When this is "ON", the effect is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                          |
| D2.Time   | 1–1300 [msec]                                                                                              | Delay time from when sound is input into the tap delay until the delay sound is heard                                     |
| D2Time Nt | Note<br>→ "Note" (p. 106)                                                                                  |                                                                                                                           |
| Dly3 Sync | OFF, ON                                                                                                    | When this is "ON", the effect is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                          |
| D3.Time   | 1–1300 [msec]                                                                                              | Delay time from when sound is input into the tap delay until the delay sound is heard                                     |
| D3Time Nt | Note<br>→ "Note" (p. 106)                                                                                  |                                                                                                                           |
| Dly3 Fbk  | -98–+98 [%]                                                                                                | Proportion of the delay sound that is to be returned to the input of the tap delay (negative (-) values invert the phase) |
| Dly HF    | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Frequency at which the hi-frequency content of the tap delay sound will be cut ( <b>BYPASS:</b> no cut)                   |
| Dly1 Pan  | L64–63R                                                                                                    | Panning of the tap delay sounds                                                                                           |
| Dly2 Pan  | L64–63R                                                                                                    |                                                                                                                           |
| Dly1 Lv   | 0–127                                                                                                      | Volume of the tap delay sounds                                                                                            |
| Dly2 Lv   | 0–127                                                                                                      |                                                                                                                           |
| Low Gain  | -15–+15 [dB]                                                                                               | Amount of boost/cut for the low-frequency range                                                                           |
| High Gain | -15–+15 [dB]                                                                                               | Amount of boost/cut for the high-frequency range                                                                          |
| Balance   | D100:0W–D0:100W                                                                                            | Volume balance between the direct sound (D) and the delay sound (W)                                                       |
| Level     | 0–127                                                                                                      | Output Level                                                                                                              |

## TIME CTRL DELAY (Time Control Delay)

A stereo delay in which the delay time can be varied smoothly.




| Parameter  | Value                     | Explanation                                                                                      |
|------------|---------------------------|--------------------------------------------------------------------------------------------------|
| Delay Sync | OFF, ON                   | When this is "ON", the effect is synchronized with the current click tempo.<br>→ "Tempo" (p. 37) |
| D.Time     | 1–1300 [msec]             | Delay time from when the original sound is heard to when the delay sound is heard                |
| D.Time Nt  | Note<br>→ "Note" (p. 106) |                                                                                                  |

| Parameter    | Value                                                                                                      | Explanation                                                                                                                                                                             |
|--------------|------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Acceleration | 0–15                                                                                                       | Speed at which the current delay time changes to the specified delay time when you change the delay time. The speed of the pitch change will change simultaneously with the delay time. |
| Feedback     | -98–+98 [%]                                                                                                | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase.                                                                |
| HF Damp      | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Adjusts the frequency above which sound fed back to the effect is filtered out. If you don't want to filter out any high frequencies, set this parameter to <b>BYPASS</b> .             |
| Low Gain     | -15–+15 [dB]                                                                                               | Amount of boost/cut for the low-frequency range                                                                                                                                         |
| High Gain    | -15–+15 [dB]                                                                                               | Amount of boost/cut for the high-frequency range                                                                                                                                        |
| Balance      | D100:0W–D0:100W                                                                                            | Volume balance between the direct sound (D) and the delay sound (W)                                                                                                                     |
| Level        | 0–127                                                                                                      | Output Level                                                                                                                                                                            |

## TAPE ECHO

A virtual tape echo that produces a realistic tape delay sound. This simulates the tape echo section of a Roland RE-201 Space Echo.



| Parameter   | Value                         | Explanation                                                                                                                                                                                       |
|-------------|-------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Mode        | S, M, L, S+M, S+L, M+L, S+M+L | Combination of playback heads to use<br>Select from three different heads with different delay times.<br><b>S:</b> short<br><b>M:</b> middle<br><b>L:</b> long                                    |
| Repeat Rate | 0–127                         | Tape speed<br>Increasing this value will shorten the spacing of the delayed sounds.                                                                                                               |
| Intensity   | 0–127                         | Amount of delay repeats                                                                                                                                                                           |
| Bass        | -15–+15 [dB]                  | Boost/cut for the lower range of the echo sound                                                                                                                                                   |
| Treble      | -15–+15 [dB]                  | Boost/cut for the upper range of the echo sound                                                                                                                                                   |
| Head S Pan  | L64–63R                       | Independent panning for the short, middle, and long playback heads                                                                                                                                |
| Head M Pan  | L64–63R                       |                                                                                                                                                                                                   |
| Head L Pan  | L64–63R                       |                                                                                                                                                                                                   |
| Distortion  | 0–5                           | Amount of tape-dependent distortion to be added<br>This simulates the slight tonal changes that can be detected by signal-analysis equipment. Increasing this value will increase the distortion. |

| Parameter  | Value | Explanation                                                                                       |
|------------|-------|---------------------------------------------------------------------------------------------------|
| Wf Rate    | 0–127 | Speed of wow/flutter (complex variation in pitch caused by tape wear and rotational irregularity) |
| Wf Depth   | 0–127 | Depth of wow/flutter                                                                              |
| Echo Level | 0–127 | Volume of the echo sound                                                                          |
| Direct Lv  | 0–127 | Volume of the original sound                                                                      |
| Level      | 0–127 | Output Level                                                                                      |

## MID SIDE DELAY

This effect applies different amounts of delay to left/right signals of similar phase and differing phase.




| Parameter   | Value                                                                                                      | Explanation                                                                                                                                                                 |
|-------------|------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| MD Level    | 0–127                                                                                                      | Delay volume of left/right input signals whose phase is similar (in phase)                                                                                                  |
| MD Mode     | 2TAP, 3TAP, 4TAP                                                                                           | Delay divisions for the input signals whose left/right phase is similar (identical phase)                                                                                   |
| MD Tm Sync  | OFF, ON                                                                                                    | If this is ON, the delay synchronizes with the tempo.                                                                                                                       |
| MD Time     | 1–1300 [msec]                                                                                              | Delay time from when the original sound is heard to when the delay sound is heard                                                                                           |
| MD Time Nt  | Note<br>→ "Note" (p. 106)                                                                                  |                                                                                                                                                                             |
| MD Feedback | -98–+98 [%]                                                                                                | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase.                                                    |
| MD HFDamp   | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Adjusts the frequency above which sound fed back to the effect is filtered out. If you don't want to filter out any high frequencies, set this parameter to <b>BYPASS</b> . |
| MD1 Pan     | L64–63R                                                                                                    | Panning of the first delay sound                                                                                                                                            |
| MD2 Pan     | L64–63R                                                                                                    | Panning of the second delay sound                                                                                                                                           |
| MD3 Pan     | L64–63R                                                                                                    | Panning of the third delay sound                                                                                                                                            |
| MD4 Pan     | L64–63R                                                                                                    | Panning of the fourth delay sound                                                                                                                                           |
| SD Level    | 0–127                                                                                                      | Delay volume of left/right input signals whose phase is distant (opposite phase)                                                                                            |
| SD Mode     | 2TAP, 3TAP, 4TAP                                                                                           | Delay divisions for the input signals whose left/right phase is distant (reverse phase)                                                                                     |
| SD Tm Sync  | OFF, ON                                                                                                    | If this is ON, the delay synchronizes with the tempo.                                                                                                                       |
| SD Time     | 1–1300 [msec]                                                                                              | Delay time from when the original sound is heard to when the delay sound is heard                                                                                           |
| SD Time Nt  | Note<br>→ "Note" (p. 106)                                                                                  |                                                                                                                                                                             |
| SD Feedback | -98–+98 [%]                                                                                                | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase.                                                    |
| SD HFDamp   | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Adjusts the frequency above which sound fed back to the effect is filtered out. If you don't want to filter out any high frequencies, set this parameter to <b>BYPASS</b> . |

| Parameter | Value   | Explanation                       |
|-----------|---------|-----------------------------------|
| SD1 Pan   | L64–63R | Panning of the first delay sound  |
| SD2 Pan   | L64–63R | Panning of the second delay sound |
| SD3 Pan   | L64–63R | Panning of the third delay sound  |
| SD4 Pan   | L64–63R | Panning of the fourth delay sound |
| Level     | 0–127   | Output Level                      |

## Looper

### BPM LOOPER

Loops a short portion of the input sound. This can automatically turn the loop on/off in synchronization with the rhythm.




| Parameter | Value                     | Explanation                                                                                                                                                                                                                          |
|-----------|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Length    | 230–12 [msec]             | Specifies the length of the loop.                                                                                                                                                                                                    |
| Rate Sync | OFF, ON                   | When this is "ON", the effect is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                                                                                                                                     |
| Rate      | 0.05–10.00 [Hz]           |                                                                                                                                                                                                                                      |
| Rate Note | Note<br>⇒ "Note" (p. 106) | Cycle at which the loop automatically turns on/off                                                                                                                                                                                   |
| Timing    | 1–8                       | Specifies the timing within the cycle at which the loop automatically starts (which step of the eight timing divisions at which the sound is heard)                                                                                  |
| Lenth     | 1–8                       | Specifies the length at which the loop automatically ends within the cycle (the number of times that the 1/8-length of sound is heard)                                                                                               |
| Loop Mode | OFF, AUTO, ON             | If this is AUTO, the loop automatically turns on/off in synchronization with the rhythm.<br>* If the effect is recalled with this ON, this parameter must first be set to something other than ON in order to make the loop operate. |
| Level     | 0–127                     | Output Level                                                                                                                                                                                                                         |

## Lo-fi

### LOFI COMP (Lo-Fi Compressor)


Degrades the sound quality.



| Parameter   | Value           | Explanation                                                                                                                                                                 |
|-------------|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pre Filter  | 1–6             | Selects the type of filter applied to the sound before it passes through the Lo-Fi effect.<br><b>1:</b> Compressor off<br><b>2–6:</b> Compressor on                         |
| LoFi Type   | 1–9             | Degrades the sound quality. The sound quality grows poorer as this value is increased.                                                                                      |
| Post Filter | OFF, LPF, HPF   | Type of filter<br><b>OFF:</b> No filter is used<br><b>LPF:</b> Cuts the frequency range above the Cutoff Freq<br><b>HPF:</b> Cuts the frequency range below the Cutoff Freq |
| Cutoff      | 200–8000 [Hz]   | Basic frequency of the Post Filter                                                                                                                                          |
| Low Gain    | –15–+15 [dB]    | Amount of boost/cut for the low-frequency range                                                                                                                             |
| High Gain   | –15–+15 [dB]    | Amount of boost/cut for the high-frequency range                                                                                                                            |
| Balance     | D100:0W–D0:100W | Volume balance between the direct sound (D) and the effect sound (W)                                                                                                        |
| Level       | 0–127           | Output Level                                                                                                                                                                |

### BIT CRUSHER


Produces an extreme lo-fi effect.



| Parameter   | Value        | Explanation                                      |
|-------------|--------------|--------------------------------------------------|
| Sample Rate | 0–127        | Adjusts the sample rate.                         |
| Bit Down    | 0–18         | Adjusts the bit depth.                           |
| Filter      | 0–127        | Adjusts the filter depth.                        |
| Low Gain    | –15–+15 [dB] | Amount of boost/cut for the low-frequency range  |
| High Gain   | –15–+15 [dB] | Amount of boost/cut for the high-frequency range |
| Level       | 0–127        | Output Level                                     |

## PHONOGRAPH

Recreates the sound of an analog record being played on a record player. This lets you simulate the unique noises produced when a record is played, as well as the variations that occur when the record spins.




| Parameter       | Value           | Explanation                                                                                                                                  |
|-----------------|-----------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| Signal Dist     | 0–127           | Sets the amount of distortion.                                                                                                               |
| Frequency Range | 0–127           | Sets the frequency characteristics of the playback system. Smaller values create the feeling of an older system with narrow frequency bands. |
| Disc Type       | LP, EP, SP      | Sets the turntable rotation speed. This has an effect on the scratch noise cycle.                                                            |
| Scratch NZ Lev  | 0–127           | Sets the volume of noise created by scratches in the record.                                                                                 |
| Dust NZ Lev     | 0–127           | Sets the volume of noise created by dust on the record.                                                                                      |
| Hiss NZ Lev     | 0–127           | Sets the volume of continuous hiss noise.                                                                                                    |
| Total NZ Lev    | 0–127           | Sets the volume of noise overall.                                                                                                            |
| Wow             | 0–127           | Sets the amount of variation in record spin (long cycle).                                                                                    |
| Flutter         | 0–127           | Sets the amount of variation in record spin (short cycle).                                                                                   |
| Random          | 0–127           | Sets the amount of non-cyclical variation in record spin.                                                                                    |
| Total W/F       | 0–127           | Sets the volume of variation in record spin overall.                                                                                         |
| Balance         | D100:0W–D0:100W | Sets the volume balance between the original sound (D) and the effect sound (W).                                                             |
| Level           | 0–127           | Sets the output volume.                                                                                                                      |

## Pitch

### PITCH SHIFTER


A stereo pitch shifter.



| Parameter  | Value                     | Explanation                                                                                                                      |
|------------|---------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Coarse     | -24–+12 [semi]            | Adjusts the pitch of the pitch shifted sound in semitone steps.                                                                  |
| Fine       | -100–+100 [cent]          | Adjusts the pitch of the pitch shifted sound in 2-cent steps.                                                                    |
| Delay Sync | OFF, ON                   | When this is "ON", the effect is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                                 |
| D.Time     | 1–1300 [msec]             | Adjusts the delay time from the direct sound until the pitch shifted sound is heard.                                             |
| D.Time Nt  | Note<br>⇒ "Note" (p. 106) |                                                                                                                                  |
| Feedback   | -98–+98 [%]               | Adjusts the proportion of the pitch shifted sound that is fed back into the effect. Negative (-) settings will invert the phase. |
| Low Gain   | -15–+15 [dB]              | Amount of boost/cut for the low-frequency range                                                                                  |
| High Gain  | -15–+15 [dB]              | Amount of boost/cut for the high-frequency range                                                                                 |
| Balance    | D100:0W–D0:100W           | Volume balance between the direct sound (D) and the pitch shifted sound (W)                                                      |
| Level      | 0–127                     | Output Level                                                                                                                     |

## 2V PITCH SHIFTER


Shifts the pitch of the original sound. This 2-voice pitch shifter has two pitch shifters, and can add two pitch shifted sounds to the original sound.



| Parameter        | Value                     | Explanation                                                                                                                      |
|------------------|---------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| P1 Coarse        | -24+12 [semi]             | Adjusts the pitch of Pitch Shift 1 in semitone steps.                                                                            |
| P1 Fine          | -100+100 [cent]           | Adjusts the pitch of Pitch Shift 1 in 2-cent steps.                                                                              |
| P1 Dly Sync      | OFF, ON                   | When this is "ON", the effect is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                                 |
| P1 Dly Time      | 1-1300 [msec]             | Adjusts the delay time from the direct sound until the Pitch Shift 1 sound is heard.                                             |
| P1 Dly Rate Note | Note<br>⇒ "Note" (p. 106) |                                                                                                                                  |
| P1 Feedback      | -98+98 [%]                | Adjusts the proportion of the pitch shifted sound that is fed back into the effect. Negative (-) settings will invert the phase. |
| P1 Pan           | L64-63R                   | Stereo location of the Pitch Shift 1 sound                                                                                       |
| P1 Level         | 0-127                     | Volume of the Pitch Shift 1 sound                                                                                                |
| P2 Coarse        | -24+12 [semi]             |                                                                                                                                  |
| P2 Fine          | -100+100 [cent]           |                                                                                                                                  |
| P2 Dly Sync      | OFF, ON                   |                                                                                                                                  |
| P2 Dly Time      | 1-1300 [msec]             | Settings of the Pitch Shift 2 sound.                                                                                             |
| P2 Dly Rate Note | Note                      | The parameters are the same as for the Pitch Shift 1 sound.                                                                      |
| P2 Feedback      | -98+98 [%]                |                                                                                                                                  |
| P2 Pan           | L64-63R                   |                                                                                                                                  |
| P2 Level         | 0-127                     |                                                                                                                                  |
| Low Gain         | -15+15 [dB]               | Amount of boost/cut for the low-frequency range                                                                                  |
| High Gain        | -15+15 [dB]               | Amount of boost/cut for the high-frequency range                                                                                 |
| Balance          | D100:0W-D0:100W           | Volume balance between the direct sound (D) and the pitch shifted sound (W)                                                      |
| Level            | 0-127                     | Output Level                                                                                                                     |


## Combination

### OD → CHORUS (Overdrive → Chorus)



| Parameter  | Value                     | Explanation                                                                                                                             |
|------------|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| OD Drive   | 0-127                     | Degree of distortion<br>Also changes the volume.                                                                                        |
| OD Pan     | L64-63R                   | Stereo location of the overdrive sound                                                                                                  |
| Cho PreDly | 0.0-100 [msec]            | Adjusts the delay time from the direct sound until the chorus sound is heard.                                                           |
| Cho Sync   | OFF, ON                   | When this is "ON", the effect is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                                        |
| C.Rate     | 0.05-10.00 [Hz]           |                                                                                                                                         |
| C.Rate Nt  | Note<br>⇒ "Note" (p. 106) | Frequency of modulation                                                                                                                 |
| Cho Depth  | 0-127                     | Depth of modulation                                                                                                                     |
| Cho Bal    | D100:0W-D0:100W           | Adjusts the volume balance between the sound that is sent through the chorus (W) and the sound that is not sent through the chorus (D). |
| Level      | 0-127                     | Output Level                                                                                                                            |

### OD → FLANGER (Overdrive → Flanger)




| Parameter  | Value                     | Explanation                                                                                      |
|------------|---------------------------|--------------------------------------------------------------------------------------------------|
| OD Drive   | 0-127                     | Degree of distortion<br>Also changes the volume.                                                 |
| OD Pan     | L64-63R                   | Stereo location of the overdrive sound                                                           |
| Flg PreDly | 0.0-100 [msec]            | Adjusts the delay time from the direct sound until the flanger sound is heard.                   |
| Flg Sync   | OFF, ON                   | When this is "ON", the effect is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37) |
| F.Rate     | 0.05-10.00 [Hz]           |                                                                                                  |
| F.Rate Nt  | Note<br>⇒ "Note" (p. 106) | Frequency of modulation                                                                          |

| Parameter | Value           | Explanation                                                                                                                               |
|-----------|-----------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| Flg Depth | 0–127           | Depth of modulation                                                                                                                       |
| Flg Fbk   | -98–+98 [%]     | Adjusts the proportion of the flanger sound that is fed back into the effect. Negative (-) settings will invert the phase.                |
| Flg Bal   | D100:0W–D0:100W | Adjusts the volume balance between the sound that is sent through the flanger (W) and the sound that is not sent through the flanger (D). |
| Level     | 0–127           | Output Level                                                                                                                              |


| Parameter  | Value                     | Explanation                                                                                                                             |
|------------|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| Dist Drive | 0–127                     | Degree of distortion<br>Also changes the volume.                                                                                        |
| Dist Pan   | L64–63R                   | Stereo location of the overdrive sound                                                                                                  |
| Cho PreDly | 0.0–100 [msec]            | Adjusts the delay time from the direct sound until the chorus sound is heard.                                                           |
| Cho Sync   | OFF, ON                   | When this is “ON”, the effect is synchronized with the current click tempo.<br>→ “Tempo” (p. 37)                                        |
| C.Rate     | 0.05–10.00 [Hz]           | Frequency of modulation                                                                                                                 |
| C.Rate Nt  | Note<br>→ “Note” (p. 106) |                                                                                                                                         |
| Cho Depth  | 0–127                     | Depth of modulation                                                                                                                     |
| Cho Bal    | D100:0W–D0:100W           | Adjusts the volume balance between the sound that is sent through the chorus (W) and the sound that is not sent through the chorus (D). |
| Level      | 0–127                     | Output Level                                                                                                                            |

## OD → DELAY (Overdrive → Delay)




| Parameter  | Value                                                                                                      | Explanation                                                                                                                                                                 |
|------------|------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| OD Drive   | 0–127                                                                                                      | Degree of distortion<br>Also changes the volume.                                                                                                                            |
| OD Pan     | L64–63R                                                                                                    | Stereo location of the overdrive sound                                                                                                                                      |
| Delay Sync | OFF, ON                                                                                                    | When this is “ON”, the effect is synchronized with the current click tempo.<br>→ “Tempo” (p. 37)                                                                            |
| D.Time     | 1–2600 [msec]                                                                                              | Delay time from when the original sound is heard to when the delay sound is heard                                                                                           |
| D.Time Nt  | Note<br>→ “Note” (p. 106)                                                                                  |                                                                                                                                                                             |
| Delay Fbk  | -98–+98 [%]                                                                                                | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase.                                                    |
| Dly HF     | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Adjusts the frequency above which sound fed back to the effect is filtered out. If you don't want to filter out any high frequencies, set this parameter to <b>BYPASS</b> . |
| Dly Bal    | D100:0W–D0:100W                                                                                            | Adjusts the volume balance between the sound that is sent through the delay (W) and the sound that is not sent through the delay (D).                                       |
| Level      | 0–127                                                                                                      | Output Level                                                                                                                                                                |

## DS → FLANGER (Distortion → Flanger)




| Parameter  | Value                     | Explanation                                                                                                                               |
|------------|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| Dist Drive | 0–127                     | Degree of distortion<br>Also changes the volume.                                                                                          |
| Dist Pan   | L64–63R                   | Stereo location of the overdrive sound                                                                                                    |
| Flg PreDly | 0.0–100 [msec]            | Adjusts the delay time from the direct sound until the flanger sound is heard.                                                            |
| Flg Sync   | OFF, ON                   | When this is “ON”, the effect is synchronized with the current click tempo.<br>→ “Tempo” (p. 37)                                          |
| F.Rate     | 0.05–10.00 [Hz]           | Frequency of modulation                                                                                                                   |
| F.Rate Nt  | Note<br>→ “Note” (p. 106) |                                                                                                                                           |
| Flg Depth  | 0–127                     | Depth of modulation                                                                                                                       |
| Flg Fbk    | -98–+98 [%]               | Adjusts the proportion of the flanger sound that is fed back into the effect. Negative (-) settings will invert the phase.                |
| Flg Bal    | D100:0W–D0:100W           | Adjusts the volume balance between the sound that is sent through the flanger (W) and the sound that is not sent through the flanger (D). |
| Level      | 0–127                     | Output Level                                                                                                                              |

## DS → CHORUS (Distortion → Chorus)




DS  $\rightarrow$  DELAY (Distortion  $\rightarrow$  Delay)




| Parameter  | Value                                                                                                      | Explanation                                                                                                                                                                 |
|------------|------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Dist Drive | 0–127                                                                                                      | Degree of distortion<br>Also changes the volume.                                                                                                                            |
| Dist Pan   | L64–63R                                                                                                    | Stereo location of the overdrive sound                                                                                                                                      |
| Delay Sync | OFF, ON                                                                                                    | When this is “ON”, the effect is synchronized with the current click tempo.<br>➔ “Tempo” (p. 37)                                                                            |
| D.Time     | 1–2600 [msec]                                                                                              | Delay time from when the original sound is heard to when the delay sound is heard                                                                                           |
| D.Time Nt  | Note<br>➔ “Note” (p. 106)                                                                                  |                                                                                                                                                                             |
| Delay Fbk  | -98–+98 [%]                                                                                                | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase.                                                    |
| Dly HF     | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Adjusts the frequency above which sound fed back to the effect is filtered out. If you don’t want to filter out any high frequencies, set this parameter to <b>BYPASS</b> . |
| Dly Bal    | D100:0W–D0:100W                                                                                            | Adjusts the volume balance between the sound that is sent through the delay (W) and the sound that is not sent through the delay (D).                                       |
| Level      | 0–127                                                                                                      | Output Level                                                                                                                                                                |

OD/DS → TWAH (Overdrive/Distortion → Touch Wah)




| Parameter    | Value                             | Explanation                                                                                                                                                                |
|--------------|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Drive Switch | OFF, ON                           | Turns overdrive/distortion on/off                                                                                                                                          |
| D.Type       | OVERDRIVE, DISTORTION             | Type of distortion                                                                                                                                                         |
| Drive        | 0–127                             | Degree of distortion<br>Also changes the volume.                                                                                                                           |
| Tone         | 0–127                             | Sound quality of the Overdrive effect                                                                                                                                      |
| Amp Switch   | OFF, ON                           | Turns the Amp Simulator on/off.                                                                                                                                            |
| Amp Type     | SMALL, BUILT-IN, 2-STACK, 3-STACK | Type of guitar amp<br><b>SMALL:</b> Small amp<br><b>BUILT-IN:</b> Single-unit type amp<br><b>2-STACK:</b> Large double stack amp<br><b>3-STACK:</b> Large triple stack amp |
| TWah Switch  | OFF, ON                           | Wah on/off                                                                                                                                                                 |
| TWah Mode    | LPF, BPF                          | Filter type<br><b>LPF:</b> The wah effect will be applied over a wide frequency range.<br><b>BPF:</b> The wah effect will be applied over a narrow frequency range.        |
| TWah Polar   | DOWN, UP                          | Direction in which the filter will move<br><b>DOWN:</b> The filter will change toward a lower frequency.<br><b>UP:</b> The filter will change toward a higher frequency.   |
| TWah Sens    | 0–127                             | Sensitivity with which the filter is modified                                                                                                                              |
| TWah Manual  | 0–127                             | Center frequency at which the wah effect is applied                                                                                                                        |
| TWah Peak    | 0–127                             | Width of the frequency region at which the wah effect is applied.<br>Increasing this value will make the frequency region narrower.                                        |
| TWah Bal     | D100:0W–D0:100W                   | Adjusts the volume balance between the sound that is sent through the wah (W) and the sound that is not sent through the wah (D).                                          |
| Low Gain     | –15–+15 [dB]                      | Amount of boost/cut for the low-frequency range                                                                                                                            |
| High Gain    | –15–+15 [dB]                      | Amount of boost/cut for the high-frequency range                                                                                                                           |
| Level        | 0–127                             | Output Level                                                                                                                                                               |

## OD/DS → AWAH (Overdrive/Distortion → Auto Wah)



| Parameter    | Value                             | Explanation                                                                                                                                                                |
|--------------|-----------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Drive Switch | OFF, ON                           | Turns overdrive/distortion on/off                                                                                                                                          |
| D.Type       | OVERDRIVE, DISTORTION             | Type of distortion                                                                                                                                                         |
| Drive        | 0–127                             | Degree of distortion<br>Also changes the volume.                                                                                                                           |
| Tone         | 0–127                             | Sound quality of the Overdrive effect                                                                                                                                      |
| Amp Switch   | OFF, ON                           | Turns the Amp Simulator on/off.                                                                                                                                            |
| Amp Type     | SMALL, BUILT-IN, 2-STACK, 3-STACK | Type of guitar amp<br><b>SMALL:</b> Small amp<br><b>BUILT-IN:</b> Single-unit type amp<br><b>2-STACK:</b> Large double stack amp<br><b>3-STACK:</b> Large triple stack amp |
| AWah Switch  | OFF, ON                           | Wah on/off                                                                                                                                                                 |
| AWah Mode    | LPF, BPF                          | Filter type<br><b>LPF:</b> The wah effect will be applied over a wide frequency range.<br><b>BPF:</b> The wah effect will be applied over a narrow frequency range.        |
| AWah Manual  | 0–127                             | Center frequency at which the wah effect is applied                                                                                                                        |
| AWah Peak    | 0–127                             | Width of the frequency region at which the wah effect is applied.<br>Increasing this value will make the frequency region narrower.                                        |
| AWah Sync    | OFF, ON                           | When this is "ON", the effect is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                           |
| AWRate       | 0.05–10.00 [Hz]                   | Frequency of modulation                                                                                                                                                    |
| AWRate Nt    | Note<br>→ "Note" (p. 106)         |                                                                                                                                                                            |
| AWah Depth   | 0–127                             | Depth at which the wah effect is modulated                                                                                                                                 |
| AWah Bal     | D100:0W–D0:100W                   | Adjusts the volume balance between the sound that is sent through the wah (W) and the sound that is not sent through the wah (D).                                          |
| Low Gain     | –15–+15 [dB]                      | Amount of boost/cut for the low-frequency range                                                                                                                            |
| High Gain    | –15–+15 [dB]                      | Amount of boost/cut for the high-frequency range                                                                                                                           |
| Level        | 0–127                             | Output Level                                                                                                                                                               |


## GT AMP → CHORUS (Guitar Amp Simulator → Chorus)



| Parameter  | Value                     | Explanation                                                                                                                                               |
|------------|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pre Amp Sw | OFF, ON                   | Turns the amp switch on/off.                                                                                                                              |
| ATyp       | <b>Type of guitar amp</b> |                                                                                                                                                           |
|            | JC-120                    | This models the sound of the Roland JC-120.                                                                                                               |
|            | CLEAN TWIN                | This models a Fender Twin Reverb.                                                                                                                         |
|            | MATCH DRIVE               | This models the sound input to left input on a Matchless D/C-30.<br>A simulation of the latest tube amp widely used in styles from blues rock and fusion. |
|            | BG LEAD                   | This models the lead sound of the MESA/ Boogie combo amp.<br>The sound of a tube amp typical of the late '70s to '80s.                                    |
|            | MS1959I                   | This models the sound input to Input I on a Marshall 1959.<br>This is a trebly sound suited to hard rock.                                                 |
|            | MS1959II                  | This models the sound input to Input II on a Marshall 1959.                                                                                               |
|            | MS1959I+II                | A model of the Marshall 1959 sound, with inputs I and II connected in parallel. Offers a sound with a more emphasized low-end than MS1959I.               |
|            | SLDN LEAD                 | This models a Soldano SLO-100. This is the typical sound of the eighties.                                                                                 |
|            | METAL 5150                | This models the lead channel of a Peavey EVH 5150.                                                                                                        |
|            | METAL LEAD                | This is distortion sound that is ideal for performances of heavy riffs.                                                                                   |
|            | OD-1                      | This models the sound of the BOSS OD-1.<br>This produces sweet, mild distortion.                                                                          |
|            | OD-2 TURBO                | This is the high-gain overdrive sound of the BOSS OD-2.                                                                                                   |
|            | DISTORTION                | This gives a basic, traditional distortion sound.                                                                                                         |
|            | FUZZ                      | A fuzz sound with rich harmonic content.                                                                                                                  |
| Drive      | 0–127                     | Volume and amount of distortion of the amp                                                                                                                |
| Master     | 0–127                     | Volume of the entire pre-amp                                                                                                                              |
| Gain       | LOW, MIDDLE, HIGH         | Amount of pre-amp distortion                                                                                                                              |
| Bass       | 0–127                     | Tone of the bass/mid/treble frequency range                                                                                                               |
| Middle     | 0–127                     |                                                                                                                                                           |
| Treble     | 0–127                     |                                                                                                                                                           |
| Speaker Sw | OFF, ON                   | Selects whether the sound will be sent through the speaker simulation (ON) or not (OFF)                                                                   |

| Parameter  | Value           | Explanation                                                                                                                             |                                                |            |
|------------|-----------------|-----------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------|------------|
|            |                 | Cabinet                                                                                                                                 | Diameter (in inches) and number of the speaker | Microphone |
| STyp       | SMALL 1         | small open-back enclosure                                                                                                               | 10                                             | dynamic    |
|            | SMALL 2         | small open-back enclosure                                                                                                               | 10                                             | dynamic    |
|            | MIDDLE          | open back enclosure                                                                                                                     | 12 x 1                                         | dynamic    |
|            | JC-120          | open back enclosure                                                                                                                     | 12 x 2                                         | dynamic    |
|            | BUILT-IN 1      | open back enclosure                                                                                                                     | 12 x 2                                         | dynamic    |
|            | BUILT-IN 2      | open back enclosure                                                                                                                     | 12 x 2                                         | condenser  |
|            | BUILT-IN 3      | open back enclosure                                                                                                                     | 12 x 2                                         | condenser  |
|            | BUILT-IN 4      | open back enclosure                                                                                                                     | 12 x 2                                         | condenser  |
|            | BUILT-IN 5      | open back enclosure                                                                                                                     | 12 x 2                                         | condenser  |
|            | BG STACK 1      | sealed enclosure                                                                                                                        | 12 x 2                                         | condenser  |
|            | BG STACK 2      | large sealed enclosure                                                                                                                  | 12 x 2                                         | condenser  |
|            | MS STACK 1      | large sealed enclosure                                                                                                                  | 12 x 4                                         | condenser  |
|            | MS STACK 2      | large sealed enclosure                                                                                                                  | 12 x 4                                         | condenser  |
|            | METAL STACK     | large double stack                                                                                                                      | 12 x 4                                         | condenser  |
|            | 2-STACK         | large double stack                                                                                                                      | 12 x 4                                         | condenser  |
|            | 3-STACK         | large triple stack                                                                                                                      | 12 x 4                                         | condenser  |
| Chorus Sw  | OFF, ON         | Chorus on/off                                                                                                                           |                                                |            |
| Cho PreDly | 0.0–100 [msec]  | Adjusts the delay time from the direct sound until the chorus sound is heard.                                                           |                                                |            |
| C.Rate     | 0.05–10.00 [Hz] | Frequency of modulation                                                                                                                 |                                                |            |
| Cho Depth  | 0–127           | Depth of modulation                                                                                                                     |                                                |            |
| Cho Bal    | D100:0W–D0:100W | Adjusts the volume balance between the sound that is sent through the chorus (W) and the sound that is not sent through the chorus (D). |                                                |            |
| Level      | 0–127           | Output Level                                                                                                                            |                                                |            |


## GT AMP → FLANGER (Guitar Amp Simulator → Flanger)



| Parameter  | Value              | Explanation                                                                                                                                               |
|------------|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pre Amp Sw | OFF, ON            | Turns the amp switch on/off.                                                                                                                              |
| ATyp       | Type of guitar amp |                                                                                                                                                           |
|            | JC-120             | This models the sound of the Roland JC-120.                                                                                                               |
|            | CLEAN TWIN         | This models a Fender Twin Reverb.                                                                                                                         |
|            | MATCH DRIVE        | This models the sound input to left input on a Matchless D/C-30.<br>A simulation of the latest tube amp widely used in styles from blues rock and fusion. |
|            | BG LEAD            | This models the lead sound of the MESA/ Boogie combo amp.<br>The sound of a tube amp typical of the late '70s to '80s.                                    |
|            | MS1959I            | This models the sound input to Input I on a Marshall 1959.<br>This is a trebly sound suited to hard rock.                                                 |
|            | MS1959II           | This models the sound input to Input II on a Marshall 1959.                                                                                               |
|            | MS1959I+II         | A model of the Marshall 1959 sound, with inputs I and II connected in parallel. Offers a sound with a more emphasized low-end than MS1959I.               |
|            | SLDN LEAD          | This models a Soldano SLO-100. This is the typical sound of the eighties.                                                                                 |
|            | METAL 5150         | This models the lead channel of a Peavey EVH 5150.                                                                                                        |
|            | METAL LEAD         | This is distortion sound that is ideal for performances of heavy riffs.                                                                                   |
|            | OD-1               | This models the sound of the BOSS OD-1.<br>This produces sweet, mild distortion.                                                                          |
|            | OD-2 TURBO         | This is the high-gain overdrive sound of the BOSS OD-2.                                                                                                   |
|            | DISTORTION         | This gives a basic, traditional distortion sound.                                                                                                         |
|            | FUZZ               | A fuzz sound with rich harmonic content.                                                                                                                  |
| Drive      | 0–127              | Volume and amount of distortion of the amp                                                                                                                |
| Master Lv  | 0–127              | Volume of the entire pre-amp                                                                                                                              |
| Gain       | LOW, MIDDLE, HIGH  | Amount of pre-amp distortion                                                                                                                              |
| Bass       | 0–127              | Tone of the bass/mid/treble frequency range                                                                                                               |
| Middle     | 0–127              |                                                                                                                                                           |
| Treble     | 0–127              |                                                                                                                                                           |
| Speaker Sw | OFF, ON            | Selects whether the sound will be sent through the speaker simulation (ON) or not (OFF)                                                                   |

| Parameter  | Value              | Explanation                                                                                                                               |                                                |            |
|------------|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------|------------|
| STyp       |                    | Cabinet                                                                                                                                   | Diameter (in inches) and number of the speaker | Microphone |
|            | SMALL 1            | small open-back enclosure                                                                                                                 | 10                                             | dynamic    |
|            | SMALL 2            | small open-back enclosure                                                                                                                 | 10                                             | dynamic    |
|            | MIDDLE             | open back enclosure                                                                                                                       | 12 x 1                                         | dynamic    |
|            | JC-120             | open back enclosure                                                                                                                       | 12 x 2                                         | dynamic    |
|            | BUILT-IN 1         | open back enclosure                                                                                                                       | 12 x 2                                         | dynamic    |
|            | BUILT-IN 2         | open back enclosure                                                                                                                       | 12 x 2                                         | condenser  |
|            | BUILT-IN 3         | open back enclosure                                                                                                                       | 12 x 2                                         | condenser  |
|            | BUILT-IN 4         | open back enclosure                                                                                                                       | 12 x 2                                         | condenser  |
|            | BUILT-IN 5         | open back enclosure                                                                                                                       | 12 x 2                                         | condenser  |
|            | BG STACK 1         | sealed enclosure                                                                                                                          | 12 x 2                                         | condenser  |
|            | BG STACK 2         | large sealed enclosure                                                                                                                    | 12 x 2                                         | condenser  |
|            | MS STACK 1         | large sealed enclosure                                                                                                                    | 12 x 4                                         | condenser  |
|            | MS STACK 2         | large sealed enclosure                                                                                                                    | 12 x 4                                         | condenser  |
|            | METAL STACK        | large double stack                                                                                                                        | 12 x 4                                         | condenser  |
|            | 2-STACK            | large double stack                                                                                                                        | 12 x 4                                         | condenser  |
| 3-STACK    | large triple stack | 12 x 4                                                                                                                                    | condenser                                      |            |
| Flg Switch | OFF, ON            | Flanger on/off                                                                                                                            |                                                |            |
| Flg PreDly | 0.0–100 [msec]     | Adjusts the delay time from the direct sound until the flanger sound is heard.                                                            |                                                |            |
| F.Rate     | 0.05–10.00 [Hz]    | Frequency of modulation                                                                                                                   |                                                |            |
| Flg Depth  | 0–127              | Depth of modulation                                                                                                                       |                                                |            |
| Flg Fbk    | -98–+98 [%]        | Adjusts the proportion of the flanger sound that is fed back into the effect. Negative (-) settings will invert the phase.                |                                                |            |
| Flg Bal    | D100:0W–D0:100W    | Adjusts the volume balance between the sound that is sent through the flanger (W) and the sound that is not sent through the flanger (D). |                                                |            |
| Level      | 0–127              | Output Level                                                                                                                              |                                                |            |


## GT AMP → PHASER (Guitar Amp Simulator → Phaser)



| Parameter  | Value             | Explanation                                                                                                                                               |
|------------|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pre Amp Sw | OFF, ON           | Turns the amp switch on/off.                                                                                                                              |
| ATyp       |                   | Type of guitar amp                                                                                                                                        |
|            | JC-120            | This models the sound of the Roland JC-120.                                                                                                               |
|            | CLEAN TWIN        | This models a Fender Twin Reverb.                                                                                                                         |
|            | MATCH DRIVE       | This models the sound input to left input on a Matchless D/C-30.<br>A simulation of the latest tube amp widely used in styles from blues rock and fusion. |
|            | BG LEAD           | This models the lead sound of the MESA/ Boogie combo amp.<br>The sound of a tube amp typical of the late '70s to '80s.                                    |
|            | MS1959I           | This models the sound input to Input I on a Marshall 1959.<br>This is a trebly sound suited to hard rock.                                                 |
|            | MS1959II          | This models the sound input to Input II on a Marshall 1959.                                                                                               |
|            | MS1959I+II        | A model of the Marshall 1959 sound, with inputs I and II connected in parallel. Offers a sound with a more emphasized low-end than MS1959I.               |
|            | SLDN LEAD         | This models a Soldano SLO-100. This is the typical sound of the eighties.                                                                                 |
|            | METAL 5150        | This models the lead channel of a Peavey EVH 5150.                                                                                                        |
|            | METAL LEAD        | This is distortion sound that is ideal for performances of heavy riffs.                                                                                   |
|            | OD-1              | This models the sound of the BOSS OD-1.<br>This produces sweet, mild distortion.                                                                          |
|            | OD-2 TURBO        | This is the high-gain overdrive sound of the BOSS OD-2.                                                                                                   |
|            | DISTORTION        | This gives a basic, traditional distortion sound.                                                                                                         |
|            | FUZZ              | A fuzz sound with rich harmonic content.                                                                                                                  |
| Drive      | 0–127             | Volume and amount of distortion of the amp                                                                                                                |
| Master     | 0–127             | Volume of the entire pre-amp                                                                                                                              |
| Gain       | LOW, MIDDLE, HIGH | Amount of pre-amp distortion                                                                                                                              |
| Bass       | 0–127             | Tone of the bass/mid/treble frequency range                                                                                                               |
| Middle     | 0–127             |                                                                                                                                                           |
| Treble     | 0–127             |                                                                                                                                                           |
| Speaker Sw | OFF, ON           | Selects whether the sound will be sent through the speaker simulation (ON) or not (OFF)                                                                   |

| Parameter  | Value           | Explanation                                                         |                                                |            |
|------------|-----------------|---------------------------------------------------------------------|------------------------------------------------|------------|
|            |                 | Cabinet                                                             | Diameter (in inches) and number of the speaker | Microphone |
| STyp       | SMALL 1         | small open-back enclosure                                           | 10                                             | dynamic    |
|            | SMALL 2         | small open-back enclosure                                           | 10                                             | dynamic    |
|            | MIDDLE          | open back enclosure                                                 | 12 x 1                                         | dynamic    |
|            | JC-120          | open back enclosure                                                 | 12 x 2                                         | dynamic    |
|            | BUILT-IN 1      | open back enclosure                                                 | 12 x 2                                         | dynamic    |
|            | BUILT-IN 2      | open back enclosure                                                 | 12 x 2                                         | condenser  |
|            | BUILT-IN 3      | open back enclosure                                                 | 12 x 2                                         | condenser  |
|            | BUILT-IN 4      | open back enclosure                                                 | 12 x 2                                         | condenser  |
|            | BUILT-IN 5      | open back enclosure                                                 | 12 x 2                                         | condenser  |
|            | BG STACK 1      | sealed enclosure                                                    | 12 x 2                                         | condenser  |
|            | BG STACK 2      | large sealed enclosure                                              | 12 x 2                                         | condenser  |
|            | MS STACK 1      | large sealed enclosure                                              | 12 x 4                                         | condenser  |
|            | MS STACK 2      | large sealed enclosure                                              | 12 x 4                                         | condenser  |
|            | METAL STACK     | large double stack                                                  | 12 x 4                                         | condenser  |
|            | 2-STACK         | large double stack                                                  | 12 x 4                                         | condenser  |
|            | 3-STACK         | large triple stack                                                  | 12 x 4                                         | condenser  |
| Phaser Sw  | OFF, ON         | Phaser on/off                                                       |                                                |            |
| P. Rate    | 0.05–10.00 [Hz] | Frequency of modulation                                             |                                                |            |
| Phs Manual | 0–127           | Adjusts the basic frequency from which the sound will be modulated. |                                                |            |
| Phs Depth  | 0–127           | Depth of modulation                                                 |                                                |            |
| Phs Reso   | 0–127           | Amount of feedback                                                  |                                                |            |
| Phs Mix    | 0–127           | Level of the phase-shifted sound                                    |                                                |            |
| Level      | 0–127           | Output Level                                                        |                                                |            |


## GT AMP → DELAY (Guitar Amp Simulator → Delay)



| Parameter  | Value              | Explanation                                                                                                                                               |
|------------|--------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pre Amp Sw | OFF, ON            | Turns the amp switch on/off.                                                                                                                              |
| ATyp       | Type of guitar amp |                                                                                                                                                           |
|            | JC-120             | This models the sound of the Roland JC-120.                                                                                                               |
|            | CLEAN TWIN         | This models a Fender Twin Reverb.                                                                                                                         |
|            | MATCH DRIVE        | This models the sound input to left input on a Matchless D/C-30.<br>A simulation of the latest tube amp widely used in styles from blues rock and fusion. |
|            | BG LEAD            | This models the lead sound of the MESA/ Boogie combo amp.<br>The sound of a tube amp typical of the late '70s to '80s.                                    |
|            | MS1959I            | This models the sound input to Input I on a Marshall 1959.<br>This is a trebly sound suited to hard rock.                                                 |
|            | MS1959II           | This models the sound input to Input II on a Marshall 1959.                                                                                               |
|            | MS1959I+II         | A model of the Marshall 1959 sound, with inputs I and II connected in parallel. Offers a sound with a more emphasized low-end than MS1959I.               |
|            | SLDN LEAD          | This models a Soldano SLO-100. This is the typical sound of the eighties.                                                                                 |
|            | METAL 5150         | This models the lead channel of a Peavey EVH 5150.                                                                                                        |
|            | METAL LEAD         | This is distortion sound that is ideal for performances of heavy riffs.                                                                                   |
|            | OD-1               | This models the sound of the BOSS OD-1.<br>This produces sweet, mild distortion.                                                                          |
|            | OD-2 TURBO         | This is the high-gain overdrive sound of the BOSS OD-2.                                                                                                   |
|            | DISTORTION         | This gives a basic, traditional distortion sound.                                                                                                         |
|            | FUZZ               | A fuzz sound with rich harmonic content.                                                                                                                  |
| Drive      | 0–127              | Volume and amount of distortion of the amp                                                                                                                |
| Master     | 0–127              | Volume of the entire pre-amp                                                                                                                              |
| Gain       | LOW, MIDDLE, HIGH  | Amount of pre-amp distortion                                                                                                                              |
| Bass       | 0–127              | Tone of the bass/mid/treble frequency range                                                                                                               |
| Middle     | 0–127              |                                                                                                                                                           |
| Treble     | 0–127              |                                                                                                                                                           |
| Speaker Sw | OFF, ON            | Selects whether the sound will be sent through the speaker simulation (ON) or not (OFF)                                                                   |

| Parameter | Value                                                                                                      | Explanation                                                                                                                           |
|-----------|------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| STyp      |                                                                                                            | <div>Cabinet</div> <div>Diameter (in inches) and number of the speaker</div> <div>Microphone</div>                                    |
|           | SMALL 1                                                                                                    | small open-back enclosure 10 dynamic                                                                                                  |
|           | SMALL 2                                                                                                    | small open-back enclosure 10 dynamic                                                                                                  |
|           | MIDDLE                                                                                                     | open back enclosure 12 x 1 dynamic                                                                                                    |
|           | JC-120                                                                                                     | open back enclosure 12 x 2 dynamic                                                                                                    |
|           | BUILT-IN 1                                                                                                 | open back enclosure 12 x 2 dynamic                                                                                                    |
|           | BUILT-IN 2                                                                                                 | open back enclosure 12 x 2 condenser                                                                                                  |
|           | BUILT-IN 3                                                                                                 | open back enclosure 12 x 2 condenser                                                                                                  |
|           | BUILT-IN 4                                                                                                 | open back enclosure 12 x 2 condenser                                                                                                  |
|           | BUILT-IN 5                                                                                                 | open back enclosure 12 x 2 condenser                                                                                                  |
|           | BG STACK 1                                                                                                 | sealed enclosure 12 x 2 condenser                                                                                                     |
|           | BG STACK 2                                                                                                 | large sealed enclosure 12 x 2 condenser                                                                                               |
|           | MS STACK 1                                                                                                 | large sealed enclosure 12 x 4 condenser                                                                                               |
|           | MS STACK 2                                                                                                 | large sealed enclosure 12 x 4 condenser                                                                                               |
|           | METAL STACK                                                                                                | large double stack 12 x 4 condenser                                                                                                   |
|           | 2-STACK                                                                                                    | large double stack 12 x 4 condenser                                                                                                   |
|           | 3-STACK                                                                                                    | large triple stack 12 x 4 condenser                                                                                                   |
| Delay Sw  | OFF, ON                                                                                                    | Delay on/off                                                                                                                          |
| Dly Time  | 1–1300 [msec]                                                                                              | Delay time from when the original sound is heard to when the delay sound is heard                                                     |
| Delay Fbk | -98–+98 [%]                                                                                                | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase.              |
| Dly HF    | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Frequency at which the high-frequency portion of the delay sound will be cut ( <b>BYPASS</b> : no cut)                                |
| Dly Bal   | D100:0W–D0:100W                                                                                            | Adjusts the volume balance between the sound that is sent through the delay (W) and the sound that is not sent through the delay (D). |
| Level     | 0–127                                                                                                      | Output Level                                                                                                                          |


## EP AMP → TREMOLO (EP Amp Simulator → Tremolo)



| Parameter | Value   | Explanation                                                   |
|-----------|---------|---------------------------------------------------------------|
| Type      |         | Type of amp                                                   |
|           | OLDCASE | A standard electric piano sound of the early 70s              |
|           | NEWCASE | A standard electric piano sound of the late 70s and early 80s |
|           | WURLY   | A standard electric piano sound of the 60s                    |

| Parameter    | Value                       | Explanation                                                                                        |
|--------------|-----------------------------|----------------------------------------------------------------------------------------------------|
| Bass         | -50–+50                     | Amount of low-frequency boost/cut                                                                  |
| Treble       | -50–+50                     | Amount of high-frequency boost/cut                                                                 |
| Tremolo Sw   | OFF, ON                     | Tremolo on/off                                                                                     |
| Tremolo Sync | OFF, ON                     | When this is "ON", the effect is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)   |
| T.Speed      | 0.05–10.00 [Hz]             | Rate of the tremolo effect                                                                         |
| T.Spd Nt     | Note<br>→ "Note" (p. 106)   |                                                                                                    |
| Trm Depth    | 0–127                       | Depth of the tremolo effect                                                                        |
| Trm Duty     | -10–+10                     | Adjusts the duty cycle of the LFO waveform used to apply tremolo.                                  |
| Sp Type      | LINE, OLD, NEW, WURLY, TWIN | Type of speaker<br>If LINE is selected, the sound will not be sent through the speaker simulation. |
| OD Switch    | OFF, ON                     | Overdrive on/off                                                                                   |
| OD Gain      | 0–127                       | Overdrive input level                                                                              |
| OD Drive     | 0–127                       | Degree of distortion<br>Also changes the volume.                                                   |
| Level        | 0–127                       | Output Level                                                                                       |


## EP AMP → CHORUS (EP Amp Simulator → Chorus)



| Parameter  | Value                     | Explanation                                                                                                                             |
|------------|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| Type       |                           | Type of amp                                                                                                                             |
|            | OLDCASE                   | A standard electric piano sound of the early 70s                                                                                        |
|            | NEWCASE                   | A standard electric piano sound of the late 70s and early 80s                                                                           |
| Bass       | -50–+50                   | Amount of low-frequency boost/cut                                                                                                       |
| Treble     | -50–+50                   | Amount of high-frequency boost/cut                                                                                                      |
| Cho Switch | OFF, ON                   | Chorus on/off                                                                                                                           |
| Cho PreDly | 0.0–100 [msec]            | Adjusts the delay time from the direct sound until the chorus sound is heard.                                                           |
| Cho Sync   | OFF, ON                   | When this is "ON", the effect is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                        |
| C.Rate     | 0.05–10.00 [Hz]           | Frequency of modulation                                                                                                                 |
| C.Rate Nt  | Note<br>→ "Note" (p. 106) |                                                                                                                                         |
| Cho Depth  | 0–127                     | Depth of modulation                                                                                                                     |
| Cho Bal    | D100:0W–D0:100W           | Adjusts the volume balance between the sound that is sent through the chorus (W) and the sound that is not sent through the chorus (D). |


| Parameter | Value                       | Explanation                                                                                        |
|-----------|-----------------------------|----------------------------------------------------------------------------------------------------|
| Sp Type   | LINE, OLD, NEW, WURLY, TWIN | Type of speaker<br>If LINE is selected, the sound will not be sent through the speaker simulation. |
| OD Switch | OFF, ON                     | Overdrive on/off                                                                                   |
| OD Gain   | 0–127                       | Overdrive input level                                                                              |
| OD Drive  | 0–127                       | Degree of distortion<br>Also changes the volume.                                                   |
| Level     | 0–127                       | Output Level                                                                                       |

## EP AMP → PHASER (EP Amp Simulator → Phaser)




| Parameter  | Value                       | Explanation                                                                                        |
|------------|-----------------------------|----------------------------------------------------------------------------------------------------|
| Type       |                             | Type of amp                                                                                        |
|            | OLDCASE                     | A standard electric piano sound of the early 70s                                                   |
|            | NEWCASE                     | A standard electric piano sound of the late 70s and early 80s                                      |
| Bass       | -50–+50                     | Amount of low-frequency boost/cut                                                                  |
| Treble     | -50–+50                     | Amount of high-frequency boost/cut                                                                 |
| Phs Switch | OFF, ON                     | Phaser on/off                                                                                      |
| Phs Sync   | OFF, ON                     | When this is "ON", the effect is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)   |
| P. Rate    | 0.05–10.00 [Hz]             | Frequency of modulation                                                                            |
| P. Rate Nt | Note<br>⇒ "Note" (p. 106)   |                                                                                                    |
| Phs Manual | 0–127                       | Adjusts the basic frequency from which the sound will be modulated.                                |
| Phs Depth  | 0–127                       | Depth of modulation                                                                                |
| Phs Reso   | 0–127                       | Amount of feedback                                                                                 |
| Phs Mix    | 0–127                       | Level of the phase-shifted sound                                                                   |
| Sp Type    | LINE, OLD, NEW, WURLY, TWIN | Type of speaker<br>If LINE is selected, the sound will not be sent through the speaker simulation. |
| OD Switch  | OFF, ON                     | Overdrive on/off                                                                                   |
| OD Gain    | 0–127                       | Overdrive input level                                                                              |
| OD Drive   | 0–127                       | Degree of distortion<br>Also changes the volume.                                                   |
| Level      | 0–127                       | Output Level                                                                                       |

## EP AMP → FLANGER (EP Amp Simulator → Flanger)




| Parameter  | Value                       | Explanation                                                                                                                               |
|------------|-----------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| Type       |                             | Type of amp                                                                                                                               |
|            | OLDCASE                     | A standard electric piano sound of the early 70s                                                                                          |
|            | NEWCASE                     | A standard electric piano sound of the late 70s and early 80s                                                                             |
| Bass       | -50–+50                     | Amount of low-frequency boost/cut                                                                                                         |
| Treble     | -50–+50                     | Amount of high-frequency boost/cut                                                                                                        |
| Flg Switch | OFF, ON                     | Flanger on/off                                                                                                                            |
| Flg PreDly | 0.0–100 [msec]              | Adjusts the delay time from the direct sound until the flanger sound is heard.                                                            |
| Flg Sync   | OFF, ON                     | When this is "ON", the effect is synchronized with the current click tempo.<br>⇒ "Tempo" (p. 37)                                          |
| F.Rate     | 0.05–10.00 [Hz]             | Frequency of modulation                                                                                                                   |
| F.Rate Nt  | Note<br>⇒ "Note" (p. 106)   |                                                                                                                                           |
| Flg Depth  | 0–127                       | Depth of modulation                                                                                                                       |
| Flg Fbk    | -98–+98 [%]                 | Adjusts the proportion of the flanger sound that is fed back into the effect. Negative (-) settings will invert the phase.                |
| Flg Bal    | D100:0W–D0:100W             | Adjusts the volume balance between the sound that is sent through the flanger (W) and the sound that is not sent through the flanger (D). |
| Sp Type    | LINE, OLD, NEW, WURLY, TWIN | Type of speaker<br>If LINE is selected, the sound will not be sent through the speaker simulation.                                        |
| OD Switch  | OFF, ON                     | Overdrive on/off                                                                                                                          |
| OD Gain    | 0–127                       | Overdrive input level                                                                                                                     |
| OD Drive   | 0–127                       | Degree of distortion<br>Also changes the volume.                                                                                          |
| Level      | 0–127                       | Output Level                                                                                                                              |

## EP AMP → DELAY (EP Amp Simulator → Delay)



| Parameter  | Value                                                                                                      | Explanation                                                                                                                                                                                |
|------------|------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Type       |                                                                                                            | Type of amp                                                                                                                                                                                |
|            | OLDCASE                                                                                                    | A standard electric piano sound of the early 70s                                                                                                                                           |
|            | NEWCASE                                                                                                    | A standard electric piano sound of the late 70s and early 80s                                                                                                                              |
| Bass       | -50+50                                                                                                     | Amount of low-frequency boost/cut                                                                                                                                                          |
| Treble     | -50+50                                                                                                     | Amount of high-frequency boost/cut                                                                                                                                                         |
| Dly Switch | OFF, ON                                                                                                    | Delay on/off                                                                                                                                                                               |
| Delay Sync | OFF, ON                                                                                                    | When this is "ON", the effect is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                                                                           |
| D.Time     | 1–1300 [msec]                                                                                              | Delay time from when the original sound is heard to when the delay sound is heard                                                                                                          |
| D.Time Nt  | Note<br>→ "Note" (p. 106)                                                                                  |                                                                                                                                                                                            |
| Dly Accel  | 0–15                                                                                                       | Speed at which the current delay time changes to the specified delay time when you change the delay time.<br>The speed of the pitch change will change simultaneously with the delay time. |
| Delay Fbk  | -98+98 [%]                                                                                                 | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase.                                                                   |
| Dly HF     | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Frequency at which the high-frequency portion of the delay sound will be cut ( <b>BYPASS</b> : no cut)                                                                                     |
| Dly Bal    | D100:0W–D0:100W                                                                                            | Adjusts the volume balance between the sound that is sent through the delay (W) and the sound that is not sent through the delay (D).                                                      |
| Sp Type    | LINE, OLD, NEW, WURLY, TWIN                                                                                | Type of speaker<br>If LINE is selected, the sound will not be sent through the speaker simulation.                                                                                         |
| OD Switch  | OFF, ON                                                                                                    | Overdrive on/off                                                                                                                                                                           |
| OD Gain    | 0–127                                                                                                      | Overdrive input level                                                                                                                                                                      |
| OD Drive   | 0–127                                                                                                      | Degree of distortion<br>Also changes the volume.                                                                                                                                           |
| Level      | 0–127                                                                                                      | Output Level                                                                                                                                                                               |


## EH → CHORUS (Enhancer → Chorus)



| Parameter  | Value          | Explanation                                                                   |
|------------|----------------|-------------------------------------------------------------------------------|
| Enh Sens   | 0–127          | Sensitivity of the enhancer                                                   |
| Enh Mix    | 0–127          | Level of the overtones generated by the enhancer                              |
| Cho PreDly | 0.0–100 [msec] | Adjusts the delay time from the direct sound until the chorus sound is heard. |


| Parameter | Value                     | Explanation                                                                                                                             |
|-----------|---------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| Cho Sync  | OFF, ON                   | When this is "ON", the effect is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                        |
| C.Rate    | 0.05–10.00 [Hz]           |                                                                                                                                         |
| C.Rate Nt | Note<br>→ "Note" (p. 106) | Frequency of modulation                                                                                                                 |
| Cho Depth | 0–127                     | Depth of modulation                                                                                                                     |
| Cho Bal   | D100:0W–D0:100W           | Adjusts the volume balance between the sound that is sent through the chorus (W) and the sound that is not sent through the chorus (D). |
| Level     | 0–127                     | Output Level                                                                                                                            |

## EH → FLANGER (Enhancer → Flanger)




| Parameter  | Value                     | Explanation                                                                                                                               |
|------------|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| Enh Sens   | 0–127                     | Sensitivity of the enhancer                                                                                                               |
| Enh Mix    | 0–127                     | Level of the overtones generated by the enhancer                                                                                          |
| Flg PreDly | 0.0–100 [msec]            | Adjusts the delay time from the direct sound until the flanger sound is heard.                                                            |
| Flg Sync   | OFF, ON                   | When this is "ON", the effect is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                          |
| F.Rate     | 0.05–10.00 [Hz]           |                                                                                                                                           |
| F.Rate Nt  | Note<br>→ "Note" (p. 106) | Frequency of modulation                                                                                                                   |
| Flg Depth  | 0–127                     | Depth of modulation                                                                                                                       |
| Flg Fbk    | -98+98 [%]                | Adjusts the proportion of the flanger sound that is fed back into the effect. Negative (-) settings will invert the phase.                |
| Flg Bal    | D100:0W–D0:100W           | Adjusts the volume balance between the sound that is sent through the flanger (W) and the sound that is not sent through the flanger (D). |
| Level      | 0–127                     | Output Level                                                                                                                              |

## EH → DELAY (Enhancer → Delay)



| Parameter  | Value                                                                                                      | Explanation                                                                                                                                                                 |
|------------|------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Enh Sens   | 0–127                                                                                                      | Sensitivity of the enhancer                                                                                                                                                 |
| Enh Mix    | 0–127                                                                                                      | Level of the overtones generated by the enhancer                                                                                                                            |
| Delay Sync | OFF, ON                                                                                                    | When this is “ON”, the effect is synchronized with the current click tempo.<br>→ “Tempo” (p. 37)                                                                            |
| D.Time     | 1–2600 [msec]                                                                                              | Delay time from when the original sound is heard to when the delay sound is heard                                                                                           |
| D.Time Nt  | Note<br>→ “Note” (p. 106)                                                                                  |                                                                                                                                                                             |
| Delay Fbk  | -98→+98 [%]                                                                                                | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase.                                                    |
| Dly HF     | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Adjusts the frequency above which sound fed back to the effect is filtered out. If you don’t want to filter out any high frequencies, set this parameter to <b>BYPASS</b> . |
| Dly Bal    | D100:0W–D0:100W                                                                                            | Adjusts the volume balance between the sound that is sent through the delay (W) and the sound that is not sent through the delay (D).                                       |
| Level      | 0–127                                                                                                      | Output Level                                                                                                                                                                |


## CHO → DELAY



| Parameter  | Value                     | Explanation                                                                                                              |
|------------|---------------------------|--------------------------------------------------------------------------------------------------------------------------|
| Cho PreDly | 0.0–100 [msec]            | Adjusts the delay time from the direct sound until the chorus sound is heard.                                            |
| Cho Sync   | OFF, ON                   | When this is “ON”, the effect is synchronized with the current click tempo.<br>→ “Tempo” (p. 37)                         |
| C.Rate     | 0.05–10.00 [Hz]           |                                                                                                                          |
| C.Rate Nt  | Note<br>→ “Note” (p. 106) | Frequency of modulation                                                                                                  |
| Cho Depth  | 0–127                     | Depth of modulation                                                                                                      |
| Cho Bal    | D100:0W–D0:100W           | Volume balance between the direct sound (D) and the chorus sound (W)                                                     |
| Delay Sync | OFF, ON                   | When this is “ON”, the effect is synchronized with the current click tempo.<br>→ “Tempo” (p. 37)                         |
| D.Time     | 1–2600 [msec]             | Delay time from when the original sound is heard to when the delay sound is heard                                        |
| D.Time Nt  | Note<br>→ “Note” (p. 106) |                                                                                                                          |
| Delay Fbk  | -98→+98 [%]               | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase. |


| Parameter | Value                                                                                                      | Explanation                                                                                                                                                                 |
|-----------|------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Dly HF    | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Adjusts the frequency above which sound fed back to the effect is filtered out. If you don’t want to filter out any high frequencies, set this parameter to <b>BYPASS</b> . |
| Dly Bal   | D100:0W–D0:100W                                                                                            | Adjusts the volume balance between the sound that is sent through the delay (W) and the sound that is not sent through the delay (D).                                       |
| Level     | 0–127                                                                                                      | Output Level                                                                                                                                                                |

## FLG → DELAY (Flanger → Delay)



| Parameter  | Value                                                                                                      | Explanation                                                                                                                                                                 |
|------------|------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Flg PreDly | 0.0–100 [msec]                                                                                             | Adjusts the delay time from the direct sound until the flanger sound is heard.                                                                                              |
| Flg Sync   | OFF, ON                                                                                                    | When this is “ON”, the effect is synchronized with the current click tempo.<br>→ “Tempo” (p. 37)                                                                            |
| F.Rate     | 0.05–10.00 [Hz]                                                                                            |                                                                                                                                                                             |
| F.Rate Nt  | Note<br>→ “Note” (p. 106)                                                                                  | Frequency of modulation                                                                                                                                                     |
| Flg Depth  | 0–127                                                                                                      | Depth of modulation                                                                                                                                                         |
| Flg Fbk    | -98→+98 [%]                                                                                                | Adjusts the proportion of the flanger sound that is fed back into the effect. Negative (-) settings will invert the phase.                                                  |
| Flg Bal    | D100:0W–D0:100W                                                                                            | Volume balance between the direct sound (D) and the flanger sound (W)                                                                                                       |
| Delay Sync | OFF, ON                                                                                                    | When this is “ON”, the effect is synchronized with the current click tempo.<br>→ “Tempo” (p. 37)                                                                            |
| D.Time     | 1–2600 [msec]                                                                                              | Delay time from when the original sound is heard to when the delay sound is heard                                                                                           |
| D.Time Nt  | Note<br>→ “Note” (p. 106)                                                                                  |                                                                                                                                                                             |
| Delay Fbk  | -98→+98 [%]                                                                                                | Adjusts the proportion of the delay sound that is fed back into the effect. Negative (-) settings will invert the phase.                                                    |
| Dly HF     | 200, 250, 315, 400, 500, 630, 800, 1000, 1250, 1600, 2000, 2500, 3150, 4000, 5000, 6300, 8000, BYPASS [Hz] | Adjusts the frequency above which sound fed back to the effect is filtered out. If you don’t want to filter out any high frequencies, set this parameter to <b>BYPASS</b> . |
| Dly Bal    | D100:0W–D0:100W                                                                                            | Adjusts the volume balance between the sound that is sent through the delay (W) and the sound that is not sent through the delay (D).                                       |
| Level      | 0–127                                                                                                      | Output Level                                                                                                                                                                |


## CHO → FLANGER (Chorus → Flanger)



| Parameter  | Value                     | Explanation                                                                                                                               |
|------------|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------|
| Cho PreDly | 0.0–100 [msec]            | Adjusts the delay time from the direct sound until the chorus sound is heard.                                                             |
| Cho Sync   | OFF, ON                   | When this is "ON", the effect is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                          |
| C.Rate     | 0.05–10.00 [Hz]           | Modulation frequency of the chorus effect                                                                                                 |
| C.Rate Nt  | Note<br>→ "Note" (p. 106) |                                                                                                                                           |
| Cho Depth  | 0–127                     | Modulation depth of the chorus effect                                                                                                     |
| Cho Bal    | D100:0W–D0:100W           | Volume balance between the direct sound (D) and the chorus sound (W)                                                                      |
| Flg PreDly | 0.0–100 [msec]            | Adjusts the delay time from the direct sound until the flanger sound is heard.                                                            |
| Flg Sync   | OFF, ON                   | When this is "ON", the effect is synchronized with the current click tempo.<br>→ "Tempo" (p. 37)                                          |
| F.Rate     | 0.05–10.00 [Hz]           | Modulation frequency of the flanger effect                                                                                                |
| F.Rate Nt  | Note<br>→ "Note" (p. 106) |                                                                                                                                           |
| Flg Depth  | 0–127                     | Modulation depth of the flanger effect                                                                                                    |
| Flg Fbk    | –98–+98 [%]               | Adjusts the proportion of the flanger sound that is fed back into the effect. Negative (–) settings will invert the phase.                |
| Flg Bal    | D100:0W–D0:100W           | Adjusts the volume balance between the sound that is sent through the flanger (W) and the sound that is not sent through the flanger (D). |
| Level      | 0–127                     | Output Level                                                                                                                              |

## JD-MULTI

Recreates the effects included in group A of the JD-800.



| Parameter | Value              | Explanation                                                                                                  |
|-----------|--------------------|--------------------------------------------------------------------------------------------------------------|
| Seq       | DS - PH - SP - EN  | Selects the connection order of the effects.<br>DS: Distortion<br>PH: Phaser<br>SP: Spectrum<br>EN: Enhancer |
|           | DS - PH - EN - SP  |                                                                                                              |
|           | DS - SP - PH - EN  |                                                                                                              |
|           | DS - SP - EN - PH  |                                                                                                              |
|           | DS - EN - PH - SP  |                                                                                                              |
|           | DS - EN - SP - PH  |                                                                                                              |
|           | PH - DS - SP - EN  |                                                                                                              |
|           | PH - DS - EN - SP  |                                                                                                              |
|           | PH - SP - DS - EN  |                                                                                                              |
|           | PH - SP - EN - DS  |                                                                                                              |
|           | PH - EN - DS - SP  |                                                                                                              |
|           | PH - EN - SP - DS  |                                                                                                              |
|           | SP - DS - PH - EN  |                                                                                                              |
|           | SP - DS - EN - PH  |                                                                                                              |
|           | SP - PH - DS - EN  |                                                                                                              |
|           | SP - PH - EN - DS  |                                                                                                              |
| DS Switch | OFF, ON            | Turns the distortion on/off.<br>Sets the type of distortion.                                                 |
|           | MELLOW DRV         |                                                                                                              |
|           | OVERDRIVE          |                                                                                                              |
|           | CRY DRV            |                                                                                                              |
|           | MELLOW DST         |                                                                                                              |
|           | LIGHT DST          |                                                                                                              |
|           | FAT DIST           |                                                                                                              |
|           | FUZZ DIST          |                                                                                                              |
| DS Type   | 0–100              | Sets the amount of distortion.                                                                               |
|           | 0–100              |                                                                                                              |
|           | 0–100              |                                                                                                              |
|           | 0–100              |                                                                                                              |
|           | 0–100              |                                                                                                              |
|           | 0–100              |                                                                                                              |
| PH Switch | OFF, ON            | Turns the phaser on/off.                                                                                     |
| PH Manual | 50 [Hz]–15.0 [kHz] | Sets the basic frequency from which the sound is modulated with the phaser effect.                           |
| PH Rate   | 0.1–10.0 [Hz]      | Sets the cycle of the phaser modulation.                                                                     |
| PH Depth  | 0–100              | Sets the depth of the phaser modulation.                                                                     |

| Parameter     | Value        | Explanation                                                                                        |
|---------------|--------------|----------------------------------------------------------------------------------------------------|
| PH Resonance  | 0–100        | Sets the amount of feedback for the phaser. Increasing the value creates a more unusual sound.     |
| PH Mix        | 0–100        | Sets the level of the phase-shifted sound.                                                         |
| SP Switch     | OFF, ON      | Turns the spectrum on/off.                                                                         |
| SP Band Ctrl1 | -15–+15 [dB] | Sets the gain (amount of boost/cut) in the 250 Hz range.                                           |
| SP Band Ctrl2 | -15–+15 [dB] | Sets the gain (amount of boost/cut) in the 500 Hz range.                                           |
| SP Band Ctrl3 | -15–+15 [dB] | Sets the gain (amount of boost/cut) in the 1000 Hz range.                                          |
| SP Band Ctrl4 | -15–+15 [dB] | Sets the gain (amount of boost/cut) in the 2000 Hz range.                                          |
| SP Band Ctrl5 | -15–+15 [dB] | Sets the gain (amount of boost/cut) in the 4000 Hz range.                                          |
| SP Band Ctrl6 | -15–+15 [dB] | Sets the gain (amount of boost/cut) in the 8000 Hz range.                                          |
| SP Width      | 1–5          | Sets the bandwidth for changing the levels, common to all bands.                                   |
| EH Switch     | OFF, ON      | Turns the enhancer on/off.                                                                         |
| EH Sens       | 0–100        | Sets how easily the enhancer effect is applied.                                                    |
| EH Mix        | 0–100        | Sets the ratio at which the harmonics generated by the enhancer are mixed with the original sound. |
| Pan           | L64–63R      | Changes the pan.                                                                                   |
| Level         | 0–127        | Sets the output volume.                                                                            |

## Note

|       |                           |       |                        |       |                            |
|-------|---------------------------|-------|------------------------|-------|----------------------------|
| 1/64T | Sixty-fourth-note triplet | 1/64  | Sixty-fourth note      | 1/32T | Thirty-second-note triplet |
| 1/32  | Thirty-second note        | 1/16T | Sixteenth-note triplet | 1/32. | Dotted thirty-second note  |
| 1/16  | Sixteenth note            | 1/8T  | Eighth-note triplet    | 1/16. | Dotted sixteenth note      |
| 1/8   | Eighth note               | 1/4T  | Quarter-note triplet   | 1/8.  | Dotted eighth note         |
| 1/4   | Quarter note              | 1/2T  | Half-note triplet      | 1/4.  | Dotted quarter note        |
| 1/2   | Half note                 | 1/1T  | Whole-note triplet     | 1/2.  | Dotted half note           |
| 1/1   | Whole note                | 2/1T  | Double-note triplet    | 1/1.  | Dotted whole note          |
| 2/1   | Double note               |       |                        |       |                            |

### NOTE

If you set the delay time as a note value, slowing down the tempo will not change the delay time beyond a certain length. There is an upper limit for the delay time so if it is set as a note value and you slow down the tempo until this upper limit is reached, the delay time cannot change any further.

# Drum kit list

| No. | Drum kit name     | Sub name                 |
|-----|-------------------|--------------------------|
| 1   | Studio A          |                          |
| 2   | Studio B          |                          |
| 3   | Rock Energy       |                          |
| 4   | Jazz Sizzle       |                          |
| 5   | Massive Metal     |                          |
| 6   | Vintage Loose     |                          |
| 7   | Neo Funk          |                          |
| 8   | Drum'n'Bass       |                          |
| 9   | Pure Analog       | Mid-O Style              |
| 10  | Deep Rock         |                          |
| 11  | Ghost Note King   |                          |
| 12  | Live is Life      | Live Pop Rock            |
| 13  | Piccolo Funk      | Voice Samples on Tom Rim |
| 14  | Bop Shop          | Sizzle Swing             |
| 15  | Dark & Open       |                          |
| 16  | Modern Gospel     |                          |
| 17  | JS Garage         | Snare Explosion          |
| 18  | Hall Ambience     |                          |
| 19  | Vintage e-Drums   | Hexagonal Pads           |
| 20  | Crush Comp        |                          |
| 21  | Dry & Muffled     |                          |
| 22  | Blast Attack      | Thrash Metal             |
| 23  | Crisp Drive       | Preamped Beatmaker       |
| 24  | All Big Sizes     | Big Arena                |
| 25  | Large Room        |                          |
| 26  | Vintage Comp      |                          |
| 27  | 12" Ringing Snare |                          |
| 28  | Classic Rock      |                          |
| 29  | Babylon Shuffle   |                          |
| 30  | Hard Rock         |                          |
| 31  | Jazz Legend       | Floor Tom Kick           |
| 32  | Funkifyer         | Live Funk Studio         |
| 33  | Jazzinator        | Hybrid Jazz Gig          |
| 34  | Pro Studio        |                          |
| 35  | Viking Metal      | Norwegian Metal          |
| 36  | Shallow Pop       |                          |
| 37  | Crossing Front    |                          |
| 38  | Alternative Rock  |                          |
| 39  | Acoustic Popper   | Aggressive - Hip Hop     |
| 40  | Heavy&Distorted   |                          |
| 41  | Lowbit World      | Bit Crusher              |
| 42  | Gate in the Air   | COMPRESSED               |
| 43  | DIGIKIT!          | SnappDkik                |
| 44  | Synthetix         |                          |
| 45  | Electro Synth     |                          |
| 46  | UK Wet Booth      |                          |
| 47  | UK Wet Studio     |                          |
| 48  | LoFi Overdrive    |                          |
| 49  | TR-808            | Transistor Rhythm        |
| 50  | TR-909            | Transistor Rhythm        |
| 51  | TR-707            | Transistor Rhythm        |
| 52  | CR-78             | CompuRhythm              |
| 53  | TR-909 Inspire    |                          |
| 54  | TexMex FX         |                          |
| 55  | R&B Ballad        |                          |
| 56  | Mellow R&B        |                          |
| 57  | The Big One       | Tom Rim Bend             |
| 58  | Detroit           | Hip Hop                  |

| No. | Drum kit name  | Sub name             |
|-----|----------------|----------------------|
| 59  | Dancing LA     |                      |
| 60  | Junk Noise     |                      |
| 61  | Orchestral     | Pedal Bend           |
| 62  | Mermaid        | Steelpan             |
| 63  | Bateria        | Carnaval do Brasil   |
| 64  | Latin Festa!   |                      |
| 65  | Wild Drumming  | Conga & Djembe       |
| 66  | Ethnic Perc    |                      |
| 67  | Camel Journey  |                      |
| 68  | Air From Asia  | Pedal Bend           |
| 69  | Jazz Brushes   | Small Room           |
| 70  | Modern Brushes | Large Room w/ Sizzle |
| 71  | User Kit       |                      |
| 72  | User Kit       |                      |
| 73  | User Kit       |                      |
| 74  | User Kit       |                      |
| 75  | User Kit       |                      |
| 76  | User Kit       |                      |
| 77  | User Kit       |                      |
| 78  | User Kit       |                      |
| 79  | User Kit       |                      |
| 80  | User Kit       |                      |
| 81  | User Kit       |                      |
| 82  | User Kit       |                      |
| 83  | User Kit       |                      |
| 84  | User Kit       |                      |
| 85  | User Kit       |                      |
| 86  | User Kit       |                      |
| 87  | User Kit       |                      |
| 88  | User Kit       |                      |
| 89  | User Kit       |                      |
| 90  | User Kit       |                      |
| 91  | User Kit       |                      |
| 92  | User Kit       |                      |
| 93  | User Kit       |                      |
| 94  | User Kit       |                      |
| 95  | User Kit       |                      |
| 96  | User Kit       |                      |
| 97  | User Kit       |                      |
| 98  | User Kit       |                      |
| 99  | User Kit       |                      |
| 100 | User Kit       |                      |
| 101 | User Kit       |                      |
| 102 | User Kit       |                      |
| 103 | User Kit       |                      |
| 104 | User Kit       |                      |
| 105 | User Kit       |                      |
| 106 | User Kit       |                      |
| 107 | User Kit       |                      |
| 108 | User Kit       |                      |
| 109 | User Kit       |                      |
| 110 | User Kit       |                      |
| 111 | User Kit       |                      |
| 112 | User Kit       |                      |
| 113 | User Kit       |                      |
| 114 | User Kit       |                      |
| 115 | User Kit       |                      |
| 116 | User Kit       |                      |

| No. | Drum kit name | Sub name |
|-----|---------------|----------|
| 117 | User Kit      |          |
| 118 | User Kit      |          |
| 119 | User Kit      |          |
| 120 | User Kit      |          |
| 121 | User Kit      |          |
| 122 | User Kit      |          |
| 123 | User Kit      |          |
| 124 | User Kit      |          |
| 125 | User Kit      |          |
| 126 | User Kit      |          |
| 127 | User Kit      |          |
| 128 | User Kit      |          |
| 129 | User Kit      |          |
| 130 | User Kit      |          |
| 131 | User Kit      |          |
| 132 | User Kit      |          |
| 133 | User Kit      |          |
| 134 | User Kit      |          |
| 135 | User Kit      |          |
| 136 | User Kit      |          |
| 137 | User Kit      |          |
| 138 | User Kit      |          |
| 139 | User Kit      |          |
| 140 | User Kit      |          |
| 141 | User Kit      |          |
| 142 | User Kit      |          |
| 143 | User Kit      |          |
| 144 | User Kit      |          |
| 145 | User Kit      |          |
| 146 | User Kit      |          |
| 147 | User Kit      |          |
| 148 | User Kit      |          |
| 149 | User Kit      |          |
| 150 | User Kit      |          |
| 151 | User Kit      |          |
| 152 | User Kit      |          |
| 153 | User Kit      |          |
| 154 | User Kit      |          |
| 155 | User Kit      |          |
| 156 | User Kit      |          |
| 157 | User Kit      |          |
| 158 | User Kit      |          |
| 159 | User Kit      |          |
| 160 | User Kit      |          |
| 161 | User Kit      |          |
| 162 | User Kit      |          |
| 163 | User Kit      |          |
| 164 | User Kit      |          |
| 165 | User Kit      |          |
| 166 | User Kit      |          |
| 167 | User Kit      |          |
| 168 | User Kit      |          |
| 169 | User Kit      |          |
| 170 | User Kit      |          |
| 171 | User Kit      |          |
| 172 | User Kit      |          |
| 173 | User Kit      |          |
| 174 | User Kit      |          |

| No. | Drum kit name | Sub name |
|-----|---------------|----------|
| 175 | User Kit      |          |
| 176 | User Kit      |          |
| 177 | User Kit      |          |
| 178 | User Kit      |          |
| 179 | User Kit      |          |
| 180 | User Kit      |          |
| 181 | User Kit      |          |
| 182 | User Kit      |          |
| 183 | User Kit      |          |
| 184 | User Kit      |          |
| 185 | User Kit      |          |
| 186 | User Kit      |          |
| 187 | User Kit      |          |
| 188 | User Kit      |          |
| 189 | User Kit      |          |
| 190 | User Kit      |          |
| 191 | User Kit      |          |
| 192 | User Kit      |          |
| 193 | User Kit      |          |
| 194 | User Kit      |          |
| 195 | User Kit      |          |
| 196 | User Kit      |          |
| 197 | User Kit      |          |
| 198 | User Kit      |          |
| 199 | User Kit      |          |
| 200 | User Kit      |          |

# Instrument list

## Preset

| No. | Instrument group | Instrument name  | Remarks     |
|-----|------------------|------------------|-------------|
| 0   | OFF              | OFF              |             |
| 1   | KICK             | TM SL Maple K    | *M          |
| 2   | KICK             | TM SL MtOff K    | *M          |
| 3   | KICK             | TM SL Jazz K     | *M          |
| 4   | KICK             | TM SL Jz MltB K  | *M          |
| 5   | KICK             | TM SC Mpl Jazz K | *M          |
| 6   | KICK             | TM SC Bubinga K  | *M          |
| 7   | KICK             | Gr USC Maple K   | *M          |
| 8   | KICK             | Gr CD Maple K    | *M          |
| 9   | KICK             | Ld VL Acrylic K  | *M          |
| 10  | KICK             | DW 90'CS Maple K | *M          |
| 11  | KICK             | NC SCP Maple K   | *M          |
| 12  | KICK             | Bd Jarrah K      | *M          |
| 13  | KICK             | So PL Maple K    | *M          |
| 14  | KICK             | So PL Jazz K     | *M          |
| 15  | KICK             | So Sig Bubinga K | *M          |
| 16  | KICK             | YH RC Birch K    | *M          |
| 17  | KICK             | YH RT Mahogany1K | *M          |
| 18  | KICK             | YH RT Mahogany2K | *M          |
| 19  | KICK             | Mx VT Maple 1 K  | *M          |
| 20  | KICK             | Mx VT Maple 2 K  | *M          |
| 21  | KICK             | Mx VT Maple 3 K  | *M          |
| 22  | KICK             | Close Mic 22"K   | *M          |
| 23  | KICK OTHERS      | Plugged Kick 1   |             |
| 24  | KICK OTHERS      | Plugged Kick 2   |             |
| 25  | KICK OTHERS      | Plugged Kick 3   |             |
| 26  | KICK OTHERS      | Tight Kick 1     |             |
| 27  | KICK OTHERS      | Tight Kick 2     |             |
| 28  | KICK OTHERS      | Tight Kick 3     |             |
| 29  | KICK OTHERS      | Meat Kick        |             |
| 30  | KICK OTHERS      | Hard Attack Kick |             |
| 31  | KICK OTHERS      | Power & Low K    |             |
| 32  | KICK OTHERS      | SubSharpness K   |             |
| 33  | KICK OTHERS      | Metal & Low K    |             |
| 34  | KICK OTHERS      | InYourFace K     |             |
| 35  | SNARE            | DW Concrete S    | *M *P *X *O |
| 36  | SNARE            | DW Concrete SR   | *M *P *X *O |
| 37  | SNARE            | PI MapleShell S  | *M *P *X *O |
| 38  | SNARE            | PI MapleShell SR | *M *P *X *O |
| 39  | SNARE            | Gr BH Poplar S   | *M *P *X *O |
| 40  | SNARE            | Gr BH Poplar SR  | *M *P *X *O |
| 41  | SNARE            | Ld BB Brass S    | *M *P *X *O |
| 42  | SNARE            | Ld BB Brass SR   | *M *P *X *O |
| 43  | SNARE            | Gr Silver Mpl S  | *M *P *X *O |
| 44  | SNARE            | Gr Silver Mpl SR | *M *P *X *O |
| 45  | SNARE            | DW CS Maple S    | *M *P *X *O |
| 46  | SNARE            | DW CS Maple SR   | *M *P *X *O |
| 47  | SNARE            | Mx Piccolo S     | *M *P *X *O |
| 48  | SNARE            | Mx Piccolo SR    | *M *P *X *O |
| 49  | SNARE            | Gr 50'Maple S    | *M *P *X    |
| 50  | SNARE            | Gr 50'Maple SR   | *M *P *X    |
| 51  | SNARE            | Cp MapleBirch S  | *M *P *X    |
| 52  | SNARE            | Cp MapleBirch SR | *M *P *X    |
| 53  | SNARE            | YH 80'Maple S    | *M *P *X    |
| 54  | SNARE            | YH 80'Maple SR   | *M *P *X    |
| 55  | SNARE            | DW Pure Steel S  | *M *P *X *O |
| 56  | SNARE            | DW Pure Steel SR | *M *P *X *O |
| 57  | CROSS STICK      | DW Concrete X    | *X          |
| 58  | CROSS STICK      | PI MapleShell X  | *X          |
| 59  | CROSS STICK      | Gr BH Poplar X   | *X          |
| 60  | CROSS STICK      | Ld BB Brass X    | *X          |
| 61  | CROSS STICK      | Gr Silver Mpl X  | *X          |
| 62  | CROSS STICK      | DW CS Maple X    | *X          |
| 63  | CROSS STICK      | Mx Piccolo X     | *X          |

| No. | Instrument group | Instrument name  | Remarks |
|-----|------------------|------------------|---------|
| 64  | CROSS STICK      | Gr 50'Maple X    | *X      |
| 65  | CROSS STICK      | Cp MapleBirch X  | *X      |
| 66  | CROSS STICK      | YH 80'Maple X    | *X      |
| 67  | CROSS STICK      | DW Pure Steel X  | *X      |
| 68  | SNARE OTHERS     | Plugged Snare 1  |         |
| 69  | SNARE OTHERS     | Plugged Snare 2  |         |
| 70  | SNARE OTHERS     | Plugged Snare 3  |         |
| 71  | SNARE OTHERS     | Plugged Snare 4  |         |
| 72  | SNARE OTHERS     | Plugged Snare 5  |         |
| 73  | SNARE OTHERS     | Plugged Snare 6  |         |
| 74  | SNARE OTHERS     | Custom Wood S    |         |
| 75  | SNARE OTHERS     | Custom Wood SR   |         |
| 76  | SNARE OTHERS     | Power Amb S      |         |
| 77  | SNARE OTHERS     | Power Amb SR     |         |
| 78  | SNARE OTHERS     | Fat Comp 1 S     |         |
| 79  | SNARE OTHERS     | Fat Comp 1 SR    |         |
| 80  | SNARE OTHERS     | Fat Comp 2 S     |         |
| 81  | SNARE OTHERS     | Fat Comp 2 SR    |         |
| 82  | SNARE OTHERS     | Power Fat S      |         |
| 83  | SNARE OTHERS     | Power Fat SR     |         |
| 84  | SNARE OTHERS     | Power Buzz 1 S   |         |
| 85  | SNARE OTHERS     | Power Buzz 1 SR  |         |
| 86  | SNARE OTHERS     | Power Buzz 2 S   |         |
| 87  | SNARE OTHERS     | Power Buzz 2 SR  |         |
| 88  | SNARE OTHERS     | Proc Op Metal S  |         |
| 89  | SNARE OTHERS     | Proc Op Metal SR |         |
| 90  | TOM              | Gr USC Maple T1  | *M      |
| 91  | TOM              | Gr USC Maple T1R | *M *P   |
| 92  | TOM              | Gr USC Maple T2  | *M      |
| 93  | TOM              | Gr USC Maple T2R | *M *P   |
| 94  | TOM              | Gr USC Maple T3  | *M      |
| 95  | TOM              | Gr USC Maple T3R | *M *P   |
| 96  | TOM              | Gr USC Maple T4  | *M      |
| 97  | TOM              | Gr USC Maple T4R | *M *P   |
| 98  | TOM              | Gr USC Maple T5  | *M      |
| 99  | TOM              | Gr USC Maple T5R | *M *P   |
| 100 | TOM              | Gr USC Maple T6  | *M      |
| 101 | TOM              | Gr USC Maple T6R | *M *P   |
| 102 | TOM              | Ld VLAcrylic T1  | *M      |
| 103 | TOM              | Ld VLAcrylic T1R | *M *P   |
| 104 | TOM              | Ld VLAcrylic T2  | *M      |
| 105 | TOM              | Ld VLAcrylic T2R | *M *P   |
| 106 | TOM              | Ld VLAcrylic T3  | *M      |
| 107 | TOM              | Ld VLAcrylic T3R | *M *P   |
| 108 | TOM              | Ld VLAcrylic T4  | *M      |
| 109 | TOM              | Ld VLAcrylic T4R | *M *P   |
| 110 | TOM              | Ld VLAcrylic T5  | *M      |
| 111 | TOM              | Ld VLAcrylic T5R | *M *P   |
| 112 | TOM              | So PL Maple T1   | *M      |
| 113 | TOM              | So PL Maple T1R  | *M *P   |
| 114 | TOM              | So PL Maple T2   | *M      |
| 115 | TOM              | So PL Maple T2R  | *M *P   |
| 116 | TOM              | So PL Maple T3   | *M      |
| 117 | TOM              | So PL Maple T3R  | *M *P   |
| 118 | TOM              | So PL Maple T4   | *M      |
| 119 | TOM              | So PL Maple T4R  | *M *P   |
| 120 | TOM              | So PL Maple T5   | *M      |
| 121 | TOM              | So PL Maple T5R  | *M *P   |
| 122 | TOM              | YH Mahogany T1   | *M      |
| 123 | TOM              | YH Mahogany T1R  | *M *P   |
| 124 | TOM              | YH Mahogany T2   | *M      |
| 125 | TOM              | YH Mahogany T2R  | *M *P   |
| 126 | TOM              | YH Mahogany T3   | *M      |
| 127 | TOM              | YH Mahogany T3R  | *M *P   |
| 128 | TOM              | YH Mahogany T4   | *M      |
| 129 | TOM              | YH Mahogany T4R  | *M *P   |
| 130 | TOM              | TM Gong Drum     | *M      |

| No. | Instrument group | Instrument name  | Remarks |
|-----|------------------|------------------|---------|
| 131 | TOM OTHERS       | Plugged Tom 1 T1 |         |
| 132 | TOM OTHERS       | Plugged Tom 1 T2 |         |
| 133 | TOM OTHERS       | Plugged Tom 1 T3 |         |
| 134 | TOM OTHERS       | Plugged Tom 1 T4 |         |
| 135 | TOM OTHERS       | Plugged Tom 2 T1 |         |
| 136 | TOM OTHERS       | Plugged Tom 2 T2 |         |
| 137 | TOM OTHERS       | Plugged Tom 2 T3 |         |
| 138 | TOM OTHERS       | Plugged Tom 3 T1 |         |
| 139 | TOM OTHERS       | Plugged Tom 3 T2 |         |
| 140 | TOM OTHERS       | Plugged Tom 3 T3 |         |
| 141 | TOM OTHERS       | Plugged Tom 4 T1 |         |
| 142 | TOM OTHERS       | Plugged Tom 4 T2 |         |
| 143 | HI-HAT           | Mn BzTradMed HH  | *P      |
| 144 | HI-HAT           | Mn BzTradMed HHE | *P      |
| 145 | HI-HAT           | Zd K&A-DB HH     | *P      |
| 146 | HI-HAT           | Zd K&A-DB HHE    | *P      |
| 147 | HI-HAT           | Zd KC D HH       | *P      |
| 148 | HI-HAT           | Zd KC D HHE      | *P      |
| 149 | HI-HAT           | Ps 602 HH        | *P      |
| 150 | HI-HAT           | Ps 602 HHE       | *P      |
| 151 | HI-HAT           | Sb HX HH         | *P      |
| 152 | HI-HAT           | Sb HX HHE        | *P      |
| 153 | HI-HAT           | Zd AC HH         | *P      |
| 154 | HI-HAT           | Zd AC HHE        | *P      |
| 155 | RIDE             | Mn BzTradMed Rd  | *P *L   |
| 156 | RIDE             | Mn BzTradMed RdE | *P *L   |
| 157 | RIDE             | Mn BzTradMed RdB | *L      |
| 158 | RIDE             | Zd KC H Rd       | *P *L   |
| 159 | RIDE             | Zd KC H RdE      | *P *L   |
| 160 | RIDE             | Zd KC H RdB      | *L      |
| 161 | RIDE             | Zd KC D Rd       | *P *L   |
| 162 | RIDE             | Zd KC D RdE      | *P *L   |
| 163 | RIDE             | Zd KC D RdB      | *L      |
| 164 | RIDE             | Zd K Jazz Rd     | *P *L   |
| 165 | RIDE             | Zd K Jazz RdE    | *P *L   |
| 166 | RIDE             | Zd K Jazz RdB    | *L      |
| 167 | RIDE             | Zd AC Rd         | *P *L   |
| 168 | RIDE             | Zd AC RdE        | *P *L   |
| 169 | RIDE             | Zd AC RdB        | *L      |
| 170 | RIDE             | Sb HX Rd         | *P *L   |
| 171 | RIDE             | Sb HX RdE        | *P *L   |
| 172 | RIDE             | Sb HX RdB        | *L      |
| 173 | RIDE             | Mn Bz Dry Rd     | *P *L   |
| 174 | RIDE             | Mn Bz Dry RdE    | *P *L   |
| 175 | RIDE             | Mn Bz Dry RdB    | *L      |
| 176 | CRASH            | Mn BzTrd MT1 Cr  | *L      |
| 177 | CRASH            | Mn BzTrd MT1 CrE | *L      |
| 178 | CRASH            | Mn BzTrd MT2 Cr  | *L      |
| 179 | CRASH            | Mn BzTrd MT2 CrE | *L      |
| 180 | CRASH            | Zd AThin 1 Cr    | *L      |
| 181 | CRASH            | Zd AThin 1 CrE   | *L      |
| 182 | CRASH            | Zd AThin 2 Cr    | *L      |
| 183 | CRASH            | Zd AThin 2 CrE   | *L      |
| 184 | CRASH            | Zd AC Pjt 1 Cr   | *L      |
| 185 | CRASH            | Zd AC Pjt 1 CrE  | *L      |
| 186 | CRASH            | Zd AC Pjt 2 Cr   | *L      |
| 187 | CRASH            | Zd AC Pjt 2 CrE  | *L      |
| 188 | CRASH            | Zd KHybd 1 Cr    | *L      |
| 189 | CRASH            | Zd KHybd 1 CrE   | *L      |
| 190 | CRASH            | Zd KHybd 2 Cr    | *L      |
| 191 | CRASH            | Zd KHybd 2 CrE   | *L      |
| 192 | CRASH            | Zd KHybd 3 Cr    | *L      |
| 193 | CRASH            | Zd KHybd 3 CrE   | *L      |
| 194 | CRASH            | Zd KC D-Thin1Cr  | *L      |
| 195 | CRASH            | Zd KC D-Thin1CrE | *L      |
| 196 | CRASH            | Zd KC D-Thin2Cr  | *L      |
| 197 | CRASH            | Zd KC D-Thin2CrE | *L      |

| No. | Instrument group | Instrument name  | Remarks |
|-----|------------------|------------------|---------|
| 198 | CRASH            | Mn Bz DTrash1Cr  | *L      |
| 199 | CRASH            | Mn Bz DTrash1CrE | *L      |
| 200 | CRASH            | Mn Bz DTrash2Cr  | *L      |
| 201 | CRASH            | Mn Bz DTrash2CrE | *L      |
| 202 | CRASH            | Zd AC Cr         | *L      |
| 203 | CRASH            | Zd AC CrE        | *L      |
| 204 | CRASH            | Sb HX Cr         | *L      |
| 205 | CRASH            | Sb HX CrE        | *L      |
| 206 | CHINA            | Mn Bz Trad Ch    | *L      |
| 207 | CHINA            | Mn Bz Trad ChE   | *L      |
| 208 | CHINA            | Zd C-B 1 Ch      | *L      |
| 209 | CHINA            | Zd C-B 1 ChE     | *L      |
| 210 | CHINA            | Zd C-B 2 Ch      | *L      |
| 211 | CHINA            | Zd C-B 2 ChE     | *L      |
| 212 | SPLASH           | Mn Bz Dual Sp    | *L      |
| 213 | SPLASH           | Mn Bz Dual SpE   | *L      |
| 214 | SPLASH           | Ib Agp Sp        | *L      |
| 215 | SPLASH           | Ib Agp SpE       | *L      |
| 216 | SPLASH           | Ps Pxrs Sp       | *L      |
| 217 | SPLASH           | Ps Pxrs SpE      | *L      |
| 218 | SPLASH           | Zd APeperThinSp  | *L      |
| 219 | SPLASH           | Zd APeperThinSpE | *L      |
| 220 | STACKED CYMBAL   | Mn+Zd Stacked1   | *L      |
| 221 | STACKED CYMBAL   | Mn+Zd Stacked1 E | *L      |
| 222 | STACKED CYMBAL   | Mn+Zd Stacked2   | *L      |
| 223 | STACKED CYMBAL   | Mn+Zd Stacked2 E | *L      |
| 224 | STACKED CYMBAL   | Sb NoiseChop Sp  | *L      |
| 225 | STACKED CYMBAL   | Sb NoiseChop SpE | *L      |
| 226 | BELL/CHIME/GONG  | Trad Gong        |         |
| 227 | BLOCK/COWBELL    | Cowbell Tip      |         |
| 228 | BLOCK/COWBELL    | Cowbell          |         |
| 229 | BLOCK/COWBELL    | ChaCha Bell Tip  |         |
| 230 | BLOCK/COWBELL    | ChaCha Bell      |         |
| 231 | BLOCK/COWBELL    | Jam Block        |         |
| 232 | PERCUSSION       | Tambourine       |         |
| 233 | PERCUSSION       | Shaker Down      |         |
| 234 | PERCUSSION       | Shaker Up        |         |
| 235 | CLAP             | Clap             |         |
| 236 | ELEMENTS         | Kick Low Freq 1  |         |
| 237 | ELEMENTS         | Kick Low Freq 2  |         |
| 238 | ELEMENTS         | Kick Low Freq 3  |         |
| 239 | ELEMENTS         | Kick Low Freq 4  |         |
| 240 | ELEMENTS         | Attack 1         |         |
| 241 | ELEMENTS         | Attack 2         |         |
| 242 | ELEMENTS         | Attack 3         |         |
| 243 | ELEMENTS         | Attack 4         |         |
| 244 | ELEMENTS         | Attack 5         |         |
| 245 | ELEMENTS         | For Pad Check    |         |

**\*M:** Supports the editing of “Mic Size” and “Mic Distance” for the instrument. (“Mic Size” only applies to kick drum sounds)

**\*P:** Can get various changes of the sound in accordance with the positioning where on the pad you hit with a stick. In rim sounds, can get such various changes of the sound in accordance with the depth of the stick on the rim.

**\*X:** When this is assigned to the rim of the snare, the corresponding cross stick sound is automatically assigned to XSTICK.

**\*O:** Supports the editing of “Overtone” for the instrument.

**\*L:** Supports the editing of “Lo Cut” for the instrument.

\* Support for methods of playing and strike position detection differs according to the trigger input. For details on how the trigger input corresponds to your performance technique and striking position, refer to “Trig Type list” (p. 60).

## Instrument Expansion

### EXV001: Wood Room Studio UK 1

| No. | Instrument group | Instrument name  | Remarks     |
|-----|------------------|------------------|-------------|
| 1   | KICK             | Cm Vintage K     | *M          |
| 2   | KICK             | Cm AmbLess K     | *M          |
| 3   | SNARE            | Cv Vintage S     | *M *P *X    |
| 4   | SNARE            | Cv Vintage SR    | *M *P *X    |
| 5   | SNARE            | Ld SP Vintage S  | *M *P *X *O |
| 6   | SNARE            | Ld SP Vintage SR | *M *P *X *O |
| 7   | SNARE            | Cv AmbLess S     | *M *P *X    |
| 8   | SNARE            | Cv AmbLess SR    | *M *P *X    |
| 9   | SNARE            | Ld SP AmbLess S  | *M *P *X *O |
| 10  | SNARE            | Ld SP AmbLess SR | *M *P *X *O |
| 11  | CROSS STICK      | Cv Vintage X     | *X          |
| 12  | CROSS STICK      | Ld SP Vintage X  | *X          |
| 13  | CROSS STICK      | Cv AmbLess X     | *X          |
| 14  | CROSS STICK      | Ld SP AmbLess X  | *X          |
| 15  | TOM              | Cm Vintage T1    | *M          |
| 16  | TOM              | Cm Vintage T1R   | *M *P       |
| 17  | TOM              | Cm Vintage T2    | *M          |
| 18  | TOM              | Cm Vintage T2R   | *M *P       |
| 19  | TOM              | Cm Vintage T3    | *M          |
| 20  | TOM              | Cm Vintage T3R   | *M *P       |
| 21  | TOM              | Cm Vintage T4    | *M          |
| 22  | TOM              | Cm Vintage T4R   | *M *P       |
| 23  | TOM              | Cm AmbLess T1    | *M          |
| 24  | TOM              | Cm AmbLess T1R   | *M *P       |
| 25  | TOM              | Cm AmbLess T2    | *M          |
| 26  | TOM              | Cm AmbLess T2R   | *M *P       |
| 27  | TOM              | Cm AmbLess T3    | *M          |
| 28  | TOM              | Cm AmbLess T3R   | *M *P       |
| 29  | TOM              | Cm AmbLess T4    | *M          |
| 30  | TOM              | Cm AmbLess T4R   | *M *P       |

### EXV002: Electronic&Percussion 1

| No. | Instrument group | Instrument name  | Remarks |
|-----|------------------|------------------|---------|
| 1   | KICK OTHERS      | Boom Low Kick    |         |
| 2   | KICK OTHERS      | Knock & Low K    |         |
| 3   | KICK OTHERS      | Full & Low K     |         |
| 4   | KICK OTHERS      | TR 2021 K        |         |
| 5   | KICK OTHERS      | Hybrid 2021 K    |         |
| 6   | KICK OTHERS      | Wobbly Kick      |         |
| 7   | KICK OTHERS      | Impact Kick      |         |
| 8   | KICK OTHERS      | Hybrid Kick      |         |
| 9   | KICK OTHERS      | Tronic Kick      |         |
| 10  | KICK OTHERS      | Hip Hop Kick 1   |         |
| 11  | KICK OTHERS      | Hip Hop Kick 2   |         |
| 12  | KICK OTHERS      | Nu Hip Kick      |         |
| 13  | KICK OTHERS      | Minimal House K  |         |
| 14  | KICK OTHERS      | Early House Kick |         |
| 15  | KICK OTHERS      | House Kick       |         |
| 16  | KICK OTHERS      | BreakBeats Kick1 |         |
| 17  | KICK OTHERS      | BreakBeats Kick2 |         |
| 18  | KICK OTHERS      | DnB Kick 1       |         |
| 19  | KICK OTHERS      | DnB Kick 2       |         |
| 20  | KICK OTHERS      | DnB Kick 3       |         |
| 21  | KICK OTHERS      | DnB Kick 4       |         |
| 22  | KICK OTHERS      | Lo-Fi Kick       |         |
| 23  | KICK OTHERS      | Hi Jumper Kick   |         |
| 24  | KICK OTHERS      | Lo Jumper Kick   |         |
| 25  | KICK OTHERS      | Enhance Kick     |         |

| No. | Instrument group | Instrument name  | Remarks |
|-----|------------------|------------------|---------|
| 26  | KICK OTHERS      | Low Kick         |         |
| 27  | KICK OTHERS      | Jungle Kick      |         |
| 28  | KICK OTHERS      | Dance Kick       |         |
| 29  | KICK OTHERS      | Dancer Kick      |         |
| 30  | KICK OTHERS      | ScratchPhat Kick |         |
| 31  | KICK OTHERS      | Mellbourne Kick  |         |
| 32  | KICK OTHERS      | Big Step Kick    |         |
| 33  | KICK OTHERS      | Big Deep Kick    |         |
| 34  | KICK OTHERS      | Dirty Kick       |         |
| 35  | KICK OTHERS      | Low Stomper      |         |
| 36  | KICK OTHERS      | Buzz Kick        |         |
| 37  | KICK OTHERS      | TR Beef Kick     |         |
| 38  | KICK OTHERS      | Electro Knock K  |         |
| 39  | KICK OTHERS      | RetroFuture Kick |         |
| 40  | KICK OTHERS      | Hard Style Kick1 |         |
| 41  | KICK OTHERS      | Hard Style Kick2 |         |
| 42  | KICK OTHERS      | HardAttack Kick1 |         |
| 43  | KICK OTHERS      | HardAttack Kick2 |         |
| 44  | KICK OTHERS      | HardAttack Kick3 |         |
| 45  | KICK OTHERS      | HardAttack Kick4 |         |
| 46  | KICK OTHERS      | HardAttack Kick5 |         |
| 47  | KICK OTHERS      | HardAttack Kick6 |         |
| 48  | KICK OTHERS      | HardAttack Kick7 |         |
| 49  | KICK OTHERS      | HardAttack Kick8 |         |
| 50  | KICK OTHERS      | HardAttack Kick9 |         |
| 51  | KICK OTHERS      | ClubMusic Kick 1 |         |
| 52  | KICK OTHERS      | ClubMusic Kick 2 |         |
| 53  | KICK OTHERS      | ClubMusic Kick 3 |         |
| 54  | KICK OTHERS      | ClubMusic Kick 4 |         |
| 55  | KICK OTHERS      | ClubMusic Kick 5 |         |
| 56  | KICK OTHERS      | ClubMusic Kick 6 |         |
| 57  | KICK OTHERS      | ClubMusic Kick 7 |         |
| 58  | KICK OTHERS      | ClubMusic Kick 8 |         |
| 59  | KICK OTHERS      | ClubMusic Kick 9 |         |
| 60  | KICK OTHERS      | ClubMusic Kick10 |         |
| 61  | KICK OTHERS      | ClubMusic Kick11 |         |
| 62  | KICK OTHERS      | ClubMusic Kick12 |         |
| 63  | KICK OTHERS      | ClubMusic Kick13 |         |
| 64  | KICK OTHERS      | ClubMusic Kick14 |         |
| 65  | KICK OTHERS      | ClubMusic Kick15 |         |
| 66  | KICK OTHERS      | ClubMusic Kick16 |         |
| 67  | KICK OTHERS      | ClubMusic Kick17 |         |
| 68  | KICK OTHERS      | ClubMusic Kick18 |         |
| 69  | KICK OTHERS      | ClubMusic Kick19 |         |
| 70  | KICK OTHERS      | ClubMusic Kick20 |         |
| 71  | KICK OTHERS      | ClubMusic Kick21 |         |
| 72  | KICK OTHERS      | ClubMusic Kick22 |         |
| 73  | KICK OTHERS      | ClubMusic Kick23 |         |
| 74  | KICK OTHERS      | ClubMusic Kick24 |         |
| 75  | KICK OTHERS      | ClubMusic Kick25 |         |
| 76  | KICK OTHERS      | ClubMusic Kick26 |         |
| 77  | KICK OTHERS      | ClubMusic Kick27 |         |
| 78  | KICK OTHERS      | Voice Kick 1     |         |
| 79  | KICK OTHERS      | Voice Kick 2     |         |
| 80  | KICK OTHERS      | Voice Kick 3     |         |
| 81  | KICK OTHERS      | Voice Kick 4     |         |
| 82  | KICK OTHERS      | Processed Kick 1 |         |
| 83  | KICK OTHERS      | Processed Kick 2 |         |
| 84  | KICK OTHERS      | Processed Kick 3 |         |
| 85  | KICK OTHERS      | Processed Kick 4 |         |

| No. | Instrument group | Instrument name  | Remarks |
|-----|------------------|------------------|---------|
| 86  | KICK OTHERS      | Processed Kick 5 |         |
| 87  | KICK OTHERS      | Processed Kick 6 |         |
| 88  | KICK OTHERS      | Processed Kick 7 |         |
| 89  | KICK OTHERS      | Processed Kick 8 |         |
| 90  | KICK ELEC        | Analog Kick 1    |         |
| 91  | KICK ELEC        | Analog Kick 2    |         |
| 92  | KICK ELEC        | Analog Kick 3    |         |
| 93  | KICK ELEC        | Analog Kick 4    |         |
| 94  | KICK ELEC        | Analog Kick 5    |         |
| 95  | KICK ELEC        | Analog Kick 6    |         |
| 96  | KICK ELEC        | CR-78 Kick       |         |
| 97  | KICK ELEC        | TR-808 Kick 1    |         |
| 98  | KICK ELEC        | TR-808 Kick 2    |         |
| 99  | KICK ELEC        | TR-808 Kick Long |         |
| 100 | KICK ELEC        | TR-808 Atk Kick  |         |
| 101 | KICK ELEC        | TR-808 Soft Kick |         |
| 102 | KICK ELEC        | TR-808 Hard Kick |         |
| 103 | KICK ELEC        | TR-909 Kick 1    |         |
| 104 | KICK ELEC        | TR-909 Kick 2    |         |
| 105 | KICK ELEC        | TR-909 Kick 3    |         |
| 106 | KICK ELEC        | TR-909 Kick 4    |         |
| 107 | KICK ELEC        | TR-909 Hard Kick |         |
| 108 | KICK ELEC        | TR-909 Dist Kick |         |
| 109 | KICK ELEC        | TR-909 Low Kick  |         |
| 110 | KICK ELEC        | TR-606 Kick      |         |
| 111 | KICK ELEC        | TR-707 Kick      |         |
| 112 | KICK ELEC        | TR-626 Kick      |         |
| 113 | KICK ELEC        | DR-110 Kick      |         |
| 114 | KICK ELEC        | R-8 Kick         |         |
| 115 | KICK ELEC        | Synth Kick       |         |
| 116 | KICK ELEC        | TR-Synth Kick 1  |         |
| 117 | KICK ELEC        | TR-Synth Kick 2  |         |
| 118 | KICK ELEC        | TR-Synth Kick 3  |         |
| 119 | KICK ELEC        | Hi-Q Kick        |         |
| 120 | KICK ELEC        | Attack Bass Kick |         |
| 121 | SNARE OTHERS     | Concert 1 S      |         |
| 122 | SNARE OTHERS     | Concert 1 SR     | *P      |
| 123 | SNARE OTHERS     | Concert 1 X      |         |
| 124 | SNARE OTHERS     | Concert 2 S      |         |
| 125 | SNARE OTHERS     | Proc Tight 1 S   |         |
| 126 | SNARE OTHERS     | Proc Tight 1 SR  |         |
| 127 | SNARE OTHERS     | Proc Tight 2 S   |         |
| 128 | SNARE OTHERS     | Proc Tight 2 SR  |         |
| 129 | SNARE OTHERS     | Layering S       |         |
| 130 | SNARE OTHERS     | Layering SR      |         |
| 131 | SNARE OTHERS     | Fat & Low S      |         |
| 132 | SNARE OTHERS     | Fat & Low SR     |         |
| 133 | SNARE OTHERS     | LA Fat Snare     |         |
| 134 | SNARE OTHERS     | House Low Snare  |         |
| 135 | SNARE OTHERS     | Garage Snare     |         |
| 136 | SNARE OTHERS     | Hip Hop Snare 1  |         |
| 137 | SNARE OTHERS     | Hip Hop Snare 2  |         |
| 138 | SNARE OTHERS     | Radio Snare      |         |
| 139 | SNARE OTHERS     | DnB Snare 1      |         |
| 140 | SNARE OTHERS     | DnB Snare 2      |         |
| 141 | SNARE OTHERS     | DnB Snare 3      |         |
| 142 | SNARE OTHERS     | Dub Step Snare 1 |         |
| 143 | SNARE OTHERS     | Dub Step Snare 2 |         |
| 144 | SNARE OTHERS     | Fat Snare        |         |
| 145 | SNARE OTHERS     | Fat Box Snare    |         |

| No. | Instrument group | Instrument name  | Remarks |
|-----|------------------|------------------|---------|
| 146 | SNARE OTHERS     | Gate Snare       |         |
| 147 | SNARE OTHERS     | 106 Snare        |         |
| 148 | SNARE OTHERS     | Tight-o-Gate S   |         |
| 149 | SNARE OTHERS     | DnBark Snare     |         |
| 150 | SNARE OTHERS     | Clap Slap Snare  |         |
| 151 | SNARE OTHERS     | Slap Snare       |         |
| 152 | SNARE OTHERS     | Slapper Snare    |         |
| 153 | SNARE OTHERS     | Clapper Snare    |         |
| 154 | SNARE OTHERS     | Low&Mid Shaper S |         |
| 155 | SNARE OTHERS     | Old School Snare |         |
| 156 | SNARE OTHERS     | ShortFbk Snare 1 |         |
| 157 | SNARE OTHERS     | ShortFbk Snare 2 |         |
| 158 | SNARE OTHERS     | Laser Snare      |         |
| 159 | SNARE OTHERS     | Echo Snare 1     |         |
| 160 | SNARE OTHERS     | Echo Snare 2     |         |
| 161 | SNARE OTHERS     | OD Break Snare   |         |
| 162 | SNARE OTHERS     | OD Jungle Snare  |         |
| 163 | SNARE OTHERS     | Stereofyer Snare |         |
| 164 | SNARE OTHERS     | R-Bright Snare   |         |
| 165 | SNARE OTHERS     | Rimflexion S     |         |
| 166 | SNARE OTHERS     | Soprano Ring S   |         |
| 167 | SNARE OTHERS     | LoFi FX Snare    |         |
| 168 | SNARE OTHERS     | ClubMusic Snr 1  |         |
| 169 | SNARE OTHERS     | ClubMusic Snr 2  |         |
| 170 | SNARE OTHERS     | ClubMusic Snr 3  |         |
| 171 | SNARE OTHERS     | ClubMusic Snr 4  |         |
| 172 | SNARE OTHERS     | ClubMusic Snr 5  |         |
| 173 | SNARE OTHERS     | ClubMusic Snr 6  |         |
| 174 | SNARE OTHERS     | ClubMusic Snr 7  |         |
| 175 | SNARE OTHERS     | ClubMusic Snr 8  |         |
| 176 | SNARE OTHERS     | ClubMusic Snr 9  |         |
| 177 | SNARE OTHERS     | ClubMusic Snr 10 |         |
| 178 | SNARE OTHERS     | ClubMusic Snr 11 |         |
| 179 | SNARE OTHERS     | ClubMusic Snr 12 |         |
| 180 | SNARE OTHERS     | ClubMusic Snr 13 |         |
| 181 | SNARE OTHERS     | ClubMusic Snr 14 |         |
| 182 | SNARE OTHERS     | ClubMusic Snr 15 |         |
| 183 | SNARE OTHERS     | ClubMusic Snr 16 |         |
| 184 | SNARE OTHERS     | ClubMusic Snr 17 |         |
| 185 | SNARE OTHERS     | ClubMusic Snr 18 |         |
| 186 | SNARE OTHERS     | ClubMusic Snr 19 |         |
| 187 | SNARE OTHERS     | ClubMusic Snr 20 |         |
| 188 | SNARE OTHERS     | ClubMusic Snr 21 |         |
| 189 | SNARE OTHERS     | ClubMusic Snr 22 |         |
| 190 | SNARE OTHERS     | ClubMusic Snr 23 |         |
| 191 | SNARE OTHERS     | ClubMusic Snr 24 |         |
| 192 | SNARE OTHERS     | ClubMusic Snr 25 |         |
| 193 | SNARE OTHERS     | ClubMusic Snr 26 |         |
| 194 | SNARE OTHERS     | ClubMusic Snr 27 |         |
| 195 | SNARE OTHERS     | ClubMusic Snr 28 |         |
| 196 | SNARE OTHERS     | ClubMusic Snr 29 |         |
| 197 | SNARE OTHERS     | Voice Snare 1    |         |
| 198 | SNARE OTHERS     | Voice Snare 2    |         |
| 199 | SNARE OTHERS     | Voice Snare 3    |         |
| 200 | SNARE OTHERS     | Voice Snare 4    |         |
| 201 | SNARE OTHERS     | Voice Snare 5    |         |
| 202 | SNARE OTHERS     | Voice Snare 6    |         |
| 203 | SNARE OTHERS     | Voice Snare 7    |         |
| 204 | SNARE OTHERS     | Voice Snare 8    |         |
| 205 | SNARE OTHERS     | Electro Snare    |         |

| No. | Instrument group | Instrument name  | Remarks |
|-----|------------------|------------------|---------|
| 206 | SNARE OTHERS     | Thick Clap Snare |         |
| 207 | SNARE OTHERS     | Timbale Snare    |         |
| 208 | SNARE OTHERS     | Plugged X 1      |         |
| 209 | SNARE OTHERS     | Plugged X 2      |         |
| 210 | SNARE OTHERS     | Plugged X 3      |         |
| 211 | SNARE OTHERS     | Tight Buzz X     |         |
| 212 | SNARE OTHERS     | Voice X 1        |         |
| 213 | SNARE OTHERS     | Voice X 2        |         |
| 214 | SNARE OTHERS     | Gate Reverb X    |         |
| 215 | SNARE ELEC       | Analog Snare 1   |         |
| 216 | SNARE ELEC       | Analog Snare 2   |         |
| 217 | SNARE ELEC       | Classic Fat S    |         |
| 218 | SNARE ELEC       | Classic Fat SR   |         |
| 219 | SNARE ELEC       | CR-78 Snare      |         |
| 220 | SNARE ELEC       | TR-808 Snare 1   |         |
| 221 | SNARE ELEC       | TR-808 Snare 2   |         |
| 222 | SNARE ELEC       | TR-808 Power S   |         |
| 223 | SNARE ELEC       | TR-808 Power SR  |         |
| 224 | SNARE ELEC       | TR-808 Fat 1 S   |         |
| 225 | SNARE ELEC       | TR-808 Fat 1 SR  |         |
| 226 | SNARE ELEC       | TR-808 Fat 2 S   |         |
| 227 | SNARE ELEC       | TR-808 Fat 2 SR  |         |
| 228 | SNARE ELEC       | TR-808 Fat 3 S   |         |
| 229 | SNARE ELEC       | TR-808 Fat 3 SR  |         |
| 230 | SNARE ELEC       | TR-909 Snare 1   |         |
| 231 | SNARE ELEC       | TR-909 Snare 2   |         |
| 232 | SNARE ELEC       | TR-909 S w/ Clap |         |
| 233 | SNARE ELEC       | TR-909 Power S   |         |
| 234 | SNARE ELEC       | TR-909 Power SR  |         |
| 235 | SNARE ELEC       | TR-909 DS Snare  |         |
| 236 | SNARE ELEC       | TR-606 Snare 1   |         |
| 237 | SNARE ELEC       | TR-606 Snare 2   |         |
| 238 | SNARE ELEC       | TR-707 Snare     |         |
| 239 | SNARE ELEC       | TR-707 EFX Snare |         |
| 240 | SNARE ELEC       | TR-626 Snare     |         |
| 241 | SNARE ELEC       | TR-626 EFX Snare |         |
| 242 | SNARE ELEC       | DR-110 Snare     |         |
| 243 | SNARE ELEC       | Synth S          |         |
| 244 | SNARE ELEC       | Synth SR         |         |
| 245 | SNARE ELEC       | CR-78 Rim        |         |
| 246 | SNARE ELEC       | TR-808 Rim       |         |
| 247 | SNARE ELEC       | TR-909 Rim 1     |         |
| 248 | SNARE ELEC       | TR-909 Rim 2     |         |
| 249 | SNARE ELEC       | TR-707 Rim       |         |
| 250 | SNARE ELEC       | TR-626 Rim       |         |
| 251 | TOM OTHERS       | Voice Tom 1      |         |
| 252 | TOM OTHERS       | Voice Tom 2      |         |
| 253 | TOM OTHERS       | Voice Tom 3      |         |
| 254 | TOM ELEC         | Analog Tom 1 T1  |         |
| 255 | TOM ELEC         | Analog Tom 1 T2  |         |
| 256 | TOM ELEC         | Analog Tom 1 T3  |         |
| 257 | TOM ELEC         | Analog Tom 1 T4  |         |
| 258 | TOM ELEC         | Analog Tom 2 T1  |         |
| 259 | TOM ELEC         | Analog Tom 2 T2  |         |
| 260 | TOM ELEC         | Analog Tom 2 T3  |         |
| 261 | TOM ELEC         | Analog Tom 2 T4  |         |
| 262 | TOM ELEC         | Analog Tom 3 T1  |         |
| 263 | TOM ELEC         | Analog Tom 3 T2  |         |
| 264 | TOM ELEC         | Analog Tom 3 T3  |         |
| 265 | TOM ELEC         | Analog Tom 3 T4  |         |

| No. | Instrument group  | Instrument name | Remarks |
|-----|-------------------|-----------------|---------|
| 266 | TOM ELEC          | Analog Tom 4 T1 |         |
| 267 | TOM ELEC          | Analog Tom 4 T2 |         |
| 268 | TOM ELEC          | Analog Tom 4 T3 |         |
| 269 | TOM ELEC          | Analog Tom 4 T4 |         |
| 270 | TOM ELEC          | Analog Tom 5 T1 |         |
| 271 | TOM ELEC          | Analog Tom 5 T2 |         |
| 272 | TOM ELEC          | Analog Tom 5 T3 |         |
| 273 | TOM ELEC          | Analog Tom 5 T4 |         |
| 274 | TOM ELEC          | Analog Tom 6 T1 |         |
| 275 | TOM ELEC          | Analog Tom 6 T2 |         |
| 276 | TOM ELEC          | Analog Tom 6 T3 |         |
| 277 | TOM ELEC          | TR-808 Tom T1   |         |
| 278 | TOM ELEC          | TR-808 Tom T2   |         |
| 279 | TOM ELEC          | TR-808 Tom T3   |         |
| 280 | TOM ELEC          | TR-808 Tom T4   |         |
| 281 | TOM ELEC          | TR-909 Tom 1 T1 |         |
| 282 | TOM ELEC          | TR-909 Tom 1 T2 |         |
| 283 | TOM ELEC          | TR-909 Tom 1 T3 |         |
| 284 | TOM ELEC          | TR-909 Tom 1 T4 |         |
| 285 | TOM ELEC          | TR-909 Tom 2 T1 |         |
| 286 | TOM ELEC          | TR-909 Tom 2 T2 |         |
| 287 | TOM ELEC          | TR-909 Tom 2 T3 |         |
| 288 | TOM ELEC          | TR-606 Tom T1   |         |
| 289 | TOM ELEC          | TR-606 Tom T2   |         |
| 290 | TOM ELEC          | TR-707 Tom T1   |         |
| 291 | TOM ELEC          | TR-707 Tom T2   |         |
| 292 | TOM ELEC          | TR-707 Tom T3   |         |
| 293 | TOM ELEC          | TR-626 Tom T1   |         |
| 294 | TOM ELEC          | TR-626 Tom T2   |         |
| 295 | TOM ELEC          | TR-626 Tom T3   |         |
| 296 | HI-HAT OTHERS     | Club Hi-Hat     |         |
| 297 | HI-HAT OTHERS     | Sharp Hi-Hat    |         |
| 298 | HI-HAT OTHERS     | Hip Hi-Hat      |         |
| 299 | HI-HAT OTHERS     | House Hi-Hat    |         |
| 300 | HI-HAT OTHERS     | DnB Hi-Hat      |         |
| 301 | HI-HAT OTHERS     | Low Step Hi-Hat |         |
| 302 | HI-HAT OTHERS     | Voice Hi-Hat 1  |         |
| 303 | HI-HAT OTHERS     | Voice Hi-Hat 2  |         |
| 304 | HI-HAT OTHERS     | Voice Hi-Hat 3  |         |
| 305 | HI-HAT OTHERS     | Spoke Hi-Hat    |         |
| 306 | HI-HAT OTHERS     | Jingle Hi-Hat   |         |
| 307 | HI-HAT ELEC       | CR-78 Hi-Hat    |         |
| 308 | HI-HAT ELEC       | CR-78 Metal HH  |         |
| 309 | HI-HAT ELEC       | TR-808 Hi-Hat   |         |
| 310 | HI-HAT ELEC       | TR-909 Hi-Hat   |         |
| 311 | HI-HAT FIXED ELEC | TR-808 HH Close |         |
| 312 | HI-HAT FIXED ELEC | TR-808 HH Open  |         |
| 313 | HI-HAT FIXED ELEC | TR-909 HH Close |         |
| 314 | HI-HAT FIXED ELEC | TR-909 HH Open  |         |
| 315 | HI-HAT FIXED ELEC | TR-606 HH Close |         |
| 316 | HI-HAT FIXED ELEC | TR-606 HH Open  |         |
| 317 | HI-HAT FIXED ELEC | TR-707 HH Close |         |
| 318 | HI-HAT FIXED ELEC | TR-707 HH Open  |         |
| 319 | HI-HAT FIXED ELEC | TR-626 HH Close |         |
| 320 | HI-HAT FIXED ELEC | TR-626 HH Open  |         |
| 321 | CYMBAL OTHERS     | Concert Cymbal  |         |
| 322 | CYMBAL OTHERS     | Sweep Crash     |         |
| 323 | CYMBAL OTHERS     | Lo-Fi Crash     |         |
| 324 | CYMBAL OTHERS     | Ambient Crash   |         |
| 325 | CYMBAL OTHERS     | Verby Crash     |         |

| No. | Instrument group | Instrument name  | Remarks |
|-----|------------------|------------------|---------|
| 326 | CYMBAL OTHERS    | Phasing Crash    |         |
| 327 | CYMBAL OTHERS    | Voice Crash      |         |
| 328 | CYMBAL OTHERS    | Trashy Ride      |         |
| 329 | CYMBAL OTHERS    | Phasing Ride     |         |
| 330 | CYMBAL OTHERS    | DnB Ride         |         |
| 331 | CYMBAL OTHERS    | Mainly Bell Ride |         |
| 332 | CYMBAL OTHERS    | Cosmo Bell       |         |
| 333 | CYMBAL OTHERS    | Electra Bell     |         |
| 334 | CYMBAL OTHERS    | Reflective Bell  |         |
| 335 | CYMBAL OTHERS    | Reverse Crash 1  |         |
| 336 | CYMBAL OTHERS    | Reverse Crash 2  |         |
| 337 | CYMBAL OTHERS    | Reverse China 1  |         |
| 338 | CYMBAL OTHERS    | Reverse China 2  |         |
| 339 | CYMBAL OTHERS    | Fat Box CloseHH  |         |
| 340 | CYMBAL OTHERS    | HipHop CloseHH 1 |         |
| 341 | CYMBAL OTHERS    | HipHop CloseHH 2 |         |
| 342 | CYMBAL OTHERS    | Voice Cymbal 1   |         |
| 343 | CYMBAL OTHERS    | Voice Cymbal 2   |         |
| 344 | CYMBAL OTHERS    | Voice Cymbal 3   |         |
| 345 | CYMBAL OTHERS    | Voice Cymbal 4   |         |
| 346 | CYMBAL ELEC      | Analog Cymbal    |         |
| 347 | CYMBAL ELEC      | CR-78 Cymbal     |         |
| 348 | CYMBAL ELEC      | TR-808 Cymbal 1  |         |
| 349 | CYMBAL ELEC      | TR-808 Cymbal 2  |         |
| 350 | CYMBAL ELEC      | TR-909 Crash 1   |         |
| 351 | CYMBAL ELEC      | TR-909 Crash 2   |         |
| 352 | CYMBAL ELEC      | TR-909 Ride      |         |
| 353 | CYMBAL ELEC      | TR-606 Cymbal 1  |         |
| 354 | CYMBAL ELEC      | TR-606 Cymbal 2  |         |
| 355 | CYMBAL ELEC      | TR-707 Crash     |         |
| 356 | CYMBAL ELEC      | TR-707 Ride      |         |
| 357 | CYMBAL ELEC      | TR-626 Crash     |         |
| 358 | CYMBAL ELEC      | TR-626 Ride      |         |
| 359 | CYMBAL ELEC      | TR-626 China     |         |
| 360 | BELL/CHIME/GONG  | Finger Cymbals 1 |         |
| 361 | BELL/CHIME/GONG  | Finger Cymbals 2 |         |
| 362 | BELL/CHIME/GONG  | Finger Cymbals 3 |         |
| 363 | BELL/CHIME/GONG  | Sleigh Bells 1   |         |
| 364 | BELL/CHIME/GONG  | Sleigh Bells 2   |         |
| 365 | BELL/CHIME/GONG  | TreeChime 1 Down |         |
| 366 | BELL/CHIME/GONG  | TreeChime 1 Up   |         |
| 367 | BELL/CHIME/GONG  | Tree Chime 2 Up  |         |
| 368 | BELL/CHIME/GONG  | Bell Tree        |         |
| 369 | BELL/CHIME/GONG  | Pin Chime        |         |
| 370 | BELL/CHIME/GONG  | Tam Tam          |         |
| 371 | BELL/CHIME/GONG  | Gong             |         |
| 372 | BELL/CHIME/GONG  | Bender Gong      |         |
| 373 | BLOCK/COWBELL    | Cowbell Rock Tip |         |
| 374 | BLOCK/COWBELL    | Cowbell Rock     |         |
| 375 | BLOCK/COWBELL    | Cowbell Afro Tip |         |
| 376 | BLOCK/COWBELL    | Cowbell Afro     |         |
| 377 | BLOCK/COWBELL    | Cowbell Mini Tip |         |
| 378 | BLOCK/COWBELL    | Cowbell Mini     |         |
| 379 | BLOCK/COWBELL    | Agogo Hi         |         |
| 380 | BLOCK/COWBELL    | Agogo Lo         |         |
| 381 | BLOCK/COWBELL    | Mounted Agogo Hi |         |
| 382 | BLOCK/COWBELL    | Mounted Agogo Lo |         |
| 383 | BLOCK/COWBELL    | Plastic Block Hi |         |
| 384 | BLOCK/COWBELL    | Plastic Block Lo |         |
| 385 | BLOCK/COWBELL    | Mini Block       |         |

| No. | Instrument group | Instrument name  | Remarks |
|-----|------------------|------------------|---------|
| 386 | BLOCK/COWBELL    | Temple Block Hi  |         |
| 387 | BLOCK/COWBELL    | Temple Block Lo  |         |
| 388 | PERCUSSION       | Bongo 1 Hi Open  |         |
| 389 | PERCUSSION       | Bongo 1 Hi Slap  | *P      |
| 390 | PERCUSSION       | Bongo 1 Low Open |         |
| 391 | PERCUSSION       | Bongo 1 Low Slap | *P      |
| 392 | PERCUSSION       | Bongo 2 Hi Open  |         |
| 393 | PERCUSSION       | Bongo 2 Hi Slap  |         |
| 394 | PERCUSSION       | Bongo 2 Lo Open  |         |
| 395 | PERCUSSION       | Bongo 2 Lo Slap  |         |
| 396 | PERCUSSION       | Quinto 1 Open    |         |
| 397 | PERCUSSION       | Quinto 1 Slap    |         |
| 398 | PERCUSSION       | Quinto 2 Open    |         |
| 399 | PERCUSSION       | Quinto 2 Slap    | *P      |
| 400 | PERCUSSION       | Conga 1 Open     |         |
| 401 | PERCUSSION       | Conga 1 Slap     |         |
| 402 | PERCUSSION       | Conga 2 Open     |         |
| 403 | PERCUSSION       | Conga 2 Slap     |         |
| 404 | PERCUSSION       | Conga 2 Bass     |         |
| 405 | PERCUSSION       | Conga 2 Gliss    |         |
| 406 | PERCUSSION       | Tumba Open       |         |
| 407 | PERCUSSION       | Tumba Slap       |         |
| 408 | PERCUSSION       | Tumba Bass       |         |
| 409 | PERCUSSION       | Tumba Gliss      |         |
| 410 | PERCUSSION       | Timbale1 Hi Open |         |
| 411 | PERCUSSION       | Timbale1 Hi Rim  | *P      |
| 412 | PERCUSSION       | Timbale1 Lo Open |         |
| 413 | PERCUSSION       | Timbale1 Lo Rim  | *P      |
| 414 | PERCUSSION       | Timbale2 Hi Open |         |
| 415 | PERCUSSION       | Timbale2 Hi Rim  | *P      |
| 416 | PERCUSSION       | Timbale2 Lo Open |         |
| 417 | PERCUSSION       | Timbale2 Lo Rim  | *P      |
| 418 | PERCUSSION       | Timbale3 Hi Open |         |
| 419 | PERCUSSION       | Timbale3 Hi Rim  |         |
| 420 | PERCUSSION       | Timbale3 HiPaila |         |
| 421 | PERCUSSION       | Timbale3 Lo Open |         |
| 422 | PERCUSSION       | Timbale3 Lo Rim  |         |
| 423 | PERCUSSION       | Timbale3 LoPaila |         |
| 424 | PERCUSSION       | Cajon Open       |         |
| 425 | PERCUSSION       | Cajon Edge       |         |
| 426 | PERCUSSION       | Cajon Slap       |         |
| 427 | PERCUSSION       | Cajon Bass       |         |
| 428 | PERCUSSION       | Djembe 1 Open    |         |
| 429 | PERCUSSION       | Djembe 1 Slap    |         |
| 430 | PERCUSSION       | Djembe 2 Open    |         |
| 431 | PERCUSSION       | Djembe 2 Slap    |         |
| 432 | PERCUSSION       | Djembe 2 Bass    |         |
| 433 | PERCUSSION       | Djembe 2 Ears    |         |
| 434 | PERCUSSION       | Tabla Na         |         |
| 435 | PERCUSSION       | Tabla Te         |         |
| 436 | PERCUSSION       | Tabla Tin        |         |
| 437 | PERCUSSION       | Tabla Tun        |         |
| 438 | PERCUSSION       | Baya Ge          |         |
| 439 | PERCUSSION       | Baya Ge Slide    |         |
| 440 | PERCUSSION       | Baya Gin         |         |
| 441 | PERCUSSION       | Baya Ka          |         |
| 442 | PERCUSSION       | Jang Gu          |         |
| 443 | PERCUSSION       | Darbuka 1 Open   |         |
| 444 | PERCUSSION       | Darbuka 1 Slap   | *P      |
| 445 | PERCUSSION       | Darbuka 2 Open   |         |

| No. | Instrument group | Instrument name  | Remarks |
|-----|------------------|------------------|---------|
| 446 | PERCUSSION       | Darbuka 2 Slap   |         |
| 447 | PERCUSSION       | Darbuka 2 Bass   |         |
| 448 | PERCUSSION       | Timpani G2       |         |
| 449 | PERCUSSION       | Timpani D3       |         |
| 450 | PERCUSSION       | Concert BD       |         |
| 451 | PERCUSSION       | Concert BD Mt    |         |
| 452 | PERCUSSION       | Doumdoumba       |         |
| 453 | PERCUSSION       | Doumdoumba Rim   |         |
| 454 | PERCUSSION       | Bombo            |         |
| 455 | PERCUSSION       | Bendir           |         |
| 456 | PERCUSSION       | Riq Open         |         |
| 457 | PERCUSSION       | Riq Slap         |         |
| 458 | PERCUSSION       | Tambourine 1     |         |
| 459 | PERCUSSION       | Tambourine 2     |         |
| 460 | PERCUSSION       | Tambourine 3     |         |
| 461 | PERCUSSION       | Tambourine 4     |         |
| 462 | PERCUSSION       | Tambourine 5     |         |
| 463 | PERCUSSION       | Tambourine 6     |         |
| 464 | PERCUSSION       | Triangle 1       |         |
| 465 | PERCUSSION       | Triangle 1 Mute  |         |
| 466 | PERCUSSION       | Triangle 2       |         |
| 467 | PERCUSSION       | Triangle 2 Mute  |         |
| 468 | PERCUSSION       | Castanets        |         |
| 469 | PERCUSSION       | Clapsticks       |         |
| 470 | PERCUSSION       | Claves           |         |
| 471 | PERCUSSION       | Afro Claves      |         |
| 472 | PERCUSSION       | Guiro 1 Slide    |         |
| 473 | PERCUSSION       | Guiro 1 Shot     |         |
| 474 | PERCUSSION       | Guiro 2 Slide    |         |
| 475 | PERCUSSION       | Guiro 2 Shot     |         |
| 476 | PERCUSSION       | Maracas Down     |         |
| 477 | PERCUSSION       | Maracas Up       |         |
| 478 | PERCUSSION       | Caxixi           |         |
| 479 | PERCUSSION       | Large Caxixi     |         |
| 480 | PERCUSSION       | Ganza            |         |
| 481 | PERCUSSION       | Chafchas         |         |
| 482 | PERCUSSION       | Afuche           |         |
| 483 | PERCUSSION       | Pot Drum 1 Hole  |         |
| 484 | PERCUSSION       | PotDrum 1 Bottom |         |
| 485 | PERCUSSION       | Pot Drum 1 Neck  |         |
| 486 | PERCUSSION       | Pot Drum 2 Side  |         |
| 487 | PERCUSSION       | Pot Drum 2 Bass  |         |
| 488 | PERCUSSION       | PotDrum2 Release |         |
| 489 | PERCUSSION       | PotDrum2 Side/Mt |         |
| 490 | PERCUSSION       | African Bracelet |         |
| 491 | PERCUSSION       | African Jingle   |         |
| 492 | PERCUSSION       | Ankle Beads      |         |
| 493 | PERCUSSION       | Rain Stick       |         |
| 494 | PERCUSSION       | Vibra-Slap       |         |
| 495 | PERCUSSION       | Ratchet          |         |
| 496 | PERCUSSION       | Flexatone Down   |         |
| 497 | PERCUSSION       | Flexatone Up     |         |
| 498 | PERCUSSION       | Steelpan D4      |         |
| 499 | PERCUSSION       | Steelpan G4      |         |
| 500 | PERCUSSION       | Steelpan B4      |         |
| 501 | PERCUSSION       | Steelpan D5      |         |
| 502 | PERCUSSION       | Steelpan G5      |         |
| 503 | PERCUSSION       | Surdo Ens1 Open  |         |
| 504 | PERCUSSION       | Surdo Ens1 Mute  |         |
| 505 | PERCUSSION       | Surdo Ens1 Rim   |         |

| No. | Instrument group | Instrument name  | Remarks |
|-----|------------------|------------------|---------|
| 506 | PERCUSSION       | Surdo Ens2 Open  |         |
| 507 | PERCUSSION       | Surdo Ens2 Mute  |         |
| 508 | PERCUSSION       | Surdo Ens2 Rim   |         |
| 509 | PERCUSSION       | Surdo Ens3 Open  |         |
| 510 | PERCUSSION       | Surdo Ens3 Mute  |         |
| 511 | PERCUSSION       | Surdo Ens3 Rim   |         |
| 512 | PERCUSSION       | Caixa Ens        |         |
| 513 | PERCUSSION       | Caixa Ens Rim    | *P      |
| 514 | PERCUSSION       | RepiniqueEns     |         |
| 515 | PERCUSSION       | RepiniqueEns Rim | *P      |
| 516 | PERCUSSION       | Chocalho Ens     |         |
| 517 | PERCUSSION       | Tamborim Ens     |         |
| 518 | PERCUSSION       | Surdo 1 Open     |         |
| 519 | PERCUSSION       | Surdo 1 Mute     |         |
| 520 | PERCUSSION       | Surdo 1 Rim      |         |
| 521 | PERCUSSION       | Surdo 2 Open     |         |
| 522 | PERCUSSION       | Surdo 2 Mute     |         |
| 523 | PERCUSSION       | Surdo 2 Rim      |         |
| 524 | PERCUSSION       | Surdo 3 Open     |         |
| 525 | PERCUSSION       | Surdo 3 Mute     |         |
| 526 | PERCUSSION       | Surdo 3 Rim      |         |
| 527 | PERCUSSION       | Caixa            |         |
| 528 | PERCUSSION       | Caixa Rim        | *P      |
| 529 | PERCUSSION       | Repinique        |         |
| 530 | PERCUSSION       | Repinique Rim    | *P      |
| 531 | PERCUSSION       | Tamborim         |         |
| 532 | PERCUSSION       | Chocalho         |         |
| 533 | PERCUSSION       | Pandeiro Open    |         |
| 534 | PERCUSSION       | Pandeiro Slap    |         |
| 535 | PERCUSSION       | Pandeiro Bass    |         |
| 536 | PERCUSSION       | Pandeiro Jingle  |         |
| 537 | PERC ELEC        | CR-78 Bongo      |         |
| 538 | PERC ELEC        | CR-78 Conga      |         |
| 539 | PERC ELEC        | CR-78 Cowbell    |         |
| 540 | PERC ELEC        | CR-78 Claves     |         |
| 541 | PERC ELEC        | CR-78 Guiro      |         |
| 542 | PERC ELEC        | CR-78 Maracas    |         |
| 543 | PERC ELEC        | CR-78 Tambourine |         |
| 544 | PERC ELEC        | CR-78 Metal Beat |         |
| 545 | PERC ELEC        | TR-808 Conga Hi  |         |
| 546 | PERC ELEC        | TR-808 Conga Mid |         |
| 547 | PERC ELEC        | TR-808 Conga Lo  |         |
| 548 | PERC ELEC        | TR-808 Cowbell 1 |         |
| 549 | PERC ELEC        | TR-808 Cowbell 2 |         |
| 550 | PERC ELEC        | TR-808 Claves    |         |
| 551 | PERC ELEC        | TR-808 Maracas   |         |
| 552 | PERC ELEC        | TR-707 Cowbell   |         |
| 553 | PERC ELEC        | TR-707 Tamb      |         |
| 554 | PERC ELEC        | TR-626 Conga Hi  |         |
| 555 | PERC ELEC        | TR-626 Conga Lo  |         |
| 556 | PERC ELEC        | TR-626 Conga Mt  |         |
| 557 | PERC ELEC        | TR-626 Cowbell   |         |
| 558 | PERC ELEC        | TR-626 Agogo Hi  |         |
| 559 | PERC ELEC        | TR-626 Agogo Lo  |         |
| 560 | PERC ELEC        | TR-626 Claves    |         |
| 561 | PERC ELEC        | TR-626 Shaker    |         |
| 562 | PERC ELEC        | TR-626 Tamb      |         |
| 563 | PERC ELEC        | TR-727 Bongo Hi  |         |
| 564 | PERC ELEC        | TR-727 Bongo Lo  |         |
| 565 | PERC ELEC        | TR-727 TimbaleHi |         |

| No. | Instrument group | Instrument name  | Remarks |
|-----|------------------|------------------|---------|
| 566 | PERC ELEC        | TR-727 TimbaleLo |         |
| 567 | PERC ELEC        | TR-727 Agogo     |         |
| 568 | PERC ELEC        | TR-727 Maracas   |         |
| 569 | PERC ELEC        | TR-727 Cabasa    |         |
| 570 | PERC ELEC        | TR-727 Whistle   |         |
| 571 | PERC ELEC        | TR-727 Quijada   |         |
| 572 | PERC ELEC        | DR-55 Claves     |         |
| 573 | CLAP             | Verb Claps       |         |
| 574 | CLAP             | House Clap       |         |
| 575 | CLAP             | High Claps       |         |
| 576 | CLAP             | ClubMusic Clap 1 |         |
| 577 | CLAP             | ClubMusic Clap 2 |         |
| 578 | CLAP             | ClubMusic Clap 3 |         |
| 579 | CLAP             | ClubMusic Clap 4 |         |
| 580 | CLAP             | ClubMusic Clap 5 |         |
| 581 | CLAP             | ClubMusic Clap 6 |         |
| 582 | CLAP             | ClubMusic Clap 7 |         |
| 583 | CLAP             | ClubMusic Clap 8 |         |
| 584 | CLAP             | ClubMusic Clap 9 |         |
| 585 | CLAP             | ClubMusic Clap10 |         |
| 586 | CLAP             | ClubMusic Clap11 |         |
| 587 | CLAP             | TR-808 Clap 1    |         |
| 588 | CLAP             | TR-808 Clap 2    |         |
| 589 | CLAP             | TR-808 Clap 3    |         |
| 590 | CLAP             | TR-808 Verb Clap |         |
| 591 | CLAP             | TR-909 Clap 1    |         |
| 592 | CLAP             | TR-909 Clap 2    |         |
| 593 | CLAP             | TR-909 EFX Clap1 |         |
| 594 | CLAP             | TR-909 EFX Clap2 |         |
| 595 | CLAP             | TR-707 Clap      |         |
| 596 | CLAP             | TR-626 Clap      |         |
| 597 | CLAP             | R-8 Clap         |         |
| 598 | CLAP             | DR-110 Clap      |         |
| 599 | CLAP             | MC Clap          |         |
| 600 | CLAP             | Noise Clap 1     |         |
| 601 | CLAP             | Noise Clap 2     |         |
| 602 | CLAP             | White Nz Clap    |         |
| 603 | CLAP             | Dist Clap        |         |
| 604 | CLAP             | Hip Hop Clap 1   |         |
| 605 | CLAP             | Hip Hop Clap 2   |         |
| 606 | CLAP             | Fat EDM Clap 1   |         |
| 607 | CLAP             | Fat EDM Clap 2   |         |
| 608 | CLAP             | Metal Room Clap  |         |
| 609 | CLAP             | Big Hall Clap    |         |
| 610 | CLAP             | Afro Clap        |         |
| 611 | CLAP             | Laid Back Clap   |         |
| 612 | CLAP             | Stereo Gater     |         |
| 613 | CLAP             | Shaker Clap      |         |
| 614 | CLAP             | Gate S Clap      |         |
| 615 | CLAP             | Bongo Clap       |         |
| 616 | CLAP             | Dist Slap Snare  |         |
| 617 | CLAP             | Clap Tail Snare  |         |
| 618 | CLAP             | Ambient Snap     |         |
| 619 | CLAP             | Torio Clap       |         |
| 620 | CLAP             | Flamenco Clap    |         |
| 621 | CLAP             | Stereo Clap      |         |
| 622 | CLAP             | Hands Clap       |         |
| 623 | CLAP             | Claps            |         |
| 624 | CLAP             | Group Claps      |         |
| 625 | CLAP             | Ambience Clap 1  |         |

| No. | Instrument group | Instrument name  | Remarks |
|-----|------------------|------------------|---------|
| 626 | CLAP             | Ambience Clap 2  |         |
| 627 | CLAP             | Ambience Clap 3  |         |
| 628 | CLAP             | Room Clap        |         |
| 629 | CLAP             | Finger Snap      |         |
| 630 | CLAP             | Dry Snap         |         |
| 631 | SOUND FX         | Pulse            |         |
| 632 | SOUND FX         | Sticks           |         |
| 633 | SOUND FX         | Dense Click      |         |
| 634 | SOUND FX         | High Q           |         |
| 635 | SOUND FX         | Dyna Filter      |         |
| 636 | SOUND FX         | Random Noise 1   |         |
| 637 | SOUND FX         | Random Noise 2   |         |
| 638 | SOUND FX         | Beep             |         |
| 639 | SOUND FX         | Fat Beep         |         |
| 640 | SOUND FX         | Dist Beep        |         |
| 641 | SOUND FX         | Techno Beef      |         |
| 642 | SOUND FX         | Space Beep       |         |
| 643 | SOUND FX         | Voice Beep       |         |
| 644 | SOUND FX         | Super Low        |         |
| 645 | SOUND FX         | Sub Drop 1       |         |
| 646 | SOUND FX         | Sub Drop 2       |         |
| 647 | SOUND FX         | Sub Drop 3       |         |
| 648 | SOUND FX         | Low Boom         |         |
| 649 | SOUND FX         | Prevision        |         |
| 650 | SOUND FX         | Ejector          |         |
| 651 | SOUND FX         | Echoic Shot      |         |
| 652 | SOUND FX         | Super Shot       |         |
| 653 | SOUND FX         | R-8 Slap         |         |
| 654 | SOUND FX         | Rusty Iron       |         |
| 655 | SOUND FX         | Digi Cup         |         |
| 656 | SOUND FX         | Abstract Noise   |         |
| 657 | SOUND FX         | Industrial 1     |         |
| 658 | SOUND FX         | Industrial 2     |         |
| 659 | SOUND FX         | Junk             |         |
| 660 | SOUND FX         | Electro Bell     |         |
| 661 | SOUND FX         | Emergency        |         |
| 662 | SOUND FX         | Discovery        |         |
| 663 | SOUND FX         | Cave             |         |
| 664 | SOUND FX         | Stomped Box      |         |
| 665 | SOUND FX         | HH FX            |         |
| 666 | SOUND FX         | Sub Heart Beat   |         |
| 667 | SOUND FX         | Afro Stomp       |         |
| 668 | SOUND FX         | Dist Shaker      |         |
| 669 | SOUND FX         | Synth Drum 1     |         |
| 670 | SOUND FX         | Synth Drum 2     |         |
| 671 | SOUND FX         | Synth Drum 3     |         |
| 672 | SOUND FX         | Room Delay Clave |         |
| 673 | SOUND FX         | Air Horn         |         |
| 674 | SOUND FX         | Scratch 1        |         |
| 675 | SOUND FX         | Scratch 2        |         |
| 676 | SOUND FX         | Scratch 3        |         |
| 677 | SOUND FX         | Scratch 4        |         |
| 678 | SOUND FX         | Voice Scratch 1  |         |
| 679 | SOUND FX         | Voice Scratch 2  |         |
| 680 | SOUND FX         | Pink Noise Hit   |         |
| 681 | SOUND FX         | Gate T           |         |
| 682 | SOUND FX         | Hammer On        |         |
| 683 | SOUND FX         | FullDistortion   |         |
| 684 | SOUND FX         | Thrilling        |         |
| 685 | SOUND FX         | Electronica S    |         |

| No. | Instrument group | Instrument name | Remarks |
|-----|------------------|-----------------|---------|
| 686 | SOUND FX         | Gunshot         |         |
| 687 | SOUND FX         | Close Door FX   |         |
| 688 | SOUND FX         | Metal Ring      |         |
| 689 | SOUND FX         | Explosion       |         |
| 690 | SOUND FX         | Bomb!           |         |
| 691 | SOUND FX         | Brass Hit       |         |
| 692 | SOUND FX         | Waterdrop       |         |
| 693 | SOUND FX         | Noise 1         |         |
| 694 | SOUND FX         | Noise 2         |         |
| 695 | SOUND FX         | Noise 3         |         |
| 696 | SOUND FX         | Noise 4         |         |
| 697 | SOUND FX         | Noise 5         |         |
| 698 | SOUND FX         | Noise 6         |         |
| 699 | SOUND FX         | Noise 7         |         |
| 700 | SOUND FX         | Noise 8         |         |
| 701 | SOUND FX         | White Noise 1   |         |
| 702 | SOUND FX         | White Noise 2   |         |
| 703 | SOUND FX         | Sweep Noise     |         |
| 704 | SOUND FX         | Glitch Nz 1     |         |
| 705 | SOUND FX         | Glitch Nz 2     |         |
| 706 | SOUND FX         | Glitch Nz 3     |         |
| 707 | SOUND FX         | Elec Tom Drop 1 |         |
| 708 | SOUND FX         | Elec Tom Drop 2 |         |
| 709 | SOUND FX         | Synth Bass C 1  |         |
| 710 | SOUND FX         | Synth Bass C 2  |         |
| 711 | SOUND FX         | Super Saw C     |         |
| 712 | SOUND FX         | LP Noise        |         |

- \*M:** Supports the editing of “Mic Size” and “Mic Distance” for the instrument. (“Mic Size” only applies to kick drum sounds)
  - \*P:** Can get various changes of the sound in accordance with the positioning where on the pad you hit with a stick. In rim sounds, can get such various changes of the sound in accordance with the depth of the stick on the rim.
  - \*X:** When this is assigned to the rim of the snare, the corresponding cross stick sound is automatically assigned to XSTICK.
  - \*O:** Supports the editing of “Overtone” for the instrument.
  - \*B:** Brush playing is supported.
  - \*L:** Supports the editing of “Lo Cut” for the instrument.
- \* Support for methods of playing and strike position detection differs according to the trigger input. For details on how the trigger input corresponds to your performance technique and striking position, refer to “Trig Type list” (p. 60).

## EXV003: The Brush 1

| No. | Instrument group | Instrument name  | Remarks  |
|-----|------------------|------------------|----------|
| 1   | SNARE            | PI MapleBrush S  | *P *X *B |
| 2   | SNARE            | PI MapleBrush SR | *P *X *O |
| 3   | CROSS STICK      | PI MapleBrush X  | *X       |
| 4   | TOM              | So PL BrushT1    |          |
| 5   | TOM              | So PL BrushT1R   | *P       |
| 6   | TOM              | So PL BrushT2    |          |
| 7   | TOM              | So PL BrushT2R   | *P       |
| 8   | TOM              | So PL BrushT3    |          |
| 9   | TOM              | So PL BrushT3R   | *P       |
| 10  | TOM              | So PL BrushT4    |          |
| 11  | TOM              | So PL BrushT4R   | *P       |
| 12  | TOM              | So PL BrushT5    |          |
| 13  | TOM              | So PL BrushT5R   | *P       |
| 14  | HI-HAT           | Zd AC Brush HH   | *P       |
| 15  | HI-HAT           | Zd AC Brush HHE  | *P       |
| 16  | RIDE             | Zd AC Brush Rd   | *P *L    |
| 17  | RIDE             | Zd AC Brush RdE  | *P *L    |
| 18  | RIDE             | Zd AC Brush RdB  | *L       |
| 19  | CRASH            | Zd AC Brush1 Cr  | *L       |
| 20  | CRASH            | Zd AC Brush1 CrE | *L       |
| 21  | CRASH            | Zd AC Brush2 Cr  | *L       |
| 22  | CRASH            | Zd AC Brush2 CrE | *L       |


# Song list

001–009: Drum performance data

010–037: Audio data

| No. | Song name           |
|-----|---------------------|
| 001 | Drum Solo           |
| 002 | Sound Check 1       |
| 003 | Sound Check 2       |
| 004 | Sound Check 3       |
| 005 | Drum Phrase 16beat  |
| 006 | Drum Phrase Metal   |
| 007 | Drum Phrase Jazz    |
| 008 | Drum Phrase Funk    |
| 009 | Drum Phrase HipHop  |
| 010 | Rock 1 (AUDIO)      |
| 011 | Rock 2 (AUDIO)      |
| 012 | Rock 3 (AUDIO)      |
| 013 | Rock 4 (AUDIO)      |
| 014 | Jazz 1 (AUDIO)      |
| 015 | Jazz 2 (AUDIO)      |
| 016 | Jazz 3 (AUDIO)      |
| 017 | Jazz 4 (AUDIO)      |
| 018 | Jazz 5 (AUDIO)      |
| 019 | Pop 1 (AUDIO)       |
| 020 | Pop 2 (AUDIO)       |
| 021 | Pop 3 (AUDIO)       |
| 022 | Pop 4 (AUDIO)       |
| 023 | Pop 5 (AUDIO)       |
| 024 | Pop 6 (AUDIO)       |
| 025 | Funk 1 (AUDIO)      |
| 026 | Funk 2 (AUDIO)      |
| 027 | Funk 3 (AUDIO)      |
| 028 | Funk 4 (AUDIO)      |
| 029 | Funk 5 (AUDIO)      |
| 030 | Metal 1 (AUDIO)     |
| 031 | Metal 2 (AUDIO)     |
| 032 | Metal 3 (AUDIO)     |
| 033 | Dance 1 (AUDIO)     |
| 034 | Dance 2 (AUDIO)     |
| 035 | Dance 3 (AUDIO)     |
| 036 | DEMO SONG 1 (AUDIO) |
| 037 | DEMO SONG 2 (AUDIO) |

# Drum kit parameter structure



\*1 KICK does not have a rim.

\*2 For RIDE, the bell can be set in the same way as the head.

\*3 XSTICK for the snare drum can be configured as follows.

- Layer Switch
- Inst Number/Bank (excluding SYNTH WAVE)
- V-EDIT Parameter
- Volume
- Transient

\*4 When Pad Send Head/Rim is "PAD"

\*5 When Pad Send Head/Rim is "HEAD/RIM"

# Block diagram

